



Mehmet Kurum, Orhan Eroglu, Dylan R. Boyd

Impress Lab: <http://impress.ece.msstate.edu/>

SCoBi Simulator User's Manual

v1.0

Table of Contents

1.	Introduction	3
1.1.	General.....	3
1.2.	System Requirements	3
1.3.	Downloading and Installation	3
1.4.	Help SCoBi Improve.....	3
2.	SCoBi Simulator Basics	4
2.1.	Initial Run	4
2.2.	Analysis Selection Window	4
2.3.	Simulation Input Window	5
2.3.1.	Analysis Selection Buttons	6
2.3.2.	Simulation Settings	7
2.3.2.1.	Campaign	7
2.3.2.2.	Simulation Mode.....	7
2.3.2.3.	Ground Cover	8
2.3.2.4.	Preferences	8
2.3.3.	Transmitter Inputs	8
2.3.3.1.	Frequency.....	9
2.3.3.2.	Range to Earth Center.....	9
2.3.3.3.	EIRP	9
2.3.3.4.	Polarization	9
2.3.3.5.	Orientation.....	9
2.3.4.	Receiver Inputs.....	10
2.3.4.1.	Altitude.....	10
2.3.4.2.	Gain	10
2.3.4.3.	Polarization	10
2.3.4.4.	Orientation.....	11
2.3.4.5.	Antenna Pattern.....	11
2.3.5.	Ground Inputs	11
2.3.5.1.	Dielectric Model.....	12
2.3.5.2.	Ground Structure	12
2.3.6.	Input Files.....	12
2.3.7.	Action Buttons	13

2.3.7.1.	Load Inputs.....	13
2.3.7.2.	Save Inputs.....	13
2.3.7.3.	RunSCoBi	13
2.3.7.4.	Exit.....	13
3.	Analysis with SCoBi	14
3.1.	Inputs	14
3.1.1.	Simulation Inputs	14
3.1.2.	Excel Input Files.....	14
3.1.2.1.	Configuration Inputs File.....	14
3.1.2.2.	Antenna Pattern File	21
3.1.2.3.	Vegetation Inputs File	22
3.2.	Simulation Preparation Flow	24
3.2.1.	Global Navigation Satellite System Reflectometry (GNSS-R) Vegetation Analysis	24
3.2.2.	P-band Vegetation Analysis	26
3.2.3.	P-band Root-zone Analysis.....	28
3.3.	Simulation Results.....	30
3.3.1.	Simulation Name.....	30
3.3.2.	Products	30
3.3.3.	Master Simulations File.....	31
References	31

1. Introduction

1.1. General

SCoBi stands for Signals of Opportunity (SoOp) Coherent Bistatic scattering simulator. The simulator is developed by using our scattering model with the same name in order to enable comprehensive analysis of bistatic configurations. SCoBi boasts the following capabilities:

- Fully polarimetric analysis with any combination of linear and/or circular polarizations
- Antenna property realizations including antenna orientation, pattern, and cross-polarization coupling
- Interferometric effects caused by complex voltage and beamforming
- Geometry effects from altitude and spreading loss over vegetation depth

SCoBi generates power and complex field outputs for the direct signals between the transmitter and the receiver, and the coherent reflection coefficient and reflectivity outputs regarding the specular point between the antennas. It is also capable of handling the diffuse vegetation scattering mechanisms through Monte Carlo simulations via distorted Born approximation, but it is not included in the current version. A comprehensive description of the theory behind the model can be found in DOI: [10.1109/TGRS.2018.2864631](https://doi.org/10.1109/TGRS.2018.2864631).

1.2. System Requirements

SCoBi supports the following platforms and environments:

- OS: Windows 8/10
- Environment: **Matlab R2015b** or above, Octave

1.3. Downloading and Installation

SCoBi software can be accessed from the following *github* repository:

<https://github.com/impresslab/SCoBi>

It can also be downloaded from the following URL:

<http://impress.ece.msstate.edu/impress-lab/software/scobi/source-code/>

There is no installation requirement for the current version. In other words, it can be directly run from within the source code when it is downloaded.

1.4. Help SCoBi Improve

Please send us an email via the following address to make requests or to report any bugs through using the software:

2. SCoBi Simulator Basics

2.1. Initial Run

The SCoBi simulator comes with an initial pack of default inputs for a number of separate SoOp analyses such as bare-soil root-zone soil moisture, agricultural or forested vegetated terrain reflectivity, etc. The single step to run the simulator in order to choose one of these analyses is to run the following function under the simulator directory:

```
./source/lib/runSCoBi.m
```

A graphical user interface (GUI) window welcomes the user and provides clickable buttons to choose one of the available SoOp analysis types. This interface is titled the **Analysis Selection Window** and will be described in **section 2.2**. When one analysis type is chosen (i.e. clicked), the **Simulation Input Window** is opened with a set of default inputs. The **Simulation Input Window** will be described in **section 2.3**. To make an easy first run, the **runSCoBi** button can be clicked with no change in to the default inputs. The simulator will run with the default inputs set and will generate outputs in the output directories that will be described in **section 3.3 Simulation Results**.

2.2. Analysis Selection Window

This window welcomes the user as a main GUI window when SCoBi is run. It is designed to provide an easy way of selecting the SoOp analysis of interest and to prepare the **Simulation Input Window** with default or last-used inputs of that analysis. It also allows the user to easily learn the SCoBi system and differences between analyses by providing default inputs for each analysis.

It currently houses the following analysis options that are ready to run:

- Agriculture
- Forest
- Soil
- Root-zone

Future options that this window will allow for are also shown within this window:

- Snow
- Topography
- Permafrost
- Wetlands

The **Analysis Selection Window** is displayed in **Figure 1**.



Figure 1: Analysis Selection Window

2.3. Simulation Input Window

SCoBi provides a **Simulation Input Window** that is always the same GUI window regardless of the analysis chosen. However, every kind of SoOp analysis may lead to enabling/disabling of corresponding inputs within this window. Additionally, the type of analysis can be changed also from this window as described in **section 2.3.1 Analysis Selection Buttons**. A sample snapshot of the **Simulation Input Window** can be seen in **Figure 2**.

The **Simulation Input Window** has the following pushbuttons and panels on it, which will be described in detail in the next subsections:

- Analysis Selection Buttons
- Simulation Settings
- Transmitter Inputs
- Receiver Inputs
- Ground Inputs
- Input Files
- Action Buttons




Figure 2: Simulation Input Window. Opened with default input values for the Forest simulation module.

2.3.1. Analysis Selection Buttons

These buttons are mainly located in the **Analysis Selection Window** in order to choose the analysis of interest and to load the **Simulation Input Window** with the corresponding input set. However, the **Simulation Input Window** also has the same buttons for the sake of allowing user to switch to another analysis at any time. When one of the so-called buttons is clicked, the **Simulation Input Window** is updated to reflect the input of the selected analysis. These buttons are shown in **Figure 3**.



Figure 3: Analysis Selection Buttons. Presently, only Forest, Agriculture, Soil, and Root are functioning.

2.3.2. Simulation Settings

Simulation Settings panel includes the main setting parameters of a simulation that determine the output directory name, simulation mode, ground cover, and preferences. This panel is displayed in **Figure 4**. These options are described in the subsections below.




Figure 4: Simulation Settings Panel

2.3.2.1. Campaign

Campaign is an editable text input that is aimed to determine the simulation output directory name, merged with the time-stamp of the time a simulation is run. User can freely decide on a campaign name; however, it is highly recommended to choose a self-explanatory name such as:

“Corn-Maturity-MS-39762” for a corn field that is at its maturity growth-stage and located in Mississippi at the zip code 39762.

2.3.2.2. Simulation Mode

SCoBi simulator currently supports two different simulation modes: **Snapshot** or **Time-series**. The simulation mode determines the structure of the **Configuration Inputs File** which is described in detail in section **3.1 Inputs**.

2.3.2.2.1. Snapshot Simulation

Snapshot simulation is the appropriate mode for generating large amount of SoOp simulated data for comprehensive analysis. The simulator runs simulations for all the snapshots (i.e. combinations) of the following configuration inputs and scene parameters such as: Transmitter incidence and azimuth angles (if Transmitter is not **Geo-stationary**), surface roughness (via root mean square height), and volumetric soil moisture (VSM).

Please refer to section **3.1 Inputs** to see how **Snapshot** mode affects the **Configuration Inputs File** in detail.

2.3.2.2.2. *Time-series Simulation*

Time-series simulation mode is the perfect option to analyze realistic scenarios. This mode requires the user provides Configuration Inputs File in a suitable form for time-series, which requirement is described in section **3.1 Inputs** in detail.

2.3.2.3. *Ground Cover*

Ground cover can be determined to be **Bare-soil** or **Vegetation** cover. The **Ground Cover** value determines if the **Vegetation Inputs File** is needed or not. The effect of **Bare-soil** and **Vegetation** is described in detail both below and in section **3.1 Inputs**.

2.3.2.3.1. *Bare-soil*

When **Bare-soil** is selected, there is no need for vegetation inputs, the **Vegetation Inputs File** GUI elements are disabled, and SCoBi does not operate its functions for canopy computations (such as propagation) and only generates the outputs for bare soil.

2.3.2.3.2. *Vegetation*

Vegetation cover option requires a **Vegetation Inputs File** of the correct form, which is described in section **3.1 Inputs**. This file can be given via the **Vegetation Inputs File - Browse** button in the **Input Files** panel. This selection makes SCoBi runs the vegetation-related functions and generate both vegetation and bare soil results.

2.3.2.4. *Preferences*

There are currently two preferences in the SCoBi:

2.3.2.4.1. *Include in Master Simulations*


This preference is for running a simulation whether as a temporary trial or a recorded one that is logged in the **Master Simulations File** (Will be described in **section 3.3.3 Master Simulations File**).

2.3.2.4.2. *Write Attenuation to Excel File*

This preference is for recording the attenuation output of a simulation with vegetation cover into an MS Excel file for further analysis.

2.3.3. *Transmitter Inputs*

This panel includes editable text fields and pop-up menus for transmitter-related inputs, as shown in **Figure 5**.



Transmitter Inputs

Frequency MHz

Range to Earth Center km

EIRP dB

Polarization ▼

Orientation ▼

Variable orientation angles (incidence and azimuth) for transmitter should be given in the Configuration Inputs File.

Figure 5: Transmitter Inputs Panel

2.3.3.1. Frequency

This editable text field is dedicated to the transmitter antenna's operating frequency. It should be filled with numerical values in MHz units.

2.3.3.2. Range to Earth Center

The transmitter's range to Earth center should be given (in kilometers).

2.3.3.3. EIRP

EIRP of the transmitter should be given in decibels and it makes an offset impact on the results.

2.3.3.4. Polarization

Polarization of the transmitter can be chosen to be:

- R: Right hand circular polarization (RHCP)
- L: Left hand circular polarization (LHCP)
- X: Linear X-polarization (Stands for vertical polarization)
- Y: Linear Y-polarization (Accounts for horizontal polarization since Y-axis is always considered parallel to the ground plane)

2.3.3.5. Orientation

SCoBi simulator currently supports two different transmitter orientations: **Geo-stationary** or **Variable**. The orientation of the transmitter determines the structure of the Configuration Inputs File, which is described in detail both below and in section **3.1 Inputs**.

2.3.3.5.1. Geo-stationary


Geo-stationary transmitter orientation requires a transmitter to have fixed incidence and azimuth angles even if the simulation spans a temporal range. Therefore, when the transmitter orientation is chosen to be **Geo-stationary**, the fixed **Incidence (Theta)** and **Azimuth (Phi)** angles should be given in degrees in the **Simulation Input Window**. In addition, there should be no **Theta** and **Phi** columns in the **Configuration Inputs File**.

2.3.3.5.2. Variable

Variable transmitter orientation enables a transmitter to have changing incidence and azimuth angles in a simulation. Therefore, when the transmitter orientation is chosen to be **Variable**, the **Incidence (Theta)** and **Azimuth (Phi)** angle values should be given in degrees in the **Theta** and **Phi** columns in the **Configuration Inputs File**. For details of this input file, please refer to section **3.1 Inputs**.

2.3.4. Receiver Inputs

This panel includes editable text fields and pop-up menus for receiver-related inputs, as shown in **Figure 6**.



Receiver Inputs

Altitude: 50 m

Gain: 0 dB

Polarization: X

Orientation: Specular-facing

Specular-facing orientation angles (observation and azimuth) for receiver are always equal to transmitter's angles.

Antenna Pattern Input

Antenna Pattern: User-defined

Use-defined antenna pattern for receiver should be given in the Antenna Pattern Input File.

Figure 6: Receiver Inputs Panel

2.3.4.1. Altitude

Receiver altitude should be given in meters in numerical values. The altitude makes only difference on the received power calculations.

2.3.4.2. Gain

Antenna gain of the receiver should be given in decibels and it makes an offset impact on the results.

2.3.4.3. Polarization

Polarization of the receiver can be chosen to be:

- R: Right hand circular polarization (RHCP)
- L: Left hand circular polarization (LHCP)

- X: Linear X-polarization (Stands for vertical polarization)
- Y: Linear Y-polarization (Accounts for horizontal polarization since Y-axis is always considered parallel to the ground plane)

2.3.4.4. Orientation

SCoBi simulator currently supports two different receiver orientations: **Fixed** or **Specular-facing**. **Fixed** orientation means that receiver observes a fixed point with constant looking and azimuth angles, which setup is common, for example, in tower applications. **Specular-facing** means that the receiver gets the same orientation angles for changing transmitter orientations, which is hard to obtain in real-world experiments, but might allow to create more simulated data.

2.3.4.4.1. Fixed

The fixed **Observation (Theta)** and **Azimuth (Phi)** angles should be given in degrees in the **Simulation Input Window**.

2.3.4.4.2. Specular-facing

When the receiver is **Specular-facing**, there is no need to give orientation angles; instead, the SCoBi always equates the receiver's orientation angles to transmitter's ones, even if the configuration changes.

2.3.4.5. Antenna Pattern

SCoBi simulator currently supports two different receiver antenna pattern generation methods: **Generalized-Gaussian** or **User-defined**. A third option **Cosine to the power n** is also listed in the pop-up menu for reference to developers. Antenna pattern selection affects if **Antenna Pattern File** is needed or not, which effect is described in detail below and in section **3.1 Inputs**.

2.3.4.5.1. Generalized-Gaussian

A simple generalized Gaussian antenna pattern can be created quickly by giving the significant parameter values via the **Simulation Input Window**. When this option is selected under the **Antenna Pattern** pop-up menu, SCoBi shows the following parameters for user input:

- **Beamwidth**: Half-power beamwidth of the antenna pattern should be given in degrees in numerical values.
- **Side-lobe level**: The levels of the first side-lobes should be given in decibels in numerical values.
- **Cross-pol level**: The level of the cross-polarization of the antenna pattern should be given in decibels in numerical values.
- **Pattern Resolution**: The minimum sensitivity of the antenna pattern should be given in degrees in numerical values.

2.3.4.5.2. User-defined

This option requires an **Antenna Pattern File** of the correct form, which is described in section **3.1 Inputs**. This file can be given via the **Antenna Pattern File - Browse** button in the **Input Files** panel.

2.3.5. Ground Inputs

This panel includes pop-up menus and checkboxes for ground-related inputs, as shown in **Figure 7**.




Figure 7: Ground Inputs Panel

2.3.5.1. Dielectric Model

SCoBi currently supports three dielectric models: **Dobson**, **Mironov**, and **Wang**. Surface dielectric through the simulations is calculated by the selected dielectric model.

2.3.5.2. Ground Structure

SCoBi supports analyses for both **Single-layered** and **Multi-layered** ground structures. The ground structure selection affects the **Configuration Inputs File**, which is described in detail in section **3.1 Inputs**.

2.3.5.2.1. Single-layered

When **Single-layered** ground structure is selected, the rest of the ground inputs should be given in the **Configuration Inputs File**, details of which are described in section **3.1 Inputs**.

2.3.5.2.2. Multi-layered

When **Multi-layered** ground structure is selected, checkboxes are shown for four different fitting functions for dielectric profiles through the multiple ground layers:

- 2nd-order
- 3rd-order
- Discrete slab
- Logistic regression

This option is dedicated to root-zone analysis. Any subset of these fitting functions may be selected for **Multi-layered** ground analysis. The rest of the **Multi-layered** ground inputs should be given in the **Configuration Inputs File**, details of which are described in section **3.1 Inputs**.

2.3.6. Input Files

This panel houses the browsing buttons and text fields that enable loading and presentation of the MS Excel input files, if required depending on the other inputs on the **Simulation Input Window**. The Excel input files that can be loaded and shown within his panel are as follows, as shown in Figure 8:

- Configuration Inputs File: Default files that are provided with the SCoBi distribution are located under **./source/input/configuration/** directory.
- Antenna Pattern File: Default files that are provided with the SCoBi distribution are located under **./source/input/Rx_antenna_pattern/** directory.

- Vegetation Inputs File: Default files that are provided with the SCoBi distribution are located under *./source/input/vegetation/* directory.




Figure 8: Input Files Panel

2.3.7. Action Buttons

Action buttons are located in the **Simulation Input Window** for the aim of overall management, as shown in **Figure 9**.

2.3.7.1. Load Inputs

A simulation input can be loaded any time into the **Simulation Input Window**.

2.3.7.2. Save Inputs

The current state of the **Simulation Input Window** can be saved as a simulation input (.mat) file.

2.3.7.3. RunSCoBi

RunSCoBi button is for running the simulation with the current state of the **Simulation Input Window**. If no change is made on the recently loaded or saved simulation inputs, SCoBi immediately begins to run after this button is clicked. Otherwise, the software prompts the user to save the current state of the **Simulation Input Window** as a different simulation inputs file.

2.3.7.4. Exit

The window close button of the **Simulation Input Window** can be used to terminate SCoBi. When the button is clicked, SCoBi prompts user to confirm the termination.




Figure 9: Action buttons

3. Analysis with SCoBi

3.1. Inputs

There are two main types of the inputs for a SCoBi simulation: **Simulation Inputs** and **Excel Input Files**.

3.1.1. Simulation Inputs

Simulation inputs are initially provided as default simulation input files, and their values can be altered by modifying the defaults and saving new input files. Simulation inputs are accessed through GUI (**Simulation Input Window**), saved as “.mat” files. Simulation input files map all information (from single parameter values to full paths for Excel input files) to variables within the SCoBi simulator in order to perform the user’s simulation of interest. The user deals with simulation inputs only via GUI. Initially provided, default simulation input files can be found within the **./source/input/system** directory. It is suggested that the newly generated simulation input files stored in the same location as well; however, it is not required.

When SCoBi is run, the **Simulation Input Window** is loaded with the recently saved simulation input file. Otherwise, it is loaded with the default simulation input file for the selected analysis type. If no default input file is present (since input files can be removed by the user), the window is opened empty.

Whenever there is a change to the recently loaded or saved simulation input file and **RunSCoBi** button is clicked, SCoBi prompts the user to save the current state of the **Simulation Input Window** as a new simulation input file.

3.1.2. Excel Input Files

SCoBi simulations may require from one to three separate MS Excel input files depending on the chosen settings and parameter values within the simulation inputs. It is highly encouraged that users view the example Excel input files in the following directories before creating their own:

- **./source/input/configuration,**
- **./source/input/Rx_antenna_pattern,** and
- **./source/input/vegetation.**

3.1.2.1. Configuration Inputs File

A **Configuration Inputs File** is required in every simulation and consists of two sheets: **Dynamic** and **Ground**. While the order of the sheets is required for the operation of SCoBi, the name of these sheets can be arbitrary. The first sheet in the **Configuration Inputs File** should correspond to the **Dynamic** sheet and the second sheet should correspond to the **Ground** sheet. Additionally, it is suggested that these two sheets be named **Dynamic** and **Ground** as depicted in **Figure 10**.

Dynamic	Ground
---------	--------

Figure 10: Example Vegetation Inputs File Sheet Titles

The **Dynamic** sheet defines parameters that may be given changing values within a simulation. Variable parameters include timestamps, azimuth and incidence angles of the transmitter, root-mean-square height (RMSH) roughness, and volumetric soil moisture.

The **Ground** sheet consists of static parameters that define the ground structure such as soil texture, soil bulk density, layer depths where soil moisture probes are located, and layering effects.

The content (being the name and value of variables within the **Dynamic** and **Ground** sheets) found in the **Configuration Inputs File** should be prepared according to the joint requirements of the simulation mode and analysis type. In other words, **Configuration Inputs File** should be created in a way that it satisfies all the directives listed for the following parameters. Example input files will be given after the requirements for all the parameters are described.

While the order of the parameter columns in both **Dynamic** and **Ground** spreadsheets of the **Configuration Inputs File** is required for the operation of SCoBi, the name of the parameters can be arbitrary. However, it is suggested that the parameter columns be named as in the examples in section 3.1.2.1.4 Example Configuration Inputs File for the sake of familiarity.

3.1.2.1.1. Simulation Mode Effect: Snapshot vs. Time-series

Simulation mode selection places requirements on writing the **Dynamic** sheet of the **Configuration Inputs File**, but not on the **Ground** spreadsheet. The requirements for creating a **Configuration Inputs File** that satisfies SCoBi's different simulation modes are described as follows:

3.1.2.1.1.1. Snapshot

Snapshot simulations are just for analyzing the combinations of changing configurational and environmental parameters such as transmitter orientation, surface roughness, and soil moisture. There is no need for timestamp information in a **Snapshot** mode; therefore, there should not be a **DoY** (Day-of-Year) column in the **Dynamic** sheet of the **Configuration Inputs File**. The following parameter columns may be included with totally different number of rows (samples) than each other in the **Dynamic** spreadsheet:

- **Tx_th(deg):** Transmitter incidence (theta, θ) angle in degrees
- **Tx_ph(deg):** Transmitter azimuth (phi, φ) angle in degrees
- **RMSH(cm):** Surface roughness – root mean square height in centimeters
- **VSM(cm³/cm³):** Volumetric soil moisture in cm³/cm³

3.1.2.1.1.2. Time-series

Time-series simulations are for analyzing a temporally changing configuration and environment. In other words, in a Time-series simulation, there should be configurational and environmental parameter values as well as timestamps, which have exactly the same length or some of them are constant. Thus, following parameters may be given in separate columns in **Dynamic** spreadsheet as same-length sequences or only one value (to represent being constant) for a period in time:

- **DoY:** Day of Year
- **Tx_th(deg):** Transmitter incidence (theta, θ) angle in degrees
- **Tx_ph(deg):** Transmitter azimuth (phi, φ) angle in degrees
- **RMSH(cm):** Surface roughness – root mean square height in centimeters
- **VSM(cm³/cm³):** Volumetric soil moisture in cm³/cm³

3.1.2.1.2. Transmitter Orientation

Transmitter orientation selection affects the **Dynamic** sheet of the **Configuration Inputs File**. When transmitter orientation is **Geo-stationary**, there should be neither **Incidence Angle (Theta)** nor **Azimuth Angle (Phi)** columns in the **Dynamic** sheet.

3.1.2.1.3. Ground Structure: Single-layered vs. Multi-layered

Ground structure selection may make effects on both the **Dynamic** and **Ground** sheets of the **Configuration Inputs File**. The effects of the ground structures are described as follows:

3.1.2.1.3.1. Single-layered

Single-layered ground structure simulations only require the **Volumetric Soil Moisture** and ground texture information for the ground surface. Therefore, there should be only one **VSM(cm3/cm3)** column in the **Dynamic** sheet. The following parameter columns should be included with only one row for numeric values in addition to the column names row in the **Ground** sheet:

- **sand_ratio**: Sand ratio of the ground surface within [0,1]
- **clay_ratio**: Clay ratio of the ground surface within [0,1]
- **rho_b(g/cm3)**: Bulk density of the soil in g/cm³

3.1.2.1.3.2. Multi-layered

Multi-layered ground structure simulations require the **VSM(cm3/cm3)** and ground texture information for multiple layers of the ground. Number of **VSM(cm3/cm3)** columns in the **Dynamic** sheet should exactly match the number of ground layers to be analyzed. Each **VSM(cm3/cm3)** corresponds to **VSM** measurements in a different ground layer. The following parameter columns should be included with the equal number of rows for numeric values as in the number of ground layers in addition to the column names row in the **Ground** sheet:

- **layer_depth**: Layer depths of each ground layer should be given in meters. Thus, this column should include its name in the first row, then enough number of layer depths as much as the number of ground layers.
- **sand_ratio**: Sand ratios of the ground layers within [0,1]. This column should include its name in the first row, then enough number of sand ratios as much as the number of ground layers.
- **clay_ratio**: Clay ratios of the ground layers within [0,1]. This column should include its name in the first row, then enough number of clay ratios as much as the number of ground layers.
- **rho_b(g/cm3)**: Bulk densities of the ground layers in g/cm³. This column should include its name in the first row, then enough number of bulk densities as much as the number of ground layers.
- **delZ(m)**: Layer discretization in meters. Only one value is enough to make discretization through all the ground layers.
- **zA(m)**: Air layer thickness in meters.
- **zB(m)**: The bottom-most layer thickness in meters. This should generally be defined to be greater than or equal to the penetration depth of the SoOp transmitter's frequency and beneath the deepest point of interest within the soil moisture profile.

3.1.2.1.4. Example Configuration Inputs File

Table 1 demonstrates the **Dynamic** spreadsheet of the **Configuration Inputs File** when

- **Simulation Mode** is **Snapshot**,

- **Transmitter Orientation** is **Variable**, and
- **Ground Structure** is **Single-layered**.

All values of the parameters within each column will be combined with the values of the parameters within the other columns since **Table 1** defines a **Snapshot** simulation. This means that **Table 1** will result in 210 (7x2x3x5) different simulations. The transmitter's incidence angle (***Tx_th(deg)***) will be varied from 10° to 70° in 10° units. The transmitter's azimuth (***Tx_ph(deg)***) will be varied at 0° and 15°. The root-mean-square height roughness (***RMSH(cm)***) will be varied from 0.5, 1, and 1.5 cm. **Table 1** is an example of a **Single-layered** ground structure so that soil moisture has one column on varying values for the ground surface in which it will be varied from 0.05 to 0.25 cm^3/cm^3 .

The definitions for variables seen in the **Dynamic** spreadsheet of **Table 1** will require defined **Ground** spreadsheet parameters similar to the definitions seen in **Table 7**.

Table 1: Example **Dynamic** spreadsheet of the **Configuration Inputs File** when Simulation Mode is **Snapshot**, Transmitter Orientation is **Variable**, and Ground Structure is **Single-layered**.

<i>Tx_th(deg)</i>	<i>Tx_ph(deg)</i>	<i>RMSH(cm)</i>	<i>VSM(cm³/cm³)</i>
10	0	0.5	0.05
20	15	1	0.10
30		1.5	0.15
40			0.20
50			0.25
60			
70			

Table 2 demonstrates the **Dynamic** spreadsheet of the **Configuration Inputs File** when

- **Simulation Mode** is **Snapshot**,
- **Transmitter Orientation** is **Variable**, and
- **Ground Structure** is **Multi-layered**.

All values of the parameters within each column will be combined with the values of the parameters within the other columns since **Table 2** defines a **Snapshot** simulation. This means that **Table 2** will result in 10752 (7x2x3x4x4x4x4) different simulations. The transmitter's incidence angle (***Tx_th(deg)***) will be varied from 10° to 70° in 10° units. The transmitter's azimuth (***Tx_ph(deg)***) will be varied at 0° and 15°. The root-mean-square height roughness (***RMSH(cm)***) will be varied from 0.5, 1, and 1.5 cm. **Table 2** is an example of a **Multi-layered** ground structure so that soil moisture has also a multi-layered profile in which the soil moisture at 5, 10, 20, and 40 centimeters is defined. It is worth noting here that the number and depth of the soil moisture measurements can be different than what is exemplified here. The values between these defined points are interpolated using different function fits as defined in section **2.3.5.2.2 Multi-layered**.

The definitions for variables seen in the **Dynamic** spreadsheet of **Table 2** will require defined **Ground** spreadsheet parameters similar to the definitions seen in **Table 8**.

Table 2: Example **Dynamic** spreadsheet of the **Configuration Inputs File** when Simulation Mode is **Snapshot**, Transmitter Orientation is **Variable**, and Ground Structure is **Multi-layered**.

Tx_th (deg)	Tx_ph0 (deg)	RMSH (cm)	VSM_5 (cm3/cm3)	VSM_10 (cm3/cm3)	VSM_20 (cm3/cm3)	VSM_40 (cm3/cm3)
10	0	0.5	0.374	0.364	0.374	0.436
20	15	1	0.374	0.361	0.372	0.440
30		1.5	0.375	0.355	0.375	0.440
40			0.371	0.332	0.388	0.440
50						
60						
70						

Table 3 demonstrates the **Dynamic** spreadsheet of the **Configuration Inputs File** when

- **Simulation Mode** is **Snapshot**,
- **Transmitter Orientation** is **Geo-stationary**, and
- **Ground Structure** is **Single-layered**.

Whenever **Transmitter Orientation** is **Geo-stationary**, the transmitter orientation columns (**Tx_th(deg)** and **Tx_ph(deg)**) are discarded from the **Dynamic** spreadsheet regardless of the other parameter selections (**Simulation Mode** and **Ground Structure**) since the fixed orientation angle values are given via **Simulation Input Window**. Processing of the input in **Table 3** is then similar to that in **Table 1** (combinations of all the columns).

Table 3: Example **Dynamic** spreadsheet of the **Configuration Inputs File** when Simulation Mode is **Snapshot**, Transmitter Orientation is **Geo-stationary**, and Ground Structure is **Single-layered**.

RMSH (cm)	VSM(cm3/cm3)
0.5	0.05
1	0.10
1.5	0.15
	0.20

Table 4 demonstrates the **Dynamic** spreadsheet of the **Configuration Inputs File** when

- **Simulation Mode** is **Snapshot**,

- **Transmitter Orientation** is **Geo-stationary**, and
- **Ground Structure** is **Multi-layered**.

Whenever **Transmitter Orientation** is **Geo-stationary**, the transmitter orientation columns (**$Tx_{th}(deg)$** and **$Tx_{ph}(deg)$**) are discarded from the **Dynamic** spreadsheet regardless of the other parameter selections (**Simulation Mode** and **Ground Structure**) since the fixed orientation angle values are given via **Simulation Input Window**. Processing of the input in **Table 4** is then similar to that in **Table 2** (combinations of all the columns).

Table 4: Example **Dynamic** spreadsheet of the **Configuration Inputs File** when **Simulation Mode** is **Snapshot**, **Transmitter Orientation** is **Geo-stationary**, and **Ground Structure** is **Multi-layered**.

RMSH (cm)	VSM_5 (cm ³ /cm ³)	VSM_10 (cm ³ /cm ³)	VSM_20 (cm ³ /cm ³)	VSM_40 (cm ³ /cm ³)
0.5	0.374	0.364	0.374	0.436
1	0.374	0.361	0.372	0.440
1.5	0.375	0.355	0.375	0.440
	0.371	0.332	0.388	0.440

Table 5 demonstrates the **Dynamic** spreadsheet of the **Configuration Inputs File** when

- **Simulation Mode** is **Time-series**,
- **Transmitter Orientation** is **Variable**, and
- **Ground Structure** is **Single-layered**.

Each row in this **Dynamic** spreadsheet corresponds to a **Time-series** data; the number of simulations will be equal to the number of rows beneath the **DOY** heading (7 for the example seen in **Table 5**). The value of 123.75, for example, corresponds to the 123rd day of the year, May 3, at a time 75% through the day, 6:00PM. The transmitter's incidence angle (**$Tx_{th}(deg)$**) and the effective soil moisture of the ground surface (**$VSM(cm^3/cm^3)$**) changes as a function of time defined by the **DOY** column while the transmitter's azimuth angle (**$Tx_{ph}(deg)$**) and the root-mean-square-height of the soil (**$RMSH(cm)$**) remains fixed throughout the displayed time period. Since **Table 5** displays a **Dynamic** sheet for a **Single-layered** soil moisture profile, a corresponding **Ground** spreadsheet will be required similar to one seen in **Table 7**.

Table 5 Example **Dynamic** spreadsheet of the **Configuration Inputs File** when Simulation Mode is **Time-series**, Transmitter Orientation is **Variable**, and Ground Structure is **Single-layered**.

DOY	Tx_th(deg)	Tx_ph(deg)	RMSH(cm)	VSM(cm3/cm3)
123.72917	40.7	200	0.5	0.37388012
123.73958	40			0.37388012
123.75	40.1			0.37492744
123.76042	40.4			0.371428366
123.77083	39.6			0.369494043
123.78125	39.6			0.369494043
123.79167	39.8			0.369494043

Table 6 demonstrates the **Dynamic** spreadsheet of the **Configuration Inputs File** when

- **Simulation Mode** is **Time-series**,
- **Transmitter Orientation** is **Variable**, and
- **Ground Structure** is **Multi-layered**.

Each row in this **Dynamic** spreadsheet corresponds to a **Time-series** data, similar to **Table 5**; but now for a **Multi-layered** soil moisture profile. Hence, a corresponding **Ground** spreadsheet will be required similar to one seen in **Table 8**. Note also that **Table 6** includes transmitter azimuth angles and surface roughness that vary with time, in contrast to **Table 5**.

Table 6 Example **Dynamic** spreadsheet of the **Configuration Inputs File** when Simulation Mode is **Time-series**, Transmitter Orientation is **Variable**, and Ground Structure is **Multi-layered**.

DOY	Tx_th(deg)	Tx_ph(deg)	RMSH(cm)	VSM-5(cm3/cm3)	VSM-10(cm3/cm3)	VSM-15(cm3/cm3)	VSM-25(cm3/cm3)
123.72917	40.7	200	0.5	0.373	0.398	0.413	0.415
123.73958	40	210	0.52	0.375	0.398	0.409	0.416
123.75	40.1	220	0.48	0.329	0.390	0.412	0.418
123.76042	40.4	230	0.55	0.356	0.385	0.415	0.420
123.77083	39.6	240	0.51	0.399	0.400	0.426	0.430
123.78125	39.6	250	0.49	0.413	0.422	0.447	0.455
123.79167	39.8	260	0.54	0.429	0.456	0.470	0.475

Table 7 demonstrates the **Ground** spreadsheet of the **Configuration Inputs File** when

- **Ground Structure** is **Single-layered**

Table 7 Example **Ground** spreadsheet of the **Configuration Inputs File** when Ground Structure is **Single-layered**.

sand_ratio	clay_ratio	rho_b (g/cm3)
0.8	0.07	1.25

Note that in

Table 7, we find that our **sand_ratio** value is 80% of the total effective soil layer, and our **clay_ratio** is 7% of the total effective soil layer. Our soil bulk density (**rho_b**) is 1.25 g/cm³ for the effective single layer soil profile.

Table 8 demonstrates the **Ground** spreadsheet of the **Configuration Inputs File** when

- **Ground Structure is Multi-layered.**

*Table 8: Example **Ground** spreadsheet of the **Configuration Inputs File** when Ground Structure is **Multi-layered**.*

layer_depth (m)	sand_ratio	clay_ratio	rho_b (g/cm3)	delZ (m)	zA (m)	zB (m)
0.05	0.1	0.31	1.4	0.001	0.1	0.3
0.1	0.1	0.31	1.4			
0.2	0.1	0.31	1.4			
0.4	0.1	0.34	1.5			

Note that in **Table 8**, we have placed variable soil moisture points at 5 cm, 10 cm, 20 cm, and 40 cm under the **layer_depth** column. The **sand_ratio**, **clay_ratio**, and **rho_b** parameters must be defined at each of these depths. The air layer (**zA**) has been defined to be 10 cm, and the bottom-most layer (**zB**) is defined as 30 cm. Given our bottom soil moisture point location is 40 cm, our total profile will be 10cm + 40cm + 30cm = 80 cm with our bottom soil layer being a point 70 cm beneath the surface of the soil. The layer discretization is 1 mm (**delZ**). Because we have defined 4 different **layer_depths** within this **Ground** sheet, we will require 4 columns that define the soil moisture content at these depths (**VSM5_cm3cm3**, **VSM10_cm3cm3**, **VSM20_cm3cm3**, and **VSM40_cm3cm3**) in the corresponding **Dynamic** sheet for the variables seen in **Table 8's Ground** sheet. An example of this can be seen in **Table 2**.

3.1.2.2. Antenna Pattern File

Antenna Pattern File is required only if the receiver antenna pattern is selected to be **User-defined**. It consists of four sheets within an Excel spreadsheet: **gnXX**, **gnXY**, **gnYX**, and **gnYY**, which holds the normalized voltage values for co- and cross-polarizations for X and Y ports. An example antenna pattern file can be found in `.\source\input\Rx_antenna_pattern`.

Antenna pattern should be provided such that in each sheet of the Excel file, columns represent the theta-angle look-up and rows represent the phi-angle look-up. Theta (θ) angles have a 180° scan, while phi (ϕ) angles have a 360° scan.

Note that the antenna pattern files do not have headers within the Excel spreadsheet. Each sheet consists of numbers only.

EXAMPLE EXCEL FILE

3.1.2.3. Vegetation Inputs File

Vegetation Inputs File is required only if the ground cover is selected to be **Vegetation**. It consists of two spreadsheets: **Layers** and **Kinds**. While the order of the sheets is required for the operation of SCoBi, the name of these sheets can be arbitrary. The first sheet in the **Vegetation Inputs File** should correspond to the **Layers** sheet and the second sheet should correspond to the **Kinds** sheet. Additionally, it is suggested that these two sheets be named **Layers** and **Kinds** as depicted in **Figure 11**.




Figure 11: Vegetation Inputs File spreadsheets

An example Vegetation Inputs File for each of analysis types **Forest** and **Agriculture** is included in:

./source/input/vegetation.

3.1.2.3.1. Layers

The **Layers** sheet should provide detailed information about the vegetation layer thicknesses and the content of each individual layer. Vegetation layer can be divided into a number of sub-layers by defining separate layer thicknesses for the purpose of locating specific **Kinds** (**Leaf**, **Branch**, **Trunk**, or **Needle**) into different layers. Thicknesses of the vegetation cover should be given (in integer or double numbers in meters) in the second column of the **Layers** spreadsheet in a way that ascending rows should represent an ascending height from top to bottom. The first column of the **Layers** spreadsheet is reserved to the names of individual layers. This column should be included in any **Vegetation Inputs File**; however; the name of each row in this column can be arbitrary. The example **Vegetation Inputs Files** use meaningful layer names to increase familiarity with the vegetation layer structure. For each separate vegetation layer. The first row is reserved for the descriptions of columns. Again, this row should be included in any **Vegetation Inputs File**; however; the name of each row in this column can be arbitrary. In other words, the actual layer data should begin from the second row and the second column.

For each vegetation layer row, columns after the thickness column should have the information about content of each vegetation layer. This information is related to the **Kinds** spreadsheet, and each vegetation layer can include from one to several **Kinds** (Please refer to section **3.1.2.3.2 Kinds** for naming conventions). The content of each layer should be given such that exactly one **Particle ID** (the same as given in the **Kinds** spreadsheet) exists in a column as shown in **Table 9**. For instance in **Table 9**, Layer 2 has L1 (first kind of the type Leaf), B2 (second kind of the type Branch), B3 (third kind of the type Branch), and B4 (fourth kind of the type Branch); however, Layer 4 only includes T1 (first kind of the type Trunk) that is intuitive to put **Trunk** fixed to the ground. In addition, the spreadsheet represents such a vegetation cover that can be analyzed as four distinct layers, each including different **Trunk**, **Branch**, and **Leaf Kinds**.

Table 9: Example Layers spreadsheet for Vegetation Inputs File

	Thickness (m)	Included Kinds			
Layer 1 (Top)	2	L1	B4		
Layer 2	4	L1	B2	B3	B4
Layer 3	3	B1	B2		
Layer 4 (Bottom)	4	T1			

3.1.2.3.2. Kinds

The **Kinds** sheet should provide detailed information about the scatterer types and kinds declared in the **Layers** sheet. The four scatterer **Types** used in SCoBi are **Leaf**, **Branch**, **Trunk**, or **Needle**. A **Leaf** should be considered as an elliptical disk, while the types **Branch**, **Trunk**, and **Needle** are considered as cylinders. Several **Kinds** of a **Type** can be defined in this spreadsheet (e.g. L1, L2, etc.).

The whole sheet should define the different Kinds of scatterers that exist in the vegetation layers. First column of the spread sheet is reserved for row descriptions. This column should be included in any Vegetation Inputs File, but the names of the rows in this column can be arbitrary. However, the example input files have meaningful row names for ease. Each column after the first column should represent one of the **Kinds**. As seen in **Table 9**, the **Kinds** can be reused throughout the different layers. There are nine rows for each column that define the following information:

- **Particle ID:** It can be also assumed the Kind name. A character array, where the first character must be one of the following letters 'L', 'B', 'T' or 'N' to stand for the **Types** (**Leaf**, **Branch**, **Trunk**, or **Needle**), and next characters should be integer to represent a specific **Kind** of the selected **Type** (e.g. "L1", "L2", "T1", "B3", etc.). This ID is used in the **Layers** sheet to link the vegetation layers to the scatterer **Kinds**.
- **Density:** It should be given in count/m³
- **Dimension1:** It should be the radius of the bottom of a cylinder (**Branch**, **Trunk**, or **Needle**) or major axis of an elliptical disk (**Leaf**) in meters.
- **Dimension2:** It should be the radius of the top of a cylinder (**Branch**, **Trunk**, or **Needle**) or minor axis of an elliptical disk (**Leaf**) in meters.
- **Dimension3:** It should be the length of a cylinder (**Branch**, **Trunk**, or **Needle**) or thickness of an elliptical disk (**Leaf**) in meters.
- **Epsr_real:** It is the real part of the dielectric constant of a scatterer.
- **Epsr_im:** It is the imaginary part of the dielectric constant of a scatterer.
-
- **Begin Angle:** It is the beginning angle of a particle, which means the angle between the starting point of the particle from its connection to another particle and zenith, in degrees.
- **End Angle:** It is the ending angle of a particle, which means the angle between the end point of the particle and zenith, in degrees.

An example **Kindzs** spreadsheet is displayed in **Table 10**.

Table 10: Example Kinds spreadsheet for Vegetation Inputs File

L1	B1	B2	B3	B4	T1
0	1	1	0	0	1
11.12	0.016	0.188	0.734	1.933	0.005
1.02E-01	4.30E-02	1.58E-02	9.80E-03	4.50E-03	8.73E-02
1.02E-01	4.30E-02	1.58E-02	9.80E-03	4.50E-03	8.73E-02
1.20E-04	1.87E+00	1.54E+00	6.36E-01	4.81E-01	6.17E+00
35.2	12	12	12	12	15.6
5.3	2.93	2.93	2.93	2.93	3.8
5	20	10	5	5	0
85	50	60	85	85	0.1

3.2. Simulation Preparation Flow

The preparation process of different SCoBi simulations may differ based on the analysis type and configurations selected by the user, although the general flow is the same. In this section, the flow of the overall simulation preparation will be described, and changes within steps due to different parameter selections will be emphasized by using example scenarios.

1. The first and most significant step of creating a SCoBi simulation is to determine the SoOp analysis type, the bistatic configuration (transmitter and receiver characteristics, and the geometry), ***Simulation Mode***, ***Vegetation Cover***, and the ***Ground Structure***.
2. The second major step is either the preparation of the required Excel input files (***Configuration***, ***Vegetation***, and ***Antenna Pattern*** input files, if needed), or use of the existing default files for the simulation of interest. Details of the requirements for the contents of the Excel input files when using the default ones or preparing new ones are mentioned in **section 3.1.2 Excel Input Files**, and it is highly recommended to read that section carefully.
3. The final main step is to give individual simulation parameters through the ***Simulation Input Window***, to select the Excel input files through this window, and to run SCoBi.

Two different examples regarding these three major steps will be provided in this section:

3.2.1. Global Navigation Satellite System Reflectometry (GNSS-R) Vegetation Analysis

The major three steps of a GNSS-R simulation can be described as follows:

1. In a GNSS-R simulation, the transmitter can be one of the typical GNSS satellites. In this example, an ***Agriculture*** SoOp analysis over a ***Vegetation Cover*** of an agricultural field will be considered. The transmitter will be a GNSS satellite operating at L1A-band with a ***Variable*** orientation (for the purpose of analyzing the changing transmitter angles). The receiver will be a ground-based GNSS receiver, which has a ***Generalized-Gaussian*** antenna pattern. Further details about the transmitter and the receiver parameters will be given below. This simulation will be a ***Snapshot*** simulation, where the combinations of simulation parameters are used for generating individual

simulation snapshots to generate large amount of simulated data. **Ground Structure** will be **Single-layered** since the surface dielectric calculations are considered enough for such a vegetation analysis scenario.

2. For such a simulation, below Excel input files (either the default or the newly generated files) must satisfy the simulation specifications in the first major step as follows:

- a. **Configuration Inputs File:** It should satisfy:
 - **Simulation Mode: Snapshot,**
 - **Transmitter Orientation: Variable,** and
 - **Ground Structure: Single-layered**

which corresponds to a file similar to what is shown in **Table 1** and **Table 7** for **Dynamic** and **Ground** spreadsheets, respectively.

- b. **Vegetation Inputs File:** It should represent the agricultural field of interest, in a similar way to what is shown in **Table 9** and **Table 10** for **Layers** and **Kinds** spreadsheets, respectively.
- c. **Antenna Pattern File:** This simulation does not involve this file since the receiver antenna pattern is a **Generalized-Gaussian**.

3. The type of analysis should be chosen **Agriculture** in the **Analysis Selection Window**.

It should be noted again that the selection of the analysis type does not prevent the user to study another analysis in the **Simulation Input Window**, but it helps determine the simulation parameters within this window easier. For example, **Multi-layered** ground could be defined within the **Configuration Inputs File** even if the analysis type was selected to be **Soil** (Single-layered).

In addition, it can be concluded that the analysis type should be picked regarding the main interest of the simulation; then, the other effects can be still performed. For instance, if a **Multi-layered** ground analysis was the main concern of this simulation, but an agricultural terrain would be studied over that surface, analysis type should have been chosen as **Root-zone**, and agricultural field should be defined with the help of vegetation parameters (**Vegetation-cover** and **Vegetation Inputs File**).

Simulation Inputs Window: All the simulation parameters are determined via this window, as described in detail in **section 2.3 Simulation Input Window**.

- a. **Campaign:** It should be given as a unique name that reflects the content of this simulation. It may **be** the geo-location, if any, of the simulated field, or any meaningful character array. For example., it can be assumed “GNSSR-Corn_Reproductive-MS-39762” for this example, which shows this simulation is a GNSS-R analysis over a corn field that is at reproductive stage and located in MS 39762.
- b. **Simulation Mode:** It is **Snapshot** for this simulation; details for **Simulation Mode** are described in **section 2.3.2.2 Simulation Mode**. Note again that this selection affects the content of the **Configuration Inputs File**. Please refer to **section 3.1.2.1.1 Simulation Mode Effect: Snapshot vs. Time-series** for details of such effects.
- c. **Ground-cover:** It is **Vegetation** for this simulation.
- d. **Preferences:** Preferences of this simulation should be determined as well. If this simulation is of a temporary purpose, then it should not be included in the **Master**

simulations. Attenuation can be written to Excel file when it is a **Vegetation-cover** simulation and the attenuation details are of interest.

- e. **Transmitter Frequency:** Because this is a GNSS-R scenario, the frequency should be one of the GNSS frequencies (e.g. L1A – 1575.42 MHz)
- f. **Transmitter Range to Earth Center:** This range is also based on the transmitter selection. The transmitter's range to Earth center should be given properly for the GNSS satellite selected. For example, it can be 26578 km in this simulation.
- g. **Transmitter EIRP:** If it is known for the selected transmitter, then it can be given. If it is not known, then an **EIRP** value of user's choice can be given since it has only an offset effect on the simulated results. For example, it can be 0 dB in this simulation.
- h. **Transmitter Polarization:** Similar to the above parameters, polarization of the transmitter should be chosen properly. For example, it can be a RHCP in this simulation.
- i. **Transmitter Orientation:** It is **Variable** in this example. Note again that this is an important parameter that also affects the content of the **Configuration Inputs File**. Please refer to **section 3.1.2.1.2 Transmitter Orientation** for details of such effects.
- j. **Ground Dielectric Model:** Any one of the available models can be selected. For instance, **Dobson** can be chosen in this scenario.
- k. **Ground Structure:** It is **Single-layered** in this example. Note again that this is an important parameter that also affects the content of the **Configuration Inputs File**. Please refer to **section 3.1.2.1.3 Ground Structure: Single-layered vs. Multi-layered** for details of such effects.
- l. **Receiver Altitude:** It is 20 m in this simulation.
- m. **Receiver Gain:** Similar to **EIRP**, if it is known for the selected receiver, then it can be given. If it is not known, a **Gain** value of user's choice can be given since it has only an offset effect on the simulated results. For example, it can be 0 dB in this simulation.
- n. **Receiver Polarization:** Polarization of the receiver should be chosen properly. For example, it can be a RHCP in this simulation.
- o. **Receiver Orientation:** It can be chosen Specular-facing in this example to get rid of antenna pattern effects and polarization mismatch.
- p. **Receiver Antenna Pattern Input:** It can be selected **Generalized-Gaussian** with the following parameters:
 - i. **Beamwidth:** 30 degrees
 - ii. **Side-lobe level:** 30 dB
 - iii. **Cross-polarization level:** 25 dB
 - iv. **Pattern resolution:** 1 degree
- q. **Input Files:** The Excel input files should be fed accordingly via the Browse buttons.
- r. **Run SCoBi:** The simulation can be run with the above parameters.

3.2.2. P-band Vegetation Analysis

The major three steps of a P-band vegetation analysis simulation can be described as follows:

1. In this example, **Forest** SoOp analysis over a **Vegetation Cover** of a forest field will be considered. The transmitter will be a satellite operating at P-band with a **Variable** orientation (for the purpose of analyzing the changing transmitter angles). The receiver will be a ground-based antenna with a **User-defined** pattern. Further details about the transmitter and the receiver parameters will be

given below. This simulation will be a **Snapshot** simulation, where the combinations of simulation parameters are used for generating individual simulation snapshots to generate large amount of simulated data. **Ground Structure** will be **Single-layered** since the surface dielectric calculations are considered enough for such a vegetation analysis scenario.

2. For such a simulation, below Excel input files (either the default or the newly generated files) must satisfy the simulation specifications in the first major step as follows:
 - a. **Configuration Inputs File:** It should satisfy:
 - **Simulation Mode:** *Snapshot*,
 - **Transmitter Orientation:** *Variable*, and
 - **Ground Structure:** *Single-layered*

which corresponds to a file similar to what is shown in **Table 1** and **Table 7** for **Dynamic** and **Ground** spreadsheets, respectively.

- b. **Vegetation Inputs File:** It should represent the forest field of interest, in a similar way to what is shown in **Table 9** and **Table 10** for **Layers** and **Kinds** spreadsheets, respectively.
 - c. **Antenna Pattern File:** The user defined antenna pattern can be given as described in sections **2.3.4.5.2 User-defined** and **3.1.2.2 Antenna Pattern File**.
3. The type of analysis should be chosen **Forest** in the **Analysis Selection Window**.

Simulation Inputs Window: All the simulation parameters are determined via this window, as described in detail in **section 2.3 Simulation Input Window**.

- a. **Campaign:** For example, it can be assumed “Forest-P_band-MS-39762” for this example, which shows this simulation is a Forest analysis at P-band and located in MS 39762.
- b. **Simulation Mode:** It is **Snapshot** for this simulation; details for **Simulation Mode** are described in **section 2.3.2.2 Simulation Mode**. Note again that this selection affects the content of the **Configuration Inputs File**. Please refer to **section 3.1.2.1.1 Simulation Mode Effect: Snapshot vs. Time-series** for details of such effects.
- c. **Ground-cover:** It is **Vegetation** for this simulation.
- d. **Preferences:** Preferences of this simulation should be determined as well. If this simulation is of a temporary purpose, then it should not be included in the **Master** simulations. Attenuation can be written to Excel file when it is a **Vegetation-cover** simulation and the attenuation details are of interest.
- e. **Transmitter Frequency:** Because this is a P-band scenario, the frequency should be a P-band frequency (e.g. 370 MHz)
- f. **Transmitter Range to Earth Center:** For example, it can be 42164 km in this simulation.
- g. **Transmitter EIRP:** If it is known for the selected transmitter, then it can be given. If it is not known, then an **EIRP** value of user’s choice can be given since it has only an offset effect on the simulated results. For example, it can be 0 dB in this simulation.
- h. **Transmitter Polarization:** Similar to the above parameters, polarization of the transmitter should be chosen properly. For example, it can be a RHCP in this simulation.
- i. **Transmitter Orientation:** It is **Variable** in this example. Note again that this is an important parameter that also affects the content of the **Configuration Inputs File**. Please refer to **section 3.1.2.1.2 Transmitter Orientation** for details of such effects.

- j. **Ground Dielectric Model:** Any one of the available models can be selected. For instance, **Mironov** can be chosen in this scenario.
- k. **Ground Structure:** It is **Single-layered** in this example. Note again that this is an important parameter that also affects the content of the **Configuration Inputs File**. Please refer to **section 3.1.2.1.3 Ground Structure: Single-layered vs. Multi-layered** for details of such effects.
- l. **Receiver Altitude:** It is 50 m in this simulation.
- m. **Receiver Gain:** Similar to **EIRP**, if it is known for the selected receiver, then it can be given. If it is not known, a **Gain** value of user's choice can be given since it has only an offset effect on the simulated results. For example, it can be 0 dB in this simulation.
- n. **Receiver Polarization:** Polarization of the receiver should be chosen properly. For example, it can be an X-pol in this simulation.
- o. **Receiver Orientation:** It can be chosen Specular-facing in this example to get rid of antenna pattern effects and polarization mismatch.
- p. **Receiver Antenna Pattern Input:** It should be selected **User-defined** antenna pattern.
- q. **Input Files:** The Excel input files should be fed accordingly via the Browse buttons.
- r. **Run SCoBi:** The simulation can be run with the above parameters.

3.2.3. P-band Root-zone Analysis

The major three steps of a **Root-zone** simulation at P-band can be described as follows:

1. In such a simulation, a **Root-zone** SoOp analysis over a **Bare-soil** will be considered. The transmitter will be a **Geo-stationary** (orientation) communication satellite that operates at P-band (e.g. 370 MHz). The receiver will be a ground-based receiver, which has a **Generalized-Gaussian** antenna pattern. Further details about the transmitter and the receiver parameters will be given below. This **Simulation Mode** will be **Time-series**, where a temporal analysis is performed. **Ground Structure** will be **Multi-layered** since the dielectric calculations through the multiple layers of the soil are of major interest in this example.
2. For such a simulation, below Excel input files (either the default or the newly generated files) must satisfy the simulation specifications in the first major step as follows:
 - a. **Configuration Inputs File:** It should satisfy:
 - **Simulation Mode: Time-series,**
 - **Transmitter Orientation: Geo-stationary,** and
 - **Ground Structure: Multi-layered**

which corresponds to a file similar to what is shown in **Table 6** and **Table 8** for **Dynamic** and **Ground** spreadsheets, respectively, except that **Table 6** should be modified for a **Geo-stationary** transmitter as in **Table 4**.
 - b. **Vegetation Inputs File:** This simulation does not involve this file since the **Vegetation Cover** is a **Bare-soil**.
 - c. **Antenna Pattern File:** This simulation does not involve this file since the receiver antenna pattern is a **Generalized-Gaussian**.
3. The type of analysis should be chosen **Root-zone** in the **Analysis Selection Window**.

Simulation Inputs Window: All the simulation parameters are determined via this window, as described in detail in **section 2.3 Simulation Input Window**.

- a. **Campaign:** It can be given, for instance, “Root_zone-P_band-MS-39762” for this example, which shows this simulation is a **Root-zone** analysis through P-band and located in MS 39762.
- b. **Simulation Mode:** It is **Time-series** for this simulation; details for **Simulation Mode** are described in **section 2.3.2.2 Simulation Mode**. Note again that this selection affects the content of the **Configuration Inputs File**. Please refer to **section 3.1.2.1.1 Simulation Mode Effect: Snapshot vs. Time-series** for details of such effects.
- c. **Ground-cover:** It is **Bare-soil** for this simulation.
- d. **Preferences:** Preferences of this simulation should be determined as well. If this simulation is of a temporary purpose, then it should not be included in the **Master** simulations.
- e. **Transmitter Frequency:** It can be 370 MHz for this example.
- f. **Transmitter Range to Earth Center:** For example, it can be 42164 km in this simulation.
- g. **Transmitter EIRP:** If it is known for the selected transmitter, then it can be given. If it is not known, then an **EIRP** value of user’s choice can be given since it has only an offset effect on the simulated results. For example, it can be 0 dB in this simulation.
- h. **Transmitter Polarization:** Similar to the above parameters, polarization of the transmitter should be chosen properly. For example, it can be a RHCP in this simulation.
- i. **Transmitter Orientation:** It is **Geo-stationary** in this example (Incidence angle: 40 degrees, Azimuth angle: 0 degree). Note again that this is an important parameter that also affects the content of the **Configuration Inputs File**. Please refer to **section 3.1.2.1.2 Transmitter Orientation** for details of such effects.
- j. **Ground Dielectric Model:** Any one of the available models can be selected. For instance, **Dobson** can be chosen in this scenario.
- k. **Ground Structure:** It is **Multi-layered** in this example. Note again that this is an important parameter that also affects the content of the **Configuration Inputs File**. Please refer to **section 3.1.2.1.3 Ground Structure: Single-layered vs. Multi-layered** for details of such effects.
- l. **Receiver Altitude:** It is 20 m in this simulation.
- m. **Receiver Gain:** Similar to **EIRP**, if it is known for the selected receiver, then it can be given. If it is not known, a **Gain** value of user’s choice can be given since it has only an offset effect on the simulated results. For example, it can be 0 dB in this simulation.
- n. **Receiver Polarization:** Polarization of the receiver should be chosen properly. For example, it can be an X-pol in this simulation.
- o. **Receiver Orientation:** It can be chosen **Fixed** (Zenith observation angle: 40 degrees, Azimuth observation angle: 0 degree) in this.
- s. **Receiver Antenna Pattern Input:** It can be selected **Generalized-Gaussian** with the following parameters:
 - i. **Beamwidth:** 30 degrees
 - ii. **Side-lobe level:** 30 dB
 - iii. **Cross-polarization level:** 25 dB
 - iv. **Pattern resolution:** 1 degree

- p. **Input Files:** The Excel input files should be fed accordingly via the Browse buttons.
- q. **Run SCoBi:** The simulation can be run with the above parameters.

3.3. Simulation Results

Simulation results are generated under the following directory:

\source\sims

If the preference under **Simulation Settings** is chosen to be **Include in Master Simulations**, then output is generated under **\master** folder, if not it is generated under **\temp** folder in that directory.

There are the following folders under both **\temp** and **\master** simulations:

- **Analysis:** This folder is dedicated to possible analyses about a simulation or a more exhaustive analysis between a number of simulations.
- **Output:** This folder is for holding the actual outputs of every simulation.

3.3.1. Simulation Name

Simulation names are generated uniquely under **\output** folder by using the **Campaign** parameter and the timestamp that the simulation is run.

Example

The record of the simulation that are included in master simulations is logged with the simulation name into **Master Simulations File**, which will be described in the next section.

The actual output of each simulation is generated under its unique simulation name folder, where the following folders are common:

- **figure:** This folder may include the common plots that are generic for any type of simulations if plots are generated by the user. In other words, the SCoBi has general-purpose plotting functions (e.g. reflectivity as a function of transmitter incidence angle), but it does not plot them automatically. Figures are stored under this folder when plotted by the user.
- **input:** This folder stores the copies of the simulation input and MS Excel input files used in the current simulation in the folder **\used_files**. The purpose of this folder is to avoid possible information loss if the actual input files of a simulation are removed or corrupted after it is run. The **\input** folder also keeps the **input_report.txt** file that is shown immediately when a simulation is run and stored here for user's reference. It also keeps the **inputParamsStruct.mat** file that is for SCoBi simulation controls and not for the user.
- **metadata:** This folder may include some meta-data of a simulation when it is needed, currently only propagation calculations.
- **products:** This folder is the exact product folder of a simulation. It stores the direct field and power, and specular reflection coefficient and reflectivity results of a simulation. This folder is described in detail in section **3.3.2 Products**.

3.3.2. Products

The **/products** folder involves the following structure for direct and specular outputs:

- Direct
 - Field
 - Power
- Specular
 - Reflection Coefficient
 - Reflectivity

If the simulation is a **Time-series** simulation, **DoYs.dat** file that keeps the Day-of-Year timestamps for each observation.

If the simulation has a Multi-layered ground structure, then the reflection coefficient and reflectivity folder of the Specular term has the following subfolder for different dielectric profiles supported:

- 2nd-order
- 3rd-order
- Discrete slab
- Logistic regression

The above subfolders may keep (If they were selected for the current simulation) separate Specular term results for the corresponding dielectric profile.

FOLDER CONTENT FILES

3.3.3. Master Simulations File

Master Simulations File is for the purpose of logging the simulations that have importance. Simulations that are logged into the **Master Simulations File** can be identified easily by checking their row in this file in the future. The file shows the significant parameters of the simulation besides its unique name.

Example

On the other hand, **\temp** simulations are for temporary cases. They generate the same output with the master simulations; however, they are not included in the **Master Simulations File**.

References