



# Cisco IOS Commands

## abort

Use the **abort** VLAN database command to abandon the proposed new VLAN database, exit VLAN database mode, and return to privileged EXEC mode.

**abort**

Syntax Description	This command has no arguments or keywords.	
Defaults	No default is defined.	
Command Modes	VLAN database	
Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.
Usage Guidelines	If you have added, deleted, or modified VLAN parameters in VLAN database mode but you do not want to keep the changes, the <b>abort</b> command causes all the changes to be abandoned. The VLAN configuration that was running before you entered VLAN database mode continues to be used.	
Examples	<p>The following example shows how to abandon the proposed new VLAN database and exit to the privileged EXEC mode:</p> <pre>Switch(vlan) # abort Switch#</pre> <p>You can verify that no VLAN database changes occurred by entering the <b>show vlan brief</b> command in privileged EXEC mode.</p>	

Related Commands	Command	Description
	<a href="#">apply</a>	Implements the proposed new VLAN database, increments the database configuration revision number, propagates it throughout the administrative domain, and remains in VLAN database mode.
	<a href="#">exit</a>	Implements the proposed new VLAN database, increments the database configuration number, propagates it throughout the administrative domain, and returns to privileged EXEC mode.
	<a href="#">reset</a>	Abandons the proposed VLAN database and remains in VLAN database mode. Resets the proposed database to the currently implemented VLAN database on the switch.
	<a href="#">show vlan</a>	Displays the parameters for all configured VLANs in the administrative domain.
	<a href="#">shutdown vlan</a>	Shuts down (suspends) local traffic on the specified VLAN.
	<a href="#">vlan database</a>	Enters VLAN database mode from the command-line interface (CLI).

# apply

Use the **apply** VLAN database command to implement the proposed new VLAN database, increment the database configuration revision number, propagate it throughout the administrative domain, and remain in VLAN database mode.

## apply

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Defaults</b>	No default is defined.
-----------------	------------------------

<b>Command Modes</b>	VLAN database
----------------------	---------------

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

<b>Usage Guidelines</b>	The <b>apply</b> command implements the configuration changes you made after you entered VLAN database mode and uses them for the running configuration. This command keeps you in VLAN database mode. You cannot use this command when the switch is in the VLAN Trunk Protocol (VTP) client mode.
-------------------------	---

<b>Examples</b>	The following example shows how to implement the proposed new VLAN database and recognize it as the current database:
-----------------	---

```
Switch(vlan) # apply
```

You can verify that VLAN database changes occurred by entering the **show vlan** command in privileged EXEC mode.

Related Commands	Command	Description
	<b>apply</b>	Implements the proposed new VLAN database, increments the database configuration revision number, propagates it throughout the administrative domain, and remains in VLAN database mode.
	<b>exit</b>	Implements the proposed new VLAN database, increments the database configuration number, propagates it throughout the administrative domain, and returns to privileged EXEC mode.
	<b>reset</b>	Abandons the proposed VLAN database and remains in VLAN database mode. Resets the proposed database to the currently implemented VLAN database on the switch.
	<b>show vlan</b>	Displays the parameters for all configured VLANs in the administrative domain.
	<b>shutdown vlan</b>	Shuts down (suspends) local traffic on the specified VLAN.
	<b>vlan database</b>	Enters VLAN database mode from the command-line interface (CLI).

# cgmp

Use the **cgmp** global configuration command to enable Cisco Group Management Protocol (CGMP) and other CGMP options. Use the **no** form of this command to disable CGMP and its options.

**cgmp** {**leave-processing** | **holdtime** *time* | **reserved**}

**no cgmp** {**leave-processing** | **holdtime** | **reserved**}

Syntax Description	leave-processing	Enable Fast Leave processing on the switch.
	holdtime <i>time</i>	Number of seconds a router connection is retained before the switch ceases to exchange messages with it. You can enter a number from 10 to 6000 (seconds).
	reserved	Allow reserved addresses from 0100.5E00.0000 to 0100.5E00.00FF to join as group destination addresses.

Defaults	CGMP is enabled. Fast Leave is disabled. The hold time is 300 seconds. Reserved addresses are allowed as group destination addresses.
----------	--

Command Modes	Global configuration
---------------	----------------------

Command History	Release	Modification
	11.2(8)SA3	This command was first introduced.
	12.0(5)XP	The <b>reserved</b> keyword was added.

Usage Guidelines	CGMP must be enabled before the Fast Leave option can be enabled.
------------------	---

## Examples

The following example shows how to disable CGMP:

```
Switch(config)# no cgmp
```

The following example shows how to disable the Fast Leave option:

```
Switch(config)# no cgmp leave-processing
```

The following example shows how to set 400 seconds as the length of time the switch waits before ceasing to exchange messages with a router:

```
Switch(config)# cgmp holdtime 400
```

The following example shows how to remove the amount of time the switch waits before ceasing to exchange messages with a router:

```
Switch(config)# no cgmp holdtime
```

The following example shows how to exclude reserved addresses from the group destination address for compatibility with Catalyst 5000 series switches.

```
Switch(config)# no cgmp reserved
```

You can verify the previous commands by entering the **show cgmp** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">clear cgmp</a>	Deletes information that was learned by the switch using the CGMP.
<a href="#">show cgmp</a>	Displays the current state of the CGMP-learned multicast groups and routers.

# clear cgmp

Use the **clear cgmp** privileged EXEC command to delete information that was learned by the switch using the Cisco Group Management Protocol (CGMP).

**clear cgmp** [**vlan** *vlan-id*] | [**group** *address*] | **router** *address*]

<b>Syntax Description</b>	<b>vlan</b> <i>vlan-id</i>	(Optional) VLAN for which the CGMP groups or routers are to be deleted. Valid IDs are from 1 to 1001; do not enter leading zeroes.
	<b>group</b> <i>address</i>	Delete all known multicast groups and their destination ports. Limited to a VLAN if the <b>vlan</b> keyword is entered. Limited to a specific group if the <i>address</i> parameter (MAC address of the group or router) is entered.
	<b>router</b> <i>address</i>	(Optional) Delete all routers, their ports, and expiration times. Limited to a given VLAN if the <b>vlan</b> keyword is entered. Limited to a specific router if the <i>address</i> parameter is entered.

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA3	This command was first introduced.

<b>Usage Guidelines</b>	Using <b>clear cgmp</b> with no arguments deletes all groups and routers in all VLANs.
-------------------------	--

<b>Examples</b>	The following example shows how to delete all groups and routers on VLAN 2:
	Switch# <b>clear cgmp vlan 2</b>
	The following example shows how to delete all groups on all VLANs:
	Switch# <b>clear cgmp group</b>
	The following example shows how to delete a router address on VLAN 2:
	Switch# <b>clear cgmp vlan 2 router 0012.1234.1234</b>
	You can verify the previous commands by entering the <b>show cgmp</b> command in privileged EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>cgmp</b>	Enables CGMP and the Fast Leave option and sets the router port aging time.
	<b>show cgmp</b>	Displays the current state of the CGMP-learned multicast groups and routers.

# clear controllers ethernet-controller

Use the **clear controllers ethernet-controller** privileged EXEC command to delete the Ethernet link transmit and receive statistics on a Fast Ethernet or LRE port on an LRE switch.

**clear controllers ethernet-controller** *interface-id*

<b>Syntax Description</b>	<i>interface-id</i>	ID of the Fast Ethernet or LRE port.
---------------------------	---------------------	--------------------------------------

<b>Defaults</b>	N/A.
-----------------	------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(5)WC1	This command was first introduced.

<b>Usage Guidelines</b>	Using the <b>clear controllers ethernet-controller</b> command without specifying a Fast Ethernet or LRE port deletes the Ethernet link statistics of all ports on the switch and on the connected customer premises equipment (CPE) devices.
-------------------------	---

The Ethernet link on an LRE port is the connection between the remote Cisco 575 LRE CPE and the PC. It is not the link between the LRE port and the CPE.

It takes the switch several seconds to clear all of the ports. The LRE ports take longer to clear than all the other port types.

<b>Examples</b>	The following example shows how to use the <b>clear controllers ethernet-controller</b> command to delete the Ethernet link statistics between the CPE and PC, where the CPE is connected to LRE port 1:
-----------------	--

```
Switch# clear controllers ethernet-controller lo0/1
Switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show controllers ethernet-controller</a>	Displays the Ethernet link transmit and receive statistics on a Fast Ethernet or LRE port on an LRE switch.



# clear controllers lre log

Use the **clear controllers lre log** privileged EXEC command to delete the history of link, configuration, and timer events for a specific LRE port or all LRE ports on the switch.

**clear controllers lre log** *interface-id*

<b>Syntax Description</b>	<i>interface-id</i>	ID of the LRE port.
---------------------------	---------------------	---------------------

<b>Defaults</b>	There is no default.	
-----------------	----------------------	--

<b>Command Modes</b>	Privileged EXEC	
----------------------	-----------------	--

Command History	Release	Modification
	12.0(5)WC1	This command was first introduced.

<b>Usage Guidelines</b>	Using the <b>clear controllers lre log</b> command without specifying an LRE port deletes the history of events on all LRE ports.	
-------------------------	---	--

<b>Examples</b>	The following example shows how to use the <b>clear controllers lre log</b> command to delete the history of events on LRE port 3:	
-----------------	--	--

```
Switch# clear controllers lre log longReachEthernet 0/3
Switch#
```

Related Commands	Command	Description
	<a href="#">show controllers lre log</a>	Displays the history of link, configuration, and timer events for a specific LRE port or all LRE ports on the switch.

# clear ip address

Use the **clear ip address** privileged EXEC command to delete an IP address for a switch without disabling the IP processing.

**clear ip address** [**vlan** *vlan-id*]

## Syntax Description

<b>vlan</b> <i>vlan-id</i>	(Optional) Delete an IP address only within the specified VLAN. Valid IDs are from 1 to 1000; do not enter leading zeroes.
----------------------------	--

## Defaults

No IP address is defined for the switch.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.
11.2(8)SA3	The <b>vlan</b> keyword was added.

## Usage Guidelines

A switch can have one IP address.

The IP address of the switch can be accessed only by nodes connected to ports that belong to the management VLAN. By default, the management VLAN is VLAN 1, but you can configure a different VLAN as the management VLAN.

If your switch receives its IP address from a Bootstrap Protocol (BOOTP) or Dynamic Host Configuration Protocol (DHCP) server and you delete the switch IP address by using the **clear ip address** command, the BOOTP or DHCP server reassigns the address.

## Examples

The following example shows how to clear the IP address for the switch on VLAN 1:

```
Switch# clear ip address vlan 1
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>show running-config</b>	Displays the configuration information currently running on the switch.

# clear mac-address-table

Use the **clear mac-address-table** privileged EXEC command to delete entries from the MAC address table.

```
clear mac-address-table [static | dynamic | secure] [address hw-addr] [interface interface]
                        [atm slot/port] [vlan vlan-id]
```

Syntax Description	<b>static</b>	(Optional) Delete only static addresses.
	<b>dynamic</b>	(Optional) Delete only dynamic addresses.
	<b>secure</b>	(Optional) Delete only secure addresses.
	<b>address hw-addr</b>	(Optional) Delete the address <i>hw-addr</i> of type static, dynamic, and secure as specified.
	<b>interface interface</b>	(Optional) Delete an address on the interface <i>interface</i> of type static, dynamic, or secure as specified.
	<b>atm slot/port</b>	(Optional) Delete only ATM addresses on this slot and port.
	<b>vlan vlan-id</b>	(Optional) Delete all the MAC addresses for <i>vlan-id</i> . Valid IDs are from 1 to 1005; do not enter leading zeroes.

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	11.2(8)SA	This command was first introduced.
	11.2(8)SA3	The <b>vlan</b> keyword was added.
	11.2(8)SA5	The <b>atm</b> keyword was added.

Usage Guidelines	This command deletes entries from the global MAC address table. Specific subsets can be deleted by using the optional keywords and values. If more than one optional keyword is used, all of the conditions in the argument must be true for that entry to be deleted.
------------------	--

## Examples

The following example shows how to delete static addresses on port fa0/7:

```
Switch# clear mac-address-table static interface fa0/7
```

The following example shows how to delete all secure addresses in VLAN 3:

```
Switch# clear mac-address-table secure vlan 3
```

The following example shows how to delete address 0099.7766.5544 from all ports in all VLANs. If the address exists in multiple VLANs or multiple ports, all the instances are deleted.

```
Switch# clear mac-address-table address 0099.7766.5544
```

The following example shows how to delete address 0099.7766.5544 only in VLAN 2:

```
Switch# clear mac-address-table address 0099.7766.5544 vlan 2
```

The following example shows how to delete the secure MAC address 00c0.00a0.03fa associated with the ATM port in expansion slot 2:

```
Switch(config)# clear mac-address-table secure 00c0.00a0.03fa atm 2/1
```

The following example shows how to delete the static address 00c0.00a0.03fa associated with the ATM port in expansion slot 2:

```
Switch(config)# clear mac-address-table static 00c0.00a0.03fa atm 2/1
```

You can verify the previous commands by entering the **show mac-address-table** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">show mac-address-table</a>	Displays the MAC address table.

# clear vmpls statistics

Use the **clear vmpls statistics** privileged EXEC command to clear the statistics maintained by the VLAN Query Protocol (VQP) client.

## clear vmpls statistics

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Defaults</b>	No default is defined.
-----------------	------------------------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA4	This command was first introduced.

<b>Examples</b>	The following example shows how to clear VLAN Membership Policy Server (VMPS) statistics:
-----------------	---

Switch# **clear vmpls statistics**

You can verify the previous command by entering the **show vmpls statistics** command in privileged EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show vmpls statistics</a>	Displays the VLAN Query Protocol (VQP) version, reconfirmation interval, retry count, VMPS IP addresses, and the current and primary servers.

# clear vtp counters

Use the **clear vtp counters** privileged EXEC command to clear the VLAN Trunk Protocol (VTP) and pruning counters.

**clear vtp counters**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default is defined.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

**Examples** The following example shows how to clear the VTP counters:

```
Switch# clear vtp counters
```

You can verify the previous command by entering the **show vtp counters** command in privileged EXEC mode.

Related Commands	Command	Description
	<a href="#">show vtp counters</a>	Display general information about the VTP management domain, status, and counters.

# cluster commander-address

The command switch automatically provides its MAC address to member switches when these switches join the cluster. The member switch adds this information and other cluster information to its running configuration file. You do not need to enter this command. Enter the **no** form of this global configuration command on a member switch to remove it from a cluster only during debugging or recovery procedures.

**cluster commander-address** *mac-address* **member** *number* **name** *name*

**no** cluster commander-address

**default** cluster commander-address

## Syntax Description

<i>mac-address</i>	MAC address of the cluster command switch.
<b>member</b> <i>number</i>	Number of member switch. The range is from 0 to 15.
<b>name</b> <i>name</i>	Name of the cluster up to 31 characters.
<b>no</b>	Remove a switch from the cluster. Entered on the member switch.
<b>default</b>	Remove a switch from the cluster. Entered on the member switch.

## Defaults

The switch is not a member of any cluster.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.
12.0(5)XU	The <b>member</b> and <b>name</b> keywords were added.

## Usage Guidelines

A cluster member can have only one command switch.

The member switch retains the identity of the command switch during a system reload by using the *mac-address* parameter.

You can enter the **no** form on a member switch to remove it from the cluster only during debugging or recovery procedures. However, with normal switch configuration, we recommend that you remove member switches only by entering the **no cluster member** *n* command on the command switch.

When a standby command switch becomes active, it removes the cluster commander-address line from its configuration.

## Examples

The following is sample text from the running configuration of a cluster member.

```
Switch(config)# cluster commander-address 00e0.9bc0.a500 member 4 name my_cluster
```

The following example shows how to remove a member from the cluster by using the cluster member console.

```
Switch-es3# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch-es3(config)# no cluster commander-address
```

You can verify the previous command by entering the **show cluster** command in user EXEC mode.

## Related Commands

Command	Description
<a href="#">show cluster</a>	Displays the cluster status and a summary of the cluster to which the switch belongs.



# cluster discovery hop-count

Use the **cluster discovery hop-count** global configuration command on the command switch to set the hop-count limit for extended discovery of candidate switches. Use the **no** form of this command to set the hop count to the default value.

**cluster discovery hop-count** *number*

**no cluster discovery hop-count**

**default cluster discovery hop-count**

## Syntax Description

<i>number</i>	Number of hops from the cluster edge that the command switch limits the discovery of candidates. The range is from 1 to 7.
<b>no</b>	Set the hop count to the default value (3).
<b>default</b>	Set the hop count to the default value (3).

## Defaults

The hop count is set to 3.

## Command Modes

Global configuration

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Usage Guidelines

Enter this command only on the command switch. This command does not operate on member switches. If the hop count is set to 1, it disables extended discovery. The command switch discovers only candidates that are one hop from the edge of the cluster. The edge of the cluster is the point between the last discovered member switch and the first discovered candidate switch.

## Examples

The following example shows how to set hop count limit to 4. This command is executed on the command switch.

```
Switch(config)# cluster discovery hop-count 4
```

You can verify the previous command by entering the **show cluster** command in user EXEC mode.

## Related Commands

Command	Description
<a href="#">show cluster</a>	Displays the cluster status and a summary of the cluster to which the switch belongs.
<a href="#">show cluster candidates</a>	Displays a list of candidate switches.

# cluster enable

Use the **cluster enable** global configuration command on a command-capable switch to enable it as the cluster command switch, assign a cluster name, and optionally assign a member number to it. Use the **no** form of the command to remove all members and make the command switch a candidate switch.

**cluster enable** *name* [*command-switch-member-number*]

**no cluster enable**

**default cluster enable**

## Syntax Description

<i>name</i>	Name of the cluster up to 31 characters. Valid characters include only alphanumerics, dashes, and underscores.
<i>command-switch-member-number</i>	(Optional) Assign a member number to the command switch of the cluster. The range is from 0 to 15.
<b>no</b>	Remove all member switches and make the command switch a candidate.
<b>default</b>	Switch is not a command switch.

## Defaults

The switch is not a command switch.

No cluster name is defined.

The member number is 0 when this is the command switch.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.
12.0(5)XU	The <i>command-switch-member-number</i> variable was added.

## Usage Guidelines

This command runs on any command-capable switch that is not part of any cluster. This command fails if a device is already configured as a member of the cluster.

You must name the cluster when you enable the command switch. If the switch is already configured as the command switch, this command changes the cluster name if it is different from the previous name.

---

**Examples**

The following example shows how to enable the command switch, name the cluster, and set the command switch member number to 4.

```
Switch(config)# cluster enable Engineering-IDF4 4
```

You can verify the previous command by entering the **show cluster** command in user EXEC mode on the command switch.

---

**Related Commands**

Command	Description
<a href="#">show cluster</a>	Displays the cluster status and a summary of the cluster to which the switch belongs.

# cluster holdtime

Use the **cluster holdtime** global configuration command on the command switch to set the duration in seconds before a switch (either the command or member switch) declares the other switch down after not receiving heartbeat messages. Use the **no** form of this command to set the duration to the default value.

**cluster holdtime** *holdtime-in-secs*

**no cluster holdtime**

**default cluster holdtime**

<b>Syntax Description</b>	<i>holdtime-in-secs</i>	Duration in seconds before a switch (either a command or member switch) declares the other switch down. The range is from 1 to 300 seconds
	<b>no</b>	Set the holdtime to the default value (80 seconds).
	<b>default</b>	Set the holdtime to the default value (80 seconds)

**Defaults** The holdtime is 80 seconds.

**Command Modes** Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(5)XU	This command was first introduced.

**Usage Guidelines** Use this command with the **cluster timer** global configuration command only on the command switch. The command switch propagates the values to all its cluster members.

The holdtime is typically set as a multiple of the interval timer (**cluster timer**). For example, it takes (holdtime-in-secs divided by interval-in-secs) number of heartbeat messages to be missed in a row to declare a switch down.

**Examples** The following example shows how to change the interval timer and the duration on the command switch.

```
Switch(config)# cluster timer 3
Switch(config)# cluster holdtime 30
```

You can verify the previous commands by entering the **show cluster** command in user EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show cluster</a>	Displays the cluster status and a summary of the cluster to which the switch belongs.

# cluster management-vlan

Use the **cluster management-vlan** global configuration command on the command switch to change the management VLAN for the entire cluster. Use the **no** form of this command to change the management VLAN to VLAN 1.

**cluster management-vlan** *n*

**no cluster management-vlan**

**default cluster management-vlan**

## Syntax Description

<i>n</i>	VLAN ID of the new management VLAN. Valid VLAN IDs are from 1 to 1001.
<b>no</b>	Set the management VLAN to VLAN 1
<b>default</b>	Set the management VLAN to VLAN 1

## Defaults

The default management VLAN is VLAN 1.

## Command Modes

Global configuration

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Usage Guidelines

Enter this command only on the command switch.  
This command is not written to the configuration file.

## Examples

The following example shows how to change the management VLAN to VLAN 5 on the entire cluster.

```
Switch(config)# cluster management-vlan 5
```

You can verify the previous command by entering the **show interface vlan** *number* command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">management</a>	Shuts down the current management VLAN interface and enables the new management VLAN interface on an individual switch.

# cluster member

Use the **cluster member** global configuration command on the command switch to add members to a cluster. Use the **no** form of the command to remove members from the cluster.

**cluster member** [*n*] **mac-address** *H.H.H* [**password** *enable-password*]

**no cluster member** *n*

**default cluster member** *n*

<b>Syntax Description</b>	<i>n</i>	(Optional) The number that identifies a cluster member. The range is from 0 to 15
	<b>mac-address</b> <i>H.H.H</i>	MAC address of the member switch in hexadecimal format.
	<b>password</b> <i>enable-password</i>	Enable password of the candidate switch. The password is not required if there is no password on the candidate switch.
	<b>no</b>	Remove the specified member from the cluster.
	<b>default</b>	Remove the specified member from the cluster.

## Defaults

A newly enabled command switch has no associated cluster members.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

Enter this command only on the command switch to add a member to or remove a member from the cluster. If a switch is not commanding a cluster, this command displays an error message.

You do not need to enter a member number. The command switch selects the next available member number and assigns it to the switch joining the cluster.

You must enter the enable password of the candidate switch for authentication when it joins the cluster. The password is not saved in the running or startup configuration. After a candidate switch becomes a member of the cluster, its password becomes the same as the command-switch password.

If a switch does not have a configured host name, the command switch appends a member number to the command-switch host name and assigns it to the member switch.

## Examples

The following example shows how to add a switch as member 2 with MAC address 00E0.1E00.2222 and the password grandkey to a cluster.

```
Switch(config)# cluster member 2 mac-address 00E0.1E00.2222 password grandkey
```

The following example shows how to add a switch with MAC address 00E0.1E00.3333 to the cluster. The command switch selects the next available member number and assigns it to the switch joining the cluster.

```
Switch(config)# cluster member mac-address 00E0.1E00.3333
```

You can verify the previous command by entering the **show cluster members** command in user EXEC mode on the command switch.

## Related Commands

Command	Description
<a href="#">show cluster</a>	Displays the cluster status and a summary of the cluster to which the switch belongs.
<a href="#">show cluster candidates</a>	Displays a list of candidate switches.
<a href="#">show cluster members</a>	Displays information about the cluster members.

# cluster run

Use the **cluster run** global configuration command to enable clustering on a switch. Use the **no** form of this command to disable clustering on a switch.

**cluster run**

**no cluster run**

**default cluster run**

## Syntax Description

<b>no</b>	Disable clustering on a switch.
<b>default</b>	Enable clustering on a switch.

## Defaults

Clustering is enabled on all switches.

## Command Modes

Global configuration

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Usage Guidelines

When you enter the **no cluster run** command on a command switch, the command switch is disabled.

When you enter the **no cluster run** command on a member switch, it is removed from the cluster.

When you enter the **no cluster run** command on a switch, it disables clustering on that switch. This switch is then incapable of becoming a candidate switch.

## Examples

The following example shows how to disable clustering on the command switch:

```
Switch(config)# no cluster run
```

You can verify the previous command by entering the **show cluster** command in user EXEC mode.

## Related Commands

Command	Description
<a href="#">show cluster</a>	Displays the cluster status and a summary of the cluster to which the switch belongs.



# cluster setup

Use the **cluster setup** privileged EXEC command on the command switch to automatically build a cluster.

## cluster setup

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	11.2(8)SA6	This command was first introduced.

**Usage Guidelines** You can use the **cluster setup** command to add new switches to an existing cluster. The **cluster setup** command provides a high-level view of the configuration and guides you through the configuration change process. You can only see candidate switches that are one hop away from the command switch and have no IP address. To see devices farther away, use the **show cluster members** or **show cluster candidates** command.

If a candidate switch has a password, this information will not be passed to the cluster.

**Examples** The following is an example of the **cluster setup** command output:

```
Switch# cluster setup

--- Cluster Configuration Dialog ---

At any point you may enter a question mark '?' for help.
Use ctrl-c to abort configuration dialog at any prompt.
Default settings are in square brackets '[]'.

This switch is already configured as cluster command switch:
Command Switch Name:m217, contains 7 members

Continue with cluster configuration dialog? [yes/no]:yes
The suggested Cluster configuration is as follows:

                                     |---Upstream---|
SN MAC Address      Name           PortIf FEC Hops   SN PortIf FEC State
0  00d0.796d.2f00 3524-24                0                Cmdr
1  00d0.7960.66c0 3508             Gi0/4      1      0 Gi0/1      Up
2  00d0.7961.c4c0 3512-12          Fa0/3      1      0 Fa0/13     Up
3  00e0.1e9f.8300 2924M           Fa0/11     2      2 Fa0/12     Up
4  00e0.1e9f.7a00 2924-24 Fa0/5      1      0 Fa0/3      Up
5  00e0.1e9f.8c00 2912-12-2 Fa0/4      1      0 Fa0/7      Up
6  00e0.1e9f.8c40 2912-12-1 Fa0/1      1      0 Fa0/9      Up
7* 0010.7bb6.1cc0 2912MF          Fa2/1      3      3 Fa0/24     Candidat
```

## cluster setup

The following configuration command script was created:

```
cluster member 7 mac-address 0010.7bb6.1cc0
!
end
```

Use this configuration? [yes/no]:yes

Building configuration...

[OK]

Use the enabled mode 'configure' command to modify this configuration.

Switch#

Related Commands	Command	Description
	<b>cluster enable</b>	Enables a switch as the cluster command switch, assigns a cluster name, and optionally assigns a member number to it.
	<b>show cluster</b>	Displays the cluster status and a summary of the cluster to which the switch belongs.
	<b>show cluster candidates</b>	Displays a list of candidate switches.
	<b>show cluster members</b>	Displays information about the cluster members.

# cluster standby-group

Use the **cluster standby-group** global configuration command to enable command switch redundancy by binding the Hot Standby Router Protocol (HSRP) standby group to the cluster. Use the **no** form of this command to unbind the cluster from the HSRP standby group.

**cluster standby-group** *HSRP-group-name*

**no cluster standby-group**

**default cluster standby-group**

Syntax Description		
	<i>HSRP-group-name</i>	Name of the HSRP group that is bound to the cluster. The group name is limited to 32 characters.
	<b>no</b>	Unbind the cluster from the HSRP standby group.
	<b>default</b>	Unbind the cluster from the HSRP standby group.

**Defaults** The cluster is not bound to any HSRP group.

**Command Modes** Global configuration

Command History	Release	Modification
	12.0(5)XU	This command was first introduced.

**Usage Guidelines**

You must enter this command only on the command switch. If you enter it on a member switch, an error message appears.

The command switch propagates the cluster-HSRP binding information to all members. Each member switch stores the binding information in its nonvolatile RAM (NVRAM).

The HSRP group name must be a valid standby group; otherwise, the command exits with an error.

## Examples

The following example shows how to bind the HSRP group named my\_hsrp to the cluster. This command is executed on the command switch.

```
Switch(config)# cluster standby-group my_hsrp
```

The following example shows the error message when this command is executed on a command switch and the specified HSRP standby group does not exist:

```
Switch(config)# cluster standby-group my_hsrp
%ERROR: Standby group 'my_hsrp' doesn't exist
```

The following example shows the error message when this command is executed on a member switch.

```
Switch(config)# cluster standby-group my_hsrp
%ERROR: This command runs only on the command switch
```

You can verify the previous commands by entering the **show cluster** command in user EXEC mode.

## Related Commands

Command	Description
<b>standby ip</b>	Enables HSRP on the interface.
<b>show cluster</b>	Displays the cluster status and a summary of the cluster to which the switch belongs.
<b>show standby</b>	Displays standby group information.

# cluster timer

Use the **cluster timer** global configuration command on the command switch to set the interval in seconds between heartbeat messages. Use the **no** form of this command to set the interval to the default value.

**cluster timer** *interval-in-secs*

**no cluster timer**

**default cluster timer**

## Syntax Description

<i>interval-in-secs</i>	Interval in seconds between heartbeat messages. The range is from 1 to 300 seconds.
<b>no</b>	Set the interval to the default value (8 seconds).
<b>default</b>	Set the interval to the default value (8 seconds).

## Defaults

The interval is 8 seconds.

## Command Modes

Global configuration

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Usage Guidelines

Use this command with the **cluster holdtime** global configuration command only on the command switch. The command switch propagates the values to all its cluster members.

The holdtime is typically set as a multiple of the heartbeat interval timer (**cluster timer**). For example, it takes (holdtime-in-secs divided by the interval-in-secs) number of heartbeat messages to be missed in a row to declare a switch down.

## Examples

The following example shows how to change the heartbeat interval timer and the duration on the command switch.

```
Switch(config)# cluster timer 3
Switch(config)# cluster holdtime 30
```

You can verify the previous commands by entering the **show cluster** command in user EXEC mode.

## Related Commands

Command	Description
<a href="#">show cluster</a>	Displays the cluster status and a summary of the cluster to which the switch belongs.

# debug lre

Use the **debug lre** privileged EXEC command to enable debugging of Long-Reach Ethernet (LRE)-related events. Use the **no** form to disable debugging.

**debug lre** [**controller** | **errors** | **profile** | **state**] *interface-id*

**no debug lre** [**controller** | **profile** | **state**]

## Syntax Description

<b>controller</b>	Display the remote customer premises equipment (CPE) Ethernet chipset control accesses and CPE timing information.
<b>errors</b>	Display certain types of unexpected events that indicate the switch is configured or operating in a non-standard way.
<b>profile</b>	Display profile management events on the switch.
<b>state</b>	Display state transition events of each LRE port.
<i>interface-id</i>	ID of the LRE port.

## Defaults

The default is **off**.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
12.0(5)WC1	This command was first introduced.

## Usage Guidelines

If you use the **debug lre** command without providing a specific debug option, all LRE debug options are enabled. Conversely, if you use the **no debug lre** command without providing a specific debug option, all LRE debug options are disabled.

You can enable and disable the LRE debug options on individual ports, for example, by using the **debug lre state interface-id** command. If a specific port is not provided, the debug option will apply to all LRE ports.

To troubleshoot LRE connectivity problems, use the **debug lre state** command to display the state machine transitions and the **debug lre errors** command to display other information that might explain unusual occurrences that could be affecting connectivity.

## Examples

The following example shows how to use the command to enable LRE controller event debugging on all LRE ports on the switch:

```
Switch# debug lre controller  
LRE Controller Events debugging is on
```

The following shows sample output when the debug lre state option is enabled.

```
*Mar  1 02:11:39: LRE: Lo0/3: FSM_PROFILE_LINKUP: event:EVT_PORT_CONFIG_CHANGE  
*Mar  1 02:11:40: LRE: Lo0/3: FSM_PROFILE_APPLIED: event:EVT_LRE_LINK_DOWN  
*Mar  1 02:11:41: LRE: Lo0/3: FSM_PROFILE_APPLIED: event:EVT_LRE_LINK_UP
```

The following example shows how to disable LRE controller event debugging:

```
Switch# no debug lre controller
```

## Related Commands

Command	Description
<a href="#">show controllers lre status</a>	Displays the Long-Reach Ethernet (LRE) link statistics and profile information on an LRE port, including link state, link duration, data rates, power levels, signal-to-noise ratio, and Reed-Solomon errors.

# delete

Use the **delete** privileged EXEC command to delete a file from the file system.

**delete** {*device:*}*filename*

<b>Syntax Description</b>	<i>device:</i>	Device containing the file to be deleted. Valid devices include the switch Flash memory and ATM module files. To access the ATM module, specify the slot number (1 or 2).
	<i>filename</i>	Name of file.

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

<b>Usage Guidelines</b>	A colon (:) follows the <i>device</i> variable. Do not enter spaces after the colon.
-------------------------	--

<b>Examples</b>	The following example shows how to delete the file <i>atm_image</i> from the file system for an ATM module installed in slot 1:
-----------------	---

```
Switch# delete slot1:atm_image
```

The following example shows how to delete a file from the switch Flash memory:

```
Switch# delete flash:filename
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>copy tftp</b>	Downloads a file from a TFTP server to a device.



# duplex

Use the **duplex** interface configuration command to specify the duplex mode of operation for Fast Ethernet and Gigabit Ethernet ports. Use the **no** form of this command to return the port to its default value.

**duplex {full | half | auto}**

**no duplex**

## Syntax Description

<b>full</b>	Port is in full-duplex mode.
<b>half</b>	Port is in half-duplex mode.
<b>auto</b>	Port automatically detects whether it should run in full- or half-duplex mode.

## Defaults

The default is **auto**.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.

## Usage Guidelines

Certain ports can be configured to be either full duplex or half duplex. Applicability of this command depends on the device to which the switch is attached.

For Fast Ethernet ports, setting the port to **auto** has the same effect as specifying **half** if the attached device does not autonegotiate the duplex parameter.

For Gigabit Ethernet ports, setting the port to **auto** has the same effect as specifying **full** if the attached device does not autonegotiate the duplex parameter.

If the speed is set to auto, the switch negotiates with the device at the other end of the link for the speed setting and then forces the speed setting to the negotiated value. The duplex setting remains as configured on each end of the link, which could result in a duplex setting mismatch.

If both the speed and duplex are set to specific values, autonegotiation is disabled.



### Note

For guidelines on setting the switch speed and duplex parameters, see the *Catalyst 2900 Series XL Hardware Installation Guide* and the *Catalyst 3500 Series XL Hardware Installation Guide*.

This command is not supported on the ATM module.

---

**Examples**

The following example shows how to set port 1 on a Fast Ethernet module installed in slot 2 to full duplex:

```
Switch(config)# interface fastethernet2/1  
Switch(config-if)# duplex full
```

The following example shows how to set port 1 on a Gigabit Ethernet module installed in slot 2 to full duplex:

```
Switch(config)# interface gigabitethernet2/1  
Switch(config-if)# duplex full
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<b>show running-config</b>	Displays the running configuration on the switch.
<b>speed</b>	Specifies the speed of a Fast Ethernet port.

# enable last-resort

Use the **enable last-resort** global configuration command to specify what happens if the Terminal Access Controller Access Control System (TACACS) and Extended TACACS servers used by the **enable** command do not respond. Use the **no** form of this command to restore the default.

**enable last-resort {password | succeed}**

**no enable last-resort**

## Syntax Description

<b>password</b>	Provide access to enable mode with entry of the privileged command level password. A password must contain from 1 to 25 uppercase and lowercase alphanumeric characters.
<b>succeed</b>	Provide access to enable mode without further question.

## Defaults

Authentication is disabled.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

This secondary authentication is used only if the first attempt fails.



### Note

This command is not used with Terminal Access Controller Access Control System Plus (TACACS+), a Cisco proprietary protocol that instead uses the authentication, authorization, and accounting (AAA) suite of commands.

## Examples

In the following example, if the TACACS servers do not respond to the **enable** command, you can enable access by entering the privileged-level password:

```
Switch(config)# enable last-resort <password>
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>enable</b>	Accesses privileged EXEC mode.
<b>show running-config</b>	Displays the running configuration on the switch.

# enable use-tacacs

Use the **enable use-tacacs** global configuration command to enable the use of Terminal Access Controller Access Control System (TACACS) to determine whether a user can access the privileged command level. Use the **no** form of this command to disable TACACS verification.

**enable use-tacacs**

**no enable use-tacacs**



## Tips

If you use the **enable use-tacacs** command, you must also use the **tacacs-server authenticate enable** command, or you will be locked out of the privileged command level.

## Syntax Description

This command has no arguments or keywords.

## Defaults

TACACS verification is disabled.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

When you add this command to the configuration file, the **enable** privilege EXEC command prompts for a new username and password. This pair is then passed to the TACACS server for authentication. If you are using Extended TACACS, it also sends any existing UNIX user identification code to the server.



## Note

This command initializes TACACS. Use the **tacacs server-extended** command to initialize Extended TACACS or use the **aaa new-model** command to initialize authentication, authorization, and accounting (AAA) and Terminal Access Controller Access Control System Plus (TACACS+).

---

**Examples**

The following example sets TACACS verification on the privileged EXEC login sequence:

```
Switch(config)# enable use-tacacs
Switch(config)# tacacs-server authenticate enable
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<b>show running-config</b>	Displays the running configuration on the switch.
<b>tacacs-server authenticate enable</b>	Indicates whether users can perform an attempted action under TACACS and extended TACACS.

# exit

Use the **exit** VLAN database command to implement the proposed new VLAN database, increment the database configuration number, propagate it throughout the administrative domain, and return to privileged EXEC mode.

**exit**

---

**Syntax Description** This command has no arguments or keywords.

---

**Defaults** No default is defined.

---

**Command Modes** VLAN database

---

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

---



---

**Usage Guidelines** The **exit** command implements all the configuration changes you made since you entered VLAN database mode and uses them for the running configuration. This command returns you to privileged EXEC mode.

---

**Examples** The following example shows how to implement the proposed new VLAN database and exit to privileged EXEC mode:

```
Switch(vlan) # exit
Switch#
```

You can verify the previous command by entering the **show vlan brief** command in privileged EXEC mode.

Related Commands	Command	Description
	<b>abort</b>	Abandons the proposed new VLAN database, exits VLAN database mode, and returns to privileged EXEC mode.
	<b>apply</b>	Implements the proposed new VLAN database, increments the database configuration revision number, propagates it throughout the administrative domain, and remains in VLAN database mode.
	<b>reset</b>	Abandons the proposed VLAN database and remains in VLAN database mode. Resets the proposed database to the currently implemented VLAN database on the switch.
	<b>show vlan</b>	Displays the parameters for all configured VLANs in the administrative domain.
	<b>shutdown vlan</b>	Shuts down (suspends) local traffic on the specified VLAN.
	<b>vlan database</b>	Enters VLAN database mode from the command-line interface (CLI).

# flowcontrol

Use the **flowcontrol** interface configuration command on Gigabit Ethernet ports to control traffic rates during congestion. Use the **no** form of this command to disable flow control on the port.

**flowcontrol** { **asymmetric** | **symmetric** }

**no flowcontrol**

Syntax Description	<b>asymmetric</b>	Enable the local port to perform flow control of the remote port. If the local port is congested, it can request the remote port to stop transmitting. When the congestion clears, the local port requests that the remote port begin transmitting.
	<b>symmetric</b>	Enable the local port to perform flow control only if the remote port can also perform flow control of the local port. If the remote port cannot perform flow control, the local port also does not.

**Defaults** The default is asymmetric.

**Command Modes** Interface configuration

Command History	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

**Examples** The following example shows how to configure the local port to support any level of flow control by the remote port:

```
Switch(config-if)# flowcontrol
```

The following example shows how to configure the local port to control the traffic flow from the remote port:

```
Switch(config-if)# flowcontrol asymmetric
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

Related Commands	<b>Command</b>	<b>Description</b>
	<b>show interface</b> <i>[interface-id]</i> <b>flow-control</b>	Displays flow-control information for the specified port.



# interface

Use the **interface** global configuration command to configure an interface type, create a switch virtual interface to be used as the management VLAN interface, and to enter interface configuration mode.

**interface** *type slot/port* | **vlan** *number*

**no interface** *type slot/port* | **vlan** *number*

## Syntax Description

<i>type</i>	Type of interface to be configured. Can be Fast Ethernet, Gigabit Ethernet, or Asynchronous Transfer Mode (ATM).
<i>slot</i>	Slot number (0, 1, or 2). For an ATM module, use slot number 1 or 2.
<i>port</i>	Port ID.
<b>vlan</b> <i>number</i>	VLAN number from 1 to 1001 to be used as the management VLAN. Do not enter leading zeroes.

## Defaults

The default management VLAN interface is VLAN 1.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.
11.2(8)SA3	The <b>vlan</b> keyword was added.

## Usage Guidelines

When creating a management VLAN interface, a space between **vlan** and *number* is accepted.

Only one management VLAN interface can be active.

You cannot delete the management VLAN 1 interface.

Before bringing up a new management VLAN interface with the **no shutdown** command, you must issue the **shutdown** command to disable the old one.

You can use the **management** command to shut down the active management VLAN interface and to enable the newly created management VLAN interface.

You can configure the management VLAN interface on static-access, multi-VLAN, dynamic-access, and trunk ports.

## Examples

The following example shows how to enable the switch to act on ATM interface 1/2:

```
Switch(config)# interface atm 1/2
Switch(config-if)#
```

The following example shows how to change the management VLAN from VLAN 1 to VLAN 3. This series of commands should only be executed from the console. If these commands are executed through a Telnet session, the **shutdown** command disconnects the session, and there is no way to use IP to access the system.

```
Switch# configure terminal
Switch(config)# interface vlan 3
Switch(config-subif)# ip address 172.20.128.176 255.255.255.0
Switch(config-subif)# exit
Switch(config-if)# exit
Switch(config)# interface vlan 1
Switch(config-subif)# shutdown
Switch(config-subif)# exit
Switch(config-if)# exit
Switch(config)# interface vlan 3
Switch(config-subif)# no shutdown
Switch(config-subif)# exit
Switch(config-if)# exit
```

The following example shows how to change the management VLAN from VLAN 1 to VLAN 3 through a Telnet session. In this situation, the **management** command shuts down VLAN 1 and brings up VLAN 3. The Telnet session must be re-established through the new management VLAN.

```
Switch# configure terminal
Switch(config)# interface vlan 3
Switch(config-subif)# ip address 172.20.128.176 255.255.255.0
Switch(config-subif)# management
```

The following example shows how to copy the IP address and network mask information from the current management VLAN to VLAN 3 and make VLAN 3 the new management VLAN:

```
Switch# configure terminal
Switch(config)# interface vlan 3
Switch(config-subif)# management
```

You can verify the previous commands by entering the **show interface** and **show interface vlan number** command in privilege EXEC mode.

## Related Commands

Command	Description
<b>management</b>	Shuts down the current management VLAN interface and enables the new management VLAN interface.
<b>show interface</b>	Displays the administrative and operational status of a switching (nonrouting) port.
<b>shutdown</b>	Disables a port and shuts down the management VLAN.

# ip address

Use the **ip address** interface configuration command to set an IP address for a switch. Use the **no** form of this command to remove an IP address or to disable IP processing.

**ip address** *ip-address subnet-mask*

**no ip address** *ip-address subnet-mask*

## Syntax Description

<i>ip-address</i>	IP address.
<i>subnet-mask</i>	Mask for the associated IP subnet.

## Defaults

No IP address is defined for the switch.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.

## Usage Guidelines

A switch can have one IP address.

The IP address of the switch can be accessed only by nodes connected to ports that belong to the management VLAN. By default, the management VLAN is VLAN 1, but you can configure a different VLAN as the management VLAN.

If you remove the IP address through a Telnet session, your connection to the switch will be lost.

If your switch receives its IP address from a Bootstrap Protocol (BOOTP) or Dynamic Host Configuration Protocol (DHCP) server and you remove the switch IP address by using the **no ip address** command, IP processing is disabled, and the BOOTP or DHCP server cannot reassign the address.

## Examples

The following example shows how to configure the IP address for the switch on a subnetted network:

```
Switch(config)# interface vlan 1
Switch(config-if)# ip address 172.20.128.2 255.255.255.0
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>show running-config</b>	Displays the running configuration on the switch.
<b>clear ip address</b>	Deletes an IP address for a switch without disabling the IP processing.

# login

Use the **login** line configuration command to enable password checking at login. Use the **no** form of this command to disable password checking and to allow connections without a password.

**login** [**local** | **tacacs**]

**no login**

## Syntax Description

<b>local</b>	(Optional) Select local password checking. Authentication is based on the username specified with the <b>username</b> global configuration command.
<b>tacacs</b>	(Optional) Select the Terminal Access Controller Access Control System (TACACS)-style user ID and password-checking mechanism.

## Defaults

No password is assigned, and you cannot access the switch through Telnet. Virtual terminals require a password. If you do not set a password for a virtual terminal, it responds to attempted connections by displaying an error message and closing the connection.

## Command Modes

Line configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

If you specify the login command without the **local** or **tacacs** option, authentication is based on the password specified with the line configuration **password** command.



### Note

This command cannot be used with authentication, authorization, and accounting (AAA) and TACACS+. Use the **login authentication** command instead.

## Examples

The following example shows how to set the password *letmein* on virtual terminal line 4:

```
Switch(config-line)# line vty 4  
Switch(config-line)# password letmein  
Switch(config-line)# login
```

The following example shows how to enable the TACACS-style user ID and password-checking mechanism:

```
Switch(config-line)# line 0  
Switch(config-line)# password <mypassword>  
Switch(config-line)# login tacacs
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>enable password</b>	Sets a local password to control access to various privilege levels.
<b>password</b>	Specifies a password on a line.
<b>show running-config</b>	Displays the running configuration on the switch.
<b>username</b>	Establishes a username-based authentication system.

# login authentication

Use the **login authentication** line configuration command to enable authentication, authorization, and accounting (AAA) for logins. Use the **no** form of this command to either disable Terminal Access Controller Access Control System Plus (TACACS+) authentication for logins or to return to the default.

**login authentication** { **default** | *list-name* }

**no login** { **default** | *list-name* }

## Syntax Description

<b>default</b>	Use the default list created with the AAA <b>authentication login</b> command.
<i>list-name</i>	Use the indicated list created with the AAA <b>authentication login</b> command.

## Defaults

Login authentication is disabled.

## Command Modes

Line configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

To create a default list that is used if no list is specified in the **login authentication** command, use the **default** keyword followed by the methods you want used in default situations. The default method list is automatically applied to all interfaces.

## Examples

The following example shows how to specify TACACS+ as the default method for user authentication during login:

```
Switch(config)# aaa new-model
Switch(config)# aaa authentication login default tacacs
Switch(config)# line vty 0 4
Switch(config-line)# login authentication default tacacs
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>enable password</b>	Sets a local password to control access to various privilege levels.
<b>password</b>	Specifies a password on a line.
<b>show running-config</b>	Displays the running configuration on the switch.
<b>username</b>	Establishes a username-based authentication system.

# lre patchfile

Use the **lre patchfile** global configuration command to specify the Long-Reach Ethernet (LRE) patch file used when the switch boots.

**lre patchfile** *patchfile-name*

**Caution**

Do not use the **lre patchfile** command on the switch without Cisco assistance. This command is for updating the switch LRE patch file in future maintenance releases. Contact Cisco Systems for information about the Cisco 575 LRE CPE.

**Syntax Description**

<i>patchfile-name</i>	Name of the LRE patch file for the switch.
-----------------------	--

**Defaults**

The default name of an LRE patch file is **flash:e2rb.bin**.

**Command Modes**

Global configuration mode

**Command History**

Release	Modification
12.0(5)WC1	This command was first introduced.

**Usage Guidelines**

The LRE chipset on the switch might require software maintenance releases referred to as patches. Each patch provides a complete set of LRE features. To take advantage of the full feature set, the LRE switch and connected customer premises equipment (CPE) device should use the same patch version.

If you use this command to change to a different patch file, the change takes effect on the next reload *only* if you have saved this change to the startup-configuration.

If you rename the patch file, use the new name when using this command.

---

**Examples**

The following example shows how to use the **lre patchfile e2rb.bin** command:

```
Switch(config)#lre patchfile flash:e2rb.bin
Switch(config)#
```

---

**Related Commands**

Command	Description
<a href="#">show controllers lre</a>	Displays the version number of the hardware, software, and patch software components of the switch LRE chipset and, if a Cisco 575 LRE CPE is connected, the CPE LRE chipset.
<a href="#">debug lre</a>	Enable debugging of LRE-related events.



# lre profile global

Use the **lre profile global** global configuration command to assign a Long-Reach Ethernet (LRE) public profile to all LRE ports on the switch.

**lre profile global** *profile-name* [**public-ansi** | **public-etsi**]

**no lre profile global**

Syntax Description	<i>profile-name</i>	Name of the public profile, either PUBLIC-ANSI or PUBLIC-ETSI.
--------------------	---------------------	--

Defaults	N/A.
----------	------

Command Modes	Global configuration mode
---------------	---------------------------

Command History	Release	Modification
	12.0(5)WC1	This command was first introduced.

**Usage Guidelines**

We strongly recommend using a public profile if the LRE switch requires a connection to a Public Switched Telephone Network (PSTN). Depending on the PSTN, use either the ANSI- or ETSI-compliant public profile. Public profiles prevent the switch from causing interference with the other lines on the PSTN. Public profiles are assigned on a switch-wide (global) basis, meaning all LRE ports on the switch use the same public profile at a time.

Public profiles take precedence over private profiles. If a private profile is assigned to an LRE port, the switch ignores the private profile settings and uses the public profile settings.

A configuration conflict occurs if a switch cluster has LRE switches using both private and public profiles. If at least one LRE switch in a cluster is assigned a public profile, all LRE switches in that cluster must be assigned that same public profile. Before adding an LRE switch to a cluster, make sure it is assigned the same public profile that is being used by other LRE switch cluster members. A cluster can have a mix of LRE switches using different private profiles.

When you change the profile of a port, the port resets and uses the newly assigned profile.



**Note**

The standards for spectral profiles have not yet been ratified. The PUBLIC-ANSI profile corresponds to ANSI Plan 998. The PUBLIC-ETSI profile corresponds to ETSI Plan 997. Both plans are draft standards. Contact Cisco Systems for the latest information about standards ratification or for updates to the public profiles.

---

**Examples**

The following example shows how to use the **lre profile global PUBLIC-ANSI** command:

```
Switch(config)# lre profile global PUBLIC-ANSI
```

---

**Related Commands**

Command	Description
<a href="#">lre profile</a>	Assigns a private profile to a specific LRE port.
<a href="#">show controllers lre profile</a>	Displays information about the LRE profiles available on the switch, and how they are assigned to the LRE ports.

# lre profile

Use the **lre profile** interface configuration command to assign a Long-Reach Ethernet (LRE) private profile to a specific LRE port.

**lre profile** *profile-name*

## Syntax Description

<i>profile-name</i>	Name of the private profile:
	<ul style="list-style-type: none"><li>• LRE-5</li><li>• LRE-10</li><li>• LRE-15</li></ul>

## Defaults

LRE-10 private profile is the default profile on each LRE port.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
12.0(5)WC1	This command was first introduced.

## Usage Guidelines

A private profile can be used if the LRE switch does not require a connection to a public switched telephone network (PSTN). Three private profiles offer different line speeds and maximum distances. In general, the higher the line speed, the shorter the maximum distance. Private profiles are assigned on a per-port basis. The ports on an LRE switch can be assigned the same or different private profiles.

An LRE port always has a private profile assigned to it. However, public profiles have priority over private profiles.

- If you assign a public profile to the switch, the switch ignores the private profile settings and uses the public profile settings on all LRE ports. If you assign a different public profile, the change immediately takes effect.
- If a public profile is configured on the switch and you want the LRE ports to use private profiles, you must first disable the public profile mode by using CMS or by using the **no lre profile global** global configuration command.
- If no public profile is configured on the switch, the LRE port uses its private profile. If you assign a different private profile to the LRE port, the change immediately takes effect.

A configuration conflict occurs if a switch cluster has LRE switches using both private and public profiles. If at least one LRE switch in a cluster is assigned a public profile, all LRE switches in that cluster must be assigned that same public profile. Before adding an LRE switch to a cluster, make sure it is assigned the same public profile that is being used by other LRE switch cluster members. A cluster can have a mix of LRE switches using different private profiles.

---

**Examples**

The following example shows how to assign the LRE-15 private profile to LRE port 1 on the switch:

```
Switch(config)# interface lo0/1  
Switch(config-if)# lre profile LRE-15
```

---

**Related Commands**

Command	Description
<a href="#">lre profile global</a>	Assigns a public profile to all LRE ports on the switch.
<a href="#">show controllers lre profile</a>	Displays information about the LRE profiles available on the switch and how they are assigned to the LRE ports.

# lre reset

Use the **lre reset** interface configuration command to reset the switch Long-Reach Ethernet (LRE) chipset or, if a Cisco 575 LRE CPE is connected, the customer premises equipment (CPE) LRE chipset.

**lre reset** [**local** | **remote**]

## Syntax Description

<b>local</b>	Resets the LRE chipset for an LRE port.
<b>remote</b>	Resets the LRE chipset for the remote Cisco 575 LRE CPE.

## Defaults

N/A.

## Command Modes

Interface configuration mode

## Command History

Release	Modification
12.0(5)WC1	This command was first introduced.

## Usage Guidelines

Use this command to troubleshoot LRE port performance.

## Examples

The following example shows how to reset LRE port 1 on the switch:

```
Switch(config)# interface lo0/1  
Switch(config-if)# lre reset local
```

The following example shows how to reset the remote Cisco 575 LRE CPE, which is connected to LRE port 1:

```
Switch(config)# interface lo0/1  
Switch(config-if)# lre reset remote
```

## Related Commands

Command	Description
<a href="#">lre shutdown</a>	Disables the Long-Reach Ethernet (LRE) chipset transmitter of an LRE port that not being used.

# lre shutdown

Use the **lre shutdown** interface configuration command to disable the Long-Reach Ethernet (LRE) chipset transmitter of an LRE port that not being used.

## lre shutdown

### Defaults

There is no default.

### Command Modes

Interface configuration mode

### Command History

Release	Modification
12.0(5)WC1	This command was first introduced.

### Usage Guidelines

Use this command to disable the LRE chipset transmitter of an LRE port that is not connected to a working CPE. In some unusual circumstances, the power emitted by LRE ports can affect other LRE ports in various ways. We recommend that ports that are not wired to CPEs be shutdown in this way. Use this command to also disable access to the switch from this port.

### Examples

The following example shows how to deactivate the LRE link on LRE port 1 on the switch:

```
Switch(config)# interface lo0/1
Switch(config-if)# lre shutdown
```

### Related Commands

Command	Description
<a href="#">lre reset</a>	Resets the switch LRE chipset for a specific LRE port or the Cisco 575 LRE CPE LRE chipset, if the CPE is connected.

# mac-address-table aging-time

Use the **mac-address-table aging-time** global configuration command to set the length of time that a dynamic entry remains in the MAC address table after the entry is used or updated. Use the **no** form of this command to use the default aging-time interval. The aging time applies to all VLANs.

**mac-address-table aging-time** *age*

**no mac-address-table aging-time**

## Syntax Description

<i>age</i>	Number from 10 to 1000000 (seconds).
------------	--------------------------------------

## Defaults

The default is 300 seconds.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.

## Usage Guidelines

If hosts do not transmit continuously, increase the aging time to record the dynamic entries for a longer time. This can reduce the possibility of flooding when the hosts transmit again.

## Examples

The following example shows how to set the aging time to 200 seconds:

```
Switch(config)# mac-address-table aging-time 200
```

You can verify the previous command by entering the **show mac-address-table** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">clear mac-address-table</a>	Deletes entries from the MAC address table.
<a href="#">mac-address-table dynamic</a>	Adds dynamic addresses to the MAC address table.
<a href="#">mac-address-table secure</a>	Adds secure addresses to the MAC address table.
<a href="#">port block</a>	Blocks the flooding of unknown unicast or multicast packets to a port.
<a href="#">show cgmp</a>	Displays the current state of the CGMP-learned multicast groups and routers.
<a href="#">show mac-address-table</a>	Displays the MAC address table.

## mac-address-table dynamic

Use the **mac-address-table dynamic** global configuration command to add dynamic addresses to the MAC address table. Dynamic addresses are automatically added to the address table and dropped from it when they are not in use. Use the **no** form of this command to remove dynamic entries from the MAC address table.

**mac-address-table dynamic** *hw-addr* interface [**atm** slot/port] [**vlan** vlan-id]

**no mac-address-table dynamic** *hw-addr* [**vlan** vlan-id]

Syntax Description	
<i>hw-addr</i>	MAC address added to or removed from the table.
<i>interface</i>	Port to which packets destined for <i>hw-addr</i> are forwarded.
<b>atm</b> slot/port	(Optional) Add dynamic addresses to ATM module <i>in slot 1 or 2</i> . The <i>port</i> is always 0 for an ATM interface.
<b>vlan</b> vlan-id	<p>(Optional) The <i>interface</i> and <b>vlan</b> parameters together specify a destination to which packets destined for <i>hw-addr</i> are forwarded.</p> <p>The <b>vlan</b> keyword is optional if the port is a static-access or dynamic-access VLAN port. In this case, the VLAN assigned to the port is assumed to be that of the port associated with the MAC address.</p> <p><b>Note</b> When this command is executed on a dynamic-access port, queries to the VLAN Membership Policy Server (VMPS) do not occur. The VMPS cannot verify that the address is allowed or determine to which VLAN the port should be assigned. This command should only be used for testing purposes.</p> <p>The <b>vlan</b> keyword is required for multi-VLAN and trunk ports. This keyword is required on trunk ports to specify to which VLAN the dynamic address is assigned.</p> <p>The <i>vlan-id</i> is the ID of the VLAN to which packets destined for <i>hw-addr</i> are forwarded. Valid IDs are 1 to 1005; do not enter leading zeroes.</p>

**Command Modes** Global configuration

Command History	Release	Modification
	11.2(8)SA	This command was first introduced.
	11.2(8)SA3	The <b>vlan</b> keyword was added.
	11.2(8)SA5	The <b>atm</b> keyword was added.

**Usage Guidelines** If the variable *vlan-id* is omitted and the **no** form of the command is used, the MAC address is removed from all VLANs.



**Examples**

The following example shows how to add a MAC address on port fa1/1 to VLAN 4:

```
Switch(config)# mac-address-table dynamic 00c0.00a0.03fa fa1/1 vlan 4
```

You can verify the previous command by entering the **show mac-address-table** command in privileged EXEC mode.

**Related Commands**

Command	Description
<a href="#">clear mac-address-table</a>	Deletes entries from the MAC address table.
<a href="#">mac-address-table aging-time</a>	Sets the length of time that a dynamic entry remains in the MAC address table after the entry is used or updated.
<a href="#">mac-address-table static</a>	Adds static addresses to the MAC address table.
<a href="#">show mac-address-table</a>	Displays the MAC address table.

# mac-address-table secure

Use the **mac-address-table secure** global configuration command to add secure addresses to the MAC address table. Use the **no** form of this command to remove secure entries from the MAC address table.

**mac-address-table secure** *hw-addr interface* [**atm slot/port**] [**vlan vlan-id**]

**no mac-address-table secure** *hw-addr* [**vlan vlan-id**]

Syntax Description		
<i>hw-addr</i>		MAC address that is added to the table.
<i>interface</i>		Port to which packets destined for <i>hw-addr</i> are forwarded.
<b>atm slot/port</b>		(Optional) Add secure address to the ATM module in slot 1 or 2. The port is always 0 for an ATM interface.
<b>vlan vlan-id</b>		(Optional) The <i>interface</i> and <b>vlan</b> parameters together specify a destination to which packets destined for <i>hw-addr</i> are forwarded.  The <b>vlan</b> keyword is optional if the port is a static-access VLAN port. In this case, the VLAN assigned to the port is assumed to be that of the port associated with the MAC address. This keyword is required for multi-VLAN and trunk ports.  The <i>vlan-id</i> is the ID of the VLAN to which secure entries are added. Valid IDs are 1 to 1005; do not enter leading zeroes.

Command Modes	Global configuration
---------------	----------------------

Command History	Release	Modification
	11.2(8)SA	This command was first introduced.
	11.2(8)SA3	The <b>vlan</b> keyword was added.
	11.2(8)SA5	The <b>atm</b> keyword was added.

Usage Guidelines	Secure addresses can be assigned only to one port at a time. Therefore, if a secure address table entry for the specified MAC address and VLAN already exists on another port, it is removed from that port and assigned to the specified one.  Dynamic-access ports cannot be configured with secure addresses.
------------------	--

**Examples**

The following example shows how to add a secure MAC address to VLAN 6 of port fa1/1:

```
Switch(config)# mac-address-table secure 00c0.00a0.03fa fa1/1 vlan 6
```

The following example shows how to add a secure MAC address to ATM port 2/1:

```
Switch(config)# mac-address-table secure 00c0.00a0.03fa atm 2/1
```

You can verify the previous command by entering the **show mac-address-table** command in privileged EXEC mode.

**Related Commands**

Command	Description
<a href="#">clear mac-address-table</a>	Deletes entries from the MAC address table.
<a href="#">mac-address-table aging-time</a>	Sets the length of time that a dynamic entry remains in the MAC address table after the entry is used or updated.
<a href="#">mac-address-table dynamic</a>	Adds dynamic addresses to the MAC address table.
<a href="#">mac-address-table static</a>	Adds static addresses to the MAC address table.
<a href="#">show mac-address-table</a>	Displays the MAC address table.

# mac-address-table static

Use the **mac-address-table static** global configuration command to add static addresses to the MAC address table. Use the **no** form of this command to remove static entries from the MAC address table.

**mac-address-table static** *hw-addr in-port out-port-list* [**atm** *slot/port*] [**vlan** *vlan-id*]

**no mac-address-table static** *hw-addr* [**in-port** *in-port*] [**out-port-list** *out-port-list*] [**vlan** *vlan-id*]

Syntax Description	
<i>hw-addr</i>	MAC address to add to the address table.
<i>in-port</i>	Input port from which packets received with a destination address of <i>hw-addr</i> are forwarded to the list of ports in the <i>out-port-list</i> . The <i>in-port</i> must belong to the same VLAN as all the ports in the <i>out-port-list</i> .
<i>out-port-list</i>	List of ports to which packets received on ports in <i>in-port</i> are forwarded. All ports in the list must belong to the same VLAN.
<b>atm</b> <i>slot/port</i>	(Optional) Add static addresses to ATM module in slot 1 or 2. The port is always 0 for an ATM interface.
<b>vlan</b> <i>vlan-id</i>	<p>(Optional) The <i>interface</i> and <b>vlan</b> parameters together specify a destination to which packets destined for the specified MAC address are forwarded.</p> <p>The <b>vlan</b> keyword is optional if all the ports specified by <i>in-port</i> and <i>out-port-list</i> are static-access VLAN ports. The VLAN assigned to the ports is assumed. This keyword is required for multi-VLAN and trunk ports.</p> <p>Dynamic-access ports cannot be included in static addresses as either the source (inport) or destination (outport).</p> <p>The <b>vlan</b> keyword is required on trunk ports to specify to which VLAN the static address is assigned.</p> <p>The <i>vlan-id</i> is the ID of the VLAN to which static address entries are forwarded. Valid IDs are 1 to 1005; do not enter leading zeroes.</p>

Command Modes	Global configuration
---------------	----------------------

Command History	Release	Modification
	11.2(8)SA	This command was first introduced.
	11.2(8)SA3	The <b>vlan</b> keyword was added.
	11.2(8)SA5	The <b>atm</b> keyword was added.

**Usage Guidelines**

When a packet is received on the input port, it is forwarded to the VLAN of each port you specify for the *out-port-list*. Different input ports can have different output-port lists for each static address. Adding a static address already defined as one modifies the port map (*vlan* and *out-port-list*) for the input port specified.

If the variable *vlan-id* is omitted and the **no** form of the command is used, the MAC address is removed from all VLANs.

Traffic from a static address is only accepted from a port defined in the *in-port* variable.

Dynamic-access ports cannot be configured as the source or destination port in a static address entry.

**Examples**

The following example shows how to add a static address with port 1 as an input port and ports 2 and 8 of VLAN 4 as output ports:

```
Switch(config)# mac-address-table static c2f3.220a.12f4 fa0/1 fa0/2 fa0/8 vlan 4
```

You can verify the previous command by entering the **show mac-address-table** command in privileged EXEC mode.

**Related Commands**

Command	Description
<a href="#">clear mac-address-table</a>	Deletes entries from the MAC address table.
<a href="#">mac-address-table aging-time</a>	Sets the length of time that a dynamic entry remains in the MAC address table after the entry is used or updated.
<a href="#">mac-address-table dynamic</a>	Adds dynamic addresses to the MAC address table.
<a href="#">mac-address-table secure</a>	Adds secure addresses to the MAC address table.
<a href="#">show mac-address-table</a>	Displays the MAC address table.

# management

Use the **management** interface configuration command to shutdown the current management VLAN interface and enable the new management VLAN interface. The management VLAN is the VLAN used for managing a cluster of switches. To use this VLAN for switch management, apply this VLAN to a switched virtual interface or the management interface. The default management VLAN is VLAN 1, however it can be changed to a new management interface on a different VLAN with valid IDs from 1 to 1001.

This command also copies the current management VLAN IP information to the new management VLAN interface if no new IP address or network mask is provided. It also copies the cluster standby group configuration to the new management VLAN.

## management

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Defaults</b>	No default is defined.
-----------------	------------------------

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(5)XP	This command was first introduced.

<b>Usage Guidelines</b>	No <b>default management</b> or <b>no management</b> command exists to return the management VLAN to its default state.
	The management command is not written to the configuration file, and it is not displayed in the output of the <b>show running-config</b> command.

Before entering the **management** command, make sure the following conditions exist:

- You must be able to move your network management station to a switch port assigned to the same VLAN as the new management VLAN. (Depending on your network topology, you might not need to move your network management station: for example, you have ISL routing configured on a router between two VLANs.)
- Connectivity through the network must exist from the network management station to all switches involved in the management VLAN change.
- The switch must already have a port assigned to the same VLAN as the management VLAN.

Use the management command to change the management VLAN on a single switch. Use the global configuration command **cluster management-vlan n** on the command switch to change the management VLAN on the entire cluster.

## Examples

The following example shows how to shut down the current management VLAN interface and start VLAN 2 as the management VLAN:

```
Switch# configure terminal
Switch(config)# interface vlan 2
Switch(config-subif)# ip address 172.20.128.176 255.255.255.0
Switch(config-subif)# management
Switch(config-subif)# exit
Switch(config)#
```

The following example shows how to copy the IP address and network mask from the current management VLAN to VLAN 2 and make VLAN 2 the management VLAN:

```
Switch# configure terminal
Switch(config)# interface vlan 2
Switch(config-subif)# management
Switch(config-subif)# exit
Switch(config)#
```

You can verify the previous command by entering the **show interface vlan *number*** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>cluster management-vlan</b>	Changes the management VLAN for the entire cluster.
<b>interface vlan</b>	Configures an interface type, creates a switch virtual interface to be used as the management VLAN interface, and enters interface configuration mode
<b>show interface</b> <i>vlan number</i>	Displays the administrative and operational status of a switching (nonrouting) port.

## mvr

Use the **mvr** global configuration command without keywords to enable the multicast VLAN registration (MVR) feature on the switch. Use the **no** form of this command to disable MVR and its options.

Use the command with keywords to set the maximum time to wait for a query reply before removing a port from group membership and to specify the MVR multicast VLAN. Use the **no** form of the commands to return the switch to the default settings.

**mvr** [**querytime** *value*] [**vlan** *vlan-id*]

**no mvr** [**querytime** *value*] [**vlan** *vlan-id*]

### Syntax Description

<b>querytime</b> <i>value</i>	(Optional) Set the maximum time to wait for IGMP report memberships on a receiver port. This time only applies to receiver-port leave processing. When an IGMP query is sent from a receiver port, the switch waits for the default or configured MVR querytime for an IGMP group membership report before removing the port from multicast group membership.  The value is the response time in units of tenths of a second. The default is 0.5 second.  Use the no form of the command to return to the default setting.
<b>vlan</b> <i>vlan-id</i>	Specify the VLAN on which MVR multicast data is expected to be received. This is also the VLAN to which all the source ports belong.

### Defaults

MVR is disabled by default.

The maximum number of mvr entries is determined by the switch hardware.

By default, no IP multicast addresses are configured on the switch.

The default count is 1.

The default query response time is 0.5 second.

The default multicast VLAN is VLAN 1.

### Command Modes

Global configuration

### Command History

Release	Modification
12.0(5)XW	This command was first introduced.

### Usage Guidelines

The maximum number of mvr entries is determined by the switch hardware.

Use the **mvr group** command to statically set up all the IP multicast addresses that will take part in MVR. Any multicast data sent to a configured multicast address is sent to all the source ports on the switch and to all receiver ports that have registered to receive data on that IP multicast address.



**Note**

The **mvr group** command prevents adding IP multicast addresses that cause address aliasing. Each IP multicast address translates to a multicast 48-bit MAC address. If the IP address being configured translates (aliases) to the same 48-bit MAC address as a previously configured IP multicast address, the command fails.

The **mvr querytime** parameter applies only to receiver ports. You should configure the query time before enabling MVR and configuring the static multicast groups. You can change the query time after MVR is enabled, but you receive a warning message:

Warning: Changing MVR query response time while MVR is running.

The MVR multicast VLAN must be set before the multicast addresses are configured. If it is necessary to change the multicast VLAN, disable MVR, change the VLAN number, then reenables MVR. Previously configured groups will be restored.

**Examples**

The following example shows how to enable MVR:

```
Switch(config)# mvr
```

The following example shows how to disable MVR:

```
Switch(config)# no mvr
```

Use the privileged EXEC **show mvr** command to display the current setting for maximum multicast groups.

The following example shows how to configure 228.1.23.4 as an IP multicast address:

```
Switch(config)# mvr group 228.1.23.4
```

The following command fails because of address aliasing:

```
Switch(config)# mvr group 230.1.23.4
```

Cannot add this IP address - aliases with previously configured IP address 228.1.23.4.

The following example shows how to configure ten contiguous IP multicast groups with multicast addresses from 228.1.23.1 to 228.1.23.10:

```
Switch(config)# mvr group 228.1.23.1 10
```

The following example shows how to delete the previously configured ten IP multicast addresses:

```
Switch(config)# no mvr group 228.1.23.1 10
```

The following example shows how to delete all previously configured IP multicast addresses:

```
Switch(config)# no mvr group
```

Use the command **show mvr members** to display the IP multicast group addresses configured on the switch.

The following example shows how to set the maximum query response time as 1 second (10 tenths):

```
Switch(config)# mvr querytime 10
```

The following example shows how to return the maximum query response time to the default setting of 0.5 second:

```
Switch(config)# no mvr querytime
```

The following example shows how to set VLAN 2 as the multicast VLAN:

```
Switch(config)# mvr vlan 2
```

Use the **show mvr** command to display the current multicast VLAN setting.

Related Commands	Command	Description
	<b>mvr</b> (interface configuration mode)	Configures MVR source or receiver ports.
	<b>show mvr</b>	Displays MVR global parameters or port parameters.
	<b>show mvr members</b>	Displays all receiver ports that are members of an MVR multicast group.
	<b>show mvr interface</b>	Displays the configured MVR interfaces.

# mvr type

Use the **mvr type** interface configuration command to configure a port as a multicast VLAN registration (MVR) receiver or source port and to set the Immediate Leave feature, the port threshold, and to statically assign a receiver port to an IP multicast VLAN and an IP address.

Use the **no** form of the commands to return the port to the default settings.

```
mvr { type value | immediate | threshold value }
```

```
no mvr { type value | immediate | threshold value }
```

<b>Syntax Description</b>	<b>type</b> <i>value</i>	Configure the port as an MVR receiver port or a source port.  A source port can send and receive multicast data for the configured multicast groups. A receiver port can only receive multicast data.  The <b>no mvr type</b> command resets the port as neither a source or a receiver port.
	<b>immediate</b>	Enable the Immediate Leave feature of MVR on a port. Use the <b>no</b> form of this command to disable the feature.
	<b>threshold</b> <i>value</i>	Limit the number of multicast data packets received on a receiver port before it is administratively shut down. The threshold value is specified in packets per second.  Use the <b>no</b> form of the command to return the threshold to the default value, 20.

## Defaults

By default, a port is configured as neither receiver nor source.

By default, the Immediate Leave feature is disabled on all ports.

The default value of the threshold on all ports is 20.

By default, no receiver port is a member of any configured multicast group.

## Command Modes

Interface configuration

## Command History

Release	Modification
12.0(5)XW	This command was first introduced.

## Usage Guidelines

Configure a port as a source port if that port should be able to both send and receive multicast data bound for the configured multicast groups. Multicast data is received on all ports configured as source ports.

Configure a port as a receiver port if that port should only be able to receive multicast data and should not be able to send multicast data to the configured multicast groups. None of the receiver ports receives multicast data unless it sends an IGMP group join message for a multicast group.

**Note**

For the Catalyst 2900 XL and Catalyst 3500 XL switches, all receiver ports must belong to the same VLAN and must not be trunk ports.

A port that is not taking part in MVR should not be configured as an MVR receiver port or source port. This port is a normal switch port and is able to send and receive multicast data with normal switch behavior.

The Immediate Leave feature applies only to receiver ports. When the Immediate Leave feature is enabled, a receiver port leaves a multicast group more quickly. When the switch receives an IGMP leave message from a group on a receiver port, it sends out an IGMP query on that port and waits for IGMP group membership reports. If no reports are received in a configured time period, the receiver port is removed from multicast group membership. With Immediate Leave, an IGMP query is not sent from the receiver port on which the IGMP leave was received. As soon as the leave message is received, the receiver port is removed from multicast group membership, thus speeding up leave latency.

The Immediate Leave feature should only be enabled on receiver ports to which a single receiver device is connected.

The MVR threshold command is used to prevent multicast data from an unauthorized source from flooding the switch CPU. With the exception of IGMP leaves and joins, multicast data packets are not expected from a receiver port. Therefore, the threshold value should be set to a low value. Any multicast data within the threshold limits that is received on the receiver port is discarded.

You should configure the MVR threshold on a port before enabling MVR and configuring the static multicast groups. You can change the query time after MVR is enabled, but you receive a warning message:

Warning: Changing MVR threshold while MVR is running.

The **mvr group** and **mvr vlan** commands only apply to ports configured as receiver ports. If the specified port is not a receiver port, the commands report an error. All receiver ports must be on the same VLAN and cannot be trunk ports. A receiver configured as a static member of a multicast group remains a member until statically removed from membership.

MVR does not support IGMP dynamic joins. Therefore, you must configure static multicast addresses for receiver ports so that the multicast router can send data to the ports.

The receiver VLAN is the VLAN to which the first configured receiver port belongs. If the first receiver port is a dynamic port with an unassigned VLAN, it becomes an inactive receiver port and does not take part in MVR unless and until it is assigned to the receiver VLAN. The receiver VLAN is reset whenever there are no remaining receiver ports on the switch (active or inactive), which means that the receiver VLAN might change every time the first receiver port is configured.

## Examples

The following example shows how to configure port 0/1 as an MVR receiver port:

```
Switch(config)# interface FastEthernet 0/1
Switch(config-if)# mvr type receiver
```

The following example shows how to configure port 0/3 as an MVR source port:

```
Switch(config)# interface FastEthernet 0/3
Switch(config-if)# mvr type source
```

The following example shows how to remove port 0/1 from taking part in MVR:

```
Switch(config)# interface FastEthernet 0/1
Switch(config-if)# no mvr
```

The following example shows how to display configured receiver ports and source ports.

```
Switch# show mvr ports
MVR PORTS
Port: Fa0/1 Type: RECEIVER Status: ACTIVE
Port: Fa0/2 Type: RECEIVER Status: ACTIVE
Port: Fa0/3 Type: SOURCE Status: ACTIVE
```

The following example shows how to enable Immediate Leave on Fast Ethernet port 0/1:

```
Switch(config)# interface FastEthernet 0/1
Switch(config-if)# mvr immediate
```

The following example shows how to disable Immediate Leave on port 0/1:

```
Switch(config)# interface FastEthernet 0/1
Switch(config-if)# no mvr immediate
```

The following example shows how to set the threshold value for all ports to 100:

```
Switch(config)# mvr threshold 100
```

The following example shows how to set the threshold value for port 0/1 to 30:

```
Switch(config)# interface FastEthernet 0/1
Switch(config-if)# mvr threshold 30
```

To display the threshold value and whether or not Immediate Leave is enabled on an interface, use the command **show mvr** for the interface as in the example below.

```
Switch# show mvr interface fastethernet 0/1
Interface: Fa0/1
    Threshold: 20
    Immediate Leave: FALSE
    Multicast packets received: 13
```

Use the privileged EXEC command **show mvr members** to display the multicast group address, the VLAN, and the receiver port.

## Related Commands

Command	Description
<b>mvr</b> (global configuration mode)	Enables multicast VLAN registration on the switch.
<b>show mvr</b>	Displays MVR global parameters or port parameters.
<b>show mvr members</b>	Displays all receiver ports that are members of an MVR multicast group.
<b>show mvr interface</b>	Displays the configured MVR ports.

# ntp access-group

Use the **ntp access-group** global configuration command to control access to the system Network Time Protocol (NTP) services. Use the **no** form of the command to remove access control to the system NTP services.

**ntp access-group** { **query-only** | **serve-only** | **serve** | **peer** } *access-list-number*

**no ntp access-group** { **query-only** | **serve** | **peer** }

## Syntax Description

<b>query-only</b>	Enable only NTP control queries. See RFC 1305 (NTP version 3).
<b>serve-only</b>	Enable only time requests.
<b>serve</b>	Enable time requests and NTP control queries, but does not enable the system to synchronize to the remote system.
<b>peer</b>	Enable time requests and NTP control queries; enable the system to synchronize to the remote system.
<i>access-list-number</i>	Number (1 to 99) of a standard IP access list

## Defaults

NTP is disabled.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

The access group options are scanned in the following order from least restrictive to most restrictive:

1. peer
2. serve
3. serve-only
4. query-only

Access is granted for the first match that is found. If no access groups are specified, all access is granted to all sources. If any access groups are specified, only the specified access is granted. This facility provides minimal security for the time services of the system. If tighter security is desired, use the NTP authentication facility.

### Examples

The following example shows how to configure the system to be synchronized by a peer from access list 99.

However, the system restricts access to allow only time requests from access list 42:

```
Switch(config)# ntp access-group peer 99  
Switch(config)# ntp access-group serve-only 42
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

### Related Commands

Command	Description
<b>access-list</b>	Differentiates one packet from another so that different treatment can be applied.
<b>show running-config</b>	Displays the running configuration on the switch.

# ntp authenticate

Use the **ntp authenticate** global configuration command to enable Network Time Protocol (NTP) authentication. Use the **no** form of this command to disable the feature.

**ntp authenticate**

**no ntp authenticate**

**Syntax Description** This command has no keywords or arguments.

**Defaults** NTP authentication is disabled.

**Command Modes** Global configuration

Command History	Release	Modification
	11.2(8)SA6	This command was first introduced.

**Usage Guidelines** Use this command if you want authentication. If this command is specified, the system will not synchronize to a system unless it carries one of the authentication keys specified in the **ntp trusted-key** command.

**Examples** The following example shows how to enable NTP authentication:

```
Switch(config)# ntp authenticate
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

Related Commands	Command	Description
	<a href="#">ntp authentication-key</a>	Defines an authentication key for NTP.
	<a href="#">ntp trusted-key</a>	Authenticates the identity of a system to which NTP will synchronize.
	<a href="#">show running-config</a>	Displays the running configuration on the switch.



# ntp authentication-key

Use the **ntp authentication-key** global configuration command to define an authentication key for Network Time Protocol (NTP). Use the **no** form of this command to remove the authentication key for NTP.

**ntp authentication-key** *number* **md5** *value*

**no ntp authentication-key** *number*

## Syntax Description

<i>number</i>	Key number (1 to 4294967295).
<b>md5</b>	Use MD5 authentication.
<i>value</i>	Key value (an arbitrary string of up to eight characters, with the exception of control or escape characters).

## Defaults

No authentication key is defined.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

Use this command to define authentication keys for use with other NTP commands for greater security.

## Examples

The following example shows how to set authentication key 10 to *aNiceKey*:

```
Switch(config)# ntp authentication-key 10 md5 aNiceKey
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.



### Note

When this command is written to nonvolatile RAM (NVRAM), the key is encrypted so that it is not displayed when the configuration is viewed.

Related Commands	Command	Description
	<a href="#">ntp authenticate</a>	Enables NTP authentication.
	<a href="#">ntp peer</a>	Configures the switch system clock to synchronize a peer or to be synchronized by a peer.
	<a href="#">ntp server</a>	Allows the switch system clock to be synchronized by a time server.
	<a href="#">ntp trusted-key</a>	Authenticates the identity of a system to which NTP will synchronize.
	<a href="#">show running-config</a>	Displays the running configuration on the switch.

# ntp broadcast client

Use the **ntp broadcast client** interface configuration command to allow the system to receive Network Time Protocol (NTP) broadcast packets on an interface. Use the **no** form of the command to disable this capability.

**ntp broadcast client**

**no ntp broadcast [client]**

## Syntax Description

This command has no arguments or keywords.

## Defaults

Broadcast client mode is disabled.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

Use this command to allow the system to listen to broadcast packets on an interface-by-interface basis. You must configure this command on the management VLAN interface. By default, the management VLAN is VLAN 1, but you can configure a different VLAN as the management VLAN.

## Examples

The following example shows how to synchronize the router to NTP packets that are broadcast on interface VLAN1:

```
Switch(config-if)# interface vlan1  
Switch(config-if)# ntp broadcast client
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>ntp broadcastdelay</b>	Sets the estimated round-trip delay between the IOS software and an NTP broadcast server.
<b>show running-config</b>	Displays the running configuration on the switch.

# ntp broadcastdelay

Use the **ntp broadcastdelay** global configuration command to set the estimated round-trip delay between the IOS software and a Network Time Protocol (NTP) broadcast server. Use the **no** form of this command to revert to the default value.

**ntp broadcastdelay** *microseconds*

**no ntp broadcastdelay**

<b>Syntax Description</b>	<i>microseconds</i>	Estimated round-trip time (in microseconds) for NTP broadcasts. The range is from 1 to 999999.
---------------------------	---------------------	--

<b>Defaults</b>	The default is 3000 microseconds.
-----------------	-----------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

<b>Usage Guidelines</b>	Use this command when the switch is configured as a broadcast client and the round-trip delay on the network is other than 3000 microseconds.
-------------------------	---

<b>Examples</b>	The following example shows how to configure the estimated round-trip delay between the switch and the broadcast client to 5000 microseconds:
-----------------	---

```
Switch(config)# ntp broadcastdelay 5000
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">ntp broadcast client</a>	Allows the system to receive NTP broadcast packets on an interface.
	<b>show running-config</b>	Displays the running configuration on the switch.

# ntp broadcast destination

Use the **ntp broadcast destination** interface configuration command to configure a Network Time Protocol (NTP) server or peer to restrict the broadcast of NTP frames to the IP address of a designated client or a peer. Use the **no** form of the command to return the setting to its default.

**ntp broadcast destination** *IP-address*

**no ntp broadcast destination**

## Syntax Description

<i>IP-address</i>	IP address or host name of a designated client or a peer.
-------------------	---

## Defaults

No IP address or host name is assigned.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

You must configure this command on the management VLAN interface. By default, the management VLAN is VLAN 1, but you can configure a different VLAN as the management VLAN.

## Related Commands

Command	Description
<a href="#">ntp broadcast client</a>	Allows the system to receive NTP broadcast packets on an interface.
<a href="#">ntp broadcastdelay</a>	Sets the estimated round-trip delay between the IOS software and an NTP broadcast server.

# ntp broadcast key

Use the **ntp broadcast key** interface configuration command to configure a Network Time Protocol (NTP) server or peer to broadcast NTP frames with the authentication key embedded into the NTP packet. Use the **no** form of the command to return the setting to its default.

**ntp broadcast key** *number*

**no ntp broadcast key**

## Syntax Description

<i>number</i>	The NTP authentication key that is embedded in the NTP packet. The range is from 0 to 4294967295.
---------------	--

## Defaults

No NTP broadcast key is defined.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

You must configure this command on the management VLAN interface. By default, the management VLAN is VLAN 1, but you can configure a different VLAN as the management VLAN.

## Related Commands

Command	Description
<a href="#">ntp broadcast client</a>	Allows the system to receive NTP broadcast packets on an interface.
<a href="#">ntp broadcastdelay</a>	Sets the estimated round-trip delay between the IOS software and an NTP broadcast server.

# ntp broadcast version

Use the **ntp broadcast** interface configuration command to specify that a specific interface should send Network Time Protocol (NTP) broadcast packets. Use the **no** form of the command to disable this capability.

**ntp broadcast version** *number*

**no ntp broadcast**

## Syntax Description

<i>number</i>	Number from 1 to 3.
---------------	---------------------

## Defaults

Version 3 is the default.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

If you are using version 2 and the NTP synchronization does not occur, use NTP version 2.

You must configure this command on the management VLAN interface. By default, the management VLAN is VLAN 1, but you can configure a different VLAN as the management VLAN.

## Examples

The following example shows how to configure interface VLAN 1 to send NTP version 2 packets:

```
Switch(config-if)# interface vlan1  
Switch(config-if)# ntp broadcast version 2
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">ntp broadcast client</a>	Allows the system to receive NTP broadcast packets on an interface.
<a href="#">ntp broadcastdelay</a>	Sets the estimated round-trip delay between the IOS software and an NTP broadcast server.
<a href="#">show running-config</a>	Displays the running configuration on the switch.

## ntp clock-period

Do not enter this command; it is documented for informational purposes only. The system automatically generates this command as the Network Time Protocol (NTP) determines the clock error and compensates.

As the NTP compensates for the error in the system clock, it keeps track of the correction factor for this error. The system automatically saves this value into the system configuration using the **ntp clock-period** global configuration command. The system uses the **no** form of this command to revert to the default.

**ntp clock-period** *value*

**no ntp clock-period**

<b>Syntax Description</b>	<i>value</i>	Amount to add to the system clock for each clock hardware tick (in units of 2 to 32 seconds).				
<b>Command Modes</b>	Global configuration					
<b>Command History</b>	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.2(8)SA6</td><td>This command was first introduced.</td></tr></table>	Release	Modification	11.2(8)SA6	This command was first introduced.	
Release	Modification					
11.2(8)SA6	This command was first introduced.					
<b>Usage Guidelines</b>	If a <b>write memory</b> command is entered to save the configuration to nonvolatile RAM (NVRAM), this command is automatically added to the configuration. We recommend that you perform this task after NTP has been running for a week or so; NTP synchronizes more quickly if the system is restarted.					



# ntp disable

Use the **ntp disable** interface configuration command to prevent an interface from receiving Network Time Protocol (NTP) packets. To enable receipt of NTP packets on an interface, use the **no** form of the command.

**ntp disable**

**no ntp disable**

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Interface configuration

Command History	Release	Modification
	11.2(8)SA6	This command was first introduced.

**Usage Guidelines** You must configure this command on the management VLAN interface. By default, the management VLAN is VLAN 1, but you can configure a different VLAN as the management VLAN.

The preferred command to disable NTP is **no ntp**.

**Examples** The following example shows how to prevent interface VLAN 1 from receiving NTP packets:

```
Switch(config-if)# interface vlan1  
Switch(config-if)# ntp disable
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

Related Commands	Command	Description
	<b>show running-config</b>	Displays the running configuration on the switch.

# ntp max-associations

Use the **ntp max-associations** global configuration command to set the maximum number of Network Time Protocol (NTP) associations that are allowed on a server. Use the **no** form of this command to disable this feature.

**ntp max-associations** [*number*]

**no ntp max-associations**

## Syntax Description

*number* (Optional) Specify the number of NTP associations. The range is from 0 to 4294967295.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

This command provides a simple method to control the number of peers that can use the switch to synchronize to it through NTP.

After you enable a switch as an NTP server, use this command to set the maximum number of associations that are allowed on a server.

## Examples

The following example shows how to set the maximum number of NTP associations to 44:

```
Switch(config)# ntp max-associations 44
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>show running-config</b>	Displays the running configuration on the switch.

# ntp peer

Use the **ntp peer** global configuration command to configure the switch system clock to synchronize a peer or to be synchronized by a peer. Use the **no** form of the command to disable this capability.

**ntp peer** *ip-address* [**version** *number*] [**key** *keyid*] [**source** *interface*] [**prefer**]

**no ntp peer** *ip-address*

<b>Syntax Description</b>	<i>ip-address</i>	IP address of the peer providing, or being provided, the clock synchronization.
	<b>version</b> <i>number</i>	(Optional) Define the Network Time Protocol (NTP) version number as version 1, 2, or 3.
	<b>key</b> <i>keyid</i>	(Optional) Define the authentication key, which is used when sending packets to this peer. The range is from 0 to 4294967295.
	<b>source</b> <i>interface</i>	(Optional) Authentication key to use when sending packets to this peer. Also includes the name of the interface from which to pick the IP source address.
	<b>prefer</b>	(Optional) Make this peer the preferred peer that provides synchronization.

**Defaults**

No IP address is defined.

NTP version 3 is the default.

No NTP authentication key is defined.

No source interface is defined.

**Command Modes**

Global configuration

**Command History**

Release	Modification
11.2(8)SA6	This command was first introduced.

**Usage Guidelines**

Using the **prefer** keyword will reduce switching between peers.

If you are using the default NTP version of 3 and NTP synchronization does not occur, try using NTP version 2. Many NTP servers on the Internet run version 2.

### Examples

The following example shows how to configure the router to allow its system clock to be synchronized with the clock of the peer (or vice versa) at IP address 131.108.22.33 using NTP version 2. The source IP address will be the address of Ethernet 0.

```
Switch(config)# ntp peer 131.108.22.33 version 2 source Ethernet 0
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

### Related Commands

Command	Description
<a href="#">ntp authentication-key</a>	Defines an authentication key for NTP.
<a href="#">ntp server</a>	Allows the switch system clock to be synchronized by a time server.
<a href="#">ntp source</a>	Uses a particular source address in NTP packets.
<a href="#">show running-config</a>	Displays the running configuration on the switch.

# ntp server

Use the **ntp server** global configuration command to allow the switch system clock to be synchronized by a time server. Use the **no** form of the command to disable this capability.

**ntp server** *ip-address* [**version** *number*] [**key** *keyid*] [**source** *interface*] [**prefer**]

**no ntp server** *ip-address*

## Syntax Description

<i>ip-address</i>	IP address of the time server providing the clock synchronization.
<b>version</b> <i>number</i>	(Optional) Define the Network Time Protocol (NTP) version number (1 to 3).
<b>key</b> <i>keyid</i>	(Optional) Define the authentication key. Authentication key to use when sending packets to this peer. The range is from 0 to 4294967295.
<b>source</b> <i>interface</i>	(Optional) Identify the interface from which to pick the IP source address.
<b>prefer</b>	(Optional) Make this server the preferred server that provides synchronization.

## Defaults

No IP address is defined.

NTP version 3 is the default.

No NTP authentication key is defined.

No source interface is defined.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

Use this command if you want to allow this machine to synchronize with the specified server. The server will not synchronize to this machine.

Using the **prefer** keyword will reduce switching between servers.

If you are using the default NTP version of 3 and NTP synchronization does not occur, try using NTP version 2. Many NTP servers on the Internet run version 2.

---

**Examples**

The following example shows how to configure the router to allow its system clock to be synchronized with the clock of the peer at IP address 128.108.22.44 using NTP version 2:

```
Switch(config)# ntp server 128.108.22.44 version 2
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<a href="#">ntp authentication-key</a>	Defines an authentication key for NTP.
<a href="#">ntp server</a>	Allows the switch system clock to be synchronized by a time server.
<a href="#">ntp source</a>	Uses a particular source address in NTP packets.
<a href="#">show running-config</a>	Displays the running configuration on the switch.

# ntp source

Use the **ntp source** global configuration command to use a particular source address in Network Time Protocol (NTP) packets. Use the **no** form of this command to remove the specified source address.

**ntp source** *interface*

**no ntp source**

## Syntax Description

<i>interface</i>	Any valid system interface name.
------------------	----------------------------------

## Defaults

No source address is defined.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

Use this command when you want to use a particular source IP address for all NTP packets. The address is taken from the specified interface. This command is useful if the address on an interface cannot be used as the destination for reply packets. If the **source** keyword is present on an **ntp server** or **ntp peer** command, that value overrides the global value.

## Examples

The following example shows how to configure the router to use the IP address of VLAN1 as the source address of all outgoing NTP packets:

```
Switch(config)# ntp source vlan1
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">ntp peer</a>	Configures the switch system clock to synchronize a peer or to be synchronized by a peer.
<a href="#">ntp server</a>	Allows the switch system clock to be synchronized by a time server.
<a href="#">show running-config</a>	Displays the running configuration on the switch.

# ntp trusted-key

Use the **ntp trusted-key** global configuration command if you want to authenticate the identity of a system to which the Network Time Protocol (NTP) will synchronize. Use the **no** form of this command to disable authentication of the identity of the system.

**ntp trusted-key** *key-number*

**no ntp trusted-key** *key-number*

<b>Syntax Description</b>	<i>key-number</i>	Authentication key to be used for time authentication. The range is from 1 to 4294967295.
---------------------------	-------------------	---

<b>Defaults</b>	No key number is defined.
-----------------	---------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

<b>Usage Guidelines</b>	If authentication is enabled, use this command to define one or more key numbers that a peer NTP system must provide in its NTP packets in order for this system to synchronize to it. The key numbers must correspond to the keys defined with the <b>ntp authentication-key</b> command. This provides protection against accidentally synchronizing the system to a system that is not allowed because the other system must know the correct authentication key.
-------------------------	--

<b>Examples</b>	The following example shows how to configure the system to synchronize only to systems providing authentication key 42 in its NTP packets:
-----------------	--

```
Switch(config)# ntp authenticate
Switch(config)# ntp authentication-key 42 md5 aNiceKey
Switch(config)# ntp trusted-key 42
```

You can verify the previous commands by entering the **show running-config** command in privileged EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">ntp authenticate</a>	Enables NTP authentication.
	<a href="#">ntp authentication-key</a>	Defines an authentication key for NTP.
	<a href="#">show running-config</a>	Displays the running configuration on the switch.



# port block

Use the **port block** interface configuration command to block the flooding of unknown unicast or multicast packets to a port. Use the **no** form of this command to resume normal forwarding.

**port block {unicast | multicast}**

**no port block {unicast | multicast}**

## Syntax Description

<b>unicast</b>	Packets with unknown unicast addresses are not forwarded to this port
<b>multicast</b>	Packets with unknown multicast addresses are not forwarded to this port.

## Defaults

Flood unknown unicast and multicast packets to all ports.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.

## Usage Guidelines

The **port block** command cannot be entered for a network port.

If a trunk port is not a network port, the **unicast** keyword applies. The **multicast** keyword is supported on trunk ports. Both port block features affect all the VLANs associated with the trunk port.

## Examples

The following example shows how to block the forwarding of multicast and unicast packets to a port:

```
Switch(config-if)# port block unicast  
Switch(config-if)# port block multicast
```

You can verify the previous commands by entering the **show port block** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">show port block</a>	Displays the blocking of unicast or multicast flooding to a port.

# port group

Use the **port group** interface configuration command to assign a port to a Fast EtherChannel or Gigabit EtherChannel port group. Up to 12 port groups can be created on a switch. Any number of ports can belong to a destination-based port group. Up to eight ports can belong to a source-based port group. Use the **no** form of this command to remove a port from a port group.

**port group** *group-number* [**distribution** {**source** | **destination**}]

**no port group**

## Syntax Description

<i>group-number</i>	Port group number to which the port belongs. The range is from 1 to 12.
<b>distribution</b> { <b>source</b>   <b>destination</b> }	(Optional) Forwarding method for the port group. <ul style="list-style-type: none"> <li>• <b>source</b>—Set the port to forward traffic to a port group based on the packet source address. This is the default forwarding method</li> <li>• <b>destination</b>—Set the port to forward traffic to a port group based on the packet destination address.</li> </ul>

## Defaults

Port does not belong to a port group.  
The default forwarding method is source.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA3	This command was first introduced.

## Usage Guidelines

An ATM port is the only port that *cannot* belong to a port group. For all other ports, the following restrictions apply:

- Do not group Fast Ethernet and gigabit ports together.
- No port group member can be configured for Switched Port Analyzer (SPAN) port monitoring.
- No port group member can be enabled for port security.
- You can create up to 12 port groups. You can have source-based port groups and destination-based source groups. A source-based port group can have up to eight ports in its group. A destination-based port group can contain an unlimited number of ports in its group. You cannot mix source-based and destination-based ports in the same group. You can independently configure port groups that link switches, but you must consistently configure both ends of a port group.

- Port group members must belong to the same set of VLANs and must be all static-access, all multi-VLAN, or all trunk ports.
- Dynamic-access ports cannot be grouped with any other port, not even with other dynamic-access ports.

When a group is first formed, the switch automatically sets the following parameters to be the same on all ports:

- VLAN membership of ports in the group
- VLAN mode (static, multi, trunk) of ports in the group
- Encapsulation method of the trunk
- Native VLAN configuration if the trunk uses IEEE 802.1Q
- Allowed VLAN list configuration of the trunk port
- Spanning Tree Protocol (STP) Port Fast option
- STP port priority
- STP path cost
- Network port configuration for source-based port group
- Protected port

Configuration of the first port added to the group is used when setting the above parameters for other ports in the group. After a group is formed, changing any parameter in the above list changes the parameter on all other ports.

Use the **distribution** keyword to customize the port group to your particular environment. The forwarding method you choose depends on how your network is configured. However, source-based forwarding works best for most network configurations.

This command is not supported on the ATM modules.

### Examples

The following example shows how to add a port to a port group using the default source-based forwarding:

```
Switch(config-if)# port group 1
```

The following example shows how to add a port to a group using destination-based forwarding:

```
Switch(config-if)# port group 2 distribution destination
```

You can verify the previous commands by entering the **show port group** command in privileged EXEC mode.

### Related Commands

Command	Description
<b>show port group</b>	Displays the ports that belong to a port group.

# port monitor

Use the **port monitor** interface configuration command to enable Switch Port Analyzer (SPAN) port monitoring on a port. Use the **no** form of this command to return the port to its default value.

**port monitor** [*interface* | **vlan** *vlan-id*]

**no port monitor** [*interface* | **vlan** *vlan-id*]

## Syntax Description

<i>interface</i>	(Optional) Module type, slot, and port number for the SPAN to be enabled. The interface specified is the port to be monitored.
<b>vlan</b> <i>vlan-id</i>	(Optional) ID of the VLAN to be monitored.
<b>Note</b> VLAN 1 is the only valid option.	

## Defaults

Port does not monitor any other ports.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.
11.2(8)SA3	The <b>vlan</b> keyword was added.

## Usage Guidelines

Enabling port monitoring without specifying a port causes all other ports in the same VLAN to be monitored.

Entering the **port monitor vlan 1** command causes monitoring of all traffic to and from the IP address configured on VLAN 1.

ATM ports are the only ports that *cannot* be monitor ports. However, you can monitor ATM ports. The following restrictions apply for ports that have port-monitoring capability:

- A monitor port cannot be in a Fast EtherChannel or Gigabit EtherChannel port group.
- A monitor port cannot be enabled for port security.
- A monitor port cannot be a multi-VLAN port.
- A monitor port must be a member of the same VLAN as the port monitored. VLAN membership changes are disallowed on monitor ports and ports being monitored.
- A monitor port cannot be a dynamic-access port or a trunk port. However, a static-access port can monitor a VLAN on a trunk, a multi-VLAN, or a dynamic-access port. The VLAN monitored is the one associated with the static-access port.
- Port monitoring does not work if both the monitor and monitored ports are protected ports.

---

**Examples**

The following example shows how to enable port monitoring on port fa0/2:

```
Switch(config-if)# port monitor fa0/2
```

You can verify the previous command by entering the **show port monitor** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<a href="#">show port monitor</a>	Displays the ports for which SPAN port monitoring is enabled.

# port network

Use the **port network** interface configuration command to define a port as the switch network port. All traffic with unknown unicast addresses is forwarded to the network port on the same VLAN. Use the **no** form of this command to return the port to the default value.

**port network**

**no port network**

## Syntax Description

This command has no arguments or keywords.

## Defaults

No network port is defined.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Usage Guidelines

The following restrictions apply to network ports:

- A network port can be a static-access port, a multi-VLAN port, a port group, or a trunk port. Both the multi-VLAN port and the trunk port become the network port for all the VLANs associated with that port.
- A network port cannot be an ATM, a secure, a monitor, a protected, or a dynamic-access port. You can assign a dynamic-access port to a VLAN in which another port is the network port.
- Each VLAN can have one network port.
- A network port cannot be in a destination-based port group.
- A network port cannot be on an ATM module.
- A network port cannot be a protected port.

## Examples

The following example shows how to set a port as a network port:

```
Switch(config-if)# port network
```

You can verify the previous command by entering the **show port network** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">show port network</a>	Displays the network port defined for the switch or VLAN.

# port protected

Use the **port protected** interface configuration command to isolate unicast, multicast, and broadcast traffic at Layer 2 from other protected ports on the same switch. Use the **no** form of the command to disable the protected port.

**port protected**

**no port protected**

## Syntax Description

This command has no keywords or arguments.

## Defaults

No protected port is defined.

A protected port does not forward any unicast, multicast, or broadcast traffic to any other protected port.

A protected port continues to forward unicast, multicast, and broadcast traffic to unprotected ports and vice versa.

## Command Modes

Interface configuration

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Usage Guidelines

The port protection feature is local to the switch; communication between protected ports on the same switch is possible only through a Layer 3 device. To prevent communication between protected ports on different switches, you must configure the protected ports for unique VLANs on each switch and configure a trunk link between the switches.

A protected port cannot be a network port.

Port monitoring does not work if both the monitor and monitored ports are protected ports.

A protected port is different from a secure port.

---

**Examples**

The following example shows how to enable a protected port on interface fa0/3:

```
Switch(config)# interface fa0/3  
Switch(config-if)# port protected
```

You can verify the previous command by entering the **show port protected** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<a href="#">show port protected</a>	Displays the ports that are in port-protected mode.



# port security

Use the **port security** interface configuration command to enable port security on a port and restrict the use of the port to a user-defined group of stations. Use the **no** form of this command to return the port to its default value.

**port security** [**action** {**shutdown** | **trap**} | **max-mac-count** *addresses*]

**no port security**

## Syntax Description

<b>action</b> { <b>shutdown</b>   <b>trap</b> }	(Optional) Action to take when an address violation occurs on this port. <ul style="list-style-type: none"> <li>• <b>shutdown</b>—Disable the port when a security violation occurs.</li> <li>• <b>trap</b>—Generate an SNMP trap when a security violation occurs</li> </ul>
<b>max-mac-count</b> <i>addresses</i>	(Optional) The maximum number of secure addresses that this port can support. The range is from 1 to 132.

## Defaults

Port security is disabled.  
When enabled, the default action is to generate an SNMP trap.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.

## Usage Guidelines

If you specify **trap**, use the **snmp-server host** command to configure the SNMP trap host to receive traps.

The following restrictions apply to secure ports:

- A secure port cannot belong to a Fast EtherChannel or Gigabit EtherChannel port group.
- A secure port cannot have Switched Port Analyzer (SPAN) port monitoring enabled on it.
- A secure port cannot be a multi-VLAN port.
- A secure port cannot be a network port.
- A secure port cannot be an ATM port.
- A secure port cannot be a dynamic-access port or a trunk port.

---

**Examples**

The following example shows how to enable port security and what action the port takes in case of an address violation (shutdown).

```
Switch(config-if)# port security action shutdown
```

The following example shows how to set the maximum number of addresses that the port can learn to 8.

```
Switch(config-if)# port security max-mac-count 8
```

You can verify the previous commands by entering the **show port security** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<a href="#">show port security</a>	Displays the port security settings defined for the port.

# port storm-control

Use the **port storm-control** interface configuration command to enable broadcast, multicast, or unicast storm control on a port. Use the **no** form of this command to disable storm control or one of the storm-control parameters on the port.

```
port storm-control {broadcast | multicast | unicast} [{action {filter | shutdown} | threshold
{rising rising-number falling falling-number} | trap}]
```

```
no port storm-control {broadcast | multicast | unicast}
```

## Syntax Description

<b>{broadcast   multicast   unicast}</b>	Determine the type of packet-storm suppression. <ul style="list-style-type: none"> <li>• <b>broadcast</b>—Enable broadcast storm control on the port.</li> <li>• <b>multicast</b>—Enable multicast storm control on the port.</li> <li>• <b>unicast</b>—Enable unicast storm control on the port.</li> </ul>
<b>{action {filter   shutdown}}</b>	(Optional) Determines the type of action to perform. <ul style="list-style-type: none"> <li>• <b>filter</b>—Filter traffic during a storm.</li> <li>• <b>shutdown</b>—Disable the port during a storm.</li> </ul>
<b>threshold {rising rising-number falling falling-number}</b>	Defines the rising and falling thresholds <ul style="list-style-type: none"> <li>• <b>rising rising-number</b>—Block the flooding of storm packets when the value specified for <i>rising-number</i> is reached. The <i>rising-number</i> is 0 to 4294967295 packets per second.</li> <li>• <b>falling falling-number</b>—Restart the normal transmission of broadcast packets when the value specified for <i>falling-number</i> is reached. The <i>falling-number</i> is 0 to 4294967295 packets per second.</li> </ul>
<b>trap</b>	(Optional) Generate an SNMP trap when the traffic on the port crosses the rising or falling threshold. Traps are generated only for broadcast traffic and not for unicast or multicast traffic.

## Defaults

Broadcast, multicast, and unicast storm control are disabled.

The rising thresholds are 500 broadcast packets per second, 2500 multicast packets per second, and 5000 unicast packets per second.

The falling thresholds are 250 broadcast packets per second, 1200 multicast packets per second, and 2500 unicast packets per second.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.
12.0(5)XU	The <b>multicast</b> , <b>unicast</b> , <b>action</b> , and <b>shutdown</b> keywords were added.

---

**Usage Guidelines**

Do not set the rising and falling thresholds to the same value.

---

**Examples**

The following example shows how to enable broadcast storm control on a port. In this example, transmission is inhibited when the number of broadcast packets arriving on the port reaches 1000 and is restarted when the number drops to 200.

```
Switch(config-if)# port storm-control broadcast threshold rising 1000 falling 200
```

You can verify the previous command by entering the **show port storm-control** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<a href="#">show port storm-control</a>	Displays the packet-storm control information.

# power inline

Use the **power inline** interface configuration command to determine how inline power is applied to the device on the specified Fast Ethernet port of the 3524-PWR-XL switch. Use the **no** form of this command to return the setting to its default.

**power inline {auto | never}**

**no power inline**

## Syntax Description

<b>auto</b>	Automatically detect and power inline devices.
<b>never</b>	Never apply inline power.

## Defaults

Power is applied when a telephone is detected on the port (auto).

## Command Modes

Interface configuration

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Examples

The following example shows how to always apply power to the port:

```
Switch(config-if)# power inline auto
```

You can verify the previous command by entering the **show power inline** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">show power inline</a>	Displays the power status for the specified port or for all ports.
<a href="#">switchport priority extend</a>	Determines how the telephone connected to the specified port handles priority traffic received on its incoming port.
<a href="#">switchport voice vlan</a>	Configures the voice VLAN on the port.

# rcommand

Use the **rcommand** user EXEC command to start a Telnet session and to execute commands on a member switch from the command switch. To end the session, enter the **exit** command.

**rcommand** {*n* | **commander** | **mac-address** *hw-addr*}

<b>Syntax Description</b>	<i>n</i>	Provide the number that identifies a cluster member. The range is from 0 to 15.
	<b>commander</b>	Provide access to the command switch from a member switch.
	<b>mac-address</b> <i>hw-addr</i>	MAC address of the member switch.

<b>Command Modes</b>	User EXEC
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

**Usage Guidelines**

If the switch is the command switch but the member switch *n* does not exist, an error message appears. To obtain the switch number, enter the EXEC mode **show cluster members** command on the command switch.

You can use this command to access a member switch from the command-switch prompt or to access a command switch from the member-switch prompt.

For Catalyst 2900 XL and Catalyst 3500 XL switches, the Telnet session accesses the member-switch command-line interface (CLI) at the same privilege level as on the command switch. For example, if you execute this command at user level on the cluster command switch, the member switch is accessed at user level. If you use this command on the command switch at privileged level, the command accesses the remote device at privileged level. If you use an intermediate enable-level lower than *privileged*, access to the member switch is at user level.

For Catalyst 1900 and Catalyst 2820 switches running standard edition software, the Telnet session accesses the menu console (the menu-driven interface) if the command switch is at privilege level 15. If the command switch is at privilege level 1, you are prompted for the password before being able to access the menu console. Command switch privilege levels map to the member switches running standard edition software as follows:

- If the command switch privilege level is from 1 to 14, the member switch is accessed at privilege level 1.
- If the command switch privilege level is 15, the member switch is accessed at privilege level 15.

The Catalyst 1900 and Catalyst 2820 CLI is available only on switches running Enterprise Edition Software.

This command will not work if the vty lines of the command switch have access-class configurations.

You are not prompted for a password because the member switches inherited the password of the command switch when they joined the cluster.

### Examples

The following example shows how to start a session with member 3. All subsequent commands are directed to member 3 until you enter the **exit** command or close the session.

```
Switch# rcommand 3
Switch-3# show version
Cisco Internet Operating System Software ...
...
Switch-3# exit
Switch#
```

### Related Commands

Command	Description
<a href="#">show cluster members</a>	Displays information about the cluster members.

# reset

Use the **reset** VLAN database command to abandon the proposed VLAN database and remain in VLAN database mode. This command resets the proposed database to the currently implemented VLAN database on the switch.

**reset**

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default is defined.

**Command Modes** VLAN database

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

**Examples** The following example shows how to abandon the proposed VLAN database and reset to the current VLAN database:

```
Switch(vlan) # reset
Switch(vlan) #
```

You can verify the previous command by entering the **show changes** and **show proposed** commands in VLAN database mode.

Related Commands	Command	Description
	<b>abort</b>	Abandons the proposed new VLAN database, exits VLAN database mode, and returns to privileged EXEC mode.
	<b>apply</b>	Implements the proposed new VLAN database, increments the database configuration revision number, propagates it throughout the administrative domain, and remains in VLAN database mode.
	<b>exit</b>	Implements the proposed new VLAN database, increments the database configuration number, propagates it throughout the administrative domain, and returns to privileged EXEC mode.
	<b>show changes</b>	Displays the differences between the VLAN database currently on the switch and the proposed VLAN database.
	<b>show proposed</b>	Displays the proposed VLAN database or a selected VLAN from it.
	<b>shutdown vlan</b>	Shuts down (suspends) local traffic on the specified VLAN.
	<b>vlan database</b>	Enters VLAN database mode from the command-line interface (CLI).



# rmon collection stats

Use the **rmon collection stats** interface configuration command to collect Ethernet group statistics. The Ethernet group statistics include utilization statistics about broadcast and multicast packets, and error statistics about Cyclic Redundancy Check (CRC) alignment errors and collisions. Use the **no** form of this command to return to the default setting.

**rmon collection stats** *index* [**owner name**]

**no rmon collection stats** *index* [**owner name**]

<b>Syntax Description</b>	<i>index</i>	Remote Network Monitoring (RMON) collection control index. The range is 1 to 65535.
	<i>owner name</i>	(Optional) Owner of the RMON collection.

**Defaults** The RMON statistics collection is disabled.

**Command Modes** Interface configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(5)WC1	This command was first introduced.

**Usage Guidelines** The RMON statistics collection command is based on hardware counters.

**Examples** The following example shows how to collect RMON statistics for the owner root on interface fa01:

```
Switch(config)# interface fa0/1
Switch(config-if)# rmon collection stats 2 owner root
```

You can verify this command by entering the **show rmon statistics** command in user EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show rmon statistics</b>	Displays RMON statistics.  Refer to the Cisco IOS Release 12.0 documentation on Cisco.com for information about this command.

# session

Use the **session** privileged EXEC command to log into the ATM module operating system and to start a command-line interface (CLI) session. Enter the **exit** command, or press **Ctrl-G** to return to the switch command-line interface.

**session** *number*

## Syntax Description

<i>number</i>	Slot number (1 or 2).
---------------	-----------------------

## Command Modes

Privileged EXEC

## Command History

Release	Modification
11.2(8)SA5	This command was first introduced.

## Examples

The following example shows how to log into the ATM module number 1:

```
Switch# session 1
```

## Related Commands

Command	Description
<a href="#">exit</a>	Exits the session with the ATM module and returns you to the CLI.

# show cgmp

Use the **show cgmp** privileged EXEC command to display the current state of the Cisco Group Management Protocol (CGMP)-learned multicast groups and routers.

```
show cgmp [state | holdtime | [vlan vlan-id] | [group address] | router address]]
```

<b>Syntax Description</b>	<b>state</b>	(Optional) Display whether CGMP is enabled or not, whether Fast Leave is enabled or not, and the router port timeout value.
	<b>holdtime</b>	(Optional) Display the router port timeout value in seconds.
	<b>vlan</b> <i>vlan-id</i>	(Optional) Limit the display to the specified VLAN. Valid IDs are from 1 to 1001; do not enter leading zeroes.
	<b>group</b> <i>address</i>	(Optional) Display all known multicast groups and the destination ports. Limited to given VLAN if <b>vlan</b> keyword is entered; limited to a specific group if the <i>address</i> variable is entered. The <i>address</i> is the MAC address of the group.
	<b>router</b> <i>address</i>	(Optional) Display all routers, their ports, and expiration times. Limited to given VLAN if the <b>vlan</b> keyword entered; limited to a specific router if the <i>address</i> variable is entered. The <i>address</i> is the MAC address of the router.

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA3	This command was first introduced.

<b>Usage Guidelines</b>	This command displays CGMP information about known routers and groups, as well as whether CGMP is enabled, whether Fast Leave is enabled, and the current value of the router timeout. If <b>show cgmp</b> is entered with no arguments, all information is displayed.
-------------------------	--

**Examples**

The following is sample output from the **show cgmp** command.

```
Switch# show cgmp
```

```
CGMP is running.
CGMP Fast Leave is not running.
CGMP Allow reserved address to join GDA.
Default router timeout is 300 sec.
```

vLAN	IGMP MAC Address	Interfaces
1	0100.5e01.0203	Fa0/8
1	0100.5e00.0128	Fa0/8

vLAN	IGMP Router	Expire	Interface
1	0060.5cf3.d1b3	197 sec	Fa0/8

**Related Commands**

Command	Description
<a href="#">cgmp</a>	Enables CGMP. Also enables and disables the Fast Leave parameter and sets the router port aging time.
<a href="#">clear cgmp</a>	Deletes information that was learned by the switch using CGMP.

# show changes

Use the **show changes** VLAN database command to display the differences between the VLAN database currently on the switch and the proposed VLAN database. You can also display the differences between the two for a selected VLAN.

**show changes** [*vlan-id*]

Syntax Description	<i>vlan-id</i> (Optional) ID of the VLAN in the current or proposed database. If this variable is omitted, all the differences between the two VLAN databases are displayed, including the pruning state and Version 2 mode. Valid IDs are from 1 to 1005; do not enter leading zeroes.
--------------------	---

Command Modes	VLAN database
---------------	---------------

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

**Examples** The following is sample output from the **show changes** command. It displays the differences between the current and proposed databases.

```
Switch(vlan) # show changes

DELETED:
  VLAN ISL Id: 4
    Name: VLAN0004
    Media Type: Ethernet
    VLAN 802.10 Id: 100004
    State: Operational
    MTU: 1500

DELETED:
  VLAN ISL Id: 6
    Name: VLAN0006
    Media Type: Ethernet
    VLAN 802.10 Id: 100006
    State: Operational
    MTU: 1500

MODIFIED:
  VLAN ISL Id: 7
    Current State: Operational
    Modified State: Suspended
```

The following is sample output from the **show changes 7** command. It displays the differences between VLAN 7 in the current database and the proposed database.

```
Switch(vlan)# show changes 7

MODIFIED:
  VLAN ISL Id: 7
    Current State: Operational
    Modified State: Suspended
```

**Related Commands**

Command	Description
<a href="#">show current</a>	Displays the current VLAN database on the switch or a selected VLAN from it.
<a href="#">show proposed</a>	Displays the proposed VLAN database or a selected VLAN from it.

# show cluster

Use the **show cluster** user EXEC command to display the cluster status and a summary of the cluster to which the switch belongs. This command can be entered on command and member switches.

## show cluster

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Modes</b>	User EXEC
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

<b>Usage Guidelines</b>	If the switch is not a command switch or a member switch, the command displays an empty line at the prompt.
	On a member switch, this command displays the identity of the command switch, the switch member number, and the state of its connectivity with the command switch.
	On a command switch, this command displays the cluster name, and the total number of members. It also shows the cluster status and time since the status changed. If redundancy is enabled, it displays the primary and secondary command-switch information.
	If you enter this command on a switch that is not a cluster member, the error message <code>Not a management cluster member</code> is displayed.

<b>Examples</b>	The following is sample output when this command is executed on the active command switch:
-----------------	--

```
Switch# show cluster
Command switch for cluster "Ajang"
Total number of members:      7
Status:                       1 members are unreachable
Time since last status change: 0 days, 0 hours, 2 minutes
Redundancy:                   Enabled
    Standby command switch: Member 1
    Standby Group:            Ajang_standby
    Standby Group Number:     110
Heartbeat interval:           8
Heartbeat hold-time:          80
Extended discovery hop count: 3
```

The following is sample output when this command is executed on a member switch:

```
Switch1# show cluster
Member switch for cluster "mcluster"
Member number:                3
Management IP address:        192.192.192.192
Command switch mac address:    0000.0c07.ac14
Heartbeat interval:            8
Heartbeat hold-time:           80
```

The following is sample output when this command is executed on a member switch that is configured as the standby command switch:

```
Switch# show cluster
Member switch for cluster "mcluster"
  Member number:          3 (Standby command switch)
  Management IP address:   192.192.192.192
  Command switch mac address: 0000.0c07.ac14
  Heartbeat interval:      8
  Heartbeat hold-time:     80
```

The following is sample output when this command is executed on the command switch that is separated from member 1:

```
3524-24> show cluster
Command switch for cluster "Ajang"
  Total number of members: 7
  Status:                  1 members are unreachable
  Time since last status change: 0 days, 0 hours, 5 minutes
  Redundancy:              Disabled
  Heartbeat interval:      8
  Heartbeat hold-time:     80
  Extended discovery hop count: 3
```

The following is sample output when this command is executed on a member switch that is separated from the command switch:

```
3512-12> show cluster
Member switch for cluster "mcluster"
  Member number:          <UNKNOWN>
  Management IP address:   192.192.192.192
  Command switch mac address: 0000.0c07.ac14
  Heartbeat interval:      8
  Heartbeat hold-time:     80
```

## Related Commands

Command	Description
<a href="#">cluster enable</a>	Enables a command-capable switch as the cluster command switch, assigns a cluster name, and optionally assigns a member number to it.
<a href="#">show cluster candidates</a>	Displays a list of candidate switches.
<a href="#">show cluster members</a>	Displays information about the cluster members.



# show cluster candidates

Use the **show cluster candidates** user EXEC command on the command switch to display a list of candidate switches.

**show cluster candidates** [*mac-address H.H.H.* | **detail**]

## Syntax Description

<b>mac-address</b> <i>H.H.H.</i>	(Optional) MAC address of the cluster candidate.
<b>detail</b>	(Optional) Display detailed information for all candidates.

## Command Modes

User EXEC

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.
12.0(5)XU	The <b>detail</b> keyword was added.

## Usage Guidelines

You should enter this command only on a command switch.

If the switch is not a command switch, the command displays an empty line at the prompt.

The SN in the display means “switch member number.” If E is displayed in the SN column, it means that the switch is discovered through extended discovery. The hop count is the number of devices the candidate is from the command switch.

## Examples

The following is sample output from the **show cluster candidates** command.

Switch# **show cluster candidates**

```

                                     |---Upstream---|
MAC Address   Name           Device Type   PortIf   FEC Hops SN PortIf   FEC
00d0.7961.c4c0 3512-12      WS-C3512-XL   Fa0/3     1  0  Fa0/13
00d0.bbf5.e900 1df-dist-128 WS-C3524-XL   Fa0/7     1  0  Fa0/24
00e0.1e7e.be80 1900_Switch  1900         3         0  1  0  Fa0/11
00e0.1e9f.7a00 2924-24      WS-C2924-XL   Fa0/5     1  0  Fa0/3
00e0.1e9f.8c00 2912-12-2    WS-C2912-XL   Fa0/4     1  0  Fa0/7
00e0.1e9f.8c40 2912-12-1    WS-C2912-XL   Fa0/1     1  0  Fa0/9
0050.2e4a.9fb0      murali-132    WS-C3508-XL           E
0050.354e.7cd0      murali-134    WS-C2924-XL           E

```

The following is sample output from the **show cluster candidates** command that uses the MAC address of a member switch directly connected to the command switch:

Switch# **show cluster candidates mac-address 00d0.7961.c4c0**

```

Device '3512-12' with mac address number 00d0.7961.c4c0
Device type:          cisco WS-C3512-XL
Upstream MAC address: 00d0.796d.2f00 (Cluster Member 0)
Local port:           Fa0/3   FEC number:
Upstream port:        Fa0/13  FEC Number:
Hops from cluster edge: 1
Hops from command device: 1

```

The following is sample output from the **show cluster candidates** command that uses the MAC address of a member switch three hops from the cluster edge:

```
Switch# show cluster candidates mac-address 0010.7bb6.1cc0
Device '2912MF' with mac address number 0010.7bb6.1cc0
  Device type:          cisco WS-C2912MF-XL
  Upstream MAC address: 0010.7bb6.1cd4
  Local port:           Fa2/1   FEC number:
  Upstream port:        Fa0/24  FEC Number:
  Hops from cluster edge: 3
  Hops from command device: -
```

The following is sample output from the **show cluster candidates detail** command:

```
Switch# show cluster candidates detail
Device '3512-12' with mac address number 00d0.7961.c4c0
  Device type:          cisco WS-C3512-XL
  Upstream MAC address: 00d0.796d.2f00 (Cluster Member 1)
  Local port:           Fa0/3   FEC number:
  Upstream port:        Fa0/13  FEC Number:
  Hops from cluster edge: 1
  Hops from command device: 2
Device '1900_Switch' with mac address number 00e0.1e7e.be80
  Device type:          cisco 1900
  Upstream MAC address: 00d0.796d.2f00 (Cluster Member 2)
  Local port:           3       FEC number: 0
  Upstream port:        Fa0/11  FEC Number:
  Hops from cluster edge: 1
  Hops from command device: 2
Device '2924-24' with mac address number 00e0.1e9f.7a00
  Device type:          cisco WS-C2924-XL
  Upstream MAC address: 00d0.796d.2f00 (Cluster Member 3)
  Local port:           Fa0/5   FEC number:
  Upstream port:        Fa0/3   FEC Number:
  Hops from cluster edge: 1
  Hops from command device: 2
```

## Related Commands

Command	Description
<a href="#">show cluster</a>	Displays the cluster status and a summary of the cluster to which the switch belongs.
<a href="#">show cluster members</a>	Displays information about the cluster members.

# show cluster members

Use the **show cluster members** user EXEC command on the command switch to display information about the cluster members.

**show cluster members** [*n* | **detail**]

## Syntax Description

<b><i>n</i></b>	(Optional) Number that identifies a cluster member. The range is from 0 to 15.
<b>detail</b>	(Optional) Display detailed information for all cluster members.

## Command Modes

User EXEC

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.
12.0(5)XU	The <b>detail</b> keyword was added.

## Usage Guidelines

You should enter this command only on a command switch.

If the cluster has no members, this command displays an empty line at the prompt.

## Examples

The following is sample output from the **show cluster members** command. The SN in the display means “switch number.”

Switch# **show cluster members**

```

                                |---Upstream---|
SN MAC Address      Name          PortIf FEC Hops   SN PortIf  FEC  State
0  00d0.796d.2f00 3524-24                0                      Up (Cmdr)
1  00d0.7960.66c0                255                    Down
2  00e0.1e9f.8c00 2912-12-2 Fa0/4      1      0 Fa0/7      Up (Standby)
3  00e0.1e9f.7a00 2924-24 Fa0/5      1      0 Fa0/3      Up
4  00d0.bbf5.e900 ldf-dist-128 Fa0/7      1      0 Fa0/24     Up
5  00d0.7961.c4c0 3512-12 Fa0/3      1      0 Fa0/13     Up
6  00e0.1e9f.8c40 2912-12-1 Fa0/1      1      0 Fa0/9      Up
7  00e0.1e7e.be80 1900_Switch 3        0  1      0 Fa0/11     Up
8  00e0.1e9f.8300 2924M      Fa0/11     2      5 Fa0/12     Up
9  0010.7bb6.1cc0 2912MF      Fa2/1      3      8 Fa0/24     Up
10 00e0.1e87.2140 2820-01      24        0  4      9 Fa2/3      Up

```

The following is sample output from the **show cluster members** for cluster member 3:

Switch# **show cluster members 3**

Device '2924-24' with member number 3

```

Device type:      cisco WS-C2924M-XL
MAC address:      00e0.1e9f.9440
Upstream MAC address: 00d0.796d.2e00 (Cluster member 0)
Local port:      Fa0/18 FEC number:
Upstream port:   Fa0/20 FEC Number:
Hops from command device: 1

```

The following is sample output from the **show cluster members detail** command:

```
Switch# show cluster members detail
Device '3524-24' with member number 0 (Command Switch)
  Device type:          cisco WS-C3524-XL
  MAC address:          00d0.7964.1f00
  Upstream MAC address:
  Local port:           FEC number:
  Upstream port:        FEC Number:
  Hops from command device: 0
'Unknown'device with member number 1
  Device type:
  MAC address:
  Upstream MAC address:
  Local port:           FEC number:
  Upstream port:        FEC Number:
  Hops from command device: 255
Device '2912-12-2' with member number 2
  Device type:          cisco WS-C3548-XL
  MAC address:          00d0.5868.f5c0
  Upstream MAC address: 00d0.7964.1f00 (Cluster member 0)
  Local port:          Fa0/7   FEC number: 1
  Upstream port:        Fa0/6   FEC Number:
  Hops from command device: 1
Device '2924-24' with member number 3
  Device type:          cisco WS-C3508G-XL
  MAC address:          00d0.7968.5380
  Upstream MAC address: 00d0.7964.1f00 (Cluster member 0)
  Local port:          Gi0/6   FEC number:
  Upstream port:        Gi0/1   FEC Number:
  Hops from command device: 1
```

Related Commands	Command	Description
	<a href="#">show cluster</a>	Displays the cluster status and a summary of the cluster to which the switch belongs.
	<a href="#">show cluster candidates</a>	Displays a list of candidate switches.

# show controllers ethernet-controller

Use the **show controllers ethernet-controller** privileged EXEC command to display the Ethernet link transmit and receive statistics on a Fast Ethernet or LRE port on an LRE switch.

**show controllers ethernet-controller** *interface-id*

<b>Syntax Description</b>	<i>interface-id</i>	ID of the Fast Ethernet or LRE port.
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(5)WC1	This command was first introduced.

**Usage Guidelines**

Using the **show controllers ethernet-controller** command without specifying a Fast Ethernet or LRE port displays the Ethernet link statistics of all ports on the switch and on the connected customer premises equipment (CPE) devices. The output shows the internal switch statistics, the statistics collected by the LRE chipset on the switch, and the statistics collected by the LRE chipset on the CPE.

The Ethernet link on an LRE port is the connection between the remote Cisco 575 LRE CPE and PC. It is not the link between the LRE port and the CPE.

**Examples**

The following is sample output from the **show controllers ethernet-controller** command on Fast Ethernet port 1:

Switch#**show controllers ethernet-controller fa0/1**

```

Transmit                      Receive
877634 Bytes                  8834435 Bytes
 3853 Unicast frames           5212 Unicast frames
   606 Multicast frames        20600 Multicast frames
 3496 Broadcast frames         32756 Broadcast frames
    0 Discarded frames         0 No bandwidth frames
    0 Too old frames           0 No buffers frames
    0 Deferred frames         10697 No dest, unicast
    0 1 collision frames       42555 No dest, multicast
    0 2 collision frames        0 No dest, broadcast
    0 3 collision frames        0 Alignment errors
    0 4 collision frames        0 FCS errors
    0 5 collision frames        0 Collision fragments
    0 6 collision frames
    0 7 collision frames        0 Undersize frames
    0 8 collision frames       33602 Minimum size frames
    0 9 collision frames       75929 65 to 127 byte frames
    0 10 collision frames      760 128 to 255 byte frames
    0 11 collision frames     1527 256 to 511 byte frames
    0 12 collision frames      2 512 to 1023 byte frames
    0 13 collision frames      0 1024 to 1518 byte frames
    0 14 collision frames      0 Oversize frames
    0 15 collision frames
    0 Excessive collisions
    0 Late collisions

```

The following is sample output from the **show controllers ethernet-controller** command to display the Ethernet link statistics between the CPE and PC, where the CPE is connected to LRE port 2:

Switch#**show controllers ethernet-controller lo0/2**

```

Transmit
 28548 Bytes
   0 Unicast frames
  72 Multicast frames
   0 Broadcast frames
   0 Discarded frames
   0 Too old frames
   0 Deferred frames
   0 1 collision frames
   0 2 collision frames
   0 3 collision frames
   0 4 collision frames
   0 5 collision frames
   0 6 collision frames
   0 7 collision frames
   0 8 collision frames
   0 9 collision frames
   0 10 collision frames
   0 11 collision frames
   0 12 collision frames
   0 13 collision frames
   0 14 collision frames
   0 15 collision frames
   0 Excessive collisions
   0 Late collisions

Receive
197152 Bytes
   0 Unicast frames
 1822 Multicast frames
   0 Broadcast frames
   0 No bandwidth frames
   0 No buffers frames
   1 No dest, unicast
  746 No dest, multicast
   3 No dest, broadcast
   0 Alignment errors
   0 FCS errors
   0 Collision fragments
   0 Undersize frames
 1758 Minimum size frames
  746 65 to 127 byte frames
   0 128 to 255 byte frames
   68 256 to 511 byte frames
   0 512 to 1023 byte frames
   0 1024 to 1518 byte frames
   0 Oversize frames

```

LRE PHY on Switch:

```

22864 Bytes
  58 Frames

   0 Pause frames
282 1 collision frames
   0 Multiple collisions
   0 Late collisions
   0 Excessive collisions
   0 Deferred frames
   0 Carrier sense errors

148067 Bytes
 1923 Frames

   0 Broadcast frames
   0 Pause frames
   0 Alignment errors
   0 Collisions and Runts
   0 Oversize frames
   0 FCS errors

```

LRE MAC on CPE:

```

22864 Bytes
  58 Frames

   0 Pause frames
101 1 collision frames
   0 Multiple collisions
   0 Late collisions
   0 Excessive collisions
   0 Deferred frames
   0 Carrier sense errors

148067 Bytes
 1923 Frames

   3 Broadcast frames
   0 Pause frames
   0 Alignment errors
   0 Collisions and Runts
   0 Oversize frames
   0 FCS errors

```

## Related Commands

Command	Description
<a href="#">clear controllers ethernet-controller</a>	Deletes the Ethernet link transmit and receive statistics on a Fast Ethernet or LRE port on an LRE switch.

## show controllers lre *interface-id* actual

Use the **show controllers lre interface-id actual** privileged EXEC command to display the actual values of the Long-Reach Ethernet (LRE) link on a specific LRE port.

**show controllers lre interface-id actual** [**dsrserrs** | **usrserrs** | **txpower** | **rxpower** | **snr** | **link**]

Syntax Description		
<i>interface-id</i>	ID of the LRE port.	
<b>actual</b>	Display the LRE port current status, which might not be the same as the administratively configured settings.	
<b>dsrserrs</b>	Display the downstream Reed-Solomon errors on the LRE port.	
<b>link</b>	Display the LRE link status of the LRE port.	
<b>rxpower</b>	Display the local receive power (dBm/Hz) on the remote customer premises equipment (CPE) port.	
<b>snr</b>	Display the signal-to-noise ratio (SNR) ratio on the LRE port.	
<b>txpower</b>	Display the remote transmit power (dBm/Hz) on the LRE port.	
<b>usrserrs</b>	Display the upstream Reed-Solomon errors on the LRE port.	

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.0(5)WC1	This command was first introduced.

**Usage Guidelines**

Use the SNR and Reed-Solomon error information to measure the quality of the LRE link. The SNR represents the amount of increased received signal power (in decibels) relative to the noise power level the switch is designed to tolerate without disconnecting from the remote CPE. The higher the ratio, the more resilient is the link. The Reed-Solomon errors show the number of errors detected and corrected in the data being received on and transmitted from the LRE ports. Reed-Solomon errors are the result of noise exceeding the noise margin. For short bursts of noise (such as motor startup or power surges), the interleaver prevents loss of Ethernet data packets. In this case, the number of Reed-Solomon errors exceeds the number of Ethernet CRC errors.

The remote transmit power from the connected CPEs might be different from each other, depending on how long the cable is between the switch and the CPE. A longer cable typically causes the CPE to transmit a higher signal to overcome the loss effects of distance.

The local receive power actually displays the switch's adjustment to the incoming power level. These numbers might be different from LRE port to LRE port, as the length of the cables to the CPEs might be different.

**Examples**

The following is sample output from the **show controllers lre interface-id actual dsrserrs** command on LRE port 1:

```
Switch#show controller lre lo0/2 actual dsrserrs
0
Switch#show controller lre lo0/2 actual link
UP
Switch#show controller lre lo0/2 actual rxpower
26.0
Switch#show controller lre lo0/2 actual snr
27
Switch#show controller lre lo0/2 actual txpower
-89.7
Switch#show controller lre lo0/2 actual usrerrs
0
```

The following is sample output from the **show controllers lre interface-id actual link** command on LRE port 1:

```
Switch#show controllers lre lo0/1 actual link
DOWN
```

**Related Commands**

Command	Description
<a href="#">show controllers lre interface-id admin</a>	Displays the administrative settings of the LRE link on a specific LRE port.
<a href="#">show controllers lre status</a>	Displays the LRE link status of a specific LRE port.



## show controllers lre *interface-id* admin

Use the **show controllers lre *interface-id* admin** privileged EXEC command to display the administrative settings of the Long-Reach Ethernet (LRE) link on a specific LRE port.

**show controllers lre *interface-id* admin [dsrate | usrate]**

Syntax Description		
<i>interface-id</i>		ID of the LRE port.
<b>admin</b>		Display the administrative settings, which might not be the same as the actual values.
<b>dsrate</b>		Display the downstream rate (Mbps) of the LRE link.
<b>usrate</b>		Display the upstream rate (Mbps) of the LRE link.

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.0(5)WC1	This command was first introduced.

Usage Guidelines	<p>This command displays the private profile settings of an LRE port, even though they might not be active if a global profile is configured on the switch.</p> <p>The upstream and downstream rates are defined by the profile on the LRE port. To change these rates, assign a different profile to the LRE port. For information about the LRE profiles, refer to the <i>Catalyst 2900 Series XL and Catalyst 3500 Series XL Software Configuration Guide</i>.</p>
------------------	---

Examples	<p>The following is sample output from the <b>show controllers lre <i>interface-id</i> admin dsrate</b> and <b>show controllers lre <i>interface-id</i> admin usrate</b> commands on LRE port 1 and LRE port 2:</p>
----------	---

```
Switch#show controller lre lo0/1 admin usrate
18.750
Switch#show controller lre lo0/1 admin dsrate
16.667
Switch#show controller lre lo0/2 admin usrate
12.500
Switch#show controller lre lo0/2 admin dsrate
12.500
```

Related Commands	Command	Description
	<b>show controllers lre interface-id actual</b>	Displays the actual values of the LRE link on a specific LRE port.
	<b>show controllers lre status</b>	Displays the LRE link status of a specific LRE port.
	<b>lre profile global</b>	Assigns a public profile to all LRE ports on the switch.
	<b>lre profile</b>	Assigns a private profile to a specific LRE port.

# show controllers lre log

Use the **show controllers lre log** privileged EXEC command to display the history of link, configuration, and timer events for a specific LRE port or all LRE ports on the switch.

**show controllers lre log** *interface-id*

## Syntax Description

<i>interface-id</i>	ID of the LRE port.
---------------------	---------------------

## Command Modes

Privileged EXEC

## Command History

Release	Modification
12.0(5)WC1	This command was first introduced.

## Usage Guidelines

Using the **show controllers lre log** command without specifying a LRE port displays the events for all LRE ports on the switch.

The time-stamped and sequentially tagged log entries can be helpful in confirming LRE link drops and configuration changes. The format of the timestamps can be changed by using the **service timestamps log** global configuration command.

## Examples

The following is sample output from the **show controllers lre log** command to display events on LRE port 1:

```
Switch#sh controller lre log longReachEthernet 0/1
```

```
LongReachEthernet0/1:Events Log:=====
*Mar  1 00:00:22.051:[0]:State MODEZERO_APPLIED:Got event:Port Profile Changed
*Mar  1 00:00:48.213:[1]:State MODEZERO_APPLIED:Got event:Link Up
*Mar  1 00:00:52.045:[2]:State PROFILE_APPLIED:Got event:Link Down
*Mar  1 00:00:53.589:[3]:State PROFILE_APPLIED:Got event:Link Up
*Mar  1 00:15:44.666:[4]:State PROFILE_LINKUP:Got event:Link Down
*Mar  1 00:16:09.869:[5]:State PROFILE_LINKUP:Got event:Timer 2 Expired
*Mar  1 00:31:35.046:[6]:State MODEZERO_APPLIED:Got event:Link Up
*Mar  1 00:31:36.325:[7]:State PROFILE_APPLIED:Got event:Link Down
*Mar  1 00:31:37.250:[8]:State PROFILE_APPLIED:Got event:Link Up
*Mar  1 00:34:13.520:[9]:State PROFILE_LINKUP:Got event:Link Down
*Mar  1 00:34:14.309:[10]:State PROFILE_LINKUP:Got event:Link Up
*Mar  1 00:34:18.330:[11]:State PROFILE_LINKUP:Got event:Link Down
*Mar  1 00:34:21.814:[12]:State PROFILE_LINKUP:Got event:Link Up
*Mar  1 00:34:24.441:[13]:State PROFILE_LINKUP:Got event:Link Down
*Mar  1 00:34:27.890:[14]:State PROFILE_LINKUP:Got event:Link Up
*Mar  1 00:34:31.558:[15]:State PROFILE_LINKUP:Got event:Link Down
*Mar  1 00:34:34.520:[16]:State PROFILE_LINKUP:Got event:Link Up
*Mar  1 00:35:49.640:[17]:State PROFILE_LINKUP:Got event:Link Down
*Mar  1 00:36:15.430:[18]:State PROFILE_LINKUP:Got event:Timer 2 Expired
*Mar  1 00:36:35.442:[19]:State MODEZERO_APPLIED:Got event:Link Up
*Mar  1 00:36:37.195:[20]:State PROFILE_APPLIED:Got event:Link Down
*Mar  1 00:36:38.472:[21]:State PROFILE_APPLIED:Got event:Link Up
*Mar  8 02:45:47.609:[22]:State PROFILE_LINKUP:Got event:Global Config Changed
```

```
*Mar  8 02:45:48.113:[23]:State PROFILE_APPLIED:Got event:Link Down
*Mar  8 02:45:49.442:[24]:State PROFILE_APPLIED:Got event:Link Up
*Mar  8 02:46:31.392:[25]:State PROFILE_LINKUP:Got event:Global Config Changed
*Mar  8 02:46:32.250:[26]:State PROFILE_APPLIED:Got event:Link Down
*Mar  8 02:46:32.868:[27]:State PROFILE_APPLIED:Got event:Link Up
*Mar  8 02:47:35.510:[28]:State PROFILE_LINKUP:Got event:Port Config Changed
*Mar  8 02:47:36.074:[29]:State PROFILE_APPLIED:Got event:Link Down
*Mar  8 02:47:36.957:[30]:State PROFILE_APPLIED:Got event:Link Up
```

## Related Commands

Command	Description
<b>clear controllers lre log</b>	Deletes the history of link, configuration, and timer events for a specific LRE port or all LRE ports on the switch.
<b>service timestamps log</b>	Enables log timestamps.

# show controllers lre profile

Use the **show controllers lre profile** privileged EXEC command to display information about the Long-Reach Ethernet (LRE) profiles available on the switch, and how they are assigned to the LRE ports.

**show controllers lre profile** [**mapping** | **names**]

Syntax Description

mapping	Display a list of the LRE ports and their assigned private profiles. If a public profile is active on the switch, the output shows the status of any private profile assigned to an LRE port as inactive, and, appearing at the top of the output, is the name of the public profile that is active for all LRE ports.
names	Display the names, types, and upstream and downstream data rates of all profiles available on the switch.  The data rates displayed are the gross data rates of each direction of the channel. The actual bandwidth is somewhat less.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.0(5)WC1	This command was first introduced.

**Usage Guidelines**

The data rates displayed from the **show controllers lre profile names** command are the gross data rates of each direction of the channel. The actual bandwidth is somewhat less.

[Table 2-1](#) lists the LRE profiles shipped with the switch, including the upstream and downstream data rates they support on the LRE link. For more information about LRE profiles and LRE links, refer to the *Catalyst 2900 Series XL and Catalyst 3500 Series XL Software Configuration Guide*.

**Note**

Use the rates and distances in [Table 2-1](#) as guidelines only. Factors such as the type of cable you use, how it is bundled, and the interference and noise on the LRE link can affect the actual LRE link performance. Contact Cisco Systems for information about limitations and optimization of LRE link performance.

The net data rates in [Table 2-1](#) are slightly less than the gross data rates displayed by the **show controllers lre profile names** command.

**Table 2-1 LRE Profiles**

Profile Name	Profile Type	LRE Link Downstream Rate (Mbps)	LRE Link Upstream Rate (Mbps)	Maximum Distance between the LRE Port and the CPE
PUBLIC-ANSI	Public	15.17	4.27	4101 ft (1250 m)
PUBLIC-ETSI	Public	11.38	4.27	4101 ft (1250 m)
LRE-5	Private	5.69	5.69	4921 ft (1500 m)
LRE-10 (default)	Private	11.38	11.38	4101 ft (1250 m)
LRE-15	Private	15.17	17.06	3445 ft (1050 m)

**Examples**

The following is sample output from the **show controllers lre profile mapping** command:

Interface	Port	Profile	Status
-----	-----	-----	-----
Lo0/1		LRE-15	Active
Lo0/2		LRE-10	Active
Lo0/3		LRE-10	Active
Lo0/4		LRE-10	Active
Lo0/5		LRE-10	Active
Lo0/6		LRE-10	Active
Lo0/7		LRE-10	Active
Lo0/8		LRE-10	Active
Lo0/9		LRE-10	Active
Lo0/10		LRE-10	Active
Lo0/11		LRE-10	Active
Lo0/12		LRE-10	Active
Lo0/13		LRE-10	Active
Lo0/14		LRE-10	Active
Lo0/15		LRE-10	Active
Lo0/16		LRE-10	Active
Lo0/17		LRE-10	Active
Lo0/18		LRE-10	Active
Lo0/19		LRE-10	Active
Lo0/20		LRE-10	Active
Lo0/21		LRE-10	Active
Lo0/22		LRE-10	Active
Lo0/23		LRE-10	Active
Lo0/24		LRE-10	Active

The following is sample output from the **show controllers lre profile names** command:

Switch#**show controllers lre profile names**

Profile Name	Type	Downstream Rate (Mbps)	Upstream Rate (Mbps)
-----	-----	-----	-----
LRE-15	Port	16.667	18.750
LRE-10	Port	12.500	12.500
LRE-5	Port	6.250	6.250
Public-ANSI	Global	16.667	4.688
Public-ETSI	Global	12.500	4.688

**Related Commands**

Command	Description
<b>lre profile global</b>	(Global configuration command) Assigns a public profile to all LRE ports on the switch.
<b>lre profile</b>	(Interface configuration command) Assigns a private profile to a specific LRE port.

## show controllers lre status

Use the **show controllers lre status** privileged EXEC command to display the Long-Reach Ethernet (LRE) link statistics and profile information on an LRE port including link state, link duration, data rates, power levels, signal-to-noise ratio, and Reed-Solomon errors.

**show controllers lre status** [**link** | **profile**] *interface-id*

Syntax Description	<i>interface-id</i>	ID of the LRE port.
	<b>link</b>	Display various parameters and status associated with the LRE link
	<b>profile</b>	Display various administrative parameters and status associated with the LRE link.

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.0(5)WC1	This command was first introduced.

**Usage Guidelines** Using the **show controllers lre status** command without specifying a LRE port displays the status of all LRE ports.

Use the SNR and Reed-Solomon error information to measure the quality of the LRE link. The SNR represents the amount of increased received signal power (in decibels) relative to the noise power level the switch is designed to tolerate without disconnecting from the remote CPE. The higher the ratio, the more resilient is the link. The Reed-Solomon errors show the number of errors detected and corrected in the data being received on and transmitted from the LRE ports. Reed-Solomon errors are the result of noise exceeding the noise margin. For short bursts of noise (such as motor startup or power surges), the interleaver prevents loss of Ethernet data packets. In this case, the number of Reed-Solomon errors exceeds the number of Ethernet CRC errors.

The remote transmit power from the connected CPEs might be different from each other, depending on how long the cable is between the switch and the CPE. A longer cable typically causes the CPE to transmit a higher signal to overcome the loss effects of distance.

The local receive power actually displays the switch's adjustment to the incoming power level. These numbers might be different from LRE port to LRE port, as the length of the cables to the CPEs might be different.

The interleaver columns display the interleaver block size for both directions of data. A higher interleaver setting is less susceptible to certain kinds of impairments but can introduce a very small amount of delay in the data path.

The PMD-S column refers to physical media dependent status, and is provided as diagnostic information.

**Examples**

The following is sample output from the **show controllers lre status link** command:

Switch#show controllers lre status link

Port	Link	SNR (dB)	RS Errs	CPE-Tx (dBm/Hz)	Sw-AGC-Gain (dB)	Interleaver		PMD-S
						Rx-Bsz	Tx-Bsz	
Lo0/1	UP	33	0	- 83.7	19.0	0	0	0x04
Lo0/2	UP	27	0	- 89.7	26.0	0	0	0x04
Lo0/3	UP	27	0	- 89.7	26.0	0	0	0x04
Lo0/4	UP	27	0	- 89.7	26.0	0	0	0x04
Lo0/5	UP	27	0	- 89.7	26.0	0	0	0x04
Lo0/6	UP	27	0	- 89.7	26.0	0	0	0x04
Lo0/7	UP	27	0	- 89.7	26.0	0	0	0x04
Lo0/8	DOWN	0	0	0.0	0.0	0	0	0x80
Lo0/9	UP	27	0	- 89.7	25.0	0	0	0x04
Lo0/10	DOWN	0	0	0.0	0.0	0	0	0x80
Lo0/11	DOWN	0	0	0.0	0.0	0	0	0x80
Lo0/12	UP	27	0	- 89.7	26.0	0	0	0x04
Lo0/13	UP	27	0	- 89.7	26.0	0	0	0x04
Lo0/14	DOWN	0	0	0.0	0.0	0	0	0x04
Lo0/15	UP	27	0	- 89.7	26.0	0	0	0x04
Lo0/16	DOWN	0	0	0.0	0.0	0	0	0x04
Lo0/17	DOWN	0	0	0.0	0.0	0	0	0x04
Lo0/18	DOWN	0	0	0.0	0.0	0	0	0x04
Lo0/19	DOWN	0	0	0.0	0.0	0	0	0x04
Lo0/20	DOWN	0	0	0.0	0.0	2	0	0x04
Lo0/21	DOWN	0	0	0.0	0.0	0	0	0x84
Lo0/22	DOWN	0	0	0.0	0.0	0	0	0x04
Lo0/23	DOWN	0	0	0.0	0.0	0	0	0x84
Lo0/24	DOWN	0	0	0.0	0.0	0	0	0x04

The following is sample output from the **show controllers lre status profile**:

Switch#show controllers lre status profile

Port	Link	Uptime	Profile	DSRate	USRate	Fail
Lo0/1	UP	00:36:10	LRE-15	16.667	18.750	0
Lo0/2	UP	00:36:15	LRE-10	12.500	12.500	0
Lo0/3	UP	00:36:14	LRE-10	12.500	12.500	0
Lo0/4	UP	00:36:14	LRE-10	12.500	12.500	0
Lo0/5	UP	00:36:13	LRE-10	12.500	12.500	0
Lo0/6	UP	00:36:10	LRE-10	12.500	12.500	0
Lo0/7	UP	00:36:13	LRE-10	12.500	12.500	0
Lo0/8	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/9	UP	00:36:12	LRE-10	12.500	12.500	0
Lo0/10	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/11	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/12	UP	00:36:12	LRE-10	12.500	12.500	0
Lo0/13	UP	00:36:11	LRE-10	12.500	12.500	0
Lo0/14	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/15	UP	00:36:11	LRE-10	12.500	12.500	0
Lo0/16	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/17	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/18	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/19	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/20	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/21	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/22	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/23	DOWN	00:00:00	LRE-10	0.000	0.000	0
Lo0/24	DOWN	00:00:00	LRE-10	0.000	0.000	0



Related Commands	Command	Description
	<a href="#">show controllers lre interface-id actual</a>	Displays the actual values of the LRE link on a specific LRE port.
	<a href="#">show controllers lre interface-id admin</a>	Displays the administrative settings of the LRE link on a specific LRE port.
	<a href="#">show controllers lre profile</a>	Displays information about the LRE profiles available on the switch.
	<a href="#">debug lre</a>	Enables debugging of LRE-related events.

# show controllers lre

Use the **show controllers lre version** privileged EXEC command to display the version numbers of the various components that make up the switch Long-Reach Ethernet (LRE) chipset and, if a Cisco 575 LRE CPE is connected, the customer premises equipment (CPE) LRE chipset.

**show controllers lre version** *interface-id*

Syntax Description	<i>interface-id</i>	ID of the LRE port.
--------------------	---------------------	---------------------

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.0(5)WC1	This command was first introduced.

Usage Guidelines	Using the <b>show controllers lre version</b> command without specifying a LRE port displays the version numbers of the switch LRE chipset and the CPE chipset of all connected CPEs.
------------------	---

Examples	The following is sample output from the <b>show controllers lre version</b> command:
----------	--

```
Switch#show controllers lre version
--- SWITCH ---      ---- CPE ----
Interface   Hw   Sw   Patch   Hw   Sw   Patch
Lo0/1       32   B4   4C      32   B4   4C
Lo0/2       32   B4   4C      32   B4   4C
Lo0/3       32   B4   4C      32   B4   4C
Lo0/4       32   B4   4C      32   B4   4C
Lo0/5       32   B4   4C      32   B4   4C
Lo0/6       32   B4   4C      32   B4   4C
Lo0/7       32   B4   4C      32   B4   4C
Lo0/8       32   B4   4C      00   00   00
Lo0/9       32   B4   4C      32   B4   4C
Lo0/10      32   B4   4C      00   00   00
Lo0/11      32   B4   4C      00   00   00
Lo0/12      32   B4   4C      32   B4   4C
Lo0/13      32   B4   4C      32   B4   4C
Lo0/14      32   B4   4C      00   00   00
Lo0/15      32   B4   4C      32   B4   4C
Lo0/16      32   B4   4C      00   00   00
Lo0/17      32   B4   4C      00   00   00
Lo0/18      32   B4   4C      00   00   00
Lo0/19      32   B4   4C      00   00   00
Lo0/20      32   B4   4C      00   00   00
Lo0/21      32   B4   4C      00   00   00
Lo0/22      32   B4   4C      00   00   00
Lo0/23      32   B4   4C      00   00   00
Lo0/24      32   B4   4C      00   00   00
```

The following is sample output from the **show controllers lre version mfg** command on LRE port 15:

```
switch#show controllers lre ver mfg lo0/15
CPE Manufacturer Information
```

```
Lo0/15
Assembly Revision Number: 07          (2)
Model Number           : Cisco575-LRE (12)
Model Revision Number  : A0           (12)
Board Assembly Number  : 73-5579-07   (10)
Board Serial Number    : FAA0000C001   (11)
System Serial Number   : FAA0000Z001   (11)
```

#### Related Commands

Command	Description
<a href="#">debug lre</a>	Enables debugging of LRE-related events.
<a href="#">show controllers lre version mfg</a>	Display the revision and serial numbers of the connected Cisco 575 LRE CPE board, assembly, and system.

# show controllers lre version mfg

Use the **show controllers lre version mfg** privileged EXEC command to display the revision and serial numbers of the connected Cisco 575 LRE CPE board, assembly, and system.

**show controllers lre version mfg** *interface-id*

Syntax Description	<i>interface-id</i>	ID of the LRE port.
--------------------	---------------------	---------------------

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.0(5)WC1	This command was first introduced.

**Examples** The following is sample output from the **show controllers lre mfg** command on LRE port 15:

```
Switch#show controllers lre version mfg lo0/15
Assembly Revision Number: ASSREV0123456789
Model Number           : MODEL#0123456789
Model Revision Number  : MODELREV01234567
Board Assembly Number  : BOARDASS#0123456
Board Serial Number    : BOARDSER#0123456
System Serial Number   : SYSSER#012345678
```

Related Commands	Command	Description
	<a href="#">debug lre</a>	Enables debugging of LRE-related events.
	<a href="#">show controllers lre</a>	Displays the version number of the hardware, software, and patch software components of the switch LRE chipset and, if a Cisco 575 LRE CPE is connected, the customer premises equipment (CPE) LRE chipset.

# show current

Use the **show current** VLAN database command to display the current VLAN database on the switch or a selected VLAN from it.

**show current** [*vlan-id*]

<b>Syntax Description</b>	<i>vlan-id</i> (Optional) ID of the VLAN in the current database. If this variable is omitted, the entire VLAN database displays, including the pruning state and Version 2 mode. Valid IDs are from 1 to 1005; do not enter leading zeroes.
---------------------------	--

<b>Command Modes</b>	VLAN database
----------------------	---------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA4	This command was first introduced.

**Examples** The following is sample output from the **show current** command. It displays the current VLAN database.

```
Switch(vlan) # show current
```

```
VLAN ISL Id: 1
  Name: default
  Media Type: Ethernet
  VLAN 802.10 Id: 100001
  State: Operational
  MTU: 1500
  Translational Bridged VLAN: 1002
  Translational Bridged VLAN: 1003
```

```
VLAN ISL Id: 2
  Name: VLAN0002
  Media Type: Ethernet
  VLAN 802.10 Id: 100002
  State: Operational
  MTU: 1500
```

```
VLAN ISL Id: 3
  Name: VLAN0003
  Media Type: Ethernet
  VLAN 802.10 Id: 100003
  State: Operational
  MTU: 4000
```

```
VLAN ISL Id: 4
  Name: VLAN0004
  Media Type: Ethernet
  VLAN 802.10 Id: 100004
  State: Operational
  MTU: 1500
```

```
VLAN ISL Id: 5
  Name: VLAN0005
  Media Type: Ethernet
  VLAN 802.10 Id: 100005
  State: Operational
  MTU: 1500
```

```
VLAN ISL Id: 6
  Name: VLAN0006
  Media Type: Ethernet
  VLAN 802.10 Id: 100006
  State: Operational
  MTU: 1500
```

The following is sample output from the **show current 2** command. It displays only VLAN 2 of the current database.

```
Switch(vlan)# show current 2
```

```
VLAN ISL Id: 2
  Name: VLAN0002
  Media Type: Ethernet
  VLAN 802.10 Id: 100002
  State: Operational
  MTU: 1500
```

#### Related Commands

Command	Description
<a href="#">show changes</a>	Displays the differences between the VLAN database currently on the switch and the proposed VLAN database.
<a href="#">show proposed</a>	Displays the proposed VLAN database or a selected VLAN from it.

# show diags

Use the **show diags** privileged EXEC command to display the current state of a port or all ports on the switch.

**show diags** [**addr-move** | **link-flap**] *interface-id*

Syntax Description	<b>addr-move</b>	Show learned address movement count and rate.
	<b>link-flap</b>	Show link up/down count and rate.
	<i>interface-id</i>	ID of the Fast Ethernet or LRE port number.

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	12.0(5)XU	This command was first introduced.

**Usage Guidelines**

Using the **show diags** command without specifying a port shows the state of all ports on the switch.

Use the **show diags link-flap** command to check if link flapping on a port is occurring. Link flapping can be caused by a loose connection to a port or by numerous changes to a port connection.

Use the **show diags addr-move** command to check if address flapping is occurring. Address flapping can be caused when the switch learns the same MAC address on different ports on the same VLAN. The address table keeps changing because the MAC address is first learned on one interface, is learned on another interface, and then relearned on the previous interface, and so on. This can be caused by a loop in the switch that STP has not blocked.

**Examples**

The following is sample output from the **show link-flap** command.

```
Switch# show diags link-flap fa0/1
Interface                Total    Last Min
-----
FastEthernet0/1          14       0
FastEthernet0/2          12       0
FastEthernet0/3           1       0
FastEthernet0/7           6       0
FastEthernet0/12          6       0
```

# show env

Use the **show env** privileged EXEC command to display fan and temperature information for the 3524-PWR-XL switch.

**show env {all | fan | temperature}**

## Syntax Description

<b>all</b>	Display both fan and temperature environmental status.
<b>fan</b>	Display the switch fan status.
<b>temperature</b>	Display the switch temperature status.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Examples

The following is sample output from the **show env all** command:

```
Switch# show env all
FAN 1 is OK

FAN 2 is OK

FAN 3 is OK

FAN 4 is OK

FAN 5 is OK

TEMPERATURE is OK
```

The following is sample output from the **show env fans** command:

```
FAN 1 is OK

FAN 2 is OK

FAN 3 is OK

FAN 4 is FAULTY

FAN 5 is OK
```



# show file systems

Use the **show file systems** privileged EXEC command to display file system information.

**show file systems**

<b>Syntax Description</b>	The command has no arguments or keywords.
---------------------------	---

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA5	This command was first introduced.

<b>Examples</b>	The following is sample output from the <b>show file systems</b> command:
-----------------	---

```
Switch# show file systems
File Systems:
```

	Size(b)	Free(b)	Type	Flags	Prefixes
*	3612672	1234432	flash	rw	flash:
	3612672	1234432	unknown	rw	zflash:
	-	-	opaque	ro	bs:
	32768	30917	nvr	rw	nvr:
	-	-	network	rw	tftp:
	-	-	opaque	rw	null:
	-	-	opaque	rw	system:
	-	-	network	rw	rcp:

# show interface

Use the **show interface** privileged EXEC command to display the administrative and operational status of a switching (nonrouting) port.

**show interface** [*interface-id* | **vlan number**] [**flow-control** | **pruning** | **status** | **switchport** [**allowed-vlan** | **prune-elig** | **native-vlan**]]

Syntax Description	
<i>interface-id</i>	ID of the module and port.
<b>vlan number</b>	VLAN number of the management VLAN. Valid IDs are from 1 to 1000. Do not enter leading zeroes.
<b>flow-control</b>	Displays flowcontrol information for the specified port.
<b>pruning</b>	(Optional) Display pruning information for the trunk port.
<b>status</b>	(Optional) Display the status of the interface.
<b>switchport</b>	(Optional) Display the administrative and operational status of a switching (nonrouting) port. <ul style="list-style-type: none"> <li>• <b>allowed-vlan</b>—Display the VLAN IDs that receive and transmit all types of traffic on the trunk port. By default, all VLAN IDs are included.</li> <li>• <b>prune-elig</b>—Display the VLAN ID whose flood traffic can be pruned. By default, all VLANs, except VLAN 1 and 1002 through 1005, are pruning-eligible on the trunk.</li> <li>• <b>native-vlan</b>—Display the native VLAN ID for untagged traffic when the port is in 802.1Q trunking mode.</li> </ul>

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.
	11.2(8)SA5	The <b>native-vlan</b> keyword was added.
	12.0(5)XP	The <b>vlan number</b> keyword was added.
	12.0(5)XU	The <b>pruning</b> keyword was added.
	12.0(5)XW	The <b>status</b> keyword was added.

**Examples**

The following is sample output from the **show interface gi0/1 flow-control** command.

```
Switch# show interface gi0/1 flow-control
Any, Input only
```

The display shows two values separated by a comma. The first value is the value you configured by using the **flowcontrol** command or through the Cluster Management Suite (or the default value if you did not configure it). The first value displayed can be one of the following settings:

- None—Flow control is not enabled.
- Asymmetric—Only the transmit or receive flow control is enabled.
- Symmetric—Both the transmit and receive flow control are enabled.
- Any—Any type of flow control is supported.

The second value in the display represents the flow control value that is autonegotiated with the link partner and can be one of the following settings:

- None—Flow control with the link partner does not occur.
- Output only—The interface can only transmit pause frames but not receive any.
- Input only—The interface can only receive pause frames but not transmit any.
- Output and Input—The interface can transmit and receive pause frames.

**Note**

If you execute the **show interface *interface-id* flow-control** command on a GigaStack Gigabit Interface Converter (GBIC), the first value in the display is the setting for both GigaStack GBIC ports, and the second value is the autonegotiated setting for both ports.

The following is sample output from the **show interface fa0/2 switchport** command. [Table 2-2](#) describes each field in the display.

```
Switch# show interface fa0/2 switchport
Name: fa0/2
Switchport: Enabled
Administrative Mode: Trunk
Operational Mode: Trunk
Administrative Trunking Encapsulation: ISL
Operational Trunking Encapsulation: ISL
Negotiation of Trunking: Disabled
Access Mode VLAN: 0 (inactive)
Trunking Native Mode VLAN: 1 (default)
Trunking VLANs Enabled: 1-30, 50, 100-1005
Trunking VLANs Active: 1-4
Pruning VLANs Enabled: 2-1001

Priority for untagged frames: 0
Voice VLAN: none
Appliance trust: none
```

**Table 2-2 Show Interface fa0/2 Switchport Field Descriptions**

Field	Description
Name	Displays the port name.
Switchport	Displays the administrative and operational status of the port. In this display, the port is in switchport mode.
Administrative Mode Operational Mode	Displays the administrative and operational mode.
Administrative Trunking Encapsulation Operation Trunking Encapsulation Negotiation of Trunking	Displays the administrative and operational encapsulation method. Also displays whether trunking negotiation is enabled.
Access Mode VLAN	Displays the VLAN ID to which the port is configured.
Trunking Native Mode VLAN Trunking VLANs Enabled Trunking VLANs Active	Lists the VLAN ID of the trunk that is in native mode. Lists the allowed VLANs on the trunk. Lists the active VLANs on the trunk.
Pruning VLANs Enabled	Lists the VLANs that are pruning-eligible.
Priority for untagged frames	Displays the port priority on incoming untagged frames.
Voice VLAN	Displays the voice VLAN.
Appliance trust	Displays how the appliance (telephone) connected to the specified port handles priority traffic received on its incoming port.

The following is sample output from the **show interface fa0/9 pruning** command when pruning is enabled in the VTP domain:

```
Switch# show interface fa0/9 pruning
Port      Vlans pruned for lack of request by neighbor
Fa0/9     3,4

Port      Vlans traffic requested of neighbor
Fa0/9     1-3
```

The following is sample output from the **show interface status** command:

```
Switch# show interface status
Port      Name              Status      Vlan      Duplex  Speed  Type
-----
Fa0/1     connected         trunk       A-Full    A-100   100BASE-TX/FX
Fa0/2     notconnect        1           Auto      Auto    100BASE-TX/FX
Fa0/3     notconnect        1           Auto      Auto    100BASE-TX/FX
Fa0/4     notconnect        1           Auto      Auto    100BASE-TX/FX
Fa0/5     notconnect        1           Auto      Auto    100BASE-TX/FX
Fa0/6     notconnect        1           Auto      Auto    100BASE-TX/FX
Fa0/7     notconnect        1           Auto      Auto    100BASE-TX/FX
Fa0/8     notconnect        1           Auto      Auto    100BASE-TX/FX
Fa0/9     notconnect        1           Auto      Auto    100BASE-TX/FX
<output truncated>
```

Related Commands	Command	Description
	<a href="#">switchport access</a>	Configures a port as a static-access or dynamic-access port.
	<a href="#">switchport mode</a>	Configures the VLAN membership mode of a port.
	<a href="#">switchport multi</a>	Configures a list of VLANs to which the port is associated.
	<a href="#">switchport priority default</a>	Provides a default port priority for the incoming untagged frames.
	<a href="#">switchport trunk pruning</a>	Configures the VLAN pruning-eligible list for ports in trunking mode.
	<a href="#">switchport voice vlan</a>	Configures the voice VLAN on the port.

# show mac-address-table

Use the **show mac-address-table** privileged EXEC command to display the MAC address table.

**show mac-address-table** [**static** | **dynamic** | **secure** | **self** | **aging-time** | **count**]  
 [**address** *hw-addr*] [**interface** *interface*] [**atm** *slot/port*] [**vlan** *vlan-id*]

## Syntax Description

<b>static</b>	(Optional) Display only the static addresses.
<b>dynamic</b>	(Optional) Display only the dynamic addresses.
<b>secure</b>	(Optional) Display only the secure addresses.
<b>self</b>	(Optional) Display only addresses added by the switch itself.
<b>aging-time</b>	(Optional) Display aging-time for dynamic addresses for all VLANs.
<b>count</b>	(Optional) Display a count for different kinds of MAC addresses.
<b>address</b> <i>hw-addr</i>	(Optional) Display information for a specific address.
<b>interface</b> <i>interface</i>	(Optional) Display addresses for a specific port.
<b>atm</b> <i>slot/port</i>	(Optional) Add dynamic addresses to ATM module <i>slot/port</i> . Use 1 or 2 for the slot number. Use 0 as the port number.
<b>vlan</b> <i>vlan-id</i>	(Optional) Display addresses for a specific VLAN. Valid IDs are from 1 to 1005; do not enter leading zeroes.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.
11.2(8)SA3	The <b>self</b> , <b>aging-time</b> , <b>count</b> , and <b>vlan</b> <i>vlan-id</i> keywords were added.
11.2(8)SA5	The <b>atm</b> <i>slot/port</i> keywords were added.

## Usage Guidelines

This command displays the MAC address table for the switch. Specific views can be defined by using the optional keywords and values. If more than one optional keyword is used, then all of the conditions must be true in order for that entry to be displayed.

## Examples

The following is sample output from the **show mac-address-table** command:

```
Switch# show mac-address-table
```

```
Dynamic Addresses Count:          9
Secure Addresses (User-defined) Count: 0
Static Addresses (User-defined) Count: 0
System Self Addresses Count:      41
Total MAC addresses:              50
Non-static Address Table:
Destination Address  Address Type  VLAN  Destination Port
-----
0010.0de0.e289      Dynamic      1     FastEthernet0/1
```

```

0010.7b00.1540      Dynamic      2    FastEthernet0/5
0010.7b00.1545      Dynamic      2    FastEthernet0/5
0060.5cf4.0076      Dynamic      1    FastEthernet0/1
0060.5cf4.0077      Dynamic      1    FastEthernet0/1
0060.5cf4.1315      Dynamic      1    FastEthernet0/1
0060.70cb.f301      Dynamic      1    FastEthernet0/1
00e0.1e42.9978      Dynamic      1    FastEthernet0/1
00e0.1e9f.3900      Dynamic      1    FastEthernet0/1

```

#### Related Commands

Command	Description
<a href="#">clear mac-address-table</a>	Deletes entries from the MAC address table.

# show mvr

Use the **show mvr** privileged EXEC command without keywords to display the current MVR global parameter values, including whether or not MVR is enabled, the maximum query response time, and the multicast VLAN number.

**show mvr**

**Syntax Description** This command has no keywords.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	12.0(5)XW	This command was first introduced.

**Examples** The following example shows how to view the MVR global parameter values:

```
Switch# show mvr
MVR Enabled
MVR multicast vlan: 2
MVR Current multicast groups: 1
MVR Global query response time: 100 (tenths of sec)
```

Related Commands	Command	Description
	<a href="#">show mvr interface</a>	Displays the configured MVR interfaces or displays the multicast groups to which a receiver port belongs.
	<a href="#">show mvr members</a>	Displays all receiver ports that are members of an MVR multicast group.
	<a href="#">mvr</a> (global configuration mode)	Enables and configures multicast VLAN registration on the switch.
	<a href="#">mvr type</a> (interface configuration mode)	Configures MVR ports.



# show mvr interface

Use the **show mvr interface** privileged EXEC command without keywords to display the MVR receiver and source ports. Use the command with keywords to display MVR parameters for a specific receiver port.

**show mvr interface** [*interface-id* [**members** [**vlan** *vlan-id*]]]

## Syntax Description

<i>interface-id</i>	(Optional) Enter a receiver port identification to display parameters for the specified port.
<b>members</b>	(Optional) Display all MVR groups that the specified receive port is a member of.
<b>vlan</b> <i>vlan-id</i>	(Optional) Display the VLAN to which the receiver port belongs.

## Usage Guidelines

If the entered port identification is a non-MVR port or a source port, the command returns an error message. For receiver ports, it displays the port type and per port parameters, such as maximum threshold and immediate-leave setting.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
12.0(5)XW	This command was first introduced.

## Examples

The following example shows how to display all MVR interfaces:

```
Switch# show mvr interface
MVR PORTS
Port: Fa0/1 Type: RECEIVER Status: ACTIVE
Port: Fa0/2 Type: RECEIVER Status: ACTIVE
Port: Fa0/3 Type: SOURCE Status: ACTIVE
```

The following example shows how to view the MVR parameters for Fast Ethernet port 0/1:

```
Switch# show mvr interface fastethernet 0/1
Interface: Fa0/1
  Threshold: 20
  Immediate Leave: Disabled
  Multicast packets received: 13
```

The following example shows the response displayed when the entered port is not a receiver port:

```
Switch# show mvr fastethernet 0/3
Sorry, Cannot display parameter information for non-receiver port
```

Related Commands	Command	Description
	<b>show mvr</b>	Displays the global MVR configuration on the switch.
	<b>show mvr members</b>	Displays all receiver ports that are members of an MVR multicast group.
	<b>mvr</b> (global configuration mode)	Enables and configures multicast VLAN registration on the switch.
	<b>mvr type</b> (interface configuration mode)	Configures MVR ports.

# show mvr members

Use the **show mvr members** privileged EXEC command to display all receiver ports that are members of an IP multicast group.

**show mvr members** [*ip-address*]

<b>Syntax Description</b>	<i>ip-address</i>	(Optional) The IP multicast address. If the address is entered, all receiver ports that are members of the multicast group are displayed. If no address is entered, all members of all MVR groups are listed.
---------------------------	-------------------	---

<b>Usage Guidelines</b>	The <b>show mvr members</b> command only applies to receiver ports. All source ports are members of all multicast groups.
-------------------------	---

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(5)XW	This command was first introduced.

**Examples** The following example shows how to view the members of any IP multicast group:

```
Switch# show mvr members
MVR Group IP:239.255.0.1
    Vlan 2 Interface:Fa0/16 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/17 DYNAMIC ACTIVE

MVR Group IP:239.255.0.2
    Vlan 2 Interface:Fa0/15 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/17 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/20 DYNAMIC ACTIVE

MVR Group IP:239.255.0.3
    Vlan 2 Interface:Fa0/23 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/16 DYNAMIC ACTIVE

MVR Group IP:239.255.0.4
    Vlan 2 Interface:Fa0/26 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/16 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/23 DYNAMIC ACTIVE

MVR Group IP:239.255.0.5
    Vlan 2 Interface:Fa0/15 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/14 DYNAMIC ACTIVE

MVR Group IP:239.255.0.6
    Vlan 2 Interface:Fa0/17 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/18 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/20 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/23 DYNAMIC ACTIVE
    Vlan 2 Interface:Fa0/15 DYNAMIC ACTIVE
```

The following example shows how to view the members of the IP multicast group 239.255.0.4:

```
Switch# show mvr members 239.255.0.4
MVR Group IP:239.255.0.4
      Vlan 2 Interface:Fa0/26 DYNAMIC ACTIVE
      Vlan 2 Interface:Fa0/16 DYNAMIC ACTIVE
      Vlan 2 Interface:Fa0/23 DYNAMIC ACTIVE
```

#### Related Commands

Command	Description
<a href="#">show mvr</a>	Displays the global MVR configuration on the switch.
<a href="#">show mvr interface</a>	Displays the configured MVR interfaces or displays the multicast groups to which a receiver port belongs.
<a href="#">mvr</a> (global configuration mode)	Enables and configures multicast VLAN registration on the switch.
<a href="#">mvr type</a> (interface configuration mode)	Configures MVR ports.

# show ntp associations

Use the **show ntp associations** privileged EXEC command to display the status of Network Time Protocol (NTP) associations.

**show ntp associations [detail]**

Syntax Description	detail	(Optional) Show detailed information about each NTP association.
--------------------	--------	--

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	11.2(8)SA6	This command was first introduced.

**Examples** Detailed descriptions of the information displayed by this command can be found in the NTP specification RFC 1305.

The following is sample output from the **show ntp associations** command:

```
Switch# show ntp associations
      address          ref clock      st  when  poll reach  delay  offset  disp
~160.89.32.2          160.89.32.1      5   29  1024  377    4.2   -8.59   1.6
+~131.108.13.33       131.108.1.111     3   69   128  377    4.1    3.48   2.3
*~131.108.13.57       131.108.1.111     3   32   128  377    7.9   11.18   3.6
* master (syncd), # master (unsyncd), + selected, - candidate, ~ configured
```

# show ntp status

Use the **show ntp status** EXEC command to display the status of Network Time Protocol (NTP).

**show ntp status**

---

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

---

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

---

---

<b>Usage Guidelines</b>	This command deletes entries from the global MAC address table. Specific subsets can be deleted by using the optional keywords and values. If more than one optional keyword is used, all of the conditions in the argument must be true for that entry to be deleted.
-------------------------	--

---

<b>Examples</b>	The following is sample output from the <b>show ntp status</b> command:
-----------------	---

```
Switch# show ntp status
Clock is synchronized, stratum 4, reference is 131.108.13.57
nominal freq is 250.0000 Hz, actual freq is 249.9990 Hz, precision is 2**19
reference time is AFE2525E.70597B34 (00:10:22.438 PDT Mon Jul 5 1993)
clock offset is 7.33 msec, root delay is 133.36 msec
root dispersion is 126.28 msec, peer dispersion is 5.98 msec
```

# show port block

Use the **show port block** privileged EXEC command to display the blocking of unicast or multicast flooding to a port.

**show port block** { **unicast** | **multicast** } [*interface-id* | **vlan** *number*]

## Syntax Description

<b>unicast</b>	Display whether or not ports are blocking unicast packets.
<b>multicast</b>	Display whether or not ports are blocking multicast packets.
<i>interface-id</i>	(Optional) ID of the module and port.
<b>vlan</b> <i>number</i>	(Optional) VLAN number from 1 to 1000. Do not enter leading zeroes.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.

## Usage Guidelines

If the variable *interface* is omitted, the **show port block unicast** and **show port block multicast** commands display packet blocking information on all ports.

## Examples

The following is sample output from the **show port block** command:

```
Switch# show port block unicast fa0/8
```

```
FastEthernet0/8 is blocked from unknown unicast addresses
```

## Related Commands

Command	Description
<a href="#">port block</a>	Blocks the flooding of unknown unicast or multicast packets to a port.

# show port group

Use the **show port group** privileged EXEC command to display the ports that belong to a port group.

**show port group** [*group-number*]

<b>Syntax Description</b>	<i>group-number</i> (Optional) Port group to which the port is assigned.	
<b>Command Modes</b>	Privileged EXEC	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA3	This command was first introduced.
<b>Usage Guidelines</b>	If the variable <i>group-number</i> is omitted, the <b>show port group</b> command displays all port groups on the switch.	
<b>Examples</b>	<p>The following is sample output from the <b>show port group</b> command:</p> <pre>Switch# show port group 1  Group  Interface -----  -       1  FastEthernet0/1       1  FastEthernet0/4</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">port group</a>	Assigns a port to a Fast EtherChannel or Gigabit EtherChannel port group.



# show port monitor

Use the **show port monitor** privileged EXEC command to display the ports for which Switched Port Analyzer (SPAN) port monitoring is enabled.

**show port monitor** [*interface-id* | **vlan** *number*]

## Syntax Description

<i>interface-id</i>	(Optional) ID of the module and port enabled for SPAN.
<b>vlan</b> <i>number</i>	(Optional) VLAN number from 1 to 1000. Do not enter leading zeroes.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.

## Usage Guidelines

If the variable *interface* is omitted, the **show port monitor** command displays all monitor ports on the switch.

## Examples

The following is sample output from the **show port monitor** command:

```
Switch# show port monitor fa0/8
```

```
Monitor Port      Port Being Monitored
-----
FastEthernet0/8   FastEthernet0/1
FastEthernet0/8   FastEthernet0/2
FastEthernet0/8   FastEthernet0/3
FastEthernet0/8   FastEthernet0/4
```

## Related Commands

Command	Description
<a href="#">port monitor</a>	Enables SPAN port monitoring on a port.

# show port network

Use the **show port network** privileged EXEC command to display the network port defined for the switch or VLAN.

**show port network** [*interface-id* | **vlan** *number*]

## Syntax Description

<i>interface-id</i>	(Optional) ID of the module and port.
<b>vlan</b> <i>number</i>	(Optional) VLAN number from 1 to 1000. Do not enter leading zeroes.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Usage Guidelines

If the variable *interface* is omitted, the **show port network** command displays all network ports on the switch.

## Examples

The following is sample output from the **show port network** command:

```
Switch# show port network

Network Port      VLAN ID
-----
FastEthernet0/11  1
```

## Related Commands

Command	Description
<b>port network</b>	Defines a port as the switch network port. All traffic with unknown unicast addresses is forwarded to the network port on the same VLAN.

# show port protected

Use the **show port protected** privileged EXEC command to display the port protected mode for all ports.

**show port protected**

<b>Syntax Description</b>	This command has no keywords or options
---------------------------	---

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	Release	Modification
	12.0(5)XU	This command was first introduced.

<b>Examples</b>	The following is sample output from the <b>show port protected</b> command:
-----------------	---

```
Switch# show port protected

FastEthernet0/3 is in protected mode
GigabitEthernet1/1 is in protected mode
```

<b>Related Commands</b>	Command	Description
	<a href="#">port protected</a>	Isolates unicast, multicast, and broadcast traffic at Layer 2 from other protected ports on the same switch.

# show port security

Use the **show port security** privileged EXEC command to display the port security settings defined for the port.

**show port security** [*interface-id* | **vlan number**]

## Syntax Description

<i>interface-id</i>	(Optional) ID of the module and port.
<b>vlan number</b>	(Optional) VLAN number from 1 to 1000. Do not enter leading zeroes.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.

## Usage Guidelines

If the variable *interface* is omitted, the **show port security** command displays all secure ports on the switch.

## Examples

The following is sample output from the **show port security** command for fixed port 07:

Switch# **show port security fa0/7**

Secure Port	Secure Addr Cnt (Current)	Secure Addr Cnt (Max)	Security Reject Cnt	Security Action
-----	-----	-----	-----	-----
FastEthernet0/7	0	132	0	Send Trap

## Related Commands

Command	Description
<a href="#">port security</a>	Enables port security on a port.

# show port storm-control

Use the **show port storm-control** privileged EXEC command to display the packet-storm control information. This command also displays the action that the switch takes when the thresholds are reached.

**show port storm-control** [*interface*] [{**broadcast** | **multicast** | **unicast** | **history**}]

<b>Syntax Description</b>	<i>interface</i>	(Optional) Port for which information is to be displayed.
	<b>broadcast</b>	(Optional) Display broadcast storm information.
	<b>multicast</b>	(Optional) Display multicast storm information.
	<b>unicast</b>	(Optional) Display unicast storm information.
	<b>history</b>	(Optional) Display storm history on a per-port basis.

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA	This command was first introduced.
	12.0(5)XU	The <b>broadcast</b> , <b>multicast</b> , <b>unicast</b> , and <b>history</b> keywords were added.

<b>Usage Guidelines</b>	If the variable <i>interface</i> is omitted, the <b>show port storm-control</b> command displays storm control settings on all ports on the switch.
	You can display broadcast, multicast, or unicast packet-storm information by using the corresponding keyword.

<b>Examples</b>	The following is sample output from the <b>show port storm-control</b> command:
-----------------	---

Switch# **show port storm-control**

Interface	Filter State	Trap State	Rising	Falling	Current	Traps Sent
-----	-----	-----	-----	-----	-----	-----
Fa0/1	<inactive>	<inactive>	1000	200	0	0
Fa0/2	<inactive>	<inactive>	500	250	0	0
Fa0/3	<inactive>	<inactive>	500	250	0	0
Fa0/4	<inactive>	<inactive>	500	250	0	0

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">port storm-control</a>	Enables broadcast, multicast, or unicast storm control on a port.

# show power inline

Use the **show power inline** privileged EXEC command to display the power status for the specified port or for all ports on the 3524-PWR-XL switch.

**show power inline** [*interface-id*] [**actual** | **configured**]

<b>Syntax Description</b>	<i>interface-id</i>	(Optional) ID of the module and port.
	<b>actual</b>	(Optional) Display the current power status, which might not be the same as the configured power.
	<b>configured</b>	(Optional) Display the configured power status.

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(5)XU	This command was first introduced.

**Examples** The following is sample output from the **show power inline fa0/4 actual** command:

```
Switch# show power inline fa0/4 actual
Interface              Power
-----
FastEthernet0/4       no
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">power inline</a>	Determines how inline power is applied to devices on the specified Fast Ethernet port of the 3524-PWR-XL switch.

# show proposed

Use the **show proposed** VLAN database command to display the proposed VLAN database or a selected VLAN from it.

**show proposed** [*vlan-id*]

## Syntax Description

<i>vlan-id</i>	(Optional) ID of the VLAN in the proposed database. If this variable is omitted, the entire VLAN database displays, included the pruning state and Version 2 mode. Valid IDs are from 1 to 1005; do not enter leading zeroes.
----------------	---

## Command Modes

VLAN database

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Usage Guidelines

If the variable *vlan-id* is omitted, the **show proposed** command displays the entire proposed VLAN database.

The proposed VLAN database is not the running configuration until you use the **exit** or **apply** command.

## Examples

The following is sample output from the **show proposed** command:

```
Switch(vlan)# show proposed

VLAN ISL Id: 1
  Name: default
  Media Type: Ethernet
  VLAN 802.10 Id: 100001
  State: Operational
  MTU: 1500
  Translational Bridged VLAN: 1002
  Translational Bridged VLAN: 1003

VLAN ISL Id: 2
  Name: VLAN0002
  Media Type: FDDI Net
  VLAN 802.10 Id: 100002
  State: Operational
  MTU: 1500
  STP Type: IBM

VLAN ISL Id: 1002
  Name: fddi-default
  Media Type: FDDI
  VLAN 802.10 Id: 101002
  State: Operational
  MTU: 1500
  Bridge Type: SRB
  Translational Bridged VLAN: 1
  Translational Bridged VLAN: 1003
```

## show proposed

```
VLAN ISL Id: 1003
  Name: trcrf-default
  Media Type: TRCRF
  VLAN 802.10 Id: 101003
  State: Operational
  MTU: 4472
  Bridge Type: SRB
  Ring Number: 3276
  Bridge Number: 1
  Parent VLAN: 1005
  Maximum ARE Hop Count: 7
  Maximum STE Hop Count: 7
  Backup CRF Mode: Disabled
  Translational Bridged VLAN: 1
  Translational Bridged VLAN: 1002
```

```
VLAN ISL Id: 1004
  Name: fddinet-default
  Media Type: FDDI Net
  VLAN 802.10 Id: 101004
  State: Operational
  MTU: 1500
  Bridge Type: SRB
  Bridge Number: 1
  STP Type: IBM
```

```
VLAN ISL Id: 1005
  Name: trbrf-default
  Media Type: TRBRF
  VLAN 802.10 Id: 101005
  State: Operational
  MTU: 4472
  Bridge Type: SRB
  Bridge Number: 15
  STP Type: IBM
```

### Related Commands

Command	Description
<a href="#">show changes</a>	Displays the differences between the VLAN database currently on the switch and the proposed VLAN database.
<a href="#">show current</a>	Displays the current VLAN database on the switch or a selected VLAN from it.



# show rps

Use the **show rps** privileged EXEC command to display the status of the Cisco Redundant Power System (RPS).

**show rps**

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	12.0(5)XU	This command was first introduced.

**Examples** The following is sample output from the **show rps** command. [Table 2-3](#) describes the possible display output.

```
Switch# show rps
ACTIVATED
```

**Table 2-3 Show RPS Display Output Description**

Display	Description	Switch RPS LED Color
NA	The RPS is off or not installed.	Off (all switch and RPS models)
ACTIVATED	The internal power supply of the switch is down. The switch is operating through the RPS.	Blinking amber (3524-PWR switch connected to RPS 300)  Solid green (all Catalyst 2900 XL and Catalyst 3500 XL switches, except the 3524-PWR, connected to the Cisco RPS)
DEACTIVATED	The RPS is connected, operational, and in standby mode. The switch is operating from its own internal power supply.	Solid green (3524-PWR switch connected to RPS 300)  Blinking green (all Catalyst 2900 XL and Catalyst 3500 XL switches, except the 3524-PWR, connected to the Cisco RPS)
FAULTY	The RPS is connected but not operating correctly (faulty). One of the power supplies in the RPS could be powered down or a fan on the RPS could have failed.	Solid amber (all switch and RPS models)
NOT AVAILABLE (only for 3524-PWR switch)	The RPS is backing up another switch; power redundancy is lost.	Blinking green (3524-PWR switch connected to RPS 300)

# show spanning-tree

Use the **show spanning-tree** privileged EXEC command to display spanning-tree information for the specified spanning-tree instances.

**show spanning-tree** [**brief**] | [**summary**] | [**vlan** *stp-list*] | [**interface** *interface-list*]

<b>Syntax Description</b>	<b>brief</b>	Display a brief status of the spanning tree.
	<b>summary</b>	Display a summary of the spanning-tree states.
	<b>vlan</b> <i>stp-list</i>	(Optional) List of spanning-tree instances. Each spanning-tree instance is associated with a VLAN ID. Enter each VLAN ID separated by a space. Valid IDs are from 1 to 1005; do not enter leading zeroes. Ranges are not supported.
	<b>interface</b> <i>interface-list</i>	List of ports for which spanning-tree information is displayed. Enter each port separated by a space. Ranges are not supported.

**Command Modes** Privileged EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA3	This command was first introduced.
	12.0(5)XW	The <b>brief</b> and <b>summary</b> keywords were added.

**Usage Guidelines** If the variable *stp-list* is omitted, the command applies to the Spanning Tree Protocol (STP) instance associated with VLAN 1.

**Examples** The following is sample output from the **show spanning-tree** command for VLAN 1:

```
Switch# show spanning-tree vlan 1
Spanning tree 1 is executing the IEEE compatible Spanning Tree protocol
Bridge Identifier has priority 49152, address 00b0.6476.08c0
Configured hello time 2, max age 20, forward delay 15
Current root has priority 32768, address 0001.42cd.a200
Root port is 31, cost of root path is 42
Topology change flag not set, detected flag not set, changes 1
Times: hold 1, topology change 35, notification 2
      hello 2, max age 20, forward delay 15
Timers: hello 0, topology change 0, notification 0
Fast uplink switchover is enabled
Stack port is GigabitEthernet0/1

Interface Fa0/1 (port 13) in Spanning tree 1 is down
Port path cost 3100, Port priority 128
Designated root has priority 32768, address 0001.42cd.a200
Designated bridge has priority 49152, address 00b0.6476.08c0
Designated port is 13, path cost 42
Timers: message age 0, forward delay 0, hold 0
BPDU: sent 0, received 0
<output truncated>
```

The following is sample output from the **show spanning-tree interface** command for port 3:

```
Switch# show spanning-tree interface fa0/3
```

```
Interface Fa0/3 (port 3) in Spanning tree 1 is down
  Port path cost 100, Port priority 128
  Designated root has priority 6000, address 0090.2bba.7a40
  Designated bridge has priority 32768, address 00e0.1e9f.4abf
  Designated port is 3, path cost 410
  Timers: message age 0, forward delay 0, hold 0
  BPDU: sent 0, received 0
```

The following is sample output from the **show spanning-tree summary** command:

```
Switch# show spanning-tree summary
```

```
UplinkFast is enabled
```

```
Stack port is GigabitEthernet0/1
```

Name	Blocking	Listening	Learning	Forwarding	STP Active
VLAN1	13	0	0	1	14
VLAN2	1	0	0	1	2
VLAN3	1	0	0	1	2

<output truncated>

#### Related Commands

Command	Description
<b>spanning-tree</b>	Enables STP on a VLAN.
<b>spanning-tree forward-time</b>	Sets the forwarding-time for the specified spanning-tree instances.
<b>spanning-tree max-age</b>	Changes the interval between messages the spanning tree receives from the root switch.
<b>spanning-tree port-priority</b>	Configures a port priority, which is used when two switches tie for position as the root switch.
<b>spanning-tree protocol</b>	Specifies the STP to be used for specified spanning-tree instances.

# show tacacs

Use the **show tacacs** privileged EXEC command to display various Terminal Access Controller Access Control System Plus (TACACS+) server statistics.

**show tacacs**

<b>Syntax Description</b>	This command has no arguments.
---------------------------	--------------------------------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

<b>Examples</b>	The following is sample output from the <b>show tacacs</b> command:
-----------------	---

```
Switch# show tacacs
```

```
Server:172.20.128.113/49:opens=4 closes=4 aborts=0 errors=0
      packets in=6 packets out=6
      no connection
```

# show udld

Use the **show udld** user EXEC command to display UniDirectional Link Detection (UDLD) status for all ports or the specified port.

**show udld** [*interface-id*]

## Syntax Description

<i>interface-id</i>	(Optional) ID of the module and port or a VLAN ID. Valid IDs are from 1 to 1000.
---------------------	--

## Command Modes

User EXEC

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Examples

The following is sample output from the **show udld fa0/11** command. For this display, UDLD is enabled on both ends of the link, and UDLD detects that the link is bidirectional. [Table 2-4](#) describes the fields in this display.

```
Switch# show udld fa0/11
Interface Fa0/11
Port enable configuration setting: Follows global setting
Operational enable state: Enabled
Current bidirectional state: Bidirectional
Message interval: 60
Message timer: 38
Current operational state: Advertisement
Time out interval: 5
Time out timer: 0
Restart counter: 0
Neighbors counter: 1
Probe counter: 0
No multiple neighbors detected
Current pool id: 1
---
Cache entry 1 (0x69D8E4)
Device name: aunguyen-1.cisco.com
Device MAC address: 00:E0:1E:9F:85:80
Port ID: Fa1/1
Expiration time: 159
Cache device ID: 1
Resynch flag clear
Current neighbor state: Bidirectional
Most recent message type received: Probe
Message interval: 5
    Neighbor echo 1 device: 00:50:0F:08:A4:00
    Neighbor echo 1 port: Fa0/11
```

**Table 2-4 Show Uddld Field Descriptions**

Field	Description
Interface	The interface on the local device configured for UDLD.
Port enable configuration setting	How UDLD is configured on the port. If UDLD is enabled or disabled, the port enable configuration setting is the same as operational enable state. Otherwise, the enable operational setting depends on the global enable setting.
Operational enable state	Operational state that indicates whether UDLD is actually running on this port.
Current bidirectional state	The bidirectional state of the link. An unknown state is displayed if the link is down or if it is connected to an UDLD-incapable device. A bidirectional state is displayed if the link is a normal two-way connection to a UDLD-capable device. All other values indicate miswiring.
Message interval	How often advertisement messages are sent from the local device. Measured in seconds.
Message timer	The length of time before the next advertisement is sent from the local device. Measured in seconds.
Current operational state	The current phase of the UDLD state machine. For a normal bidirectional link, the state machine is most often in the Advertisement phase.
Time out interval	The time period, in seconds, that UDLD waits for echoes from a neighbor device during the detection window.
Time out timer	The remaining time in seconds in the detection window. This setting is meaningful only if UDLD is in the detection phase.
Restart counter	The number of times UDLD sends probe messages in the detection phase.
Neighbors counter	The number of neighbors detected. For point-to-point links, this value should always be one. It is greater than one only when the port is connected to a hub.
Probe counter	The remaining number of probe messages to send in the current detection window. This setting is meaningful only if UDLD is in the detection phase.
Current pool id	An internal index number on the local device.
Cache entry 1	Information from the first cache entry, which contains a copy of echo information received from the neighbor.
Device name	The neighbor device name.
Device MAC address	The neighbor MAC address.
Port ID	The neighbor port ID enabled for UDLD.
Expiration time	The amount of time in seconds remaining before this cache entry is aged out.
Cache device ID	The ID of the cache device.
Resynch flag clear	Indicates that there are no outstanding requests from neighbors to resynchronize cache data.

**Table 2-4 Show Udd Field Descriptions (continued)**

Field	Description
Current neighbor state	The neighbor's current state. If both the local and neighbor devices are running UDLD normally, the neighbor state and local state should be bidirectional. If the link is down or the neighbor is not UDLD-capable, no cache entries are displayed.
Most recent message type received	The type of message received from the neighbor.
Message interval	The rate, in seconds, at which the neighbor is sending advertisement messages.
Neighbor echo 1 device	The MAC address of the neighbors neighbor from which the echo originated.
Neighbor echo 1 port	The port ID of the neighbor from which the echo originated.

#### Related Commands

Command	Description
<b>udd</b>	Enables UDLD on a port.
<b>udd enable</b>	Enables UDLD on all ports on the switch.
<b>udd reset</b>	Resets any interface that has been shut down by UDLD.

# show version

Use the **show version** privileged EXEC command to display version information for the hardware and firmware.

## show version

### Syntax Description

The command has no arguments

### Command Modes

Privileged EXEC

### Command History

Release	Modification
11.2(8)SA	This command was first introduced.

### Examples

The following is sample output from the **show version** command:

```
Switch# show version
```

```
Cisco Internetwork Operating System Technology Software
IOS Technology(tm) C3500XL Software (C3500XL-C3H2S-M), Version 12.0
Copyright (c) 1986-1998 by cisco Systems, Inc.
Compiled Mon 22-Nov-99 10:51 by mollyn
Image text-base: 0x00003000, data-base: 0x0031B6B4
```

```
ROM: Bootstrap program is C3500XL boot loader
```

```
Switch uptime is 1 hour, 32 minutes
System returned to ROM by reload
System image file is "flash:c3500XL-c3h2s-mz-120.0.0.29-XU.bin"
```

```
cisco WS-C3524-XL (PowerPC403) processor (revision 0x01) with 8192K/1024K bytes
of memory.
Processor board ID 0x12, with hardware revision 0x00
Last reset from warm-reset
```

```
Processor is running Enterprise Edition Software
Cluster command switch capable
Cluster member switch capable
24 FastEthernet/IEEE 802.3 interface(s)
2 Gigabit Ethernet/IEEE 802.3 interface(s)
```

```
32K bytes of flash-simulated non-volatile configuration memory.
Base ethernet MAC Address: 00:D0:79:6D:2F:00
Motherboard assembly number: 73-3904-08
Power supply part number: 34-0851-02
Motherboard serial number: FAA03269NLK
Power supply serial number: PHI031200D2
Model revision number: A0
Model number: WS-C3524-XL-A
System serial number: FAA0328K01G
Configuration register is 0xF
```



# show vlan

Use the **show vlan** privileged EXEC command to display the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) in the administrative domain.

**show vlan** [**brief** | **id** *vlan-id* | **name** *vlan-name*]

Syntax Description		
<b>brief</b>	(Optional) Display one line for each VLAN with the VLAN name, status, and its ports	
<b>id</b> <i>vlan-id</i>	(Optional) ID of the VLAN displayed. Valid IDs are from 1 to 1005; do not enter leading zeroes.	
<b>name</b> <i>vlan-name</i>	(Optional) Name of the VLAN displayed. The VLAN name is an ASCII string from 1 to 32 characters.	

Command Modes	Privileged EXEC
---------------	-----------------

Command History	Release	Modification
	11.2(8)SA3	This command was first introduced.
	11.2(8)SA4	The <b>name</b> <i>vlan-name</i> keywords were added.

## Examples

The following is sample output from the **show vlan** command:

```
Switch# show vlan
VLAN Name                Status    Ports
-----
1    default                active    Fa0/1, Fa0/2, Fa0/3, Fa0/4,
                                   Fa0/5, Fa0/6, Fa0/7, Fa0/8,
                                   Fa0/9, Fa0/10, Fa0/11, Fa0/12,
                                   Fa0/13, Fa0/14, Fa0/15, Fa0/16,
                                   Fa0/17, Fa0/18, Fa0/19, Fa0/20,
                                   Fa0/21, Fa0/22, Fa0/23, Fa0/24,
                                   Gi0/1, Gi0/2
1002 fddi-default          active
1003 token-ring-default    active
1004 fddinet-default       active
1005 trnet-default         active

VLAN Type  SAID      MTU    Parent RingNo BridgeNo Stp    Trans1 Trans2
-----
1    enet  100001    1500   -      -      -      -      1002  1003
6    fdnet 100006    1500   -      -      -      ieee  0      0
7    trnet 100007    1500   -      -      5      ieee  0      0
1002 fddi  101002    1500   -      -      -      -      1      1003
1003 tr   101003    1500   1005   3276   -      -      1      1002
1004 fdnet 101004    1500   -      -      1      ibm    0      0
1005 trnet 101005    1500   -      -      15     ibm    0      0
```

The following is sample output from the **show vlan brief** command:

```
Switch# show vlan brief

VLAN Name                Status    Ports
```

```

-----
1    default                                active    Fa0/1, Fa0/2, Fa0/5, Fa0/6,
                                           Fa0/7, Fa0/8, Fa0/9, Fa0/10,
                                           Fa0/11, Fa0/12, Fa0/13, Fa0/14,
                                           Fa0/15, Fa0/16, Fa1/1, Fa1/2,
                                           Fa1/3, Fa1/4, Fa2/3, Fa2/4

2    VLAN0002                                active
3    VLAN0003                                active
6    VLAN0006                                active
7    VLAN0007                                active
1002 fddi-default                            active
1003 token-ring-default                      active
1004 fddinet-default                        active
1005 trnet-default                          active

```

The following is sample output from the **show vlan id 6** or **show vlan name VLAN006** command:

Switch# **show vlan id 6**

```

VLAN Name                                Status   Ports
-----
6    VLAN0006                                active

VLAN Type  SAID      MTU    Parent RingNo BridgeNo Stp    Trans1 Trans2
-----
6    fdnet 100006  1500    -      -      -      ieee 0      0

```

#### Related Commands

Command	Description
<a href="#">switchport mode</a>	Configures the VLAN membership mode of a port.
<a href="#">vlan</a>	Configures VLAN characteristics.

# show vmps

Use the **show vmps** privileged EXEC command to display the VLAN Query Protocol (VQP) version, reconfirmation interval, retry count, VLAN Membership Policy Server (VMPS) IP addresses, and the current and primary servers.

## show vmps

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

<b>Examples</b>	The following is sample output from the <b>show vmps</b> command:
-----------------	---

```
Switch# show vmps

VQP Client Status:
-----
VMPS VQP Version: 1
Reconfirm Interval: 60 min
Server Retry Count: 3
VMPS domain server: 172.20.128.86 (primary, current)
                   172.20.128.87

Reconfirmation status
-----
VMPS Action:          No Dynamic Port
```

Related Commands	Command	Description
	<b>vmpls reconfirm (Privileged EXEC) and vmps reconfirm (Global Configuration)</b>	Sends VQP queries to reconfirm all dynamic VLAN assignments with the VMPS.
	<b>vmps retry</b>	Configures the per-server retry count for the VQP client.
	<b>vmps server</b>	Configures the primary VMPS and up to three secondary servers.

# show vmps statistics

Use the **show vmps statistics** privileged EXEC command to display the VLAN Query Protocol (VQP) client-side statistics and counters.

**show vmps statistics**

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

**Examples** The following is sample output from the **show vmps statistics** command. [Table 2-5](#) describes each field in the display.

```
Switch# show vmps statistics
```

```
VMPS Client Statistics
```

```
-----
```

```
VQP  Queries:           0
VQP  Responses:         0
VMPs  Changes:          0
VQP  Shutdowns:         0
VQP  Denied:            0
VQP  Wrong Domain:      0
VQP  Wrong Version:     0
VQP  Insufficient Resource: 0
```

**Table 2-5 Show VMPS Statistics Field Descriptions**

Field	Description
VQP Queries	Number of queries sent by the client to the VLAN Membership Policy Server (VMPS).
VQP Responses	Number of responses sent to the client from the VMPS.
VMPS Changes	Number of times that the VMPS changed from one server to another.
VQP Shutdowns	Number of times the VMPS sent a response to shutdown the port. The client disables the port and removes all dynamic addresses on this port from the address table. You must administratively reenable the port to restore connectivity.
VQP Denied	Number of times the VMPS denied the client request for security reasons. When the VMPS response says to deny an address, no frame is forwarded to or from the workstation with that address (broadcast or multicast frames are delivered to the workstation if the port has been assigned to a VLAN). The client keeps the denied address in the address table as a blocked address to prevent further queries from being sent to the VMPS for each new packet received from this workstation. The client ages the address if no new packets are received from this workstation on this port within the aging time period.
VQP Wrong Domain	Number of times the management domain in the request does not match the one for the VMPS. Any previous VLAN assignments of the port are not changed. Receipt of this response indicates that the server and the client have not been configured with the same VTP management domain.
VQP Wrong Version	Number of times the version field in the query packet contains a value that is higher than the version supported by the VMPS. Previous VLAN assignment of the port is not changed. The switches send only VMPS version 1 requests.
VQP Insufficient Resource	Number of times the VMPS is unable to answer the request because of a resource availability problem. If the retry limit has not yet been reached, the client repeats the request with the same server or with the next alternate server, depending on whether the per-server retry count has been reached.

**Related Commands**

Command	Description
<a href="#">clear vmps statistics</a>	Clears the statistics maintained by the VQP client.

# show vtp

Use the **show vtp** privileged EXEC command to display general information about the VLAN Trunk Protocol (VTP) management domain, status, and counters.

**show vtp {counters | status}**

## Syntax Description

<b>counters</b>	Display the VTP counters for the switch.
<b>status</b>	Display general information about the VTP management domain.

## Command Modes

Privileged EXEC

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Examples

The following is sample output from the **show vtp counters** command. [Table 2-6](#) describes each field in the display.

Switch# **show vtp counters**

VTP statistics:

```
Summary advertisements received    : 38
Subset advertisements received    : 0
Request advertisements received    : 0
Summary advertisements transmitted : 13
Subset advertisements transmitted  : 3
Request advertisements transmitted : 0
Number of config revision errors   : 0
Number of config digest errors     : 0
Number of V1 summary errors        : 0
```

VTP pruning statistics:

Trunk	Join Transmitted	Join Received	Summary advts received from non-pruning-capable device
Fa0/9	827	824	0
Fa0/10	827	823	0
Fa0/11	827	823	0

**Table 2-6 Show VTP Counters Field Descriptions**

Field	Description
Summary Advts Received	Number of summary advertisements received by this switch on its trunk ports. Summary advertisements contain the management domain name, the configuration revision number, the update timestamp and identity, the authentication checksum, and the number of subset advertisements to follow.
Subset Advts Received	Number of subset advertisements received by this switch on its trunk ports. Subset advertisements contain all the information for one or more VLANs.
Request Advts Received	Number of advertisement requests received by this switch on its trunk ports. Advertisement requests normally request information on all VLANs. They can also request information on a subset of VLANs.
Summary Advts Transmitted	Number of summary advertisements sent by this switch on its trunk ports. Summary advertisements contain the management domain name, the configuration revision number, the update timestamp and identity, the authentication checksum, and the number of subset advertisements to follow.
Subset Advts Transmitted	Number of subset advertisements sent by this switch on its trunk ports. Subset advertisements contain all the information for one or more VLANs.
Request Advts Transmitted	Number of advertisement requests sent by this switch on its trunk ports. Advertisement requests normally request information on all VLANs. They can also request information on a subset of VLANs.
No. of Configuration Revision Errors	<p>Number of revision errors.</p> <p>Whenever you define a new VLAN, delete an existing one, suspend or resume an existing VLAN, or modify the parameters on an existing VLAN, the configuration revision number of the switch increments.</p> <p>Revision errors increment whenever the switch receives an advertisement whose revision number matches the revision number of the switch, but the MD5 digest values do not match. This error indicates that the VTP password in the two switches is different, or the switches have different configurations.</p> <p>These errors indicate that the switch is filtering incoming advertisements, which causes the VTP database to become unsynchronized across the network.</p>

**Table 2-6 Show VTP Counters Field Descriptions (continued)**

Field	Description
No. of Configuration Digest Errors	<p>Number of MD5 digest errors.</p> <p>Digest errors increment whenever the MD5 digest in the summary packet and the MD5 digest of the received advertisement calculated by the switch do not match. This error usually indicates that the VTP password in the two switches is different. To solve this problem, make sure the VTP password on all switches is the same.</p> <p>These errors indicate that the switch is filtering incoming advertisements, which causes the VTP database to become unsynchronized across the network.</p>
No. of V1 Summary Errors	<p>Number of version 1 errors.</p> <p>Version 1 summary errors increment whenever a switch in VTP V2 mode receives a VTP version 1 frame. These errors indicate that at least one neighboring switch is either running VTP version 1 or VTP version 2 with V2-mode disabled. To solve this problem, change the configuration of the switches in VTP V2-mode to disabled.</p>
Join Transmitted	Number of VTP pruning messages transmitted on the trunk.
Join Received	Number of VTP pruning messages received on the trunk.
Summary Advts Received from non-pruning-capable device	Number of VTP summary messages received on the trunk from devices that do not support pruning.

The following is sample output from the **show vtp status** command. [Table 2-7](#) describes each field in the display.

Switch# **show vtp status**

```

VTP Version                : 2
Configuration Revision      : 1
Maximum VLANs supported locally : 68
Number of existing VLANs    : 7
VTP Operating Mode         : Server
VTP Domain Name            : test1
VTP Pruning Mode           : Disabled
VTP V2 Mode                : Disabled
VTP Traps Generation       : Disabled
MD5 digest                 : 0x3D 0x02 0xD4 0x3A 0xC4 0x46 0xA1 0x03
Configuration last modified by 172.20.130.52 at 3-4-93 22:25:

```



**Table 2-7 Show VTP Status Field Descriptions**

Field	Description
VTP Version	Displays the VTP version operating on the switch. By default, Catalyst 2900 XL and Catalyst 3500 XL switches implement version 1 but can be set to version 2.
Configuration Revision	Current configuration revision number on this switch.
Maximum VLANs Supported Locally	Maximum number of VLANs supported locally.
Number of Existing VLANs	Number of existing VLANs.
VTP Operating Mode	<p>Displays the VTP operating mode, which can be server, client, or transparent.</p> <p>Server: a switch in VTP server mode is enabled for VTP and sends advertisements. You can configure VLANs on it. The switch guarantees that it can recover all the VLAN information in the current VTP database from nonvolatile storage after reboot. By default, every switch is a VTP server.</p> <p>Client: a switch in VTP client mode is enabled for VTP, can send advertisements, but does not have enough nonvolatile storage to store VLAN configurations. You cannot configure VLANs on it. When a VTP client starts up, it does not transmit VTP advertisements until it receives advertisements to initialize its VLAN database.</p> <p>Transparent: a switch in VTP transparent mode is disabled for VTP, does not transmit advertisements or learn from advertisements sent by other devices, and cannot affect VLAN configurations on other devices in the network. The switch receives VTP advertisements and forwards them on all trunk ports except the one on which the advertisement was received. The configuration of multi-VLAN ports causes the switch to automatically enter transparent mode.</p> <p><b>Note</b> Catalyst 2912MF, 2924M, and Catalyst 3500 XL switches support up to 250 VLANs. All other Catalyst 2900 XL switches support up to 64 VLANs. If you define more than 250 or 64 or if the switch receives an advertisement that contains more than 250 or 64 VLANs, the switch automatically enters VTP transparent mode and operates with the VLAN configuration preceding the one that sent it into transparent mode.</p>
VTP Domain Name	Name that identifies the administrative domain for the switch.
VTP Pruning Mode	Displays whether pruning is enabled or disabled. Enabling pruning on a VTP server enables pruning for the entire management domain. Pruning restricts flooded traffic to those trunk links that the traffic must use to access the appropriate network devices.
VTP V2 Mode	Displays if VTP version 2 mode is enabled. All VTP version 2 switches operate in version 1 mode by default. Each VTP switch automatically detects the capabilities of all the other VTP devices. A network of VTP devices should be configured to version 2 only if all VTP switches in the network can operate in version 2 mode.

**Table 2-7 Show VTP Status Field Descriptions (continued)**

Field	Description
VTP Traps Generation	Displays whether VTP traps are transmitted to a network management station.
MD5 Digest	A 16-byte checksum of the VTP configuration.
Configuration Last Modified	Displays the date and time of the last configuration modification. Displays the IP address of the switch that caused the configuration change to the database.

**Related Commands**

Command	Description
<b>clear vtp counters</b>	Clears the VTP and pruning counters.
<b>vtp</b>	Configures the VTP mode.

# shutdown

Use the **shutdown** interface configuration command to disable a port and to shutdown the management VLAN. Use the **no** form of this command to restart a disabled port or to activate the management VLAN.

**shutdown**

**no shutdown**

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Interface configuration

Command History	Release	Modification
	11.2(8)SA	This command was first introduced.
	12.0(5)XP	Command functionality extended to the management VLAN interface.

**Usage Guidelines** The **shutdown** command for a port causes it to stop forwarding. You can enable the port with the **no shutdown** command.

The **no shutdown** command has no effect if the port is a static-access port assigned to a VLAN that has been deleted, suspended, or shut down. The port must first be a member of an active VLAN before it can be reenabled.

Only one management VLAN interface can be active at a time. The remaining VLANs are shut down. In the **show running-config** command, the active management VLAN interface is the one with the **shutdown** command displayed.

**Examples** The following examples show how to disable fixed port fa0/8 and how to reenable it:

```
Switch(config)# interface fa0/8  
Switch(config-if)# shutdown
```

```
Switch(config-if)# no shutdown
```

You can verify the previous commands by entering the **show interface** command in privileged EXEC mode.

Related Commands	Command	Description
	<a href="#">management</a>	Shuts down the current management VLAN interface and enables the new management VLAN interface.

# shutdown vlan

Use the **shutdown vlan** global configuration command to shut down (suspend) local traffic on the specified VLAN. Use the **no** form of this command to restart local traffic on the VLAN.

**shutdown vlan** *vlan-id*

**no shutdown vlan** *vlan-id*

<b>Syntax Description</b>	<i>vlan-id</i> ID of the VLAN to be locally shut down. Valid IDs are from 2 to 1001, excluding VLANs defined as default VLANs under the VLAN Trunk Protocol (VTP). The default VLANs are 1 and 1002–1005. Do not enter leading zeroes.	
<b>Defaults</b>	No default is defined.	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA4	This command was first introduced.
<b>Usage Guidelines</b>	The <b>shutdown vlan</b> command does not change the VLAN information in VTP database. It shuts down traffic locally, but the switch still advertises VTP information.	

**Examples**

The following example shows how to shutdown traffic on VLAN 2:

```
Switch(config)# shutdown vlan 2
```

You can verify the previous command by entering the **show vlan** command in privileged EXEC mode.

**Related Commands**

Command	Description
<a href="#">abort</a>	Abandons the proposed new VLAN database, exits VLAN database mode, and returns to privileged EXEC mode.
<a href="#">apply</a>	Implements the proposed new VLAN database, increments the database configuration revision number, propagates it throughout the administrative domain, and remains in VLAN database mode.
<a href="#">exit</a>	Implements the proposed new VLAN database, increments the database configuration number, propagates it throughout the administrative domain, and returns to privileged EXEC mode.
<a href="#">reset</a>	Abandons the proposed VLAN database and remains in VLAN database mode. Resets the proposed database to the currently implemented VLAN database on the switch.
<a href="#">vlan database</a>	Enters VLAN database mode from the command-line interface (CLI).

# snmp-server enable traps vlan-membership

Use the **snmp-server enable traps vlan-membership** global configuration command to enable SNMP notification for VLAN Membership Policy Server (VMPS) changes. Use the **no** form of this command to disable the VMPS trap notification.

**snmp-server enable traps vlan-membership**

**no snmp-server enable traps vlan-membership**

## Syntax Description

This command has no arguments or keywords.

## Defaults

SNMP traps for VMPS are disabled.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Usage Guidelines

Specify the host that receives the traps by using the **snmp-server host** command.

## Examples

The following example shows how to enable VMPS to send trap notifications:

```
Switch(config)# snmp-server enable trap vlan-membership
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>show running-config</b>	Displays the running configuration on the switch.
<a href="#">snmp-server host</a>	Specifies the host that receives SNMP traps.

# snmp-server enable traps vtp

Use the **snmp-server enable traps vtp** global configuration command to enable SNMP notification for VLAN Trunk Protocol (VTP) changes. Use the **no** form of this command to disable VTP trap notification.

**snmp-server enable traps vtp**

**no snmp-server enable traps vtp**

## Syntax Description

This command has no arguments or keywords.

## Defaults

SNMP traps for VTP are disabled.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Usage Guidelines

Specify the host that receives the traps by using the **snmp-server host** command.

## Examples

The following example shows how to enable VTP to send trap notifications:

```
Switch(config)# snmp-server enable trap vtp
```

You can verify the previous command by entering the **show vtp status** or **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>show running-config</b>	Displays the running configuration on the switch.
<b>show vtp status</b>	Displays general information about the VTP management domain and status.
<b>snmp-server host</b>	Specifies the host that receives SNMP traps.

# snmp-server host

Use the **snmp-server host** global configuration command to specify the host that receives SNMP traps. Use the **no** form of this command to remove the specified host.

**snmp-server host** *host-address community-string* [**c2900** | **config** | **snmp** | **tty** | **udp-port** *port-number* | **vlan-membership** | **vtp**]

**no snmp-server host** *host-address community-string*

Syntax Description		
	<i>host-address</i>	IP address or name of the SNMP trap host.
	<i>community-string</i>	Password-like community string sent with the trap operation
	<b>c2900</b>	(Optional) Send SNMP Catalyst 2900 XL or Catalyst 3500 XL switch traps.
	<b>config</b>	(Optional) Send SNMP configuration traps.
	<b>snmp</b>	(Optional) Send SNMP-type traps.
	<b>tty</b>	(Optional) Send Cisco enterprise-specific traps when a Transmission Control Protocol (TCP) connection closes
	<b>udp-port</b> <i>port-number</i>	(Optional) UDP port of the host to use. The default is 162.
	<b>vlan-membership</b>	(Optional) Send SNMP VLAN Membership Policy Server (VMPS) traps
	<b>vtp</b>	(Optional) Send SNMP VLAN Trunk Protocol (VTP) traps.

**Defaults**

The SNMP trap host address and community string are not defined.

Traps are disabled.

**Command Modes**

Global configuration

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

**Usage Guidelines**

Use the **snmp-server host** command with the **snmp-server enable traps** commands to generate traps.



---

**Examples**

The following example shows how to configure an SNMP host to receive VTP traps:

```
Switch(config)# snmp-server host 172.20.128.178 traps vtp
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<a href="#">snmp-server enable traps vlan-membership</a>	Enables SNMP notification for VMPS changes.
<a href="#">snmp-server enable traps vtp</a>	Enables SNMP notification for VTP changes.

# spanning-tree

Use the **spanning-tree** global configuration command to enable Spanning Tree Protocol (STP) on a VLAN. Use the **no** form of the command to disable STP on a VLAN.

**spanning-tree** [**vlan** *stp-list*]

**no spanning-tree** [**vlan** *stp-list*]

Syntax Description	<b>vlan</b> <i>stp-list</i> (Optional) List of spanning-tree instances. Each spanning-tree instance is associated with a VLAN ID. Valid IDs are from 1 to 1005. Enter each VLAN ID separated by a space. Do not enter leading zeroes. Ranges are not supported.					
Defaults	STP is enabled.					
Command Modes	Global configuration					
Command History	<table><tr><th>Release</th><th>Modification</th></tr><tr><td>11.2(8)SA3</td><td>This command was first introduced.</td></tr></table>		Release	Modification	11.2(8)SA3	This command was first introduced.
Release	Modification					
11.2(8)SA3	This command was first introduced.					
Usage Guidelines	<p>Disabling STP causes the VLAN or list of VLANs to stop participating in STP. Ports that are administratively down remain down. Received Bridge Protocol Data Units (BPDUs) are forwarded like other multicast frames. The VLAN does not detect and prevent loops when STP is disabled.</p> <p>You can disable STP on a VLAN that is not currently active, and verify the change by using the privileged EXEC <b>show running-config</b> or the <b>show spanning-tree vlan</b> <i>stp-list</i> command. The setting takes effect when the VLAN is activated.</p> <p>If the variable <i>stp-list</i> is omitted, the command applies to the STP instance associated with VLAN 1.</p> <p>You can enable STP on a VLAN that has no ports assigned to it.</p>					
Examples	<p>The following example shows how to disable STP on VLAN 5:</p> <pre>Switch(config)# no spanning-tree vlan 5</pre> <p>You can verify the previous command by entering the <b>show spanning-tree</b> command in privileged EXEC mode. In this instance, VLAN 5 does not appear in the list.</p>					

Related Commands	Command	Description
	<a href="#">show spanning-tree</a>	Displays spanning-tree information for the specified spanning-tree instances.
	<a href="#">spanning-tree forward-time</a>	Sets the forwarding-time for the specified spanning-tree instances.
	<a href="#">spanning-tree max-age</a>	Changes the interval between messages the spanning tree receives from the root switch.
	<a href="#">spanning-tree port-priority</a>	Configures a port priority, which is used when two switches tie for position as the root switch.
	<a href="#">spanning-tree protocol</a>	Specifies the STP protocol to be used for specified spanning-tree instances.

## spanning-tree cost

Use the **spanning-tree cost** interface configuration command to set the path cost for Spanning Tree Protocol (STP) calculations. In the event of a loop, spanning tree considers the path cost when selecting an interface to place into the forwarding state. Use the **no** form of this command to return to the default value.

**spanning-tree** [*vlan stp-list*] **cost** *cost*

**no spanning-tree** [*vlan stp-list*] **cost**

### Syntax Description

<b>vlan</b> <i>stp-list</i>	(Optional) List of spanning-tree instances. Each spanning-tree instance is associated with a VLAN ID. Valid IDs are from 1 to 1005. Enter each VLAN ID separated by a space. Do not enter leading zeroes. Ranges are not supported.
<b>cost</b>	Path cost can range from 1 to 65535, with higher values indicating higher costs. This range applies whether or not the IEEE STP has been specified

### Defaults

The default path cost is computed from the interface bandwidth setting. The following are IEEE default path cost values:

- 10 Mbps – 100
- 100 Mbps – 19
- 155 Mbps – 14
- 1 Gbps – 4
- 10 Gbps – 2
- Speeds greater than 10 Gbps – 1

### Command Modes

Interface configuration

### Command History

Release	Modification
11.2(8)SA3	This command was first introduced.

### Usage Guidelines

If the variable *stp-list* is omitted, the command applies to the STP instance associated with VLAN 1.

You can set a cost for a port or on a VLAN that does not exist. The setting takes effect when the VLAN exists.

### Examples

The following example shows how to set a path cost value of 250 for VLAN 1:

```
Switch(config-if)# spanning-tree vlan 1 cost 250
```

You can verify the previous command by entering the **show spanning-tree** command in privileged EXEC mode.

Related Commands	Command	Description
	<a href="#">show spanning-tree</a>	Displays spanning-tree information for the specified spanning-tree instances.
	<a href="#">spanning-tree portfast</a>	Enables the Port Fast feature on a port in all its associated VLANs.
	<a href="#">spanning-tree priority</a>	Configures the switch priority for the specified spanning-tree instance.

# spanning-tree forward-time

Use the **spanning-tree forward-time** global configuration command to set the forwarding-time for the specified spanning-tree instances. The forwarding time determines how long each of the listening and learning states last before the port begins forwarding. Use the **no** form of this command to return to the default value.

```
spanning-tree [vlan stp-list] forward-time seconds

no spanning-tree [vlan stp-list] forward-time
```

Syntax Description

vlan stp-list	(Optional) List of spanning-tree instances. Each spanning-tree instance is associated with a VLAN ID. Valid IDs are from 1 to 1005. Enter each VLAN ID separated by a space. Do not enter leading zeroes. Ranges are not supported.
seconds	Forward-delay interval from 4 to 200 seconds.

Defaults

The default forwarding-time for IEEE Spanning Tree Protocol (STP) is 15 seconds. The default for IBM STP is 4 seconds.

Command Modes

Global configuration

Command History

Release	Modification
11.2(8)SA3	This command was first introduced.

Usage Guidelines

If the variable *stp-list* is omitted, the command applies to the STP instance associated with VLAN 1. You can set the forwarding-time on a VLAN that has no ports assigned to it. The setting takes effect when you assign ports to it.

Examples

The following example shows how to set the spanning-tree forwarding time to 18 seconds for VLAN 20:

```
Switch(config)# spanning-tree vlan 20 forward-time 18
```

You can verify the previous command by entering the **show spanning-tree** command in privileged EXEC mode.

Related Commands	Command	Description
	<code>show spanning-tree</code>	Displays spanning-tree information for the specified spanning-tree instances.
	<code>spanning-tree max-age</code>	Changes the interval between messages the spanning tree receives from the root switch.
	<code>spanning-tree port-priority</code>	Configures a port priority, which is used when two switches tie for position as the root switch.
	<code>spanning-tree protocol</code>	Specifies the STP protocol to be used for specified spanning-tree instances.

# spanning-tree hello-time

Use the **spanning-tree hello-time** global configuration command to specify the interval between hello Bridge Protocol Data Units (BPDUs). Use the **no** form of this command to return to the default interval.

**spanning-tree** [*vlan stp-list*] **hello-time** *seconds*

**no spanning-tree** [*vlan stp-list*] **hello-time**

<b>Syntax Description</b>	<b>vlan stp-list</b>	(Optional) List of spanning-tree instances. Each spanning-tree instance is associated with a VLAN ID. Valid IDs are from 1 to 1005. Enter each VLAN ID separated by a space. Do not enter leading zeroes. Ranges are not supported.
	<b>seconds</b>	Interval from 1 to 10 seconds.

**Defaults** The default hello time for IEEE Spanning Tree Protocol (STP) and IBM STP is 2 seconds.

**Command Modes** Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA3	This command was first introduced.

**Usage Guidelines** If the variable *stp-list* is omitted, the command applies to the STP instance associated with VLAN 1. You can set the hello time on a VLAN that has no ports assigned to it. The setting takes effect when you assign ports to it.

**Examples** The following example shows how to set the spanning-tree hello-delay time to 3 seconds for VLAN 20:

```
Switch(config)# spanning-tree vlan 20 hello-time 3
```

You can verify the previous command by entering the **show spanning-tree** command in privileged EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show spanning-tree</b>	Displays spanning-tree information for the specified spanning-tree instances.
	<b>spanning-tree</b>	Enables STP on a VLAN.
	<b>spanning-tree port-priority</b>	Configures a port priority, which is used when two switches tie for position as the root switch.
	<b>spanning-tree protocol</b>	Specifies the STP protocol to be used for specified spanning-tree instances.



# spanning-tree max-age

Use the **spanning-tree max-age** global configuration command to change the interval between messages the spanning tree receives from the root switch. If a switch does not receive a Bridge Protocol Data Unit (BPDU) message from the root switch within this interval, it recomputes the Spanning Tree Protocol (STP) topology. Use the **no** form of this command to return to the default interval.

**spanning-tree [vlan *stp-list*] max-age *seconds***

**no spanning-tree [vlan *stp-list*] max-age**

## Syntax Description

<b>vlan <i>stp-list</i></b>	(Optional) List of spanning-tree instances. Each spanning-tree instance is associated with a VLAN ID. Valid IDs are from 1 to 1005. Enter each VLAN ID separated by a space. Do not enter leading zeroes. Ranges are not supported.
<b><i>seconds</i></b>	Interval the switch waits between receiving BPDUs from the root switch. Enter a number from 6 to 200.

## Defaults

The default max-age for IEEE STP is 20 seconds. The default for IBM STP is 10 seconds.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA3	This command was first introduced.

## Usage Guidelines

The **max-age** setting must be greater than the **hello-time** setting.

If the variable *stp-list* is omitted, the command applies to the STP instance associated with VLAN 1.

You can set the **max-age** on a VLAN that has no ports assigned to it. The setting takes effect when you assign ports to the VLAN.

## Examples

The following example shows how to set **spanning-tree max-age** to 30 seconds for VLAN 20:

```
Switch(config)# spanning-tree vlan 20 max-age 30
```

The following example shows how to reset the **max-age** parameter to the default value for spanning-tree instances 100 through 102:

```
Switch(config)# no spanning-tree vlan 100 101 102 max-age
```

You can verify the previous commands by entering the **show spanning-tree** command in privileged EXEC mode.

Related Commands	Command	Description
	<code>show spanning-tree</code>	Displays spanning-tree information for the specified spanning-tree instances.
	<code>spanning-tree forward-time</code>	Sets the forwarding-time for the specified spanning-tree instances.
	<code>spanning-tree hello-time</code>	Specifies the interval between hello Bridge Protocol Data Units (BPDUs).
	<code>spanning-tree port-priority</code>	Configures a port priority, which is used when two switches tie for position as the root switch.
	<code>spanning-tree protocol</code>	Specifies the STP protocol to be used for specified spanning-tree instances.

# spanning-tree portfast

Use the **spanning-tree portfast** interface configuration command to enable the Port Fast feature on a port in all its associated VLANs. When the Port Fast feature is enabled, the port changes directly from a blocking state to a forwarding state without making the intermediate Spanning Tree Protocol (STP) status changes. Use the **no** form of this command to return the port to default operation.

**spanning-tree portfast**

**no spanning-tree portfast**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Defaults</b>	The Port Fast feature is disabled; however, it is automatically enabled on dynamic-access ports.
-----------------	--

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA3	This command was first introduced.

<b>Usage Guidelines</b>	This feature is not supported on the ATM modules.
	This feature should be used only on ports that connect to end stations.
	This feature affects all VLANs on the port.
	A port with the Port Fast feature enabled is moved directly to the spanning-tree forwarding state.

<b>Examples</b>	The following example shows how to enable the Port Fast feature on fixed port 2.
	Switch(config-if) # <b>spanning-tree portfast fa0/2</b>
	You can verify the previous commands by entering the <b>show running-config</b> in privilege EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show spanning-tree</a>	Displays spanning-tree information for the specified spanning-tree instances.
	<a href="#">spanning-tree port-priority</a>	Configures a port priority, which is used when two switches tie for position as the root switch.

# spanning-tree port-priority

Use the **spanning-tree port-priority** interface configuration command to configure a port priority, which is used when two switches tie for position as the root switch. Use the **no** form of this command to return to the default value.

**spanning-tree** [*vlan stp-list*] **port-priority** *port-priority*

**no spanning-tree** [*vlan stp-list*] **port-priority**

## Syntax Description

<b>vlan stp-list</b>	(Optional) List of spanning-tree instances. Each spanning-tree instance is associated with a VLAN ID. Valid IDs are from 1 to 1005. Enter each VLAN ID separated by a space. Do not enter leading zeroes. Ranges are not supported.
<b>port-priority</b>	Number from 0 to 255. The lower the number, the higher the priority.

## Defaults

The default port-priority for IEEE STP and IBM STP is 128.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA3	This command was first introduced.

## Usage Guidelines

If the variable *stp-list* is omitted, the command applies to the STP instance associated with VLAN 1. You can set the port priority on a VLAN that has no ports assigned to it. The setting takes effect when you assign ports to the VLAN.

## Examples

The following example shows how to increase the likelihood that the spanning-tree instance 20 is chosen as the root switch on port fa0/2:

```
Switch(config)# interface fa0/2
Switch(config-if)# spanning-tree vlan 20 port-priority 0
```

You can verify the previous commands by entering the **show spanning-tree** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">show spanning-tree</a>	Displays spanning-tree information for the specified spanning-tree instances.
<a href="#">spanning-tree protocol</a>	Specifies the STP protocol to be used for specified spanning-tree instances.

# spanning-tree priority

Use the **spanning-tree priority** global configuration command to configure the switch priority for the specified spanning-tree instance. This changes the likelihood that the switch is selected as the root switch. Use the **no** form of this command to revert to the default value.

**spanning-tree [vlan *stp-list*] priority *bridge-priority***

**no spanning-tree [vlan *stp-list*] priority**

## Syntax Description

<b>vlan <i>stp-list</i></b>	(Optional) List of spanning-tree instances. Each spanning-tree instance is associated with a VLAN ID. Valid IDs are from 1 to 1005. Enter each VLAN ID separated by a space. Do not enter leading zeroes. Ranges are not supported.
<b><i>bridge-priority</i></b>	A number from 0 to 65535. The lower the number, the more likely the switch will be chosen as root.

## Defaults

The default bridge priority for IEEE STP and IBM STP is 32768.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA3	This command was first introduced.

## Usage Guidelines

If the variable *stp-list* is omitted, the command applies to the STP instance associated with VLAN 1. You can configure the switch priority on a VLAN that has no ports assigned to it. The setting takes effect when you assign ports to the VLAN.

## Examples

The following example shows how to set the spanning-tree priority to 125 for a list of VLANs:

```
Switch(config)# spanning-tree vlan 20 100 101 102 priority 125
```

You can verify the previous command by entering the **show spanning-tree** command in privileged EXEC mode.

Related Commands	Command	Description
	<code>show spanning-tree</code>	Displays spanning-tree information for the specified spanning-tree instances.
	<code>spanning-tree forward-time</code>	Sets the forwarding-time for the specified spanning-tree instances.
	<code>spanning-tree hello-time</code>	Specifies the interval between hello Bridge Protocol Data Units (BPDUs).
	<code>spanning-tree max-age</code>	Changes the interval between messages the spanning tree receives from the root switch.
	<code>spanning-tree protocol</code>	Specifies the STP protocol to be used for specified spanning-tree instances.

# spanning-tree protocol

Use the **spanning-tree protocol** global configuration command to specify the Spanning Tree Protocol (STP) to be used for specified spanning-tree instances. Use the **no** form of this command to use the default protocol.

**spanning-tree [vlan *stp-list*] protocol {ieee | ibm}**

**no spanning-tree [vlan *stp-list*] protocol**

## Syntax Description

<b>vlan <i>stp-list</i></b>	(Optional) List of spanning-tree instances. Each spanning-tree instance is associated with a VLAN ID. Valid IDs are from 1 to 1005. Enter each VLAN ID separated by a space. Do not enter leading zeroes. Ranges are not supported.
<b>ieee</b>	IEEE Ethernet STP.
<b>ibm</b>	IBM STP.

## Defaults

The default protocol is **ieee**.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA3	This command was first introduced.

## Usage Guidelines

Changing the **spanning-tree protocol** command causes STP parameters to change to default values of the new protocol.

If the variable *stp-list* is omitted, this command applies to the STP instance associated with VLAN 1.

You can change the protocol on a VLAN that has no ports assigned to it. The setting takes effect when you assign ports to it.

## Examples

The following example shows how to change the STP protocol for VLAN 20 to the IBM version of STP:

```
Switch(config)# spanning-tree vlan 20 protocol ibm
```

You can verify the previous command by entering the **show spanning-tree** command in privileged EXEC mode.

Related Commands	Command	Description
	<code>show spanning-tree</code>	Displays spanning-tree information for the specified spanning-tree instances.
	<code>spanning-tree</code>	Enables STP on a VLAN.
	<code>spanning-tree forward-time</code>	Sets the forwarding-time for the specified spanning-tree instances.
	<code>spanning-tree max-age</code>	Changes the interval between messages the spanning tree receives from the root switch.
	<code>spanning-tree port-priority</code>	Configures a port priority, which is used when two switches tie for position as the root switch.



# spanning-tree rootguard

Use the **spanning-tree rootguard** interface configuration command to enable the root guard feature for all the VLANs associated with the selected port. Root guard restricts which port is allowed to be the Spanning Tree Protocol (STP) root port or the path-to-the root for the switch. The root port provides the best path from the switch to the root switch. Use the **no** form of this command to disable this feature.

**spanning-tree rootguard**

**no spanning-tree rootguard**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Defaults</b>	The root guard feature is disabled.
-----------------	-------------------------------------

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.0(5)XU	This command was first introduced.

<b>Usage Guidelines</b>	When the root guard feature is enabled, if spanning-tree calculations cause a port to be selected as the root port, the port transitions to the root-inconsistent (blocked) state to prevent the customer's switch from becoming the root switch or being in the path to the root.
-------------------------	--

When the <b>no spanning-tree rootguard</b> command is executed, the root guard feature is disabled for all VLANs on the selected port. If this port is in the root-inconsistent (blocked) state, the port automatically transitions to the listening state.
---

Do not enable the root guard on ports that will be used by the UplinkFast feature. With UplinkFast, the backup ports (in the blocked state) replace the root port in the case of a failure. However, if root guard is also enabled, all the backup ports used by the UplinkFast feature are placed in the root-inconsistent state (blocked) and prevented from reaching the forwarding state.
---

<b>Examples</b>	The following example shows how to enable the root guard feature on all the VLANs associated with interface fa0/3:
-----------------	--

Switch(config)# <b>interface fa0/3</b> Switch(config-if)# <b>spanning-tree rootguard</b>
---

You can verify the previous commands by entering the <b>show running-config</b> command in privileged EXEC mode.
--

Related Commands	Command	Description
	<b>show running-config</b>	Displays the current operating configuration.
	<b>show spanning-tree</b>	Displays spanning-tree information for the specified spanning-tree instances.
	<b>spanning-tree cost</b>	Sets the path cost for STP calculations. In the event of a loop, spanning tree considers the path cost when selecting an interface to place into the forwarding state.
	<b>spanning-tree port-priority</b>	Configures a port priority, which is used when two switches tie for position as the root switch.
	<b>spanning-tree priority</b>	Configures the switch priority for the specified spanning-tree instance and affects the likelihood that the switch is selected as the root switch.

# spanning-tree stack-port

Use the **spanning-tree stack-port** interface configuration command to enable cross-stack UplinkFast (CSUF) on an interface and to accelerate the choice of a new root port when a link or switch fails or when Spanning Tree Protocol (STP) reconfigures itself. Use the **no** form of this command to return to the default setting.

**spanning-tree stack-port**

**no spanning-tree stack-port**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Defaults</b>	CSUF is disabled on all interfaces.
-----------------	-------------------------------------

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	Release	Modification
	12.0(5)XW	This command was first introduced.

<b>Usage Guidelines</b>	This command is effective only if you enable the UplinkFast feature by using the <b>spanning-tree uplinkfast</b> global configuration command.
	Use this command only on access switches.
	You can enable CSUF only on one stack-port Gigabit Interface Converter (GBIC) interface. The stack port connects to the GigaStack GBIC multidrop backbone. If you try to enable CSUF on a Fast Ethernet or a copper-based Gigabit Ethernet port, you receive an error message.
	If CSUF is already enabled on an interface and you try to enable it on another interface, you receive an error message. You must disable CSUF on the first interface before enabling it on a new interface.

<b>Examples</b>	The following command shows how to enable CSUF on the GBIC interface gi0/1:
-----------------	---

<pre>Switch(config)# <b>interface gi0/1</b> Switch(config-if)# <b>spanning-tree stack-port</b></pre>
--

You can verify the previous command by entering the <b>show spanning-tree</b> command in privileged EXEC mode.
--

<b>Related Commands</b>	Command	Description
	<a href="#">show spanning-tree</a>	Displays spanning-tree information for the specified spanning-tree instances.

# spanning-tree uplinkfast

Use the **spanning-tree uplinkfast** global configuration command to accelerate the choice of a new root port when a link or switch fails or when Spanning Tree Protocol (STP) reconfigures itself. Use the **no** form of this command to return to the default value.

```
spanning-tree uplinkfast [max-update-rate pkts-per-second]
no spanning-tree uplinkfast [max-update-rate pkts-per-second]
```

Syntax Description	max-update-rate pkts-per-second	The number of packets per second at which stations address update packets are sent. The range is 0 to 1000.
--------------------	---------------------------------	---

Defaults	UplinkFast is disabled.
----------	-------------------------

Command Modes	Global configuration
---------------	----------------------

Command History	Release	Modification
	11.2(8)SA6	This command was first introduced.

Usage Guidelines	<p>When you enable UplinkFast, it is enabled for the entire switch and cannot be enabled for individual VLANs.</p> <p>When you enable UplinkFast, the bridge priority of all VLANs is set to 49152, and the path cost of all ports and VLAN trunks is increased by 3000. This change reduces the chance that the switch will become the root switch.</p> <p>When you disable UplinkFast, the bridge priorities of all VLANs and path costs are set to their default values.</p> <p>Do not enable the root guard on ports that will be used by the UplinkFast feature. With UplinkFast, the backup ports (in the blocked state) replace the root port in the case of a failure. However, if root guard is also enabled, all the backup ports used by the UplinkFast feature are placed in the root-inconsistent state (blocked) and prevented from reaching the forwarding state.</p>
------------------	--

---

**Examples**

The following command shows how to enable UplinkFast:

```
Switch(config)# spanning-tree uplinkfast
```

You can verify the previous command by entering the **show spanning-tree** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<a href="#">show spanning-tree</a>	Displays spanning-tree information for the specified spanning-tree instances.

# speed

Use the **speed** interface configuration command to specify the speed of a Fast Ethernet port. Use the **no** form of this command to return the port to its default value.

**speed { 10 | 100 | auto }**

**no speed**

## Syntax Description

<b>10</b>	Port runs at 10 Mbps.
<b>100</b>	Port runs at 100 Mbps.
<b>auto</b>	Port automatically detects whether it should run at 10 or 100 Mbps on Fast Ethernet ports.

## Defaults

For Fast Ethernet ports, the default is **auto**.

For Gigabit Ethernet ports, the speed is 1000 Mbps and is not configurable.

For ATM ports, the speed is 155 Mbps and is not configurable.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA	This command was first introduced.

## Usage Guidelines

Certain ports can be configured to be either 10 or 100 Mbps. Applicability of this command is hardware-dependent.

If the speed is set to auto, the switch negotiates with the device at the other end of the link for the speed setting and then forces the speed setting to the negotiated value. The duplex setting remains as configured on each end of the link, which could result in a duplex setting mismatch.

If both the speed and duplex are set to specific values, autonegotiation is disabled.



### Note

For guidelines on setting the switch speed and duplex parameters, see the *Catalyst 2900 Series XL and Catalyst 3500 Series XL Software Configuration Guide*.

---

**Examples**

The following example shows how to set port 1 on module 2 to 100 Mbps:

```
Switch(config)# interface fastethernet2/1  
Switch(config-if)# speed 100
```

You can verify the previous commands by entering the **show running-config** in privilege EXEC mode.

---

**Related Commands**

Command	Description
<a href="#">duplex</a>	Specifies the duplex mode of operation for Fast Ethernet and Gigabit Ethernet ports.

# switchport access

Use the **switchport access** interface configuration command to configure a port as a static-access or dynamic-access port. If the mode is set to access, the port operates as a member of the configured VLAN. If set to dynamic, the port starts discovery of VLAN assignment based on the incoming packets it receives. Use the **no** form of this command to reset the access mode to the default VLAN for the switch.

**switchport access vlan** {*vlan-id* | **dynamic**}

**no switchport access vlan** {*vlan-id* | **dynamic**}

Syntax Description	
<b>vlan</b> <i>vlan-id</i>	ID of the VLAN. Valid IDs are from 1 to 1001. Do not enter leading zeroes.
<b>dynamic</b>	Port is assigned to a VLAN based on the source MAC address of a host (or hosts) connected to that port. The switch sends every new source MAC address received to the VLAN Membership Policy Server (VMPS) to obtain the VLAN name to which the dynamic-access port should be assigned. If the port already has a VLAN assigned and the source has already been approved by the VMPS, the switch forwards the packet to the VLAN.

## Defaults

All ports are in static-access mode in VLAN 1.

A dynamic-access port is initially a member of no VLAN and receives its assignment based on the packets it receives.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA3	This command was first introduced.
11.2(8)SA4	The <b>dynamic</b> keyword was added.

## Usage Guidelines

The **port** must be in access mode before the **switchport access vlan** *vlan-id* or **switchport access vlan dynamic** command can take effect. For more information, see the [“switchport mode” section on page 2-210](#).

An access port can be assigned to only one VLAN.

When the **no switchport access vlan** form is used, the access mode is reset to static access on VLAN 1.

The following restrictions apply to dynamic-access ports:

- The software implements the VLAN Query Protocol (VQP) client, which can query a VMPS such as a Catalyst 5000 series switch. Catalyst 2900 XL and Catalyst 3500 XL switches are not VMPS servers. The VMPS server must be configured before a port is configured as dynamic.
- Use dynamic-access ports only to connect end stations. Connecting them to switches or routers (that use bridging protocols) can cause a loss of connectivity.



- Configure the network so that STP does not put the dynamic-access port into an STP blocking state. The Port Fast feature is automatically enabled on dynamic-access ports.
- Dynamic-access ports can only be in one VLAN and do not use VLAN tagging.
- Dynamic-access ports cannot be configured as:
  - The source or destination port in a static address entry.
  - A network port (dynamic-access ports can be assigned to a VLAN in which one of the other ports is a network port).
  - A port group (dynamic-access ports cannot be grouped with any other port including other dynamic ports).
  - A secure port.
  - A port with a secure address.
  - A monitor port.

### Examples

The following example shows how to assign a port already in access mode to VLAN 2 (instead of the default VLAN 1):

```
Switch(config-if)# switchport access vlan 2
```

The following example shows how to assign a port already in access mode to dynamic:

```
Switch(config-if)# switchport access vlan dynamic
```

The following example shows how to reconfigure a dynamic-access port to a static-access port:

```
Switch(config-if)# no switchport access vlan dynamic
```

You can verify the previous commands by entering the **show interface *interface-id* switchport** command in privileged EXEC mode and examining information in the Administrative Mode and Operational Mode rows.

### Related Commands

Command	Description
<b>switchport mode</b>	Configures the VLAN membership mode of a port.
<b>switchport multi</b>	Configures a list of VLANs to which the port is associated.

# switchport mode

Use the **switchport mode** interface configuration command to configure the VLAN membership mode of a port. Use the **no** form of this command to reset the mode to the appropriate default for the device.

**switchport mode** { **access** | **multi** | **trunk** }

**no switchport mode** { **access** | **multi** | **trunk** }

## Syntax Description

<b>access</b>	Set the port to access mode (either static-access or dynamic-access depending on the setting of the <b>switchport access vlan</b> command). The port operates as a nontrunking, single VLAN interface that transmits and receives nonencapsulated frames. An access port can be assigned to only one VLAN.
<b>multi</b>	Set the port to multi-VLAN port mode. The port operates as a nontrunking VLAN interface that transmits and receives nonencapsulated frames. A multi-VLAN port can be assigned to one or more VLANs.
<b>trunk</b>	Set the port to a trunking VLAN Layer-2 interface. The port transmits and receives encapsulated (tagged) frames that identify the VLAN of origination. A trunk is a point-to-point link between two switches or between a switch and a router.

## Defaults

All ports are static-access ports in VLAN 1.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA3	This command was first introduced.
11.2(8)SA4	The <b>trunk</b> keyword was added.

## Usage Guidelines

Configuration using the **access**, **multi**, or **trunk** keywords takes effect only when the port is changed to the corresponding mode by using the **switchport mode** command. The static-access, multi-VLAN, and trunk configurations are saved, but only one configuration is active at a time.

The **no switchport mode** form resets the mode to static access.

Only these combinations of port modes can appear on a single switch:

- Multi-VLAN and access ports
- Trunk and access ports

Trunk and multi-VLAN ports cannot coexist on the same switch. If you want to change a multi-VLAN or trunk port into another mode, you must first change it to an access port and then reassign it to the new mode.

### Examples

The following example shows how to configure a port for access mode:

```
Switch(config-if)# switchport mode access
```

The following example shows how to configure a port for multi-VLAN mode:

```
Switch(config-if)# switchport mode multi
```

The following example shows how to configure a port for trunk mode:

```
Switch(config-if)# switchport mode trunk
```

You can verify the previous commands by entering the **show interface *interface-id* switchport** command in privileged EXEC mode and examining information in the Administrative Mode and Operational Mode rows.

### Related Commands

Command	Description
<b>switchport access</b>	Configures a port as a static-access or dynamic-access port.
<b>switchport multi</b>	Configures a list of VLANs to which the port is associated.

# switchport multi

Use the **switchport multi** interface configuration command to configure a list of VLANs to which the port is associated. If the mode is set to multi, the port operates as a member of all VLANs in the list. Use the **no** form of this command to reconfigure the port as an access port.

**switchport multi vlan** {**add** *vlan-list* | **remove** *vlan-list*}

**no switchport multi vlan**

## Syntax Description

<b>vlan</b>	Indicate the VLAN to which the port is associated.
<b>add</b> <i>vlan-list</i>	List of VLAN IDs to add. Valid IDs are from 1 to 1001. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeroes.
<b>remove</b> <i>vlan-list</i>	List of VLAN IDs to remove. Valid IDs are from 1 to 1001. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeroes.

## Defaults

The default for VLAN membership of a multi-VLAN port is VLAN 1.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA3	This command was first introduced.

## Usage Guidelines

The **switchport mode multi** command must be entered before the **switchport multi vlan** *vlan-list* command can take effect.

In the variable *vlan-list*, separate nonconsecutive VLAN IDs with a comma; use a hyphen to designate a range of IDs.

A multi-VLAN port cannot be a secure port or a monitor port.

A multi-VLAN port cannot coexist with a trunk port on the same switch.



### Caution

To avoid loss of connectivity, do not connect multi-VLAN ports to hubs or switches. Connect multi-VLAN ports to routers or servers.

## Examples

The following example shows how to assign a multi-VLAN port already in multimode to two VLANs:

```
Switch(config-if)# switchport multi vlan 2,4
```

The following example shows how to assign a multi-VLAN port already in multimode to a range of VLANs:

```
Switch(config-if)# switchport multi vlan 5-10
```

The following example shows how to reset the VLAN list of a multi-VLAN port to the default (VLAN 1 only):

```
Switch(config-if)# no switchport multi vlan
```

You can verify the previous commands by entering the **show interface *interface-id* switchport** command in privileged EXEC mode and examining information in the Administrative Mode and Operational Mode rows.

## Related Commands

Command	Description
<a href="#">switchport access</a>	Configures a port as a static-access or dynamic-access port.
<a href="#">switchport mode</a>	Configures the VLAN membership mode of a port.

# switchport priority

Use the **switchport priority** interface configuration command to set a port priority for the incoming untagged frames or the priority of frames received by the appliance connected to the specified port. Use the **no** form of this command to return the setting to its default.

**switchport priority** {**default** *default-priority-id* | **extend** {**cos** *value* | **none** | **trust**} | **override**}

**no switchport priority** {**default** *default-priority-id* | **extend** | **override**}

## Syntax Description

<i>default-priority-id</i>	The priority number for untagged traffic. The priority is a number from 0 to 7. Seven is the highest priority.
<b>extend</b>	Set the 802.1p priority of the appliance. <ul style="list-style-type: none"> <li>• <b>cos</b> <i>value</i>—Override the 802.1p priority of devices connected to the appliance. The cos value is a number from 0 to 7. Seven is the highest priority. The <b>cos</b> keyword only applies to the 3524-PWR and the 3548 XL switches.</li> <li>• <b>none</b>—The appliance is not instructed what to do with the priority.</li> <li>• <b>trust</b>—Specify that the appliance should trust (honor) the received 802.1p priority from devices connected to it.</li> </ul>
<b>override</b>	Override the priority of tagged frames with the default value.

## Defaults

The port priority is not set, and the default value for untagged frames received on the port is zero. The appliance connected to the port is not instructed (none) what to do with the priority.

## Command Modes

Interface configuration

## Command History

Release	Modification
12.0(5)XP	This command was first introduced.
12.0(5)XU	The <b>extend</b> keyword and its options were added.

## Usage Guidelines

The default port priority applies if the incoming frame is an untagged frame received from a VLAN trunk or static-access port. This port priority does not apply to the ISL or IEEE 802.1Q VLAN tagged frames. If the incoming frame is an IEEE 802.1Q VLAN tagged frame, the IEEE 802.1p User Priority bits will be used.

The **cos** keyword only applies to the 3524-PWR and 3548 XL switches.

## Examples

The following example shows how to set a default priority on port 3.

```
Switch(config)# interface fa0/3  
Switch(config-if)# switchport priority default 7
```

All untagged frames received from this port will have the same priority value. You can verify the previous commands by entering the **show interface *interface-id* switchport** command in privileged EXEC mode.

The following example shows how to configure the appliance connected to the specified port to honor the received 802.1p priority:

```
Switch(config-if)# switchport priority extend trust
```

You can verify the previous command by entering the **show interface *interface-id* switchport** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>power inline</b>	Determines how inline power is applied to the specified port on the 3524-PWR-XL switch.
<b>show interface</b>	Displays the administrative and operational status of a switching (nonrouting) port.
<b>switchport access</b>	Configures a port as a static-access or dynamic-access port.
<b>switchport mode</b>	Configures the VLAN membership mode of a port.
<b>switchport voice vlan</b>	Configures the voice VLAN on the port.

# switchport trunk allowed vlan

Use the **switchport trunk allowed vlan** interface configuration command to control which VLANs can receive and transmit traffic on the trunk. Use the **no** form of this command to reset the allowed list to the default value.

**switchport trunk allowed vlan** {**add** *vlan-list* | **all** | **except** *vlan-list* | **remove** *vlan-list*}

**no switchport trunk allowed vlan**

## Syntax Description

<b>add</b> <i>vlan-list</i>	List of VLAN IDs to add. Valid IDs are from 1 to 1001. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeroes.
<b>all</b>	Add all VLAN IDs to the list.
<b>except</b> <i>vlan-list</i>	List of exception VLAN IDs VLANs are added except the ones specified). Valid IDs are from 1 to 1001. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeroes.
<b>remove</b> <i>vlan-list</i>	List of VLAN IDs to remove. Valid IDs are from 1 to 1001. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeroes.

## Defaults

All VLANs are included in the allowed list.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Usage Guidelines

When the **no switchport trunk allowed vlan** form is used, the allowed list is reset to the default list, which includes all VLANs.

In the variable *vlan-list*, separate nonconsecutive VLAN IDs with a comma; use a hyphen to designate a range of IDs. You cannot remove VLAN 1 or 1002 to 1005 from the list.

A trunk port cannot be a secure port or a monitor port. However, a static-access port can monitor a VLAN on a trunk port. The VLAN monitored is the one associated with the static-access port.

If a trunk port is identified as a network port, the trunk port becomes the network port for all the VLANs associated with the port.



### Examples

The following example shows how to add VLANs 1, 2, 5, and 6 to the allowed list:

```
Switch(config-if)# switchport trunk allowed vlan add 1,2,5,6
```

You can verify the previous command by entering the **show interface *interface-id* switchport** command in privileged EXEC mode.

### Related Commands

Command	Description
<a href="#">switchport mode</a>	Configures the VLAN membership mode of a port.
<a href="#">switchport trunk encapsulation</a>	Sets the encapsulation format on the trunk port.
<a href="#">switchport trunk native</a>	Sets the native VLAN for untagged traffic when in 802.1Q trunking mode.

# switchport trunk encapsulation

Use the **switchport trunk encapsulation** interface configuration command to set the encapsulation format on the trunk port. Use the **no** form of this command to reset the format to the default.

**switchport trunk encapsulation {isl | dot1q}**

**no switchport trunk encapsulation**

## Syntax Description

<b>isl</b>	Set the encapsulation format to Inter-Switch Link (ISL). The switch encapsulates all received and transmitted packets with an ISL header. The switch filters native frames received from an ISL trunk port.
<b>dot1q</b>	Set the tagging format to IEEE 802.1Q. With this format, the switch supports simultaneous tagged and untagged traffic on a port.

## Defaults

The default encapsulation format is ISL.

## Command Modes

Interface configuration

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.
11.2(8)SA5	The <b>dot1q</b> keyword was added.

## Usage Guidelines

You cannot configure one end of the trunk as an 802.1Q trunk and the other end as an ISL or nontrunk port. However, you can configure one port as an ISL trunk and another port on the same switch as a 802.1Q trunk.

This command is only applicable on switch platforms and port hardware that support both formats.

### Examples

The following example shows how to configure the encapsulation format to 802.1Q:

```
Switch(config-if)# switchport trunk encapsulation dot1q
```

You can verify the previous command by entering the **show interface *interface-id* switchport** command in privileged EXEC mode.

### Related Commands

Command	Description
<b>switchport mode</b>	Configures the VLAN membership mode of a port.
<b>switchport trunk allowed vlan</b>	Controls which VLANs can receive and transmit traffic on the trunk.
<b>switchport trunk native</b>	Sets the native VLAN for untagged traffic when in 802.1Q trunking mode.

# switchport trunk native

Use the **switchport trunk native** interface configuration command to set the native VLAN for untagged traffic when in 802.1Q trunking mode. Use the **no** form of this command to reset the native VLAN to the default.

**switchport trunk native vlan** *vlan-id*

**no switchport trunk native**

<b>Syntax Description</b>	<b>vlan</b> <i>vlan-id</i>	ID of the VLAN that is sending and receiving untagged traffic on the trunk port. Valid IDs are from 1 to 1001. Do not enter leading zeroes.
---------------------------	----------------------------	---

<b>Defaults</b>	VLAN 1 is the default native VLAN ID on the port.
-----------------	---

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA4	This command was first introduced.

<b>Usage Guidelines</b>	All untagged traffic received on the 802.1Q trunk port is forwarded with the native VLAN configured for the port.
	If a packet has a VLAN ID that is the same as the sending port native VLAN ID, the packet is transmitted untagged; otherwise, the switch transmits the packet with a tag.

<b>Examples</b>	The following example shows how to configure VLAN 3 as the default port to send all untagged traffic:
	Switch(config-if)# <b>switchport trunk native vlan 3</b>
	You can verify the previous command by entering the <b>show interface interface-id switchport</b> command in privileged EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>switchport mode</b>	Configures the VLAN membership mode of a port.
	<b>switchport trunk allowed vlan</b>	Controls which VLANs can receive and transmit traffic on the trunk.
	<b>switchport trunk encapsulation</b>	Sets the encapsulation format on the trunk port.

# switchport trunk pruning

Use the **switchport trunk pruning** interface configuration command to configure the VLAN pruning-eligible list for ports in trunking mode. Use the **no** form of this command to return the pruning list to the default setting.

**switchport trunk pruning vlan** {**add** *vlan-list* | **all** | **except** *vlan-list* | **remove** *vlan-list*}

**no switchport trunk pruning**

## Syntax Description

<b>add</b> <i>vlan-list</i>	List of VLAN IDs to add. Valid IDs are from 2 to 1001. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeroes.
<b>all</b>	Add all VLAN IDs to the list.
<b>except</b> <i>vlan-list</i>	List of exception VLAN IDs (VLANs are added except the specified ones). Valid IDs are from 2 to 1001. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeroes.
<b>remove</b> <i>vlan-list</i>	List of VLAN IDs to remove. Valid IDs are from 2 to 1001. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeroes.
<b>no</b>	Set the pruning list to the default.

## Defaults

VLANs 2 through 1001 are pruning eligible.

## Command Modes

Interface configuration

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Usage Guidelines

The pruning-eligible list applies only to trunk ports.

Each trunk port has its own eligibility list.

If you do not want a VLAN to be pruned, remove it from the pruning-eligible list. VLANs that are pruning-ineligible receive flooded traffic.

## Examples

The following example shows how to remove VLANs 3 and 10-15 from the pruning-eligible list:

```
Switch(config-if)# switchport trunk pruning vlan remove 3,10-15
```

You can verify the previous command by entering the **show interface** *interface-id* **switchport** command in privileged EXEC mode.

Related Commands	Command	Description
	<b>show interface</b> <i>interface-id</i> <b>pruning</b>	Displays pruning information for the trunk port.
	<b>show interface</b> <i>interface-id</i> <b>switchport</b>	Displays the administrative and operational status of a switching (nonrouting) port.
	<b>vtp pruning</b>	Enables pruning in the VLAN Trunk Protocol (VTP) administrative domain.

# switchport voice vlan

Use the **switchport voice vlan** interface configuration command to configure the voice VLAN on the port. Use the **no** form of this command to return the setting to its default.

**switchport voice vlan** {*vlan-id* | **dot1p** | **none** | **untagged**}

**no switchport voice vlan**

Syntax Description		
<i>vlan-id</i>		VLAN used for voice traffic. Valid IDs are from 1 to 1001 (IDs 1002 to 4094 are not supported on Catalyst 2900 XL and Catalyst 3500 XL switches). Do not enter leading zeroes. The switch port is an 802.1Q trunk port.
<b>dot1p</b>		The telephone uses priority tagging and uses VLAN 0 (the native VLAN). The switch port is an 802.1Q trunk port.
<b>none</b>		The telephone is not instructed through the CLI about the voice VLAN. The telephone uses the configuration from the telephone key pad.
<b>untagged</b>		The telephone does not tag frames and uses VLAN 4095. The switch port can be an access port or an 802.1Q trunk port.

Defaults	The switch default is not to automatically configure the telephone (none). The telephone default is not to tag frames.
----------	---

Command Modes	Interface configuration
---------------	-------------------------

Command History	Release	Modification
	12.0(5)XU	This command was first introduced.

Usage Guidelines	Ports that are not configured as trunk ports but have a configured voice VLAN are access ports with a voice VLAN ID (VVID).
------------------	---

**Examples**

The following example shows how to configure VLAN 2 as the voice VLAN:

```
Switch(config-if)# switchport voice vlan 2
```

You can verify the previous command by entering the **show interface *interface-id* switchport** command in privileged EXEC mode.

**Related Commands**

Command	Description
<b>power inline</b>	Determines how inline power is applied to the specified port on the 3524-PWR-XL switch.
<b>show interface <i>interface-id</i> switchport</b>	Displays the administrative and operational status of a switching (nonrouting) port.
<b>switchport priority extend</b>	Determines how the appliance connected to the specified port handles priority traffic received on its incoming port.



# tacacs-server attempts

Use the **tacacs-server attempts** global configuration command to control the number of login attempts that can be made on a line set up for Terminal Access Controller Access Control System (TACACS), Extended TACACS, or TACACS+ verification. Use the **no** form of this command to disable this feature and restore the default.

**tacacs-server attempts** *count*

**no tacacs-server attempts**

<b>Syntax Description</b>	<i>count</i> Integer that sets the number of attempts. The range is from 1 to 1000.
---------------------------	---

<b>Defaults</b>	The default number of login attempts is 3.
-----------------	--

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

<b>Examples</b>	The following example shows how to change the login attempt to just one:
	<pre>Switch(config)# <b>tacacs-server attempts 1</b></pre>
	You can verify the previous command by entering the <b>show running-config</b> command in privileged EXEC mode.

Related Commands	Command	Description
	<a href="#">enable use-tacacs</a>	Enables the use of TACACS to determine whether a user can access the privileged command level.
	<a href="#">login tacacs</a>	Configures the switch to use TACACS user authentication.
	<a href="#">show tacacs</a>	Displays various TACACS+ server statistics.
	<a href="#">tacacs-server directed-request</a>	Sends only a username to a specified server when a direct request is issued in association with TACACS, Extended TACACS, and TACACS+.
	<a href="#">tacacs-server host</a>	Specifies a TACACS, Extended TACACS, or TACACS+ host.
	<a href="#">tacacs-server key</a>	Sets the authentication encryption key used for all TACACS+ communications between the access server and the TACACS+ daemon.
	<a href="#">tacacs-server last-resort</a>	Causes the network access server to request the privileged password as verification for TACACS or Extended TACACS or to allow successful login without further user input.
	<a href="#">tacacs-server timeout</a>	Sets the interval that the server waits for a TACACS, Extended TACACS, or TACACS+ server to reply.

# tacacs-server directed-request

Use the **tacacs-server directed-request** global configuration command to send only a username to a specified server when a direct request is issued in association with Terminal Access Controller Access Control System (TACACS), Extended TACACS, and TACACS+. Use the **no** form of this command to send the whole string, both before and after the @ symbol.

**tacacs-server directed-request**

**no tacacs-server directed-request**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Defaults</b>	The directed-request feature is enabled.
-----------------	--

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

<b>Usage Guidelines</b>	<p>This command sends only the portion of the username before the @ symbol to the host specified after the @ symbol. In other words, with the directed-request feature enabled, you can direct a request to any of the configured servers, and only the username is sent to the specified server.</p>
-------------------------	---

Using **no tacacs-server directed-request** causes the whole string, both before and after the @ symbol, to be sent to the default TACACS server. When the directed-request feature is disabled, the router queries the list of servers, starting with the first one in the list. It sends the whole string and accepts the first response it gets from the server. The **tacacs-server directed-request** command is useful for sites that have developed their own TACACS server software that parses the whole string and makes decisions based on it.

With **tacacs-server directed-request** enabled, only configured TACACS servers can be specified by the user after the @ symbol. If the host name specified by the user does not match the IP address of a TACACS server configured by the administrator, the user input is rejected.

Use **no tacacs-server directed-request** to disable the ability of the user to choose between configured TACACS servers and to cause the entire string to be passed to the default server.

<b>Examples</b>	The following example shows how to pass the entire user input to the default TACACS server:
-----------------	---

```
Switch(config)# no tacacs-server directed-request
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

Related Commands	Command	Description
	<b>enable use-tacacs</b>	Enables the use of TACACS to determine whether a user can access the privileged command level.
	<b>login tacacs</b>	Configures the switch to use TACACS user authentication.
	<b>show tacacs</b>	Displays various TACACS+ server statistics.
	<b>tacacs-server directed-request</b>	Sends only a username to a specified server when a direct request is issued in association with TACACS, Extended TACACS, and TACACS+.
	<b>tacacs-server host</b>	Specifies a TACACS, Extended TACACS, or TACACS+ host.
	<b>tacacs-server key</b>	Sets the authentication encryption key used for all TACACS+ communications between the access server and the TACACS+ daemon.
	<b>tacacs-server last-resort</b>	Causes the network access server to request the privileged password as verification for TACACS or Extended TACACS or to allow successful login without further user input.
	<b>tacacs-server timeout</b>	Sets the interval that the server waits for a TACACS, Extended TACACS, or TACACS+ server to reply.

# tacacs-server dns-alias-lookup

Use the **tacacs-server dns-alias-lookup** global configuration command to enable IP Domain Name System alias lookup for Terminal Access Controller Access Control System Plus (TACACS+). Use the **no** form of this command to disable this feature.

**tacacs-server dns-alias-lookup**

**no tacacs-server dns-alias-lookup**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Defaults</b>	The DNS alias lookup is disabled.
-----------------	-----------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

<b>Examples</b>	The following example shows how to enable the IP DNS alias lookup:
-----------------	--

Switch(config)# **tacacs-server dns-alias-lookup**

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>ip domain-name</b>	Defines a default domain name that is used to complete unqualified host names (names without a dotted-decimal domain name).
	<b>ip name-server</b>	Specifies the address of one or more name servers to use for name and address resolution.

# tacacs-server extended

Use the **tacacs-server extended** global configuration command to enable an Extended Terminal Access Controller Access Control System (TACACS) mode. Use the **no** form of this command to disable the mode.

**tacacs-server extended**

**no tacacs-server extended**

## Syntax Description

This command has no arguments or keywords.

## Defaults

The Extended TACACS mode is disabled.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

This command initializes Extended TACACS. To initialize authentication, authorization, and accounting (AAA) and TACACS+, use the **aaa new-model** command.

## Examples

The following example shows how to enable Extended TACACS mode:

```
Switch(config)# tacacs-server extended
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

# tacacs-server host

Use the **tacacs-server host** global configuration command to specify a Terminal Access Controller Access Control System (TACACS), Extended TACACS, or TACACS+ host. Use the **no** form of this command to delete the specified name or address.

**tacacs-server host** *hostname* [**single-connection**] [**port** *integer*] [**timeout** *integer*] [**key** *string*]

**no tacacs-server host** *hostname*

## Syntax Description

<i>hostname</i>	Name or IP address of the host.
<b>single-connection</b>	(Optional) Specify that the switch maintain a single open connection for confirmation from an authentication, authorization, and accounting (AAA) and TACACS+ server (CiscoSecure Release 1.0.1 or later). This command contains no autodetect and fails if the specified host is not running a CiscoSecure daemon.
<b>port</b> <i>integer</i>	(Optional) Specify a server port number. The range is from 1 to 65535.
<b>timeout</b> <i>integer</i>	(Optional) Specify a timeout value. This overrides the global timeout value set with the <b>tacacs-server timeout</b> command for this server only. The timeout is an integer in seconds. The range is from 1 to 300 seconds.
<b>key</b> <i>string</i>	(Optional) Specify an authentication and encryption key. This key must match the key used by the TACACS+ daemon. Specifying this key overrides the key set by the global configuration <b>tacacs-server key</b> command for this server only. The key string is a character string specifying the authentication and encryption key.

## Defaults

No host is specified.  
The default port number is 49.  
The default timeout is 5 seconds.  
No key string is specified.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

You can use multiple **tacacs-server host** commands to specify additional hosts. The Cisco IOS software searches for hosts in the order in which you specify them. Use the **single-connection**, **port**, **timeout**, and **key** options only when running an AAA/TACACS+ server.

Because some of the parameters of the **tacacs-server host** command override global settings made by the **tacacs-server timeout** and **tacacs-server key** commands, you can use this command to enhance security on your network by uniquely configuring individual switches.

## Examples

The following example shows how to specify a TACACS host named *Sea\_Change*:

```
Switch(config)# tacacs-server host Sea_Change
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

The following example shows how to specify that the switch consult the CiscoSecure TACACS+ host named *Sea\_Cure* on port number 51 for AAA confirmation. The timeout value for requests on this connection is 3 seconds; the encryption key is *a\_secret*.

```
Switch(config)# tacacs-server host Sea_Cure single-connection port 51 timeout 3 key
a_secret
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">login tacacs</a>	Configures the switch to use TACACS user authentication.
<a href="#">tacacs-server key</a>	Sets the authentication encryption key used for all TACACS+ communications between the access server and the TACACS+ daemon.
<a href="#">tacacs-server timeout</a>	Sets the interval that the server waits for a TACACS, Extended TACACS, or TACACS+ server to reply.



# tacacs-server key

Use the **tacacs-server key** global configuration command to set the authentication encryption key used for all Terminal Access Controller Access Control System Plus (TACACS+) communications between the access server and the TACACS+ daemon. Use the **no** form of the command to disable the key.

**tacacs-server key** *key*

**no tacacs-server key** [*key*]

## Syntax Description

<i>key</i>	Key used to set authentication and encryption. This key must match the key used on the TACACS+ daemon.
------------	--

## Defaults

No key is specified.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

After enabling authentication, authorization, and accounting (AAA) with the **aaa new-model** command, you must set the authentication and encryption key by using the **tacacs-server key** command.

The key entered must match the key used on the TACACS+ daemon. All leading spaces are ignored; spaces within and at the end of the key are not. If you use spaces in your key, do not enclose the key in quotation marks unless the quotation marks themselves are part of the key.

## Examples

The following example shows how to set the authentication and encryption key to *dare to go*:

```
Switch(config)# tacacs-server key dare to go
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

## Related Commands

Command	Description
<b>aaa new-model</b>	Enables the AAA access control model.
<b>tacacs-server host</b>	Specifies a TACACS, Extended TACACS, or TACACS+ host.

# tacacs-server last-resort

Use the **tacacs-server last-resort** global configuration command to cause the network access server to request the privileged password as verification for Terminal Access Controller Access Control System (TACACS) or Extended TACACS or to allow successful log in without further user input. Use the **no** form of the command to restore the system to the default behavior.

**tacacs-server last-resort {password | succeed}**

**no tacacs-server last-resort {password | succeed}**

<b>Syntax Description</b>	<b>password</b>	Provide the user access to the privileged EXEC command mode by entering the password set by the <b>enable</b> command.
	<b>succeed</b>	Provide the user access to the privileged EXEC command mode without further question.

**Defaults** The last-resort feature is disabled.

**Command Modes** Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

**Usage Guidelines** Use the **tacacs-server last-resort** command to be sure that you can log in; for example, a systems administrator would use this command to log in to troubleshoot TACACS servers that might be down.



**Note**

This command is not used in authentication, authorization, and accounting (AAA) and TACACS+.

**Examples** The following example shows how to force successful log in:

```
Switch(config)# tacacs-server last-resort succeed
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>enable password</b>	Sets a local password to control access to various privilege levels.
	<b>login (EXEC)</b>	Changes a login username.

# tacacs-server login-timeout

Use the **tacacs-server login-timeout** global configuration command to cause the network access server to request the privileged password as verification for Terminal Access Controller Access Control System (TACACS) or Extended TACACS or to allow successful log in without further user input. Use the **no** form of the command to restore the system to the default behavior.

**tacacs-server login-timeout {password | succeed}**

**no tacacs-server login-timeout {password | succeed}**

## Syntax Descriptions

<b>password</b>	Provide the user access to the privileged EXEC command mode by entering the password set by the enable command.
<b>succeed</b>	Provide the user access to the privileged EXEC command mode without further question.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA6	This command was first introduced.

## Usage Guidelines

Use the **tacacs-server login-timeout** command to be sure that you can log in; for example, a system administrator would use this command to log in to troubleshoot TACACS servers that might be down.



### Note

This command is not used in authentication, authorization, and accounting (AAA)/TACACS+.

## Examples

The following example shows how to force successful log in:

```
Switch(config)# tacacs-server login-timeout succeed
```

## Related Commands

Command	Description
<b>enable password</b>	Sets a local password to control access to various privilege levels.
<b>login (EXEC)</b>	Changes a login username.

# tacacs-server optional-passwords

Use the **tacacs-server optional-passwords** global configuration command to specify that the first Terminal Access Controller Access Control System (TACACS) request to a TACACS or Extended TACACS server be made without password verification. Use the **no** form of this command to restore the default.

**tacacs-server optional-passwords**

**no tacacs-server optional-passwords**

**Syntax Description** This command has no arguments or keywords.

**Defaults** Password verification is disabled.

**Command Modes** Global configuration

Command History	Release	Modification
	11.2(8)SA6	This command was first introduced.

**Usage Guidelines** When the user enters the login name, the login request is transmitted with the name and a zero-length password. If accepted, the login procedure completes. If the TACACS server refuses this request, the server software prompts for a password and tries again when the user supplies a password. The TACACS server must support authentication for users without passwords to make use of this feature. This feature supports all TACACS request—login, Serial Line Internet Protocol (SLIP), enable, and so on.



**Note** This command is not used in authentication, authorization, and accounting (AAA)/TACACS+.

**Examples** The following example shows how to configure the first login to bypass TACACS verification:

```
Switch(config)# tacacs-server optional-passwords
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

# tacacs-server retransmit

Use the **tacacs-server retransmit** global configuration command to specify the number of times the Cisco IOS software searches the list of Terminal Access Controller Access Control System (TACACS) or Extended TACACS server hosts. Use the **no** form of this command to disable retransmission.

**tacacs-server retransmit** *retries*

**no tacacs-server retransmit**

<b>Syntax Description</b>	<i>retries</i> Integer that specifies the retransmit count. The range is from 0 to 100.
---------------------------	---

<b>Defaults</b>	The default is two retries.
-----------------	-----------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA6	This command was first introduced.

<b>Usage Guidelines</b>	The Cisco IOS software tries all servers, allowing each one to time out before increasing the retransmit count.
-------------------------	---

<b>Examples</b>	The following example shows how to specify a retransmit counter value of 5:  Switch(config)# <b>tacacs-server retransmit 5</b>
	You can verify the previous command by entering the <b>show running-config</b> command in privileged EXEC mode.

# tacacs-server timeout

Use the **tacacs-server timeout** global configuration command to set the interval that the server waits for a Terminal Access Controller Access Control System (TACACS), Extended TACACS, or TACACS+ server to reply. Use the **no** form of this command to restore the default.

**tacacs-server timeout** *seconds*

**no tacacs-server timeout**

<b>Syntax Description</b>	<i>seconds</i> Integer that specifies the timeout interval in seconds. The range is from 1 to 1000.
---------------------------	---

<b>Defaults</b>	The timeout interval is 5 seconds.
-----------------	------------------------------------

<b>Command Modes</b>	Global configuration
----------------------	----------------------

<b>Command History</b>	Release	Modification
	11.2(8)SA6	This command was first introduced.

<b>Examples</b>	The following example shows how to change the interval timer to 10 seconds:
-----------------	---

```
Switch(config)# tacacs-server timeout 10
```

You can verify the previous command by entering the **show running-config** command in privileged EXEC mode.

<b>Related Commands</b>	Command	Description
	<a href="#">tacacs-server host</a>	Specifies a TACACS, Extended TACACS, or TACACS+ host.

# udld

Use the **udld** interface configuration command to enable UniDirectional Link Detection (UDLD) on a port to assist with the detection of spanning-tree loops on logical one-way connections. Use the **no** form of this command to return the port setting to the global setting.

**udld {enable | disable}**

**no udld {enable | disable}**

## Syntax Description

<b>enable</b>	Enable UDLD on the specified port.
<b>disable</b>	Disable UDLD on the specified port.

## Defaults

UDLD follows the setting of the **udld enable** global configuration command and is disabled on all ports.

## Command Modes

Interface configuration

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Usage Guidelines

UDLD is supported on fiber- and copper-based Ethernet ports.

UDLD is not supported on ATM interfaces.

A UDLD-capable port cannot detect a unidirectional link if it is connected to a UDLD-incapable port of another switch.

This setting overrides the global UDLD configuration on the switch.

## Examples

The following example shows how to enable UDLD on port 2:

```
Switch(config)# interface fastethernet 0/2  
Switch(config-if)# udld enable
```

You can verify the previous command by entering the **show running-config** or the **show udld interface** command in privilege EXEC mode.

## Related Commands

Command	Description
<b>show running-config</b>	Displays the running configuration on the switch.
<b>show udld</b>	Displays UDLD status for all ports or the specified port.
<b>udld enable</b>	Enables UDLD on all ports on the switch.
<b>udld reset</b>	Resets any interface that has been shut down by UDLD.

# udld enable

Use the **udld enable** global configuration command to enable UniDirectional Link Detection (UDLD) on all ports on the switch to assist with the detection of spanning-tree loops on logical one-way connections. Use the **no** form of this command to return the switch setting to its default value.

**udld enable**

**no udld enable**

## Syntax Description

This command has no keywords or arguments.

## Defaults

UDLD is disabled on the switch.

## Command Modes

Global configuration mode

## Command History

Release	Modification
12.0(5)XU	This command was first introduced.

## Usage Guidelines

UDLD is supported on fiber- and copper-based Ethernet ports.

UDLD is not supported on ATM interfaces.

A UDLD-capable port cannot detect a unidirectional link if it is connected to a UDLD-incapable port of another switch.

This setting is overridden by each specific port UDLD configuration.

## Examples

The following example shows how to enable UDLD on the switch:

```
Switch(config)# udld enable
```

You can verify the previous command by entering the **show running-config** in privilege EXEC mode.

## Related Commands

Command	Description
<b>show running-config</b>	Displays the running configuration on the switch.
<b>show udld</b>	Displays UDLD status for all ports or the specified port.
<b>udld</b>	Enables UDLD on a port.
<b>udld reset</b>	Resets any interface that has been shut down by UDLD.



# udld reset

Use the **udld reset** privileged EXEC command to reset all interfaces that have been shut down by UniDirectional Link Detection (UDLD).

## udld reset

**Syntax Description** This command has no keywords or arguments.

**Command Modes** Privileged EXEC mode

Command History	Release	Modification
	12.0(5)XU	This command was first introduced.

**Examples** The following example shows how to reset all interfaces that have been shut down by UDLD:

```
Switch# udld reset  
1 ports shutdown by UDLD were reset.
```

You can verify the previous command by entering the **show udld** in user EXEC mode.

Related Commands	Command	Description
	<b>show running-config</b>	Displays the running configuration on the switch.
	<a href="#">show udld</a>	Displays UDLD status for all ports or the specified port.
	<a href="#">udld</a>	Enables UDLD on a port.
	<a href="#">udld enable</a>	Enables UDLD on all ports on the switch.

# vlan

Use the **vlan** VLAN database command to configure VLAN characteristics. Use the **no** form of this command to delete a VLAN and its configured characteristics.

```
vlan vlan-id [name vlan-name] [media {ethernet | fddi | fdi-net | tokenring | tr-net}]
[state {suspend | active}] [said said-value] [mtu mtu-size] [ring ring-number]
[bridge bridge-number | type {srb | srt}] [parent parent-vlan-id]
[stp type {ieee | ibm | auto}] [are are-number] [ste ste-number]
[backupcrf {enable | disable}] [tb-vlan1 tb-vlan1-id] [tb-vlan2 tb-vlan2-id]
```

```
no vlan vlan-id [name vlan-name] [media {ethernet | fddi | fdi-net | tokenring | tr-net}]
[state {suspend | active}] [said said-value] [mtu mtu-size] [ring ring-number]
[bridge bridge-number | type {srb | srt}] [parent parent-vlan-id]
[stp type {ieee | ibm | auto}] [are are-number] [ste ste-number]
[backupcrf {enable | disable}] [tb-vlan1 tb-vlan1-id] [tb-vlan2 tb-vlan2-id]
```



## Note

Catalyst 2900 XL and Catalyst 3500 XL switches support only Ethernet ports. You configure only FDDI and Token Ring media-specific characteristics for VLAN Trunk Protocol (VTP) global advertisements to other switches. These VLANs are locally suspended.

Table 2-8 lists the valid syntax for each media type.

**Table 2-8 Valid Syntax for Different Media Types**

Media Type	Valid Syntax
Ethernet	<b>vlan</b> <i>vlan-id</i> [ <b>name</b> <i>vlan-name</i> ] <b>media ethernet</b> [ <b>state</b> { <b>suspend</b>   <b>active</b> }] [ <b>said</b> <i>said-value</i> ] [ <b>mtu</b> <i>mtu-size</i> ] [ <b>tb-vlan1</b> <i>tb-vlan1-id</i> ] [ <b>tb-vlan2</b> <i>tb-vlan2-id</i> ]
FDDI	<b>vlan</b> <i>vlan-id</i> [ <b>name</b> <i>vlan-name</i> ] <b>media fddi</b> [ <b>state</b> { <b>suspend</b>   <b>active</b> }] [ <b>said</b> <i>said-value</i> ] [ <b>mtu</b> <i>mtu-size</i> ] [ <b>ring</b> <i>ring-number</i> ] [ <b>parent</b> <i>parent-vlan-id</i> ] [ <b>tb-vlan1</b> <i>tb-vlan1-id</i> ] [ <b>tb-vlan2</b> <i>tb-vlan2-id</i> ]
FDDI-NET	<b>vlan</b> <i>vlan-id</i> [ <b>name</b> <i>vlan-name</i> ] <b>media fdi-net</b> [ <b>state</b> { <b>suspend</b>   <b>active</b> }] [ <b>said</b> <i>said-value</i> ] [ <b>mtu</b> <i>mtu-size</i> ] [ <b>bridge</b> <i>bridge-number</i> ] [ <b>stp type</b> { <b>ieee</b>   <b>ibm</b>   <b>auto</b> }] [ <b>tb-vlan1</b> <i>tb-vlan1-id</i> ] [ <b>tb-vlan2</b> <i>tb-vlan2-id</i> ] If VTP V2 mode is disabled, do not set the <b>stp type</b> to <b>auto</b> .
Token Ring	VTP V2 mode is disabled. <b>vlan</b> <i>vlan-id</i> [ <b>name</b> <i>vlan-name</i> ] <b>media tokenring</b> [ <b>state</b> { <b>suspend</b>   <b>active</b> }] [ <b>said</b> <i>said-value</i> ] [ <b>mtu</b> <i>mtu-size</i> ] [ <b>ring</b> <i>ring-number</i> ] [ <b>parent</b> <i>parent-vlan-id</i> ] [ <b>tb-vlan1</b> <i>tb-vlan1-id</i> ] [ <b>tb-vlan2</b> <i>tb-vlan2-id</i> ]
Token Ring concentrator relay function (TRCRF)	VTP V2 mode is enabled. <b>vlan</b> <i>vlan-id</i> [ <b>name</b> <i>vlan-name</i> ] <b>media tokenring</b> [ <b>state</b> { <b>suspend</b>   <b>active</b> }] [ <b>said</b> <i>said-value</i> ] [ <b>mtu</b> <i>mtu-size</i> ] [ <b>ring</b> <i>ring-number</i> ] [ <b>parent</b> <i>parent-vlan-id</i> ] [ <b>bridge type</b> { <b>srb</b>   <b>srt</b> }] [ <b>are</b> <i>are-number</i> ] [ <b>ste</b> <i>ste-number</i> ] [ <b>backupcrf</b> { <b>enable</b>   <b>disable</b> }] [ <b>tb-vlan1</b> <i>tb-vlan1-id</i> ] [ <b>tb-vlan2</b> <i>tb-vlan2-id</i> ]

**Table 2-8 Valid Syntax for Different Media Types (continued)**

Media Type	Valid Syntax
Token Ring-NET	VTP V2 mode is disabled. <b>vlan</b> <i>vlan-id</i> [ <b>name</b> <i>vlan-name</i> ] <b>media tr-net</b> [ <b>state</b> { <b>suspend</b>   <b>active</b> }] [ <b>said</b> <i>said-value</i> ] [ <b>mtu</b> <i>mtu-size</i> ] [ <b>bridge</b> <i>bridge-number</i> ] [ <b>stp type</b> { <b>ieee</b>   <b>ibm</b> }] [ <b>tb-vlan1</b> <i>tb-vlan1-id</i> ] [ <b>tb-vlan2</b> <i>tb-vlan2-id</i> ]
Token Ring bridge relay function (TRBRF)	VTP V2 mode is enabled. <b>vlan</b> <i>vlan-id</i> [ <b>name</b> <i>vlan-name</i> ] <b>media tr-net</b> [ <b>state</b> { <b>suspend</b>   <b>active</b> }] [ <b>said</b> <i>said-value</i> ] [ <b>mtu</b> <i>mtu-size</i> ] [ <b>bridge</b> <i>bridge-number</i> ] [ <b>stp type</b> { <b>ieee</b>   <b>ibm</b>   <b>auto</b> }] [ <b>tb-vlan1</b> <i>tb-vlan1-id</i> ] [ <b>tb-vlan2</b> <i>tb-vlan2-id</i> ]

## VLAN Configuration Rules

Table 2-9 describes the rules for configuring VLANs.

**Table 2-9 VLAN Configuration Rules**

Configuration	Rule
VTP V2 mode is enabled, and you are configuring a TRCRF VLAN media type.	Specify a parent VLAN ID of a TRBRF that already exists in the database. Specify a ring number. Do not leave this field blank. Specify unique ring numbers when TRCRF VLANs have the same parent VLAN ID. Only one backup concentrator relay function (CRF) can be enabled.
VTP V2 mode is enabled, and you are configuring VLANs other than TRCRF media type.	Do not specify a backup CRF.
VTP V2 mode is enabled, and you are configuring a TRBRF VLAN media type.	Specify a bridge number. Do not leave this field blank.

**Table 2-9 VLAN Configuration Rules (continued)**

Configuration	Rule
VTP V2 mode is disabled.	No VLAN can have an STP type set to auto. This rule applies to Ethernet, FDDI, FDDI-NET, Token Ring, and Token Ring-NET VLANs.
Add a VLAN that requires translational bridging (values are not set to zero).	The translational bridging VLAN IDs that are used must already exist in the database. The translational bridging VLAN IDs that a configuration points to must also contain a pointer to the original VLAN in one of the translational bridging parameters (for example, Ethernet points to FDDI, and FDDI points to Ethernet). The translational bridging VLAN IDs that a configuration points to must be different media types than the original VLAN (for example, Ethernet can point to Token Ring). If both translational bridging VLAN IDs are configured, these VLANs must be different media types (for example, Ethernet can point to FDDI and Token Ring).

**Syntax Description**

<i>vlan-id</i>	ID of the configured VLAN. Valid IDs are from 1 to 1005 and must be unique within the administrative domain. Do not enter leading zeroes.
<b>name</b>	(Optional) Keyword to be followed by the VLAN name.
<i>vlan-name</i>	ASCII string from 1 to 32 characters that must be unique within the administrative domain.
<b>media</b>	(Optional) Keyword to be followed by the VLAN media type.
<b>ethernet</b>	Ethernet media type.
<b>fddi</b>	FDDI media type.
<b>fdi-net</b>	FDDI network entity title (NET) media type.
<b>tokenring</b>	Token Ring media type if the VTP V2 mode is disabled. TRCRF media type if the VTP V2 mode is enabled.
<b>tr-net</b>	Token Ring network entity title (NET) media type if the VTP V2 mode is disabled. TRBRF media type if the VTP V2 mode is enabled.
<b>state</b>	(Optional) Keyword to be followed by the VLAN state.
<b>active</b>	VLAN is operational.
<b>suspend</b>	VLAN is suspended. Suspended VLANs do not pass packets.
<b>said</b>	(Optional) Keyword to be followed by the security association identifier (SAID) as documented in IEEE 802.10.
<i>said-value</i>	Integer from 1 to 4294967294 that must be unique within the administrative domain.
<b>mtu</b>	(Optional) Keyword to be followed by the maximum transmission unit (packet size in bytes).
<i>mtu-size</i>	Packet size in bytes from 1500 to 18190 that the VLAN can use.
<b>ring</b>	(Optional) Keyword to be followed by the logical ring for an FDDI, Token Ring, or TRCRF VLAN.

<i>ring-number</i>	Integer from 1 to 4095.
<b>bridge</b>	(Optional) Keyword to be followed by the logical distributed source-routing bridge. This bridge that interconnects all logical rings having this VLAN as a parent VLAN in FDDI-NET, Token Ring-NET, and TRBRF VLANs.
<i>bridge-number</i>	Integer from 0 to 15.
<b>type</b>	Keyword to be followed by the bridge type. Applies only to TRCRF VLANs.
<b>srb</b>	Source-route bridging VLAN.
<b>srt</b>	Source-route transparent bridging VLAN.
<b>parent</b>	(Optional) Keyword to be followed by the parent VLAN of an existing FDDI, Token Ring, or TRCRF VLAN. This parameter identifies the TRBRF to which a TRCRF belongs and is required when defining a TRCRF.
<i>parent-vlan-id</i>	Integer from 0 to 1005.
<b>stp type</b>	(Optional) Keyword to be followed by the spanning-tree type for FDDI-NET, Token Ring-NET, or TRBRF VLAN.
<b>ieee</b>	IEEE Ethernet STP running source-route transparent (SRT) bridging.
<b>ibm</b>	IBM STP running source-route bridging (SRB).
<b>auto</b>	STP running a combination of source-route transparent bridging (IEEE) and source-route bridging (IBM).
<b>are</b>	Keyword to be followed by the number of all-routes explorer (ARE) hops. This keyword applies only to TRCRF VLANs.
<i>are-number</i>	Integer from 0 to 13 that defines the maximum number of ARE hops for this VLAN.
<b>ste</b>	Keyword to be followed by the number of spanning-tree explorer (STE) hops. This keyword applies only to TRCRF VLANs.
<i>ste-number</i>	Integer from 0 to 13 that defines the maximum number of STE hops for this VLAN.
<b>backupcrf</b>	Keyword to be followed by the backup CRF mode. This keyword applies only to TRCRF VLANs.
<b>enable</b>	Enable backup CRF mode for this VLAN.
<b>disable</b>	Disable backup CRF mode for this VLAN.
<b>tb-vlan1</b> and <b>tb-vlan2</b>	(Optional) Keyword to be followed by the first and second VLAN to which this VLAN is translationally bridged. Translational VLANs translate FDDI or Token Ring to Ethernet, for example.
<i>tb-vlan1-id</i> and <i>tb-vlan2-id</i>	Integer that ranges from 0 to 1005.

## Defaults

The *vlan-name* variable is *VLANxxxx*, where *xxxx* represents four numeric digits (including leading zeroes) equal to the VLAN ID number.

The **media** type is **ethernet**.

The state is **active**.

The *said value* is 100000 plus the VLAN ID.

The *mtu size* for Ethernet, FDDI, and FDDI-NET VLANs is 1500 bytes. The MTU size for Token Ring and Token Ring-NET VLANs is 1500 bytes. The MTU size for TRBRF and TRCRF VLANs is 4472 bytes.

The *ring number* for Token Ring VLANs is zero. For FDDI VLANs, there is no default. For TRCRF VLANs, you must specify a ring number.

The bridge number is zero (no source-routing bridge) for FDDI-NET and Token Ring-NET VLANs. For TRBRF VLANs, you must specify a bridge number.

The parent VLAN ID is zero (no parent VLAN) for FDDI and Token Ring VLANs. For TRCRF VLANs, you must specify a parent VLAN ID. For both Token Ring and TRCRF VLANs, the parent VLAN ID must already exist in the database and be associated with a Token Ring-NET or TRBRF VLAN.

The STP type is **ieee** for FDDI-NET VLANs. For Token Ring-NET and TRBRF VLANs, the default is **ibm**.

The ARE value is 7.

The STE value is 7.

Backup CRF is disabled.

The *tb-vlan1-id* and *tb-vlan2-id* variables are zero (no translational bridging).

## Command Modes

VLAN database

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Usage Guidelines

When the **no vlan** *vlan-id* form is used, the VLAN is deleted. Deleting VLANs automatically resets to zero any other parent VLANs and translational bridging parameters that refer to the deleted VLAN.

When the **no vlan** *vlan-id* **name** *vlan-name* form is used, the VLAN name returns to the default name (*VLANxxxx*, where *xxxx* represent four numeric digits (including leading zeroes) equal to the VLAN ID number).

When the **no vlan** *vlan-id* **media** form is used, the media type returns to the default (**ethernet**). Changing the VLAN media type (including the **no** form) resets the VLAN MTU to the default MTU for the type (unless the **mtu** keyword is also present in the command). It also resets the VLAN parent and translational bridging VLAN to the default (unless the **parent**, **tb-vlan1**, and/or **tb-vlan2** are also present in the command).

When the **no vlan** *vlan-id* **state** form is used, the VLAN state returns to the default (**active**).

When the **no vlan** *vlan-id* **sa** form is used, the VLAN SAID returns to the default (100,000 plus the VLAN ID).

When the **no vlan** *vlan-id* **mtu** form is used, the VLAN MTU returns to the default for the applicable VLAN media type. You can also modify the MTU using the **media** keyword.

When the **no vlan** *vlan-id* **ring** form is used, the VLAN logical ring number returns to the default (0).

When the **no vlan** *vlan-id* **bridge** form is used, the VLAN source-routing bridge number returns to the default (0). The **vlan** *vlan-id* **bridge** command is only used for FDDI-NET and Token Ring-NET VLANs and is ignored in other VLAN types.

When the **no vlan *vlan-id* parent** form is used, the parent VLAN returns to the default (0). The parent VLAN resets to the default if the parent VLAN is deleted or if the **media** keyword changes the VLAN type or the VLAN type of the parent VLAN.

When the **no vlan *vlan-id* stp type** form is used, the VLAN spanning-tree type returns to the default (ieee).

When the **no vlan *vlan-id* tb-vlan1** or **no vlan *vlan-id* tb-vlan2** form is used, the VLAN translational bridge VLAN (or VLANs, if applicable) returns to the default (0). Translational bridge VLANs must be a different VLAN type than the affected VLAN, and if two are specified, the two must be different VLAN types from each other. A translational bridge VLAN resets to the default if the translational bridge VLAN is deleted, if the **media** keyword changes the VLAN type, or if the **media** keyword changes the VLAN type of the corresponding translation bridge VLAN.

### Examples

The following example shows how to add an Ethernet VLAN with default media characteristics. The default includes a *vlan-name* of *VLANxxx*, where *xxx* represents four numeric digits (including leading zeroes) equal to the VLAN ID number. The default **media** option is **ethernet**; the **state** option is **active**. The default *said-value* variable is 100000 plus the VLAN ID; the *mtu-size* variable is 1500; the **stp-type** option is **ieee**. The VLAN is added if it did not already exist; otherwise, this command does nothing.

```
Switch(vlan)# vlan 2
```

The following example shows how to modify an existing VLAN by changing its name and MTU size:

```
Switch(vlan)# no vlan name engineering mtu 1200
```

You can verify the previous commands by entering the **show vlan** command in privileged EXEC mode.

### Related Commands

Command	Description
<b>show vlan</b>	Displays the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) in the administrative domain.

# vlan database

Use the **vlan database** privileged EXEC command to enter VLAN database mode from the command-line interface (CLI). From the CLI, you can add, delete, and modify VLAN configurations and globally propagate these changes by using the VLAN Trunk Protocol (VTP).

## vlan database

**Syntax Description** This command has no arguments or keywords.

**Defaults** No default is defined.

**Command Modes** Privileged EXEC

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

**Usage Guidelines** To return to the privileged EXEC mode from the VLAN database mode, enter the **exit** command.



### Note

This command mode is different from other modes because it is session-oriented. When you add, delete, or modify VLAN parameters, the changes are not applied until you exit the session by entering the **apply** or **exit** commands. When the changes are applied, the VTP configuration version is incremented. You can also *not* apply the changes to the VTP database by entering **abort**.

**Examples** The following example shows how to enter the VLAN database mode from the privileged EXEC mode:

```
Switch# vlan database
Switch(vlan)#
```

Related Commands	Command	Description
	<b>abort</b>	Abandons the proposed new VLAN database, exits VLAN database mode, and returns to privileged EXEC mode.
	<b>apply</b>	Implements the proposed new VLAN database, increments the database configuration revision number, propagates it throughout the administrative domain, and remains in VLAN database mode.
	<b>reset</b>	Abandons the proposed VLAN database and remains in VLAN database mode. Resets the proposed database to the currently implemented VLAN database on the switch.
	<b>shutdown vlan</b>	Shuts down (suspends) local traffic on the specified VLAN.



# vmps reconfirm (Privileged EXEC)

Use the **vmps reconfirm** privileged EXEC command to immediately send VLAN Query Protocol (VQP) queries to reconfirm all dynamic VLAN assignments with the VLAN Membership Policy Server (VMPS).

## vmps reconfirm

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Defaults</b>	No default is defined.
-----------------	------------------------

<b>Command Modes</b>	Privileged EXEC
----------------------	-----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA4	This command was first introduced.

<b>Examples</b>	The following example shows how to immediately send VQP queries to the VMPS:
	Switch# <b>vmps reconfirm</b>

You can verify the previous command by entering the **show vmps** command in privileged EXEC mode and examining the VMPS Action row of the Reconfirmation Status section. The **show vmps** command shows the result of the last time the assignments were reconfirmed either as a result of reconfirmation timer expiring or because the **vmps reconfirm** command was issued.

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show vmps</a>	Displays VQP and VMPS information.
	<a href="#">vmps reconfirm (Privileged EXEC)</a> and <a href="#">vmps reconfirm (Global Configuration)</a>	Sends VQP queries to reconfirm all dynamic VLAN assignments with the VMPS.

## vmps reconfirm (Global Configuration)

Use the **vmps reconfirm** global configuration command to change the reconfirmation interval for the VLAN Query Protocol (VQP) client.

**vmps reconfirm** *interval*

Syntax Description	<i>interval</i>	Reconfirmation interval for VQP client queries to the VLAN Membership Policy Server (VMPS) to reconfirm dynamic VLAN assignments. The interval range is from 1 to 120 minutes.
--------------------	-----------------	--

Defaults	The default reconfirmation interval is 60 minutes.
----------	--

Command Modes	Global configuration
---------------	----------------------

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

Examples	The following example shows how to set the VQP client to reconfirm dynamic VLAN entries every 20 minutes:
----------	---

```
Switch(config)# vmps reconfirm 20
```

You can verify the previous command by entering the **show vmps** command in privileged EXEC mode and examining information in the Reconfirm Interval row.

Related Commands	Command	Description
	<a href="#">show vmps</a>	Displays VQP and VMPS information.
	<a href="#">vmps reconfirm (Privileged EXEC)</a> and <a href="#">vmps reconfirm (Global Configuration)</a>	Sends VQP queries to reconfirm all dynamic VLAN assignments with the VMPS.

# vmmps retry

Use the **vmmps retry** global configuration command to configure the per-server retry count for the VLAN Query Protocol (VQP) client.

**vmmps retry** *count*

## Syntax Description

<i>count</i>	Number of attempts to contact the VLAN Membership Policy Server (VMPS) by the client before querying the next server in the list. The retry range is from 1 to 10.
--------------	--

## Defaults

The default retry count is 3.

## Command Modes

Global configuration

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Examples

The following example shows how to set the retry count to 7:

```
Switch(config)# vmmps retry 7
```

You can verify the previous command by entering the **show vmmps** command in privileged EXEC mode and examining information in the Server Retry Count row.

## Related Commands

Command	Description
<a href="#">show vmmps</a>	Displays VQP and VMPS information.

## vmps server

Use the **vmps server** global configuration command to configure the primary VLAN Membership Policy Server (VMPS) and up to three secondary servers. Use the **no** form of this command to remove a VMPS server.

**vmps server** *ipaddress* [**primary**]

**no vmps server** [*ipaddress*]

<b>Syntax Description</b>	<i>ipaddress</i>	IP address or host name of the primary or secondary VMPS servers. If you specify a host name, the Domain Name System (DNS) server must be configured.
	<b>primary</b>	(Optional) Determines whether primary or secondary VMPS servers are being configured.

**Defaults** No primary or secondary VMPS servers are defined.

**Command Modes** Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	11.2(8)SA4	This command was first introduced.

**Usage Guidelines**

The first server entered is automatically selected as the primary server whether or not **primary** is entered. The first server address can be overridden by using **primary** in a subsequent command.

If a member switch in a cluster configuration does not have an IP address, the cluster does not use the VMPS server configured for that member switch. Instead, the cluster uses the VMPS server on the command switch, and the command switch proxies the VMPS requests. The VMPS server treats the cluster as a single switch and uses the IP address of the command switch to respond to requests.

When using the **no** form without specifying the *ipaddress*, all configured servers are deleted. If you delete all servers when dynamic-access ports are present, the switch cannot forward packets from new sources on these ports because it cannot query the VMPS.

## Examples

The following example shows how to configure the server with IP address 191.10.49.20 as the primary VMPS server. The servers with IP addresses 191.10.49.21 and 191.10.49.22 are configured as secondary servers:

```
Switch(config)# vmips server 191.10.49.20 primary  
Switch(config)# vmips server 191.10.49.21  
Switch(config)# vmips server 191.10.49.22
```

The following example shows how to delete the server with IP address 191.10.49.21:

```
Switch(config)# no vmips server 191.10.49.21
```

You can verify the previous commands by entering the **show vmips** command in privileged EXEC mode and examining information in the VMPS Domain Server row.

## Related Commands

Command	Description
<a href="#">show vmips</a>	Displays VQP and VMPS information.

# vtp

Use the **vtp** VLAN database command to configure the VLAN Trunk Protocol (VTP) mode. Use the **no** form of this command to return to the default setting.

**vtp {server | client | transparent}**

**no vtp {server | client | transparent}**

## Syntax Description

<b>server</b>	Place the switch in VTP server mode. A switch in VTP server mode is enabled for VTP and sends advertisements. You can configure VLANs on it. The switch can recover all the VLAN information in the current VTP database from nonvolatile storage after reboot.
<b>client</b>	Place the switch in VTP client mode. A switch in VTP client mode is enabled for VTP, can send advertisements, but does not have enough nonvolatile storage to store VLAN configurations. You cannot configure VLANs on it. When a VTP client starts up, it does not transmit VTP advertisements until it receives advertisements to initialize its VLAN database.
<b>transparent</b>	Place the switch in VTP transparent mode. A switch in VTP transparent mode is disabled for VTP, does not transmit advertisements or learn from advertisements sent by other devices, and cannot affect VLAN configurations on other devices in the network. The switch receives VTP advertisements and forwards them on all trunk ports except the one on which the advertisement was received. The configuration of multi-VLAN ports causes the switch to automatically enter transparent mode.



## Note

The switch supports up to 250 VLANs on the Catalyst 2912MF, 2924M, and Catalyst 3500 XL switches. All other Catalyst 2900 XL switches support up to 64 VLANs. If you define more than 250 or 64, respectively, or if the switch receives an advertisement that contains more than 250 or 64 VLANs, the switch automatically enters VTP transparent mode and operates with the VLAN configuration preceding the one that put it into transparent mode. The count of 250 or 64 VLANs always includes VLAN 1 but never includes VLANs 1002 to 1005. The switch can have 250 or 64 active VLANs, plus VLANs 1002 through 1005, which are inactive.

## Defaults

Server mode is the default mode.

## Command Modes

VLAN database

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

---

**Usage Guidelines**

The **no vtp client** and **no vtp transparent** forms of the command return the switch to VTP server mode. The **vtp server** command is the same as **no vtp client** or **no vtp transparent** except that it does not return an error if the switch is not in client or transparent mode.

---

**Examples**

The following example shows how to place the switch in VTP transparent mode:

```
Switch(vlan) # vtp transparent
```

You can verify the previous commands by entering the **show vtp status** command in privileged EXEC mode.

---

**Related Commands**

Command	Description
<a href="#">show vtp status</a>	Displays general information about the VTP management domain, status, and counters.

# vtp domain

Use the **vtp domain** VLAN database command to configure the VLAN Trunk Protocol (VTP) administrative domain.

**vtp domain** *domain-name*

## Syntax Description

<i>domain-name</i>	ASCII string from 1 to 32 characters that identifies the VTP administrative domain for the switch. The domain name is case sensitive.
--------------------	---

## Defaults

No domain name is defined.

## Command Modes

VLAN database

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Usage Guidelines

The switch is in the no-management-domain state until you configure a domain name. While in the no-management-domain state, the switch does not transmit any VTP advertisements even if changes occur to the local VLAN configuration. The switch leaves the no-management-domain state after receiving the first VTP summary packet on any port that is currently trunking or after configuring a domain name using the **vtp domain** command. If the switch receives its domain from a summary packet, it resets its configuration revision number to zero. After the switch leaves the no-management-domain state, it can never be configured to reenter it until you clear the nonvolatile RAM (NVRAM) and reload the software.

Domain names are case sensitive.

Once you configure a domain name, it cannot be removed. You can only reassign it to a different domain.

## Examples

The following example shows how to set the administrative domain for the switch:

```
Switch(vlan)# vtp domain OurDomainName
```

You can verify the previous commands by entering the **show vtp status** command in privileged EXEC mode.

## Related Commands

Command	Description
<a href="#">show vtp status</a>	Displays general information about the VTP management domain, status, and counters.
<a href="#">vtp password</a>	Configures the VTP administrative domain password.



# vtp file

Use the **vtp file** global configuration command to modify the VLAN Trunk Protocol (VTP) configuration storage filename. Use the **no** form of this command to return the filename to its default name.

**vtp file** *ifsfilename*

**no vtp file**

Syntax Description	<i>ifsfilename</i>	The IOS IFS filename where the VTP VLAN configuration is stored.
--------------------	--------------------	--

Defaults	The default filename is <i>flash:vlan.dat</i> .
----------	---

Command Modes	Global configuration
---------------	----------------------

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

Usage Guidelines	This command cannot be used to load a new database; it only renames the file in which the existing database is stored.
------------------	--

Examples	The following example shows how to rename the filename for VTP configuration storage to <i>vtpfilename</i> :  Switch(config)# <b>vtp file vtpfilename</b>
----------	---

Related Commands	Command	Description
	<a href="#">vtp</a>	Configures the VTP mode

# vtp password

Use the **vtp password** VLAN database command to configure the VLAN Trunk Protocol (VTP) administrative domain password. Use the **no** form of this command to remove the password.

**vtp password** *password-value*

**no vtp password** *password-value*

## Syntax Description

<b>password</b>	Set the password for the generation of the 16-byte secret value used in MD5 digest calculation to be sent in VTP advertisements and to validate received VTP advertisements.
<i>password-value</i>	ASCII string from 8 to 64 characters. The password is case sensitive.

## Defaults

No password is defined.

## Command Modes

VLAN database

## Command History

Release	Modification
11.2(8)SA4	This command was first introduced.

## Usage Guidelines

Passwords are case sensitive. Passwords should match on all switches in the same domain.

When the **no vtp password** form of the command is used, the switch returns to the no-password state.

## Examples

The following example shows how to configure the VTP domain password:

```
Switch(vlan)# vtp password ThisIsOurDomain'sPassword
```

## Related Commands

Command	Description
<b>vtp domain</b>	Configures the VTP administrative domain.

# vtp pruning

Use the **vtp pruning** VLAN database command to enable pruning in the VLAN Trunk Protocol (VTP) administrative domain. Use the **no** form of this command to disable pruning.

**vtp pruning**

**no vtp pruning**

**Syntax Description** This command has no arguments or keywords.

**Defaults** Pruning is disabled.

**Command Modes** VLAN database

Command History	Release	Modification
	11.2(8)SA4	This command was first introduced.

**Usage Guidelines**

If you enable pruning on the VTP server, it is enabled for the entire management domain. Only VLANs included in the pruning-eligible list can be pruned. VLANs 2 through 1001 are pruning-eligible on Catalyst 2900 XL and Catalyst 3500 XL trunk ports. Pruning is support with VTP version 1 and version 2.

**Examples**

The following example shows how to enable pruning in the proposed new VLAN database:

```
Switch(vlan) # vtp pruning
```

You can verify the previous commands by entering the **show vtp status** command in privileged EXEC mode.

Related Commands	Command	Description
	<b>show interface</b> <i>interface-id</i> <b>pruning</b>	Displays pruning information for the trunk port.
	<b>show vtp status</b>	Displays general information about the VTP management domain, status, and counters.
	<b>switchport trunk pruning</b>	Configures the VLAN pruning-eligible list for ports in trunking mode.

# vtp v2-mode

Use the **vtp v2-mode** VLAN database command to enable VLAN Trunk Protocol (VTP) version 2 in the administrative domains. Use the **no** form of this command to disable V2 mode.

**vtp v2-mode**

**no vtp v2-mode**

**Syntax Description** This command has no arguments or keywords.

**Defaults** VTP version 2 is disabled.

**Command Modes** VLAN database

Release	Modification
11.2(8)SA4	This command was first introduced.

**Usage Guidelines**

Toggleing the V2 mode state modifies certain parameters of certain default VLANs.

Each VTP switch automatically detects the capabilities of all the other VTP devices. To use V2 mode, all VTP switches in the network must support version 2; otherwise, you must configure them to operate in VTP version 1 mode (no vtp v2-mode).

If you are using VTP in a Token Ring environment, VTP V2 mode must be enabled.

If you are configuring a Token Ring bridge relay function (TRBRF) or Token Ring concentrator relay function (TRCRF) VLAN media type, you must use version 2.

If you are configuring a Token Ring or Token Ring-NET VLAN media type, you must use version 1.

**Examples** The following example shows how to enable V2 mode in the proposed new VLAN database:

```
Switch(vlan)# vtp v2-mode
```

You can verify the previous commands by entering the **show vtp status** command in privileged EXEC mode.

Command	Description
<a href="#">show vtp status</a>	Displays general information about the VTP management domain, status, and counters.
<a href="#">vtp</a>	Configures the VTP mode.
<a href="#">vtp pruning</a>	Enables pruning in the VTP administrative domain.