



Clock/Timer Operating Instructions

Timer

The timer module functions as follows:

To change between timer and countdown mode, push and hold the LAP/RESET button, when the timer is stopped. The indicator will change mode each time this is done.

When in timer mode, push the START/STOP button, the timer will start to count up. Push the START/STOP button again, the timer will stop. Push the LAP/RESET button when the timer is stopped and the timer will reset.

If the LAP/RESET button is pushed when the timer is running, the time will freeze on the screen, but the timer will still be running. When the LAP/RESET is pushed again, the actual time running will be displayed instead of the screen freeze.

When in Countdown mode, Set the time required to start from by using the UP and DOWN buttons, when the timer is not running. Push the START/STOP button, the timer will start to count down. Push the START/STOP button again, the timer will stop. Push the LAP/RESET button when the timer is stopped and the timer will reset to the time that was set.

If the LAP/RESET button is pushed when the timer is running, the time will freeze on the screen, but the timer will still be running. When the LAP/RESET is pushed again, the actual time running will be displayed instead of the screen freeze.

Clock

The clock module functions as follows:

When the SEL button is pushed, the clock module will change from either 12 hour display or 24 hour display. The indicator will change mode each time this is done.

By using a small screwdriver, or small pointed device, push the HRS, MIN, SEC buttons to set the time.