

Experion PKS
Honeywell Icon Series Console Read Me First Read
Me First Important Safety Information

EP-DCNXX3-en-431A
February 2015

Release 430

Document	Release	Issue	Date
EP-DCNXX3-en-431A	430	0	February 2015

Disclaimer

This document contains Honeywell proprietary information. Information contained herein is to be used solely for the purpose submitted, and no part of this document or its contents shall be reproduced, published, or disclosed to a third party without the express permission of Honeywell International Sàrl.

While this information is presented in good faith and believed to be accurate, Honeywell disclaims the implied warranties of merchantability and fitness for a purpose and makes no express warranties except as may be stated in its written agreement with and for its customer.

In no event is Honeywell liable to anyone for any direct, special, or consequential damages. The information and specifications in this document are subject to change without notice.

Copyright 2015 - Honeywell International Sàrl

Contents

- About This Document 5**
- Introduction 7**
 - Assembled Icon Units 8
 - Icon Assembly Tasks 9
 - Console Safety Guidelines 10
 - Additional References 12
- Important Safety Information 13**
 - Electrical Safety 14
 - Video Monitor Safety 17
 - Monitor safety symbols 18
 - Standards Compliance 20
- Icon Series Modification Guidelines 21**
 - Quad Auxiliary Backpanel Modification Guidelines 22
 - Quad Upper Auxiliary Backpanel Modification Guidelines 24
 - Dual Auxiliary Backpanel Modification Guidelines 25

About This Document

This publication contains important safety information. Read it before beginning assembly or installation of the Honeywell Icon Series Console or auxiliary units. This publication also contains an overview of the tasks required to install Honeywell Icon Series consoles.

Release Information

Revision	Date	Description
A	October 2002	Initial release
B	August 2006	Updated for Microsoft Windows 2003.

Introduction



Attention

Read this document first

This publication contains important safety information. Read it before beginning assembly or installation of the Honeywell Icon Series Console or auxiliary units. This publication also contains an overview of the tasks required to install Honeywell Icon series consoles.

The *Honeywell Icon Series Console Planning, Installation, and Service Guide* contains detailed assembly and installation procedures for each of these tasks.

Following the procedures is required to ensure consoles are assembled according to CSA requirements.

Related topics

“Assembled Icon Units” on page 8

“Icon Assembly Tasks” on page 9

“Console Safety Guidelines” on page 10

“Additional References” on page 12

Assembled Icon Units






The following pictures display some of the various ways an Icon Series Console may be configured.



Figure 1: Assembled Icon Units

Icon Assembly Tasks

Refer to the following table for an overview of the major tasks required in the assembly of a Honeywell Icon Series Dual or Quad Console or table unit. Detailed procedures for all of these tasks are provided in *Honeywell Icon Series Console Planning, Installation and Service Guide HC05*. Those sections marked with the Canadian Standards Association (CSA) logo contain specific requirements that must be followed in order to CSA compliance.

No	Console Assembly Task	<i>Honeywell Icon Series Console Planning, Installation and Service Guide</i>	Section Contains CSA Requirements
<i>Console Assembly</i>			
1	Add backpanel to console base unit	Assemble Furniture	
2	Access cable routing areas	Cable Routing	
3	Mount monitors and connect cables	Install Monitors	
4	Add pop-up disk modules	Add Pop-up Disk Modules	
5	Add hot-swap manual input modules	Add Hot-swap Manual Input Modules	
6	Add OEP module & devices	Add OEP Module & Devices	
7	Connect USB Hub devices	Connect USB Hub Devices	
8	Wire power entry box	Wire Power Entry Box	
9	Install LCN MAU	Install LCN MAU	
10	Install Annunciator relay contact box	Install Annunciator Relay Contact Box	
<i>Add System Platform</i>			
11	Install local electronic module, or Install remote electronics	Install Local Electronic Module, or Install Short Haul Remote System	
<i>Console Startup and Device Configuration</i>			
12	Startup console	Startup Console	
13	Configure devices	Configure Devices	
<i>Console Complexing</i>			
14	Complex console furniture	Complex Console Furniture	

Console Safety Guidelines



Console Assembly

- Keep tools away from walk areas where you and others could fall over them.
- Wear safety glasses if you are working under any conditions that might be hazardous to your eyes.
- Do not perform any action that creates a potential hazard to people or makes the equipment unsafe.
- Verify that all nuts and other fasteners are secure.



Note



Console Modifications

Be aware that some types of modifications to the Honeywell Icon Series Console could make the console non-compliant with those standards identified in the '“Standards Compliance” on page 20' section of this publication.



Note



Safe Operation

To avoid injury, follow these general guidelines when installing, operating or servicing the Honeywell Icon Series Console:

- Use technically qualified personnel to install and service your Honeywell Icon Console and components.
- Do not sit on any worksurfaces.
- Keep fingers away from all moving parts.



Note



PINCH WARNING

Pinch Zones \ There are certain areas of the Icon Series Console or Table Unit where injury could occur if caution is not exercised. With the advent of the power work surface adjusters, pinch zones are identified with the above warning symbol: When operating the power work surface adjusters *DO NOT ALLOW FINGERS OR OTHER BODY PARTS TO BE IN THE REGION IDENTIFIED BY THESE LABELS. SAFE OPERATIONS OF*

THE POWER ADJUSTERS REQUIRES OBSERVING THIS RULE: KEEP CLEAR OF ALL PINCH ZONES WHILE OPERATING THE WORKSURFACES.

Additional References

You can find detailed installation and assembly instructions in the *Honeywell Icon Series Console Planning, Installation, and Service Guide*. The following table lists other sources of information for site planning and installation.

Document Title	Doc ID
Honeywell Icon Series Console Planning, Installation and Service Guide	
Local Control Network Planning Guide	
TPN System Installation	
Keyboards	
Button Configuration Data Entry	
Core Module Test System	
Experion Server and Client Configuration Guide	
Experion Software Installation and Upgrade Guide	
Experion Supplementary Installation and Task Guide	
TPS System Administration Guide	
TPS System Administration Guide (W2K)	
TPS System Implementation Guide	
TPS System Implementation Guide	
TPS System Site Planning	
Planning, Installation, and Service for TPN-Connected Nodes (Dell GX200)	
Planning, Installation, and Service for TPN-Connected Nodes (SVR2/WKS2))	
Planning, Installation and Service for WS360/WS370/WS470	

Important Safety Information

Related topics

“Electrical Safety” on page 14

“Video Monitor Safety” on page 17

“Monitor safety symbols” on page 18

“Standards Compliance” on page 20

Electrical Safety



Shock Prevention

- To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- Do not spill any liquids into the console or use near water.
- Do not work on the system or connect or disconnect cables during periods of lightning activity.



Note



General Safety Precautions

Follow these guidelines when working on equipment powered by electricity:

- Locate the emergency power-off switch for the room in which you are working.
- Never assume that power is disconnected from a circuit; always check the circuit.
- Look carefully for possible hazards in your work area, such as moist floors, ungrounded power extension cables, frayed power cords, and missing safety grounds.



Note



Proper Electrical Use

- Use the Honeywell Icon Series Console within its marked electrical ratings and product usage instructions.
- Install the Honeywell Icon Series Console in compliance with the following local and national electrical codes:
 - United States—National Fire Protection Association (NFPA) 70; United States National Electrical Code.
 - Canada—Canadian Electrical Code, Part I, CSA C22.1.
 - Other countries—International Electro Technical Commission (IEC) 364, Part 1.



Note



Power Cord Warning

- Before working on a system that has an ON/OFF switch, turn the ON/OFF switch to OFF and unplug the power cord.
- Do not place any heavy objects on the power cord or place it in a location where it may be damaged. Damage to the cord may cause shock or fire.
- Do not use this unit with an extension cord receptacle or other outlet unless the prong can be fully inserted.



Routing cords through console

The following figures illustrate the correct way to route cables or cords through the top portion of the console leg. If the cable or cord is not positioned correctly above the flange in the console leg, it may be pinched and damaged creating a potential shock or fire hazard.



Left Hand	Right Hand
	



Power cable installation

When completely assembled, the standard Quad Icon Series Console will have two to five power cables installed within the console unit. When installing or plugging in power cables, following the procedures in the *Honeywell Icon Series Console Planning, Installation and Service Guide*.



Backpanel Safety Shield

If any high voltage equipment or uninsulated wires are mounted inside any of the five varieties of backpanels, you must add a safety shield. The following safety shields are recommended:

- MP-ICSSQ1 Safety shield for Quad Auxiliary Console
- MP-ICSSD1 Safety shield for Dual Auxiliary Console



Potential Shock Hazard

IMPORTANT SAFETY INFORMATION

If any components or equipment that have exposed high voltage hardware are mounted on a backpanel, one of the following safety shields must be installed:

- Dual console: Honeywell part number MP-ICSSD1
- Quad console: Honeywell part number MP-ICSSQ1

Video Monitor Safety

Monitor safety symbols



Uninsulated voltage

This symbol warns the user that uninsulated voltage within the unit may have sufficient magnitude to cause electric shock. Therefore, it is dangerous to make any kind of contact with any part inside this unit.



Note



Important information

This symbol alerts the user that important literature concerning the operation and maintenance of the unit has been included. It should be read carefully in order to avoid any problems.



Note



Unplug the monitor

Immediately unplug your monitor from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power supply cord or plug is damaged.
- If liquid has been spilled or objects have fallen into the monitor.
- If the monitor has been exposed to rain or water.
- If the monitor has been dropped or the cabinet is damaged.
- If the monitor does not operate normally by following operating instructions.



Note



Operation

- Do not remove cover (or back). There are no user serviceable parts inside. Refer servicing to qualified service personnel.
- Do not insert objects of any kind into the monitor cabinet slots, as they may touch dangerous voltage points, which can be harmful or fatal or may cause electric shock, fire, or equipment failure.



Note



Monitor handling

- Allow adequate ventilation around the monitor so that heat can properly dissipate. Do not block ventilated openings or place the monitor near a radiator or other heat sources. Do not put anything on top of monitor.
- Handle the monitor with care when transporting. Save packaging for transporting.
- Do not place any monitor on a sloping or unstable cart, stand, or table, as the monitor may fall, causing serious damage to the monitor.

Standards Compliance

If assembled and operated according to the Honeywell supplied documentation, the Honeywell Icon Series Console complies with the following international and specification standards:

- ANSI HFS-100 (withdrawn), ISO 9241 and ISO 11064
- CEmark - Commercial
- CSA 1010

Icon Series Modification Guidelines

Be aware that modifying the Honeywell Icon Series Console without following the guidelines in this section may make the console non-compliant with those standards identified in Section “Standards Compliance” on page 20 of this publication.

Related topics

“Quad Auxiliary Backpanel Modification Guidelines” on page 22

“Quad Upper Auxiliary Backpanel Modification Guidelines” on page 24

“Dual Auxiliary Backpanel Modification Guidelines” on page 25

Quad Auxiliary Backpanel Modification Guidelines



Do Not Drill Areas

There are seven specific areas on the quad auxiliary backpanel MP-ICQDA1 that must not be modified. Drilling in any of the areas listed in the following table will compromise the backpanel's structural integrity. Refer to “Figure 2: Quad Auxiliary Backpanel” to identify the specific areas.



Note

No.	Area	Guideline
1	Upper valance area	Do not drill anywhere within 3 in. (7.7 cm) of the top of the auxiliary backpanel.
2	Upper left side flange	Do not drill anywhere within 2 in. (5.08 cm) from the outside of the upper portion of the left strut.
3	Upper right side flange	Do not drill anywhere within 2 in. (5.08 cm) from the outside of the upper portion of the right strut.
4	Mending plate	Do not drill anywhere on the mending plate: 2.5 x 2.5 in. (6.35 cm x 6.35 cm).
5	Lower left side flange	Do not drill anywhere within 2 in. (5.08 cm) from the outside of the lower portion of the right left strut.
6	Lower right side flange	Do not drill anywhere within 2 in. (5.08 cm) from the outside of the lower portion of the right strut.
7	Lower flange	Do not drill anywhere within 2 in. (5.08 cm) of the bottom of the auxiliary backpanel.





Figure 2: Quad Auxiliary Backpanel

Quad Upper Auxiliary Backpanel Modification Guidelines



Do Not Drill Areas

There are five areas on the Quad Upper Auxiliary Backpanel MP-ICQAU1 also known as 'QUAB' auxiliary backpanel that must not be modified. Drilling in any of the backpanel areas listed in the following table will compromise the backpanel's structural integrity. Refer to “Figure 3: QUAB Auxiliary Backpanel” to identify the specific areas.

 **Note**

1	Upper valance area	Do not drill anywhere within 3 in. (7.7 cm) of the top of the QUAB's auxiliary backpanel.
2	Left side flange	Do not drill anywhere within 2 in. (5.08 cm) from the outside of the upper portion of the left strut.
3	Right side flange	Do not drill anywhere within 2 in. (5.08 cm) from the outside of the upper portion of the right strut.
4	Lower flange	Do not drill anywhere within 2 in. (5.08 cm) of the bottom of the QUAB's auxiliary backpanel.
5	Lower half of QUAB	Do not drill anywhere in this area.



Figure 3: QUAB Auxiliary Backpanel

Dual Auxiliary Backpanel Modification Guidelines



Do Not Drill Areas

There are five specific areas on the dual auxiliary backpanel MP-ICDLA1 that must not be modified. Drilling in any of the areas listed in the following table will compromise the backpanel's structural integrity. Refer to “Figure 4: Dual Auxiliary Backpanel” to identify the specific areas.

 **Note**

No.	Area	Guideline
1	Upper valance area	Do not drill anywhere within 3 in. (7.7 cm) of the top of the QUAB auxiliary backpanel.
2	Left side flange	Do not drill anywhere within 2 in. (5.08 cm) from the outside of the upper portion of the left strut.
3	Right side flange	Do not drill anywhere within 2 in. (5.08 cm) from the outside of the upper portion of the right strut.
4	Bottom flange	Do not drill anywhere within 2 in. (5.08 cm) of the bottom of the auxiliary backpanel.




Figure 4: Dual Auxiliary Backpanel

