

# Mapping Reconstruction with Livox MID360

This repository provides a comprehensive setup for mapping reconstruction using the Livox MID360 LiDAR sensor. It includes Dockerized environments for easy deployment and tools for data recording, visualization, and processing.

## Requirements

Ensure the following requirements are met before proceeding:

- **Ubuntu:** Version 20.04 or higher
- **Docker:** [Recommended Video Installation Guide](#)
- **Static IP Address of Host PC:** E.g., 192.168.1.10
- **Static IP Address of Livox MID360:** E.g., 192.168.1.100

## Installation & Quick Run of Docker Environment

### 1. Clone the Repository

```
# Create directory for Livox MID360
mkdir livox_mid_360
cd livox_mid_360

# Clone the repository into the directory
git clone git@github.com:djetshu/LivoxMid360-3DScanEnv.git
```

### 2. Build the Docker Image

```
cd LivoxMid360-3DScanEnv

# Build the Docker image
./docker/build.sh
```

**Note:** The build step is a one-time process. For subsequent runs, proceed directly to the next step.

### 3. Run the Docker Container

```
# Enable permissions for graphics/video
# (Optional: Already in run_docker.sh)
xhost +local:root
```

```
# Start the Docker container
./docker/run_docker.sh
```

## Quick Running (Inside Docker)

Before running, ensure all configurations are properly set (refer to [Set Up and Configuration](#)).

### General Instructions

1. Navigate to the workspace:

```
cd /livox_mid_360/livox_mid_360_ws
```

2. Compile the ros workspace:

```
colcon build
```

3. Source the workspace:

```
source install/setup.bash
```

Depending on your use case, you can launch different setups as described below:

### 1. Run FastLIO with Livox MID360 ROS Driver

To perform mapping using FastLIO integrated with the Livox MID360 in Real Time:

1. Execute the following command:

```
ros2 launch fast_lio mapping_MID360.launch.py
```

### 2. Run Only FastLIO

If you only need to run the FastLIO mapping (with rosbags recordings):

1. Launch the following command:

```
ros2 launch fast_lio mapping.launch.py
```

### 3. Run Only the Livox MID360 ROS Driver

If you only need to run the Livox MID360 ROS driver for data visualization or testing (To corroborate communication of Lidar and PC):

1. Launch the required nodes:

```
# To show Data in Rviz2
ros2 launch livox_ros_driver2 rviz_MID360_launch.py
# To get data in Livox custom message
ros2 launch livox_ros_driver2 msg_MID360_launch.py
```

## Record/Play Data in ROS Bags

To save LiDAR and IMU data in a ROS bag for later analysis or processing:

1. Use the following command, specifying a name for the output bag file:

```
# Source before recording topics
source install/setup.bash
# Record only /livox/imu and /livox/lidar topics
ros2 bag record /livox/imu /livox/lidar -o /livox_mid_360/
    livox_mid_360_ws/src/rosbag/<name_of_bag>
```

To play rosbags recording:

1. Use the following command, specifying a name for the rosbag file:

```
# Source before playing topics
source install/setup.bash
# Play reosbag with only /livox/imu and /livox/lidar topics
ros2 bag play /livox_mid_360/livox_mid_360_ws/src/rosbag/
    <name_of_bag>
```

## Set Up and Configuration

### Livox MID360 Setup

Modify the MID360\_config.json file located at livox\_mid\_360/src/livox\_ros\_driver2/config to set up the IP addresses for the host PC and the Livox MID360.

Example configuration:

```
{
  "lidar_summary_info": {
    "lidar_type": 8
  },
  "MID360": {
    "lidar_net_info": {
      "cmd_data_port": 56100,
      "push_msg_port": 56200,
      "point_data_port": 56300,
      "imu_data_port": 56400,
```

```

    "log_data_port": 56500
},
"host_net_info": {
    "cmd_data_ip": "192.168.1.10",    # host ip (it can be
    revised)
    "cmd_data_port": 56101,
    "push_msg_ip": "192.168.1.10",    # host ip (it can be
    revised)
    "push_msg_port": 56201,
    "point_data_ip": "192.168.1.10", # host ip (it can be
    revised)
    "point_data_port": 56301,
    "imu_data_ip": "192.168.1.10",    # host ip (it can be
    revised)
    "imu_data_port": 56401,
    "log_data_ip": "",
    "log_data_port": 56501
}
},
"lidar_configs": [
{
    "ip": "192.168.1.100",    # ip of the LiDAR you want to
    config
    "pcl_data_type": 1,
    "pattern_mode": 0,
    "extrinsic_parameter": {
        "roll": 0.0,
        "pitch": 0.0,
        "yaw": 0.0,
        "x": 0,
        "y": 0,
        "z": 0
    }
}
]
}

```

### Notes:

- Update the placeholder IP addresses (192.168.1.5 and 192.168.1.12) with the actual static IP addresses of your host PC and Livox MID360.

## Enable/Disable save .pcd file output of FastLIO

Modify the mid360.yaml file located at livox\_mid\_360/src/FAST\_LIO/config to set up pcd\_save:pcd\_save\_en to true or false for saving FastLIO output frames or not. The .pcd file will be stored at livox\_mid\_360/src/FAST\_LIO/PCD/.

```
pcd_save:
  pcd_save_en: false          # True -> .pcd file will be
                              store at 'livox_mid_360/src/FAST_LIO/PCD/'
  interval:
    -1                        # how many LiDAR frames saved in each
    pcd file;
                              # -1 : all frames will be
                              saved in ONE pcd file, may lead to memory crash when
                              having too much frames.
```

### Notes:

- If this option is enabled ensure you have enough memory space.
- To visualize the .pcd file, use the following command: `pcl_viewer <name_of_pcd_file.pcd>`
- It is recommended to view this file on a high-performance PC to avoid lags.

## References

This repository contains the following packages: - [Livox SDK2](#) - [Livox Ros Driver](#) - [Fast LIO](#)