



# **Use FlexClone volumes to create efficient copies of your FlexVol volumes**

**ONTAP 9**

NetApp  
July 17, 2023

# Table of Contents

- Use FlexClone volumes to create efficient copies of your FlexVol volumes ..... 1
  - Use FlexClone volumes to create efficient copies of your FlexVol volumes overview ..... 1
  - Create a FlexClone volume ..... 1
  - Split a FlexClone volume from its parent volume ..... 3
  - Determine the space used by a FlexClone volume ..... 5
  - Considerations for creating a FlexClone volume from a SnapMirror source or destination volume ..... 5

# Use FlexClone volumes to create efficient copies of your FlexVol volumes

## Use FlexClone volumes to create efficient copies of your FlexVol volumes overview

FlexClone volumes are writable, point-in-time copies of a parent FlexVol volume. FlexClone volumes are space-efficient because they share the same data blocks with their parent FlexVol volumes for common data. The Snapshot copy used to create a FlexClone volume is also shared with the parent volume.

You can clone an existing FlexClone volume to create another FlexClone volume. You can also create a clone of a FlexVol volume containing LUNs and LUN clones.

You can also split a FlexClone volume from its parent volume. Beginning with ONTAP 9.4, for non-guaranteed volumes on AFF systems, the split operation for FlexClone volumes shares the physical blocks and does not copy the data. Therefore, splitting of FlexClone volumes on AFF systems is faster than the FlexClone splitting operation in other FAS systems in ONTAP 9.4 and later releases.

You can create two types of FlexClone volumes: read-write FlexClone volumes and data protection FlexClone volumes. While you can create a read-write FlexClone volume of a regular FlexVol volume, you must use only a SnapVault secondary volume to create a data protection FlexClone volume.

## Create a FlexClone volume

You can create a data protection FlexClone volume from a SnapMirror destination volume or from a parent FlexVol volume that is a SnapVault secondary volume. Beginning with ONTAP 9.7, you can create a FlexClone volume from a FlexGroup volume. After you create a FlexClone volume, you cannot delete the parent volume while the FlexClone volume exists.

### What you'll need

- The FlexClone license must be installed on the cluster.
- The volume that you want to clone must be online.

## Create a FlexClone volume of a FlexVol or FlexGroup

### Step

1. Create a FlexClone volume:

```
volume clone create
```



While creating a read-write FlexClone volume from the read-write parent volume, you do not need to specify the base Snapshot copy. ONTAP creates a Snapshot copy if you do not name any specific Snapshot copy that is to be used as the base Snapshot copy for the clone. You must specify the base Snapshot copy for creating a FlexClone volume when the parent volume is a data protection volume.

## Example

- The following command creates a read-write FlexClone volume `vol1_clone` from the parent volume `vol1`:

```
volume clone create -vserver vs0 -flexclone vol1_clone -type RW -parent-volume vol1
```

- The following command creates a data protection FlexClone volume `vol_dp_clone` from the parent volume `dp_vol` by using the base Snapshot copy `snap1`:

```
volume clone create -vserver vs1 -flexclone vol_dp_clone -type DP -parent -volume dp_vol -parent-snapshot snap1
```

## Create a FlexClone of any SnapLock type

Beginning with ONTAP 9.13.1, you can specify one of three SnapLock types, `compliance`, `enterprise`, `non-snaplock`, when creating a FlexClone of a RW volume. By default, a FlexClone volume is created with the same SnapLock type as the parent volume. However, you can override the default by using the `snaplock-type` option during FlexClone volume creation.

Using the `non-snaplock` parameter with the `snaplock-type` option, you can create a non-SnapLock type FlexClone volume from a SnapLock parent volume to provide a faster method of bringing data back online when necessary.

Learn more about [SnapLock](#).

### Before you begin

You should be aware of the following FlexClone volume limitations when they have a different SnapLock type than the parent volume.

- Only RW-type clones are supported. DP-type clones with a SnapLock type different from the parent volume are not supported.
- Volumes with LUNs cannot be cloned using the `snaplock-type` option set to a value other than 'non-snaplock' because SnapLock volumes do not support LUNs.
- A volume on a MetroCluster mirrored aggregate cannot be cloned with a Compliance SnapLock type because SnapLock Compliance volumes are not supported on MetroCluster mirrored aggregates.
- SnapLock Compliance volumes with Legal-Hold cannot be cloned with a different SnapLock type. Legal-Hold is only supported on SnapLock Compliance volumes.
- SVM DR does not support SnapLock volumes. Attempting to create a SnapLock clone from a volume in an SVM that is part of an SVM DR relationship will fail.
- FabricPool best practices recommend that clones retain the same tiering policy as the parent. However, a SnapLock Compliance clone of a FabricPool-enabled volume cannot have the same tiering policy as the parent. The tiering policy must be set to `none`. Attempting to create a SnapLock Compliance clone from a parent with a tiering policy other than `none` will fail.

### Steps

1. Create a FlexClone volume with a SnapLock type: 

```
volume clone create -vserver svm_name -flexclone flexclone_name -type RW [ -snaplock-type {non-snaplock|compliance|enterprise} ]
```

Example:

```
> volume clone create -vserver vs0 -flexclone vol1_clone -type RW
-snaplock-type enterprise -parent-volume vol1
```

## Split a FlexClone volume from its parent volume

If you want a read-write FlexClone volume to have its own disk space rather than using that of its parent volume, you can split the FlexClone volume from its parent volume. Because this operation creates a copy of the data that is currently shared between the parent volume and the FlexClone volume, the operation can take some time to complete.

### About this task

Splitting a FlexClone volume from its parent volume can result in the reservation of more space on the containing aggregate. If you do not have sufficient privileges to view the space available in your aggregate, you must contact your storage administrator to verify that there is sufficient space in the aggregate for the split operation to finish.

Beginning with ONTAP 9.4, for non-guaranteed volumes on AFF systems, the split operation for FlexClone volumes shares the physical blocks and does not copy the data. Therefore, splitting of FlexClone volumes on AFF systems is faster than the FlexClone splitting operation in other FAS systems in ONTAP 9.4. The improved FlexClone splitting operation on AFF systems has the following benefits:

- Storage efficiency is preserved after splitting the clone from the parent.
- Existing Snapshot copies are not deleted.
- The operation is faster.
- The FlexClone volume can be split from any point in the clone hierarchy.

### Steps

1. Determine the amount of free space required to complete the split operation:

```
volume clone show -estimate -vserver vs1 -flexclone clone1 -parent-volume vol1
```

The following example provides information about the free space required to split a FlexClone volume clone1 from its parent volume vol1:

```
cluster1::> volume clone show -estimate -vserver vs1 -flexclone clone1
-parent-volume vol1
```

Vserver	FlexClone	Split Estimate
vs1	clone1	40.73MB

2. Verify that the aggregate containing the FlexClone volume and its parent has sufficient space:
  - a. Determine the amount of free space in the aggregate that contains the FlexClone volume and its parent:

```
storage aggregate show
```

- b. If the containing aggregate does not have enough free space available, add storage to the aggregate:

```
storage aggregate add-disks
```

3. Start the split operation:

```
volume clone split start -vserver vserver_name -flexclone clone_volume_name
```

The following example shows how you can initiate the process to split the FlexClone volume clone1 from its parent volume vol1:

```
cluster1::> volume clone split start -vserver vs1 -flexclone clone1

Warning: Are you sure you want to split clone volume clone1 in Vserver
vs1 ?
{y|n}: y
[Job 1617] Job is queued: Split clone1.
```

4. Monitor the status of the FlexClone split operation:

```
volume clone split show -vserver vserver_name -flexclone clone_volume_name
```

The following example shows the status of the FlexClone split operation on an AFF system:

```
cluster1::> volume clone split show -vserver vs1 -flexclone clone1
```

		Inodes				
Blocks						
-----						
Vserver	FlexClone	Processed	Total	Scanned	Updated	% Inode
% Block						
Complete	Complete					
vs1	clone1	0	0	411247	153600	0
37						

5. Verify that the split volume is no longer a FlexClone volume:

```
volume show -volume volume_name -fields clone-volume
```

The value of the `clone-volume` option is `false` for a volume that is not a FlexClone volume.

The following example shows how you can verify whether the volume clone1 that is split from its parent is not a FlexClone volume.

```
cluster1::> volume show -volume clone1 -fields clone-volume
vserver volume **clone-volume**
----- **-----**
vs1      clone1 **false**
```

## Determine the space used by a FlexClone volume

You can determine the space used by a FlexClone volume based on its nominal size and the amount of space it shares with the parent FlexVol volume. When a FlexClone volume is created, it shares all of its data with its parent volume. Therefore, although the nominal size of the FlexVol volume is the same as its parent's size, it uses very little free space from the aggregate.

### About this task

The free space used by a newly-created FlexClone volume is approximately 0.5 percent of its nominal size. This space is used to store the FlexClone volume's metadata.

New data written to either the parent or the FlexClone volume is not shared between the volumes. The increase in the amount of new data that gets written to the FlexClone volume leads to an increase in the space the FlexClone volume requires from its containing aggregate.

### Step

1. Determine the actual physical space used by the FlexClone volume using the `volume show` command.

The following example shows the total physical space used by the FlexClone volume:

```
cluster1::> volume show -vserver vs01 -volume clone_vol1 -fields
size,used,available,
percent-used,physical-used,physical-used-percent
vserver    volume    size  available  used    percent-used  physical-
used       physical-used-percent
-----
vs01       clone_vol1  20MB  18.45MB   564KB   7%           196KB
1%
```

## Considerations for creating a FlexClone volume from a SnapMirror source or destination volume

You can create a FlexClone volume from the source or destination volume in an existing volume SnapMirror relationship. However, doing so could prevent future SnapMirror replication operations from completing successfully.

Replication might not work because when you create the FlexClone volume, you might lock a Snapshot copy

that is used by SnapMirror. If this happens, SnapMirror stops replicating to the destination volume until the FlexClone volume is destroyed or is split from its parent. You have two options for addressing this issue:

- If you require the FlexClone volume on a temporary basis and can accommodate a temporary stoppage of the SnapMirror replication, you can create the FlexClone volume and either delete it or split it from its parent when possible.

The SnapMirror replication continues normally when the FlexClone volume is deleted or is split from its parent.

- If a temporary stoppage of the SnapMirror replication is not acceptable, you can create a Snapshot copy in the SnapMirror source volume, and then use that Snapshot copy to create the FlexClone volume. (If you are creating the FlexClone volume from the destination volume, you must wait until that Snapshot copy replicates to the SnapMirror destination volume.)

This method of creating a Snapshot copy in the SnapMirror source volume allows you to create the clone without locking a Snapshot copy that is in use by SnapMirror.



## Copyright information

Copyright © 2023 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

## Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.