

---

1




## Notes on Power Input

Power should be supplied to only 1 (ONE) input per voltage level.


5V comes from EXP, 5V header, or 5V Screw Terminal.  
If using 5V Header/Screw Terminal and EXP1, cut JP8.  
If using Screw Terminal, do not connect 5V Header

24V comes from Fan0 In or 24V Screw Terminal  
If using Screw Terminal, cut JP11  
JP12 can be closed to make Fan0 Always On

---



LED Enable



## Mounting Holes



## Fiducials

