

Veritas NetBackup™ Appliance Fibre Channel Guide

Release 3.0

NetBackup 52xx and 5330

Document Revision 1



Veritas NetBackup™ Appliance Fibre Channel Guide

Release 3.0 - Document Revision 1

Legal Notice

Copyright © 2016 Veritas Technologies LLC. All rights reserved.

Veritas, the Veritas Logo, and NetBackup are trademarks or registered trademarks of Veritas Technologies LLC or its affiliates in the U.S. and other countries. Other names may be trademarks of their respective owners.

This product may contain third party software for which Veritas is required to provide attribution to the third party ("Third Party Programs"). Some of the Third Party Programs are available under open source or free software licenses. The License Agreement accompanying the Software does not alter any rights or obligations you may have under those open source or free software licenses. Refer to the third party legal notices document accompanying this Veritas product or available at:

<https://www.veritas.com/about/legal/license-agreements>

The product described in this document is distributed under licenses restricting its use, copying, distribution, and decompilation/reverse engineering. No part of this document may be reproduced in any form by any means without prior written authorization of Veritas Technologies LLC and its licensors, if any.

THE DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID. VERITAS TECHNOLOGIES LLC SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, PERFORMANCE, OR USE OF THIS DOCUMENTATION. THE INFORMATION CONTAINED IN THIS DOCUMENTATION IS SUBJECT TO CHANGE WITHOUT NOTICE.

The Licensed Software and Documentation are deemed to be commercial computer software as defined in FAR 12.212 and subject to restricted rights as defined in FAR Section 52.227-19 "Commercial Computer Software - Restricted Rights" and DFARS 227.7202, et seq. "Commercial Computer Software and Commercial Computer Software Documentation," as applicable, and any successor regulations, whether delivered by Veritas as on premises or hosted services. Any use, modification, reproduction release, performance, display or disclosure of the Licensed Software and Documentation by the U.S. Government shall be solely in accordance with the terms of this Agreement.

Veritas Technologies LLC
500 E Middlefield Road
Mountain View, CA 94043

<http://www.veritas.com>

Technical Support

Technical Support maintains support centers globally. All support services will be delivered in accordance with your support agreement and the then-current enterprise technical support policies. For information about our support offerings and how to contact Technical Support, visit our website:

<https://www.veritas.com/support>

You can manage your Veritas account information at the following URL:

<https://my.veritas.com>

If you have questions regarding an existing support agreement, please email the support agreement administration team for your region as follows:

Worldwide (except Japan)

CustomerCare@veritas.com

Japan

CustomerCare_Japan@veritas.com

Documentation

The latest documentation is available on the Veritas website:

<https://sort.veritas.com/documents>

Documentation feedback

Your feedback is important to us. Suggest improvements or report errors or omissions to the documentation. Include the document title, document version, chapter title, and section title of the text on which you are reporting. Send feedback to:

APPL.docs@veritas.com

You can also see documentation information or ask a question on the Veritas community site:

<http://www.veritas.com/community/>

Veritas Services and Operations Readiness Tools (SORT)

Veritas Services and Operations Readiness Tools (SORT) is a website that provides information and tools to automate and simplify certain time-consuming administrative tasks. Depending on the product, SORT helps you prepare for installations and upgrades, identify risks in your datacenters, and improve operational efficiency. To see what services and tools SORT provides for your product, see the data sheet:

https://sort.veritas.com/data/support/SORT_Data_Sheet.pdf

Contents

Chapter 1	Introducing Fibre Channel support on NetBackup Appliance	6
	About Fibre Channel supported features on NetBackup Appliance	6
	About NetBackup Fibre Transport	9
	About NetBackup SAN Client and Fibre Transport	10
	About the SAN Client license key	11
	About Fibre Transport for optimized duplication and Auto Image Replication between appliances	12
	Supported data transfer methods for NetBackup appliances	13
	About Fibre Channel feature support with appliance HBA configurations	14
	About the NetBackup 5230 rear panel configurations	18
	NetBackup 5240 Appliance I/O configuration options	20
	NetBackup 5330 Appliance compute node PCIe slot I/O configuration options	22
	About Fibre Transport paths for NetBackup appliances	24
Chapter 2	About the HBA port mode configuration	29
	About FTMS reserved HBA ports and the factory default port mode configuration	29
	Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances	33
	Supported Fibre Channel port configuration for the NetBackup 5240 appliances	40
	Supported Fibre Channel port configurations for the NetBackup 5330 appliances	44
Chapter 3	Zoning the FC SAN	48
	How to determine appliance HBA WWPNs	48
	About zoning the SAN for NetBackup appliances	48
	About HBA link status on the NetBackup Appliance Shell Menu	53

Chapter 4	Configuring Fibre Transport on the appliance	55
	Settings > Network > Fibre Transport	55
	About the HBA port mode configuration table	57
	Configuring Fibre Transport media server for SAN Client	59
	Configuring Fibre Transport media sever settings	60
	Guidelines for changing NetBackup appliance FT target ports to receive data streams from multiple SAN Client FC initiator ports	62
	Configuring Fibre Transport for optimized duplication and Auto Image Replication over FC	62
	Configuring Fibre Transport to other NetBackup appliances	64
	About the Fibre Transport chunk size	65
	Configuring Fibre Transport on a target appliance for optimized duplication and replication	67
	Configuring direct backups from a NetBackup 52xx or 5330 appliance to a NetBackup 50xx appliance using Fibre Channel	69
	How to configure two NetBackup 52xx or 5330 appliances in different domains for MSDP replication	71
Chapter 5	About backup to tape support	74
	About backup to tape support for NetBackup appliances	74
Chapter 6	VMware support	76
	About NetBackup Appliance as a VMware backup host	76
	NetBackup Appliance as backup host: component overview	76
	Notes on NetBackup Appliance as a VMware backup host	77
	About appliance dynamic multi-pathing for VMware backups with SAN transport	78
Index		79

Introducing Fibre Channel support on NetBackup Appliance

This chapter includes the following topics:

- [About Fibre Channel supported features on NetBackup Appliance](#)
- [About NetBackup Fibre Transport](#)
- [About NetBackup SAN Client and Fibre Transport](#)
- [About Fibre Transport for optimized duplication and Auto Image Replication between appliances](#)
- [Supported data transfer methods for NetBackup appliances](#)
- [About Fibre Transport paths for NetBackup appliances](#)

About Fibre Channel supported features on NetBackup Appliance

The appliances are rack-mount servers that run on the Linux operating system. NetBackup Enterprise Server software is already installed and configured to work with the operating system, the disk storage units, and the robotic tape device.

To use the NetBackup Enterprise Server software on the NetBackup Appliance with the supported Fibre Channel (FC) features, you must configure the appliance FC settings first.

The NetBackup 52xx and 5330 appliances support the use of FC with some or all of the following features depending on hardware configuration:

- SAN Client
- Optimized duplication
- Auto Image Replication
- NetBackup for VMware
- Tape out

Note: Optimized duplication and Auto Image Replication over FC are only supported with NetBackup Appliance products, and not supported with non-appliance NetBackup servers.

Note: NetBackup Appliance supports the use of the DD Boost plug-in and its capabilities.

SAN Client

This feature provides high-speed backups and restores of NetBackup clients. A SAN client is a special NetBackup client that can back up large amounts of data rapidly over a SAN connection rather than a LAN. The backup and restore traffic occurs over FC, and the NetBackup server and client administration traffic occurs over the LAN.

You must enable the Fibre Transport media server (FTMS) feature on the NetBackup 52xx or 5330 appliance to use it for backing up SAN clients.

See [“Configuring Fibre Transport media server for SAN Client”](#) on page 59.

Optimized duplication

Optimized duplication copies the deduplicated backup images between appliances within the same domain.

For optimized duplication over FC, the duplication source must be a NetBackup 52xx or 5330 appliance. The duplication destination can be a NetBackup 5020, 5030 appliance.

Starting with the appliance software release 2.7.3, you can also use a NetBackup 52xx or 5330 appliance as the duplication destination.

The source and the destination must use the same NetBackup master server. The optimized duplication operation is more efficient than normal duplication because only the unique, deduplicated data segments are transferred. Optimized duplication

reduces the amount of data transmission over your network and is a good method to copy your backup images off-site for disaster recovery.

You must configure appliances at both the source and the destination for optimized duplication over FC.

See [“Configuring Fibre Transport for optimized duplication and Auto Image Replication over FC”](#) on page 62.

Note: When you perform duplication jobs from the NetBackup Administration Console, you can monitor the jobs by using the **Activity Monitor**. But in the **Detailed Status** tab, the **Transport Type** field always reports **LAN** for jobs over FC. To see the correct transport type, refer to the details in the **Status** box.

Auto Image Replication

The backups that are generated in one NetBackup domain can be replicated to storage in one or more target NetBackup domains. This process is referred to as Auto Image Replication.

You must configure appliances at both the source and the destination for Auto Image Replication over FC.

Starting with the appliance software release 2.7.3, you can also use a NetBackup 52xx or 5330 appliance as the replication destination.

See [“Configuring Fibre Transport for optimized duplication and Auto Image Replication over FC”](#) on page 62.

For information about Auto Image Replication, see the *NetBackup Deduplication Guide*.

Note: When you perform replication jobs from the NetBackup Administration Console, you can monitor the jobs by using the **Activity Monitor**. But in the **Detailed Status** tab, the **Transport Type** field always reports **LAN** for jobs over FC. To see the correct transport type, refer to the details in the **Status** box.

NetBackup for VMware

This feature provides backup and restore of the VMware virtual machines that run on VMware ESX servers. NetBackup for VMware takes advantage of VMware vStorage APIs for data protection. The backup process is off-loaded from the ESX server to a VMware backup host.

Starting with NetBackup 52xx and 5330 appliance software version 2.5, you can use the appliance as a VMware backup host. Earlier software versions required a separate Windows system as the host.

For information about how to configure a NetBackup 52xx or 5330 as a VMware backup host, refer to the following topics:

See [“About NetBackup Appliance as a VMware backup host”](#) on page 76.

See [“Notes on NetBackup Appliance as a VMware backup host”](#) on page 77.

For complete details about NetBackup for VMware and how to configure VMware policies, see the *NetBackup for VMware Administrator's Guide*.

Tape out

NetBackup Appliance supports backups to tape so that you can connect one or more tape libraries to them with FC. An FC host bus adapter (HBA) provides for connection to a TLD tape storage device.

For information about how to configure a NetBackup 52xx or 5330 for backups to tape, refer to the following topic:

See [“About backup to tape support for NetBackup appliances”](#) on page 74.

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.

See [“Supported Fibre Channel port configuration for the NetBackup 5240 appliances”](#) on page 40.

About NetBackup Fibre Transport

NetBackup Fibre Transport is a method of data transfer. It uses Fibre Channel and a subset of the SCSI command protocol for data movement over a SAN rather than TCP/IP over a LAN. It provides a high-performance transport mechanism for the following scenarios:

- Backup and restore between NetBackup clients and NetBackup media servers
- Optimized duplication and Auto Image Replication between NetBackup media servers

See [“About NetBackup SAN Client and Fibre Transport”](#) on page 10.

See [“About Fibre Transport for optimized duplication and Auto Image Replication between appliances”](#) on page 12.

About NetBackup SAN Client and Fibre Transport

SAN Client is a NetBackup optional feature that provides high-speed backups and restores of NetBackup clients.

Note: If you plan to use the SAN Client feature with your appliance and you have SLES 10 clients with QLogic FC HBA cards, a driver update is required. Before you proceed with backups of any SLES 10 clients, Veritas recommends that you first upgrade the QLogic driver in all SLES 10 clients to version 8.03.07.03.10.3-k or later.


A SAN client is a special NetBackup client that can back up large amounts of data rapidly over a SAN connection rather than a LAN. For example, a database host can benefit from high-speed backups and restores. Fibre Transport is the name of the NetBackup high-speed data transport method that is part of the SAN Client feature.

The backup and restore traffic occurs over Fibre Channel (FC), and the NetBackup server and client administration traffic occurs over the LAN.

For a NetBackup 52xx or 5330 appliance, Fibre Transport also provides high-speed traffic to a NetBackup 5000 series appliance that supports Fibre Transport. The 5000 series appliance functions as the storage host for SAN client backups.

[Figure 1-1](#) shows a SAN Client configuration.

Figure 1-1 A SAN Client configuration



For more information about SAN Client and Fibre Transport, see the *NetBackup SAN Client and Fibre Transport Guide* from the NetBackup Documentation set at the following link:

<http://www.veritas.com/docs/DOC5332>

See “[About the SAN Client license key](#)” on page 11.

See “[About zoning the SAN for NetBackup appliances](#)” on page 48.

See “[About Fibre Transport paths for NetBackup appliances](#)” on page 24.

About the SAN Client license key

On the NetBackup master server, enter the license that activates the SAN Client feature.

If the license expires or is unavailable (such as in a disaster recovery situation), backups and restores occur over the LAN.

About Fibre Transport for optimized duplication and Auto Image Replication between appliances

For a NetBackup 52xx or 5330 appliance, Fibre Transport (FT) provides high-speed traffic to another NetBackup appliance that supports FT. The traffic can be for optimized duplication or Auto Image Replication.

For optimized duplication and Auto Image Replication over FT, the source appliance must be a NetBackup 52xx or 5330 appliance. The target appliance can be the following:

- NetBackup 5020 or 5030 appliance
- NetBackup 52xx or 5330 appliance

Note: On the NetBackup 52xx or 5330 appliances, the support for optimized duplication or Auto Image Replication over FT depends on the HBA configuration of each appliance.

See [“About Fibre Channel feature support with appliance HBA configurations”](#) on page 14.

To use FT for optimized duplication and Auto Image Replication, you must complete different FT settings on the source and the target appliances.

- On the source appliance, you must enable FT for optimized duplication and replication to other appliances.
- On the target appliance, you must enable FT for use as the target for optimized duplication and replication. You can customize the port configuration on the source and the target appliance. Note that the target mode and ports are different than those for SAN Client Fibre Transport media server (FTMS).

Note: When you perform duplication or replication jobs from the NetBackup Administration Console, you can monitor the jobs by using the **Activity Monitor**. But in the **Detailed Status** tab, the **Transport Type** field always reports **LAN** for jobs over FC. To see the correct transport type, refer to the details in the **Status** box.

See [“About Fibre Transport paths for NetBackup appliances”](#) on page 24.

See [“Configuring Fibre Transport for optimized duplication and Auto Image Replication over FC”](#) on page 62.

See [“About FTMS reserved HBA ports and the factory default port mode configuration”](#) on page 29.

See [“Settings > Network > Fibre Transport”](#) on page 55.

Supported data transfer methods for NetBackup appliances

Table 1-1 describes the supported data transfer methods between NetBackup appliances. Specifically, NetBackup deduplication appliance models 5020 or 5030 and NetBackup appliance models 5220, 5230, 5240, or 5330. The information includes whether the supported method uses Fibre Channel (FC) or TCP/IP.

Note: The supported methods over TCP/IP are also supported with non-appliance NetBackup servers. But optimized duplication and Auto Image Replication over FC are only supported with NetBackup Appliance products. Depending on the HBA configuration, some appliances cannot be used as the target appliance for optimized duplication and Auto Image Replication.

Table 1-1 Supported data transfer methods for NetBackup appliances

Method	Source	Target	Operation
FC	52xx/5330	52xx/5330	Optimized duplication
FC	52xx/5330	52xx/5330	Auto Image Replication
FC	52xx/5330	5020/5030	Optimized duplication (See note below table.)
FC	52xx/5330	5020/5030	Auto Image Replication. (See note below table.)
FC	5020/5030	5020/5030	Optimized duplication
FC	5020/5030	5020/5030	Auto Image Replication
FC	SAN Client	52xx/5330	Media server deduplication
TCP/IP	52xx/5330	52xx/5330	Optimized duplication
TCP/IP	52xx/5330	52xx/5330	Auto Image Replication
TCP/IP	52xx/5330	5020/5030	Optimized duplication
TCP/IP	52xx/5330	5020/5030	Auto Image Replication
TCP/IP	5020/5030	5020/5030	Optimized duplication
TCP/IP	5020/5030	5020/5030	Auto Image Replication

Table 1-1 Supported data transfer methods for NetBackup appliances (*continued*)

Method	Source	Target	Operation
TCP/IP	5020/5030	52xx/5330	Optimized duplication

Note: For deduplication operations, the 5220, 5230, 5240 and the 5330 appliances can also leverage FC connectivity to directly communicate with the 5020 and 5030 appliances. For more information, refer to the following topic:

See [“Configuring direct backups from a NetBackup 52xx or 5330 appliance to a NetBackup 50xx appliance using Fibre Channel”](#) on page 69.

Table 1-2 describes the unsupported data transfer methods for NetBackup Deduplication and NetBackup appliances.

Table 1-2 Unsupported data transfer methods for NetBackup appliances

Method	Source	Target	Operation
FC	5020/5030	52xx/5330	Optimized duplication
FC	5020/5030	52xx/5330	Auto Image Replication
FC	SAN Client	5020/5030	Client-side deduplication
FC	SAN Client	52xx/5330	Client-side deduplication
TCP/IP	5020/5030	52xx/5330	Auto Image Replication

See [“About Fibre Channel supported features on NetBackup Appliance”](#) on page 6.

See [“About the NetBackup 5230 rear panel configurations”](#) on page 18.

See [“NetBackup 5330 Appliance compute node PCIe slot I/O configuration options”](#) on page 22.

See [“NetBackup 5240 Appliance I/O configuration options”](#) on page 20.

About Fibre Channel feature support with appliance HBA configurations

FC feature support depends on the particular HBA configuration of each appliance. If you do not know what configuration you have, refer to the *NetBackup Appliance Product Description Guide* for your appliance model at the following link:

[NetBackup Appliance Documentation page](#)

Table 1-3, Table 1-4, and Table 1-6 describe whether a particular FC feature is supported on your appliance.

Table 1-3 Supported FC features on NetBackup 5220 appliance

Configuration	Supported FC features
5220 A	Not supported
5220 B	<ul style="list-style-type: none"> ■ Optimized Duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5220 C	<ul style="list-style-type: none"> ■ Optimized Duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5220 D	<ul style="list-style-type: none"> ■ SAN Client ■ Optimized Duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5220 E	<ul style="list-style-type: none"> ■ SAN Client ■ Optimized Duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware

Table 1-4 Supported FC features on NetBackup 5230 appliance

Configuration	Supported FC features
5230 A	Not supported
5230 B	<ul style="list-style-type: none"> ■ Optimized Duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware

Table 1-4 Supported FC features on NetBackup 5230 appliance (*continued*)

Configuration	Supported FC features
5230 C	<ul style="list-style-type: none"> ■ Optimized Duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5230 D	<ul style="list-style-type: none"> ■ SAN Client ■ Optimized Duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5230 E	<ul style="list-style-type: none"> ■ SAN Client ■ Optimized Duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware

Table 1-5 Supported FC features on NetBackup 5240 appliance

Configuration	Supported FC features
5240 A	Not supported
5240 B	<ul style="list-style-type: none"> ■ Optimized duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5240 C	<ul style="list-style-type: none"> ■ Optimized duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5240 D	<ul style="list-style-type: none"> ■ SAN Client ■ Optimized duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware

Table 1-5 Supported FC features on NetBackup 5240 appliance (*continued*)

Configuration	Supported FC features
5240 E	<ul style="list-style-type: none"> ■ SAN Client ■ Optimized duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5240 F	<ul style="list-style-type: none"> ■ Optimized duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5240 G	<ul style="list-style-type: none"> ■ Optimized duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5240 H	<ul style="list-style-type: none"> ■ SAN Client ■ Optimized duplication (Only as a source appliance) ■ Auto Image Replication (Only as a source appliance) ■ Tape out ■ NetBackup for VMware <p>Note: This configuration cannot be used as a target appliance for optimized duplication or Auto Image Replication over FC.</p>
5240 J	Not supported
5240 K	<ul style="list-style-type: none"> ■ SAN Client ■ Optimized duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware
5240 L	<ul style="list-style-type: none"> ■ Optimized duplication ■ Auto Image Replication ■ Tape out ■ NetBackup for VMware

Table 1-6 Supported FC features on NetBackup 5330 appliance

Configuration	Supported FC features
5330 A	Not supported
5330 B	<ul style="list-style-type: none">■ Optimized Duplication■ Auto Image Replication■ Tape out■ NetBackup for VMware
5330 C	<ul style="list-style-type: none">■ SAN Client■ Optimized Duplication (Only as a source appliance)■ Auto Image Replication (Only as a source appliance)■ Tape out■ NetBackup for VMware <p>Note: This configuration cannot be used as a target appliance for optimized duplication or Auto Image Replication over FC.</p>
5330 D	<ul style="list-style-type: none">■ SAN Client■ Optimized Duplication■ Auto Image Replication■ Tape out■ NetBackup for VMware
5330 E	<ul style="list-style-type: none">■ SAN Client■ Optimized Duplication■ Auto Image Replication■ Tape out■ NetBackup for VMware

See [“About the NetBackup 5230 rear panel configurations”](#) on page 18.

See [“NetBackup 5330 Appliance compute node PCIe slot I/O configuration options”](#) on page 22.

See [“NetBackup 5240 Appliance I/O configuration options”](#) on page 20.

About the NetBackup 5230 rear panel configurations

The NetBackup 5230 appliance ships in the following configurations. The external storage shelves can be ordered as separate devices.

Table 1-7 NetBackup 5230 rear panel configurations

Configuration	Slot 1	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6
A	Not populated	Not populated	Not populated	Not populated	Not populated	Not populated
B	Not populated	Not populated	Not populated	Dual 8 Gb Fibre Channel	Not populated	Not populated
C	Not populated	Not populated	Dual 10 GbE Ethernet	Dual 8 Gb Fibre Channel	Not populated	Not populated
D	Not populated	Dual 8 Gb Fibre Channel	Dual 10 GbE Ethernet	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel
E	Not populated	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel
A (with an external storage shelf)	SAS RAID controller	Not populated	Not populated	Not populated	Not populated	Not populated
B (with an external storage shelf)	SAS RAID controller	Not populated	Not populated	Dual 8 Gb Fibre Channel	Not populated	Not populated
C (with an external storage shelf)	SAS RAID controller	Not populated	Dual 10 GbE Ethernet	Dual 8 Gb Fibre Channel	Not populated	Not populated
D (with an external storage shelf)	SAS RAID controller	Dual 8 Gb Fibre Channel	Dual 10 GbE Ethernet	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel
E (with an external storage shelf)	SAS RAID controller	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel	Dual 8 Gb Fibre Channel

Configuration D notes:

- You can use the FC ports in slots 2 and 4 for VMware, Optimized Deduplication over FC, or tape library connectivity. Both ports on each card are configured in Initiator mode.
- You can use the FC ports in slots 5 and 6 for Fibre Transport media server (FTMS) support.
- Understand that port 1 on the FC HBA cards in slots 5 and 6 is configured in Target mode. The other port on these cards is configured in Initiator mode.

Configuration E notes:


- You can use the FC ports in slots 2, 3, and 4 for VMware, Optimized Deduplication over FC, or tape library connectivity. Both ports on each card are configured in Initiator mode.
- You can use the FC ports in slots 5 and 6 for Fibre Transport media server (FTMS) support.
- Understand that port 1 on the FC HBA cards in slots 5 and 6 is configured in Target mode. The other port on these cards is configured in Initiator mode.

For complete information about FC HBA card usage, see the *NetBackup Appliance Fibre Channel Guide*.

NetBackup 5240 Appliance I/O configuration options

The rear panel of the NetBackup 5240 Appliance contains three PCIe riser card assemblies. PCIe riser card assemblies 1 and 2 each support three standard PCIe cards, while PCIe riser card assembly 3 supports two low profile PCIe cards. The slots are labeled 1 to 8. Slots 1, 2, and 3 are located in PCIe riser card assembly 2. Slots 4, 5, and 6 are located in PCIe riser card assembly 1, while slots 7 and 8 are located in PCIe riser card assembly 3.

Figure 1-2 Rear panel riser assembly locations and PCIe slot assignments (example: Configuration F)



The NetBackup 5240 Appliance supports multiple PCIe-based I/O configuration options. The following table shows the different I/O configuration options that are available with the NetBackup 5240 Appliance.

Table 1-8 Available NetBackup 5240 Appliance PCIe-based I/O configuration options

I/O configuration option	Slot 1 *	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6	Slot 7 **	Slot 8
A	-	-	-	-	-	-	-	-
B	-	-	-	-	-	8 Gb FC HBA ³	-	-
C	-	-	10 GbE NIC ^{1, 3}	-	-	8 Gb FC HBA ³	-	-
D	-	8 Gb FC HBA ³	10 GbE NIC ^{1, 3}	8 Gb FC HBA ³	8 Gb FC HBA ³	8 Gb FC HBA ³	-	-
E	-	8 Gb FC HBA ³	8 Gb FC HBA ³	8 Gb FC HBA ³	8 Gb FC HBA ³	8 Gb FC HBA ³	-	-
F	-	-	1 GbE NIC ² (4 port - RJ45)	-	-	8 Gb FC HBA ³	-	-
G	-	10 GbE NIC ^{1, 3}	10 GbE NIC ^{1, 3}	-	10 GbE NIC ^{1, 3}	8 Gb FC HBA ³	-	-
H ***	-	10 GbE NIC ^{1, 3} (iSCSI capable)	10 GbE NIC ^{1, 3}	-	8 Gb FC HBA ³	8 Gb FC HBA ³	-	-
J	-	-	10 GbE NIC ^{1, 3}	-	-	-	-	-
K	-	10 GbE NIC ^{1, 3}	10 GbE NIC ^{1, 3}	8 Gb FC HBA ³	8 Gb FC HBA ³	8 Gb FC HBA ³	-	-
L	-	10 GbE NIC ^{1, 3}	1 GbE NIC ² (4 port - RJ45)	-	-	8 Gb FC HBA ³	-	-

Table 1-8 Available NetBackup 5240 Appliance PCIe-based I/O configuration options (*continued*)

I/O configuration option	Slot 1 *	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6	Slot 7 **	Slot 8
--------------------------	----------	--------	--------	--------	--------	--------	-----------	--------

* Slot 1 contains a factory installed PCIe RAID 6 controller when at least one Veritas 2U12 49TB Storage Shelf is purchased with the NetBackup 5240 Appliance. Otherwise, slot 1 is not populated.

** Slot 7 contains the NetBackup 5240 Appliance's internal PCIe raid controller. This RAID controller is used to create the RAID 1 Array for the disk drives on which the appliance operating system is installed. The operating system drives are located in slots 0 and 1 of the front panel.

PCIe card cable connection types:

¹ Direct-Attach copper cable (also called a Twinaxial cable or Twinax)

² Standard copper cable

³ Fiber optic cable

*** I/O configuration option notes:

- A NetBackup 5240 Appliance using configuration H does not support Fibre Channel Replication (FCR) as a Target.
- A NetBackup 5240 Appliance using configurations D, E, H, and K can be configured as a dual port or as a quad port Fibre Transport Media Server (FTMS) server.


You can use the Initiator ports for tape-out operations and VMware Datastores in the following scenarios:

- If you do not configure the appliance as an FTMS server.
- If you configure the appliance as a dual port FTMS server.

You can also use the ports as a Fibre Channel Replication Initiator, or in combination with the previously mentioned uses.

NetBackup 5330 Appliance compute node PCIe slot I/O configuration options

The rear panel of the NetBackup 5330 Appliance compute node contains six PCIe slots that are numbered 1 to 6. Slots 1, 2, and 3 are located in PCIe Riser Assembly 2. Slots 4, 5, and 6 are located in PCIe Riser Assembly 1.



All PCIe slots are populated with an 8 Gb Fibre Channel (FC) host bus adapter (HBA) card or a 10 Gb Ethernet network interface card (NIC). Slots 1 and 4 are reserved exclusively for attachment to the Primary Storage Shelf.

For complete information about FC HBA card usage, see the *NetBackup Appliance Fibre Channel Guide*.

[Table 1-9](#) describes the default PCIe slot I/O configuration options for the NetBackup 5330 Appliance.

Table 1-9 Available PCIe slot I/O configuration options for the NetBackup 5330 Appliance compute node

I/O configuration option	Slot 1	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6
A	8 Gb FC HBA	10 GbE NIC	10 GbE NIC	8 Gb FC HBA	10 GbE NIC	10 GbE NIC
B	8 Gb FC HBA	10 GbE NIC	10 GbE NIC	8 Gb FC HBA	10 GbE NIC	8 Gb FC HBA
C	8 Gb FC HBA	10 GbE NIC	10 GbE NIC	8 Gb FC HBA	8 Gb FC HBA	8 Gb FC HBA
D	8 Gb FC HBA	8 Gb FC HBA	10 GbE NIC	8 Gb FC HBA	8 Gb FC HBA	8 Gb FC HBA
E	8 Gb FC HBA	8 Gb FC HBA	8 Gb FC HBA	8 Gb FC HBA	8 Gb FC HBA	8 Gb FC HBA

About Fibre Transport paths for NetBackup appliances

[Table 1-10](#) shows the backup, restore, and duplication paths for NetBackup Fibre Transport (FT) for NetBackup appliances. It also shows the FT settings from the NetBackup Appliance Web Console that enable a functionality.

FT requires the following appliance software versions:

- NetBackup 5330 appliance versions 2.6.1 and later are compatible with NetBackup 50xx deduplication appliance versions 1.4.2 and later.
- NetBackup 52xx and 5330 appliances must use software version 2.7.3 and later on both the source host and the target host to duplicate data.

Table 1-10 Appliance Fibre Transport targets

Function	From	To
Backups	NetBackup SAN client.	NetBackup 52xx or 5330 appliance. The appliance is the backup server and the storage host.
Restores	NetBackup 52xx or 5330 appliance. The appliance is the restore server and the storage host.	NetBackup SAN client.
Backups	NetBackup SAN client.	NetBackup 5020 deduplication appliance. The 5020 deduplication appliance is the storage host. The 52xx or 5330 appliance is the backup server and forwards the backups to the 5020 appliance.
Restores	NetBackup 5020 appliance. The 5020 deduplication appliance is the storage host. It sends the restore traffic through the 52xx or 5330 appliance, which is the restore server.	NetBackup SAN Client.
Duplication	NetBackup 52xx or 5330 appliance.	NetBackup 5020 deduplication appliance.
Duplication	NetBackup 52xx or 5330 appliance.	NetBackup 52xx or 5330 appliance.

An external tape library uses the standard initiator mode driver over Fibre Channel (FC), not NetBackup FT. Therefore, if you duplicate backup images from a tape library to a NetBackup 5020 deduplication appliance, traffic occurs as follows:

- FC between the tape library and the 52xx or 5330 appliance.
- FT between the 52xx or 5330 appliance and the 50xx deduplication appliance.

About appliance duplication paths

Figure 1-3 shows the duplication paths from a 52xx or 5330 appliance to a NetBackup deduplication appliance.

Figure 1-3 Appliance duplication paths from a 52xx or 5330 to a 5020 or 5030 appliance





Figure 1-4 shows the duplication paths from a 52xx or 5330 appliance to another NetBackup 52xx or 5330 appliance.

Figure 1-4 Appliance duplication paths between 52xx or 5330 appliances



The following items describe the Fibre Transport path for duplication:

- Duplication from the 52xx or 5330 appliance over FT to the 50xx deduplication appliance.

The duplication source on the 52xx or 5330 must be Media Server Deduplication Pool (MSDP). The operation is optimized duplication and only the unique deduplicated segments are transferred.

- Duplication from the 52xx or 5330 appliance over FT to the other 52xx or 5330 appliance.

The duplication source and destination must both be MSDP. The operation is optimized duplication and only the unique deduplicated segments are transferred.

- Duplication from the tape storage over FC to the 52xx or 5330 appliance and then over FT to the 50xx deduplication appliance.
The operation is normal duplication.
- Duplication from the 50xx deduplication appliance over FT to the 52xx or 5330 appliance and then over FC to the tape storage.
The operation is normal duplication.

For duplication, you must configure the 50xx deduplication appliance as a storage server in NetBackup. Then, use either a storage lifecycle policy or the NetBackup Catalog utility to duplicate backup images.


The following describes the resiliency available for FT jobs:

- Multiple FT paths can exist between hosts.
- Back up, restore, and duplication jobs failover to other FT paths if they exist. If no other FT paths are available, jobs fail.
- Optimized duplication jobs failover to other FT paths if they exist. If no other FT paths are available, they failover to the Ethernet network. If no FT connection or IP connection exists, optimized duplication jobs fail.
- If no FT connections exist, NetBackup uses an IP connection for new jobs.

About SAN client backup and restore paths

[Figure 1-5](#) shows the possible backup and restore paths for a NetBackup SAN client.

Figure 1-5 SAN client backup and restore paths




The following items describe the paths in [Figure 1-5](#):

- FT between the client and the 52xx or 5330 appliance. The backups reside on disk storage on the appliance. You can use FT both for backups to deduplication storage and backups to AdvancedDisk storage.
- FT between the client and the 50xx deduplication appliance through the 52xx or 5330 appliance. The traffic travels through two different SAN zones. The backups are deduplicated and reside on disk storage on the 50xx deduplication appliance.
- FT between the client and a 52xx or 5330 appliance, and then FC between the appliance and the tape library. The traffic travels through two different SAN zones. The backups are not deduplicated.

About LAN client backup and restore paths

[Figure 1-6](#) shows the possible backup and restore paths for a NetBackup client over a LAN.

Figure 1-6 LAN client backup and restore paths



The following items describe the paths in [Figure 1-6](#):

- Ethernet between the client and the 52xx or 5330 appliance. The backups reside on either deduplicated storage or AdvancedDisk storage on the appliance.
- Ethernet between the client and the 52xx or 5330 appliance, and then FT between the 52xx or 5330 appliance and the 50xx deduplication appliance. The backups are deduplicated and reside on disk storage on the 50xx appliance.
- Ethernet between the client and the 52xx or 5330 appliance, and then FC between the appliance and the tape library. The backups are not deduplicated.

See [“About Fibre Transport for optimized duplication and Auto Image Replication between appliances”](#) on page 12.

See [“About the SAN Client license key”](#) on page 11.

See [“How to determine appliance HBA WWPNs”](#) on page 48.

See [“About backup to tape support for NetBackup appliances”](#) on page 74.

About the HBA port mode configuration

This chapter includes the following topics:

- [About FTMS reserved HBA ports and the factory default port mode configuration](#)
- [Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances](#)
- [Supported Fibre Channel port configuration for the NetBackup 5240 appliances](#)
- [Supported Fibre Channel port configurations for the NetBackup 5330 appliances](#)

About FTMS reserved HBA ports and the factory default port mode configuration

All Fibre Channel (FC) HBA ports on the NetBackup 52xx and 5330 appliance default to the standard initiator mode. The NetBackup Appliance provides a predefined target port configuration for use as Fibre Transport media server (FTMS), and also for optimized duplication and Auto Image Replication over FC. If you have not customized the port configuration when you enable the related feature, the predefined port configuration is applied.

Note: Before you start configuring a particular FC feature on the appliance, make sure that it is supported with your appliance configuration.

See [“About Fibre Channel feature support with appliance HBA configurations”](#) on page 14.

About the target port configuration for SAN client backup and restore

On an appliance that supports SAN Client, two FC HBA cards are reserved for FTMS. Target port option can be set to either of the following:

- **2 target port Fibre Channel connection**
- **4 target port Fibre Channel connection**

When you enable this feature, the default option is **2 target port Fibre Channel connection**, and Port 1 on both of the two cards is changed to the target mode.

The **2 target port Fibre Channel connection** always uses Port 1 on both of the FC HBA cards.

See [“Configuring Fibre Transport media sever settings”](#) on page 60.

About the port configuration for optimized duplication and Auto Image Replication over FC

- On an appliance that is only used as the source, you can use any HBA port except the currently used FTMS target ports.
- On an appliance that is used as both the source and target, you can use the predefined HBA port mode configuration or customize the port mode.

When you enable Fibre Transport on the target side of optimized duplication and Auto Image Replication, the appliance turn some HBA ports into target mode. The appliance applies a predefined target port configuration if the port mode has not been customized. In the predefined configuration, Port 2 on each card is used as a target port. Port 1 stays in the standard initiator mode, but is not used until you enable Fibre Transport on the appliance as a source.

See [“Configuring Fibre Transport on a target appliance for optimized duplication and replication”](#) on page 67.

Summary of factory default port configuration for NetBackup 52xx and 5330 appliances

[Table 2-1](#) describes the factory default port configuration for a 5220 appliance.

Table 2-1 5220 factory default port configuration

HBA configuration	SAN Client FTMS	Optimized duplication and replication
5220 A	Not applicable	Not applicable
5220 B	Not applicable	Slot 3, Port 1 - initiator Slot 3, Port 2 - target

Table 2-1 5220 factory default port configuration (*continued*)

HBA configuration	SAN Client FTMS	Optimized duplication and replication
5220 C	Not applicable	Slot 3, Port 1 - initiator Slot 3, Port 2 - target
5220 D	Slots 2 and 4, Port 1 - target	Slot 3, Port 1 - initiator Slot 3, Port 2 - target
5220 E	Slots 2 and 4, Port 1 - target	Slot 3, Port 1 - initiator Slot 3, Port 2 - target

[Table 2-2](#) describes the factory default target port configuration for a 5230 appliance.

Table 2-2 5230 factory default port configuration

HBA configuration	FTMS	Optimized duplication and replication
5230 A	Not applicable	Not applicable
5230 B	Not applicable	Slot 4, Port 1 - initiator Slot 4, Port 2 - target
5230 C	Not applicable	Slot 4, Port 1 - initiator Slot 4, Port 2 - target
5230 D	Slots 5 and 6, Port 1 - target	Slots 2 and 4, Port 1 - initiator Slots 2 and 4, Port 2 - target
5230 E	Slots 5 and 6, Port 1 - target	Slots 2 and 4, Port 1 - initiator Slots 2 and 4, Port 2 - target

[Table 2-3](#) describes the factory default target port configuration for a 5240 appliance.

Table 2-3 5240 factory default port configuration

HBA configuration	FTMS	Optimized duplication and replication
5240 A	Not applicable	Not applicable
5240 B	Not applicable	Slot 6, Port 1 - initiator Slot 6, Port 2 - target

Table 2-3 5240 factory default port configuration (*continued*)

HBA configuration	FTMS	Optimized duplication and replication
5240 C	Not applicable	Slot 6, Port 1 - initiator Slot 6, Port 2 - target
5240 D	Slots 5 and 6, Port 1 - target	Slots 2 and 4, Port 1 - initiator Slots 2 and 4, Port 2 - target
5240 E	Slots 5 and 6, Port 1 - target	Slots 2 and 4, Port 1 - initiator Slots 2 and 4, Port 2 - target
5240 F	Not applicable	Slot 6, Port 1 - initiator Slot 6, Port 2 - target
5240 G	Not applicable	Slot 6, Port 1 - initiator Slot 6, Port 2 - target
5240 H	Slots 5 and 6, Port 1 - target	Not applicable
5240 J	Not applicable	Not applicable
5240 K	Slots 5 and 6, Port 1 - target	Slot 4, Port 1 - initiator Slot 4, Port 2 - target
5240 L	Not applicable	Slot 6, Port 1 - initiator Slot 6, Port 2 - target

[Table 2-4](#) describes the factory default target port configuration for a 5330 appliance.

Table 2-4 5330 factory default port configuration

HBA configuration	FTMS	Optimized duplication and replication
5330 A	Not applicable	Not applicable
5330 B	Not applicable	Slot 6, Port 1 - initiator Slot 6, Port 2 - target
5330 C	Slots 5 and 6, Port 1 - target	Not applicable
5330 D	Slots 5 and 6, Port 1 - target	Slot 2, Port 1 - initiator Slot 2, Port 2 - target

Table 2-4 5330 factory default port configuration (*continued*)

HBA configuration	FTMS	Optimized duplication and replication
5330 E	Slots 5 and 6, Port 1 - target	Slots 2 and 3, Port 1 - initiator Slots 2 and 3, Port 2 - target

When you enable the appliance as a target for optimized duplication and replication, the following applies:

- The factory default port configuration is used if you have not customized the port mode.
- The customized port configuration is used if you have changed the default port mode.

By default a 52xx or 5330 appliance is not enabled as a target for optimized duplication and replication over FT. The port configuration is not functional until the feature is enabled.

See [“About the NetBackup 5230 rear panel configurations”](#) on page 18.

See [“NetBackup 5240 Appliance I/O configuration options”](#) on page 20.

See [“NetBackup 5330 Appliance compute node PCIe slot I/O configuration options”](#) on page 22.

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

See [“Supported Fibre Channel port configuration for the NetBackup 5240 appliances”](#) on page 40.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.

Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances

Note: Before you start configuring a particular FC feature on the appliance, make sure that it is supported with your appliance HBA configuration.


See [“About Fibre Channel feature support with appliance HBA configurations”](#) on page 14.

NetBackup 5220 FC HBA slots and ports

The NetBackup 5220 Appliance can be preinstalled with up to three PCIe 8 Gb Fibre Channel HBA cards.

On a NetBackup 5220, slots 2 - 4 support FC.

Figure 2-1 describes the supported FC HBA slot locations and the port order for the installed FC HBA cards.



For the slot location of the NetBackup 5220 appliance HBA configurations, see the *NetBackup 5220 Appliance Product Guide* at following link:

<http://www.veritas.com/docs/000004284>


NetBackup 5230 FC HBA slots and ports

The NetBackup 5230 Appliance can be preinstalled with up to five PCIe 8 Gb Fibre Channel HBA cards.

On a NetBackup 5230, slots 2 - 6 support FC.

Figure 2-2 describes the supported FC HBA slot locations and the port order for the installed FC HBA cards.

Figure 2-2 NetBackup 5230 FC HBA slots and ports



See [“About the NetBackup 5230 rear panel configurations”](#) on page 18.

Summary of supported NetBackup 5220 and 5230 FC port options

Note: Veritas does not support reconfiguring the FC HBA cards in the appliance rear panel. Do not switch cards in different slots or install a used card from another appliance without contacting Veritas Technical Support.

[Table 2-5](#) provides a summary of the supported NetBackup 5220 and 5230 FC options for each port.

Table 2-5 Summary of supported NetBackup 5220 and 5230 FC options

FC HBA slot	Supported options and required port configuration
Slot 2 (5220 and 5230)	<div>Port 1</div> <ul style="list-style-type: none"> SAN Client - target (5220 only) Tape out - initiator NetBackup for VMware - initiator <div>Port 2</div> <ul style="list-style-type: none"> SAN Client - target (5220 only) <p>Note: If Port 1 is in the initiator mode, Port 2 cannot be set to the target mode. Port 2 can only be configured for the target mode when the 4 target port Fibre Channel connection option is selected.</p> <ul style="list-style-type: none"> Optimized duplication - initiator Auto Image Replication - initiator Tape out - initiator NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC HBA card on the following HBA configurations:</p> <ul style="list-style-type: none"> 5220 HBA configurations D and E 5230 HBA configurations D and E <p>On 5220 HBA configurations D and E, this slot is reserved for Fibre Transport media server (FTMS). If you enable SAN Client FTMS with those two configurations, Port 1 is changed to target mode for SAN Client by default.</p>

Table 2-5

Summary of supported NetBackup 5220 and 5230 FC options
(continued)

FC HBA slot	Supported options and required port configuration
Slot 3 (5220 and 5230)	<div>Port 1</div> <div><ul style="list-style-type: none">■ Optimized duplication - initiator or target■ Auto Image Replication - initiator or target■ Tape out - initiator■ NetBackup for VMware - initiator</div> <div>Port 2</div> <div><ul style="list-style-type: none">■ Optimized duplication - initiator or target■ Auto Image Replication - initiator or target■ Tape out - initiator■ NetBackup for VMware - initiator</div> <div>Use only one option on each port.</div> <div>This slot is populated with an FC HBA card on the following HBA configurations:</div> <div><ul style="list-style-type: none">■ 5220 HBA configurations B, C, D and E■ 5230 HBA configuration E</div>

Table 2-5 Summary of supported NetBackup 5220 and 5230 FC options
(continued)

FC HBA slot	Supported options and required port configuration
Slot 4 (5220 and 5230)	<div>Port 1</div> <ul style="list-style-type: none"> SAN Client - target (5220 only) Optimized duplication - initiator or target (5230 only) Auto Image Replication - initiator or target (5230 only) Tape out - initiator NetBackup for VMware - initiator <div>Port 2</div> <ul style="list-style-type: none"> SAN Client - target (5220 only) <p>Note: If Port 1 is in the initiator mode, Port 2 cannot be set to the target mode. Port 2 can only be configured for the target mode when the 4 target port Fibre Channel connection option is selected.</p> <ul style="list-style-type: none"> Optimized duplication - initiator Optimized duplication - target (5230 only) Auto Image Replication - initiator Auto Image Replication - target (5230 only) Tape out - initiator NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC HBA card on the following HBA configurations:</p> <ul style="list-style-type: none"> 5220 HBA configurations D and E 5230 HBA configurations B, C, D and E <p>On 5220 HBA configurations D and E, this slot is reserved for FTMS. If you enable SAN Client FTMS with those two configurations, Port 1 is changed to target mode for SAN Client by default.</p>

Table 2-5 Summary of supported NetBackup 5220 and 5230 FC options
(continued)

FC HBA slot	Supported options and required port configuration
Slots 5 - 6 (5230 only)	<div>Port 1</div> <ul style="list-style-type: none"> SAN Client - target Tape out - initiator NetBackup for VMware - initiator <div>Port 2</div> <ul style="list-style-type: none"> SAN Client - target <p>Note: If Port 1 is in the initiator mode, Port 2 cannot be set to the target mode. Port 2 can only be configured for the target mode when the 4 target port Fibre Channel connection option is selected.</p> <ul style="list-style-type: none"> Optimized duplication - initiator Auto Image Replication - initiator Tape out - initiator NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>The slots 5 - 6 are each populated with an FC HBA card on 5230 HBA configurations D and E.</p> <p>The slots 5 -6 are reserved for FTMS. If you enable SAN Client FTMS with those two configurations, Port 1 is changed to target mode for SAN Client by default.</p>

See [“About NetBackup SAN Client and Fibre Transport”](#) on page 10.

See [“About Fibre Transport for optimized duplication and Auto Image Replication between appliances”](#) on page 12.

See [“How to determine appliance HBA WWPNs”](#) on page 48.

See [“About Fibre Transport paths for NetBackup appliances”](#) on page 24.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.

See [“Supported Fibre Channel port configuration for the NetBackup 5240 appliances”](#) on page 40.

Supported Fibre Channel port configuration for the NetBackup 5240 appliances


Note: Before you start configuring a particular FC feature on the appliance, make sure that it is supported with your appliance HBA configuration.

See [“About Fibre Channel feature support with appliance HBA configurations”](#) on page 14.

The NetBackup 5240 Appliance can be ordered with one to five PCIe 8GB Fibre Channel (FC) HBA cards preinstalled.

[Figure 2-3](#) describes the supported FC HBA slot locations and the port order for the installed FC HBA cards.

Figure 2-3 NetBackup 5240 FC HBA slots and ports



See [“NetBackup 5240 Appliance I/O configuration options”](#) on page 20.

Note: Veritas does not support reconfiguring the FC HBA cards in the appliance rear panel. Do not switch cards in different slots or install a used card from another appliance without contacting Veritas Technical Support.

[Table 2-6](#) provides a summary of the supported NetBackup 5240 FC options. The 5220 and 5230 slot location and the required port configuration for each option are also included.

Table 2-6 Summary of supported NetBackup 5240 FC options

FC HBA slot	Supported options and required port configuration
Slot 2	<p>Port 1</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Port 2</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC card on 5240 HBA configurations D and E.</p>
Slot 3	<p>Port 1</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Port 2</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC card on 5240 HBA configuration E.</p>

Table 2-6 Summary of supported NetBackup 5240 FC options (*continued*)

FC HBA slot	Supported options and required port configuration
Slot 4	<p>Port 1</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target (5230 only) ■ Auto Image Replication - initiator or target (5230 only) ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Port 2</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC card on 5240 HBA configurations D, E, and K.</p>
Slot 5	<p>Port 1</p> <ul style="list-style-type: none"> ■ SAN Client - target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Port 2</p> <ul style="list-style-type: none"> ■ SAN Client - target <p>Note: If Port 1 is in the initiator mode, Port 2 cannot be set to the target mode. Port 2 can only be configured for the target mode when the 4 target port Fibre Channel connection option is selected.</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator ■ Auto Image Replication - initiator ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC card on 5240 HBA configurations D, E, H, and K.</p> <p>This slot is reserved for Fibre Transport media server (FTMS) on 5240 HBA configurations D, E, H, and K. If you enable SAN Client FTMS with those two configurations, Port 1 is changed to target mode for SAN Client by default.</p>

Table 2-6 Summary of supported NetBackup 5240 FC options (*continued*)

FC HBA slot	Supported options and required port configuration
Slot 6	<p>Port 1</p> <ul style="list-style-type: none"> ■ SAN Client - target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Port 2</p> <ul style="list-style-type: none"> ■ SAN Client - target <p>Note: If Port 1 is in the initiator mode, Port 2 cannot be set to the target mode. Port 2 can only be configured for the target mode when the 4 target port Fibre Channel connection option is selected.</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator ■ Auto Image Replication - initiator ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC card on 5240 HBA configurations B, C, D, E, F, G, H, K, and L.</p> <p>This slot is reserved for FTMS on 5240 HBA configurations D, E, H, and K. If you enable SAN Client FTMS with those two HBA configurations, Port 1 is changed to target mode for SAN Client by default.</p>

See [“About NetBackup SAN Client and Fibre Transport”](#) on page 10.

See [“About Fibre Transport for optimized duplication and Auto Image Replication between appliances”](#) on page 12.

See [“How to determine appliance HBA WWPNs”](#) on page 48.

See [“About Fibre Transport paths for NetBackup appliances”](#) on page 24.

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.


Supported Fibre Channel port configurations for the NetBackup 5330 appliances

Note: Before you start configuring a particular FC feature on the appliance, make sure that it is supported with your appliance HBA configuration.

See [“About Fibre Channel feature support with appliance HBA configurations”](#) on page 14.

The NetBackup 5330 appliance contains six populated PCIe card slots. Each slot contains either a Fibre Channel (FC) HBA card or an Ethernet card.

[Figure 2-4](#) shows the PCIe slot locations and the port order for the installed FC HBA cards.



Note: Veritas does not support reconfiguring the FC HBA cards in the appliance rear panel. Do not switch cards in different slots or install a used card from another appliance without contacting Veritas Technical Support.

[Table 2-7](#) describes the supported card type for each slot and the supported FC options.

Table 2-7 Supported NetBackup 5330 PCIe card slot configurations and FC options

Card slot and type	Supported FC options
Slot 1 FC HBA	Reserved exclusively for attachment to external storage (Primary Storage Shelf).
Slot 2 10Gb NIC or 8Gb FC HBA	<p>Port 1</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Port 2</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC card on 5330 HBA configurations D and E.</p>
Slot 3 10Gb NIC or 8Gb FC HBA	<p>Port 1</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Port 2</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC card on 5330 HBA configuration E.</p>
Slot 4 FC HBA	Reserved exclusively for attachment to external storage (Primary Storage Shelf).

Table 2-7 Supported NetBackup 5330 PCIe card slot configurations and FC options (*continued*)

Card slot and type	Supported FC options
Slot 5 10Gb NIC or 8Gb FC HBA	<p>Port 1</p> <ul style="list-style-type: none"> ■ SAN Client - target ■ Optimized duplication - initiator ■ Auto Image Replication - initiator ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Port 2</p> <ul style="list-style-type: none"> ■ SAN Client - target <p>Note: If Port 1 is in the initiator mode, Port 2 cannot be set to the target mode. Port 2 can only be configured for the target mode when the 4 target port Fibre Channel connection option is selected.</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator ■ Auto Image Replication - initiator ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC card on 5330 HBA configurations C, D and E.</p> <p>This slot is reserved for Fibre Transport media server (FTMS). If you enable SAN Client FTMS with those three configurations, Port 1 is changed to target mode for SAN Client by default.</p>

Table 2-7 Supported NetBackup 5330 PCIe card slot configurations and FC options (*continued*)

Card slot and type	Supported FC options
Slot 6 10Gb NIC or 8Gb FC HBA	<p>Port 1</p> <ul style="list-style-type: none"> ■ SAN Client - target ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Port 2</p> <ul style="list-style-type: none"> ■ SAN Client - target <p>Note: If Port 1 is in the initiator mode, Port 2 cannot be set to the target mode. Port 2 can only be configured for the target mode when the 4 target port Fibre Channel connection option is selected.</p> <ul style="list-style-type: none"> ■ Optimized duplication - initiator or target ■ Auto Image Replication - initiator or target ■ Tape out - initiator ■ NetBackup for VMware - initiator <p>Use only one option on each port.</p> <p>This slot is populated with an FC card on 5230 HBA configurations B, C, D and E.</p> <p>On 5330 HBA configurations C, D, and E, this slot is reserved for FTMS. If you enable SAN Client FTMS with those three configurations, Port 1 is changed to target mode for SAN Client by default.</p>

See [“About NetBackup SAN Client and Fibre Transport”](#) on page 10.

See [“About Fibre Transport for optimized duplication and Auto Image Replication between appliances”](#) on page 12.

See [“How to determine appliance HBA WWPNs”](#) on page 48.

See [“About Fibre Transport paths for NetBackup appliances”](#) on page 24.

See [“Supported Fibre Channel port configuration for the NetBackup 5240 appliances”](#) on page 40.

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

Zoning the FC SAN

This chapter includes the following topics:

- [How to determine appliance HBA WWPNS](#)
- [About zoning the SAN for NetBackup appliances](#)
- [About HBA link status on the NetBackup Appliance Shell Menu](#)

How to determine appliance HBA WWPNS

You must use physical port ID or World Wide Port Name (WWPN) when you specify the HBA ports on NetBackup appliances.

To determine the WWPNS, use the `Main_Menu > Manage > FibreChannel > Show` command in the NetBackup Appliance Shell Menu. The command output provides the information about ports based on the slot number.

For complete information about the NetBackup Appliance Shell Menu, see the *NetBackup Appliance Commands Reference Guide*.

See [“About Fibre Transport for optimized duplication and Auto Image Replication between appliances”](#) on page 12.

See [“About Fibre Transport paths for NetBackup appliances”](#) on page 24.

See [“About backup to tape support for NetBackup appliances”](#) on page 74.

See [“About NetBackup Appliance as a VMware backup host”](#) on page 76.

About zoning the SAN for NetBackup appliances

Before you can configure and use the NetBackup Fibre Transport (FT) mechanism, the SAN must be configured and operational.

The NetBackup appliance supports the following SAN configurations:

- Node port (N_Port) switched configuration.
- Fibre Channel arbitrated loop (FC-AL) configuration.
FC-AL hubs are not supported.

For SAN switched configurations, proper zoning prevents Fibre Transport traffic from using the bandwidth that may be required for other SAN activity. Proper zoning also limits the devices that the host bus adapter (HBA) ports discover; the ports should detect the other ports in their zone only. Without zoning, each HBA port detects all HBA ports from all hosts on the SAN. The potentially large number of devices may exceed the number that the operating system supports.

Instructions for how to configure and manage a SAN are beyond the scope of the NetBackup documentation. However, the following recommendations may help you optimize your SAN traffic.

[Table 3-1](#) describes the best practices for zoning the SAN on NetBackup appliances.

Table 3-1 Best practices for zoning the SAN on NetBackup appliances

Guideline	Description
One initiator per zone, multiple targets acceptable.	<p>Veritas recommends that you create zones with only a single initiator per zone. Multiple targets in a single zone are acceptable, only if all of the targets are similar.</p> <p>Note: For data duplication between two NetBackup 52xx or 5330 appliances, you must create zones with only one single initiator and one single target per zone.</p> <p>Tape target resources should be in separate zones from disk target resources, regardless of initiator. However, both sets of resources may share the same initiator.</p>
Be aware of performance degradation when a port is configured for multiple zones.	<p>If you use a single port as an initiator or a target for multiple zones, this port can become a bottleneck for the overall performance of the system. You must analyze the aggregate required throughput of any part of the system and optimize the traffic flow as necessary.</p>

Table 3-1 Best practices for zoning the SAN on NetBackup appliances
(continued)

Guideline	Description
For fault tolerance, spread connectivity across HBA cards and not ports.	To ensure the availability of system connections, if you incorporate a multi-path approach to common resources, pair ports on separate cards for like zoning. This configuration helps you avoid the loss of all paths to a resource in the event of a card failure.
Zone the SAN based on WWN to facilitate zone migrations, if devices change ports.	It is recommended that you perform SAN zoning based on WWN. If switch port configurations or cabling architectures need to change, the zoning does not have to be recreated.

[Table 3-2](#) describes the zones you should use for your SAN traffic.

Diagrams that show the zones are available at the following link.

See [“About Fibre Transport paths for NetBackup appliances”](#) on page 24.

Note: You must use physical port ID or World Wide Port Name (WWPN) when you specify the HBA ports on NetBackup appliances.

See [“How to determine appliance HBA WWPNs”](#) on page 48.

Table 3-2 Appliance zones

Zone	Description
Fibre Transport backup zone	<p>A Fibre Transport backup zone should include only the Fibre Transport traffic between the SAN clients and the appliance.</p> <p>The backup zone should include the following HBA ports:</p> <ul style="list-style-type: none"> ■ The target port of the HBA—connect this port to a Fibre Channel switch port. If you have two HBAs, you can use both of them. The use of two ports provides redundancy. <p>Note: The supplied QLogic FC HBA card in a NetBackup appliance uses a special NetBackup target mode driver for the target port. The target mode driver replaces the default, initiator mode Fibre Channel driver. The target mode driver applies only to the supplied QLogic HBA card.</p> <p>You must define the appliance target port by physical port ID or World Wide Port Name (WWPN). The target mode driver WWPNs are not unique because they are derived from the Fibre Channel HBA WWPN.</p> <ul style="list-style-type: none"> ■ Ports on the SAN client HBAs that connect to the appliance—connect each SAN client HBA port to ports on the same Fibre Channel switch. <p>You can define SAN client ports by either port ID or WWPN. However, if you use one method for all devices, zone definition and management is easier.</p> <p>The ports on the SAN clients use the standard initiator mode driver.</p> <p>To promote multistream throughput, each SAN client should detect all target mode devices of the appliance HBA port or ports in the zone. Each appliance HBA target port exposes two target mode devices.</p> <ul style="list-style-type: none"> ■ Define the zones on the switch so that the client ports and the HBA target ports are in the same zone. <p>Some Veritas appliance models include one or more Fibre Channel HBA cards that can be used for Fibre Transport. If your appliance does not include any of these cards, an authorized Veritas representative must install and configure an approved FC HBA card.</p>

Table 3-2 Appliance zones (*continued*)

Zone	Description
Fibre Transport storage zone	<p>A Fibre Transport storage zone carries the Fibre Transport traffic from a storage source to a storage destination.</p> <p>The source host is an NetBackup 52xx or 5330 appliance. The storage destination host is a NetBackup deduplication appliance or another NetBackup 52xx or 5330 appliance.</p> <p>The traffic can be either for duplication or for backups. For duplication, the deduplicated data is sent to the destination for storage. For backups, the data first travels to the NetBackup 52xx or 5330 appliance and is then sent to the NetBackup deduplication appliance for storage.</p> <p>The storage zone should include the following HBA ports:</p> <ul style="list-style-type: none"> ■ The initiator port of the HBA in the NetBackup appliance—connect this port to a Fibre Channel switch port. It does not have to be the same switch as the backup zone. The NetBackup 52xx or 5330 appliance is the source for the duplication. The initiator ports use the standard initiator mode driver. ■ The NetBackup deduplication appliance ports. For the 5020, connect the target ports (Port 1) of the HBAs in slots 1, 2, and / or 3 to the same Fibre Channel switch. For the 5030, connect the target ports (Port 1) of the HBAs in slots 2 or 5 to the same Fibre Channel switch. The 5020 or 5030 deduplication appliance is the target of the duplication jobs. <p>Note: To use Fibre Channel on a NetBackup 5020 or 5030, you must enable the Fibre Channel communication feature. For details, see the NetBackup Deduplication Appliance Software Administrator's Guide.</p> <ul style="list-style-type: none"> ■ The NetBackup 52xx and 5330 appliance target ports. The 52xx or 5330 appliance is the target for the duplication. ■ Define the zones on the switch so that the NetBackup appliance initiator port and the NetBackup deduplication appliance target port are in the same zone. <p>Note: For data duplication between two NetBackup 52xx or 5330 appliances, you must create zones with only one single initiator port and one single target port.</p>
External tape storage zone	<p>If you use a tape library as storage, create a separate zone for that traffic. The tape storage zone does not use NetBackup Fibre Transport; it uses the standard initiator mode driver.</p> <p>The tape storage zone should include a port or ports on the FC HBA in slot 3 of a 52xx appliance, or on the FC HBA in slot 2 or 3 of a 5330 appliance.</p>

About HBA link status on the NetBackup Appliance Shell Menu

The HBA link status on a Fibre Channel (FC) HBA port shows the current FC link status on the port. By monitoring the link status, you can know whether a port is correctly connected or whether it is ready for work.

To monitor the HBA link status, run the `Main > Manage > FibreChannel > Show [Ports]` command from the NetBackup Appliance Shell Menu. The output shows the link status of all the HBA ports.

The following list shows the possible status of a port in the standard initiator mode:

- Online
 - The initiator port is connected to an FC switch.
 - The initiator port is directly connected to a target port for SAN Client Fibre Transport media server (FTMS).
- Offline
 - The initiator port is connected to an FC switch but the negotiation has failed.
- Linkdown
 - The initiator port has no FC connection

The following list shows the possible link status of a port in target mode for SAN Client FTMS:

- Fabric
 - The target port is connected to an FC switch with an active FC zone.
- Disconnected
 - The target port is connected to an FC switch but the FC zone is not active.
 - The target port is connected to another target port for SAN Client FTMS through an FC switch.

Note: : If two target ports for SAN Client FTMS are connected through an FC switch, you can find that one port shows Disconnected, and the other shows Loop.

- Loop
 - The target port is connected to another target port for SAN Client FTMS through an FC switch.
- Ptp

The target port is connected to an FC switch and the negotiation is ongoing.

The following list shows the possible link status of a port in the target mode for optimized duplication and Auto Image Replication:

- Online
The target port is connected to an FC switch.
- Offline
The target port is connected to an FC switch but the negotiation has failed.
- Linkdown
The target port has no FC connection.

To monitor the link status of the ports that are used to duplicate data between two 52xx or 5330 appliances, you can also use the NetBackup Appliance Web Console. The **Settings > Network > FibreTransport** page displays a simplified status of **up** or **down** for those ports.

See [“About the HBA port mode configuration table”](#) on page 57.

Configuring Fibre Transport on the appliance

This chapter includes the following topics:

- [Settings > Network > Fibre Transport](#)
- [Configuring Fibre Transport media server for SAN Client](#)
- [Configuring Fibre Transport media sever settings](#)
- [Guidelines for changing NetBackup appliance FT target ports to receive data streams from multiple SAN Client FC initiator ports](#)
- [Configuring Fibre Transport for optimized duplication and Auto Image Replication over FC](#)
- [Configuring Fibre Transport to other NetBackup appliances](#)
- [Configuring Fibre Transport on a target appliance for optimized duplication and replication](#)
- [Configuring direct backups from a NetBackup 52xx or 5330 appliance to a NetBackup 50xx appliance using Fibre Channel](#)
- [How to configure two NetBackup 52xx or 5330 appliances in different domains for MSDP replication](#)

Settings > Network > Fibre Transport

The Fibre Transport (FT) options let you set up the appliance for FT use with SAN Clients or for optimized duplication and Auto Image Replication. By default, the FT options are disabled and the configuration of one option does not affect the other one.

The following describes the FT options:

Table 4-1 FT option descriptions

FT option	Description
Enable SAN Client Fibre Transport on the Media Server (use FT for backups to this appliance) <ul style="list-style-type: none"> ■ 2 target port Fibre Channel connection ■ 4 target port Fibre Channel connection 	<p>This option lets you enable Fibre Transport media sever (FTMS) on the appliance for SAN Client FT use.</p> <p>You must also choose from the following appliance target port configuration for SAN clients when you enable the option.</p> <ul style="list-style-type: none"> ■ 2 target port Fibre Channel connection - Port 1 on both affected FC HBA cards is set to the target mode. ■ 4 target port Fibre Channel connection - Port 1 and Port 2 on both affected FC HBA cards are set to the target mode. <p>By default, the option is disabled and all ports are in the initiator mode.</p> <p>Before you enable this option, be aware of the following requirements and behavior:</p> <ul style="list-style-type: none"> ■ To use this option, a SAN Client license key must reside on the master server that is associated with this appliance. If FT is not currently used and you want to use the SAN Client feature, you must first obtain a SAN Client license key. To obtain the appropriate license key, contact Veritas Technical Support. Once you have the license key, you must add it to the master server. ■ When this option is enabled or changed, a warning appears to alert you that the appliance requires a restart. Before you enable this option, it is recommended that you first suspend or cancel all jobs. <p>See “Configuring Fibre Transport media server for SAN Client” on page 59.</p> <p>See “Configuring Fibre Transport media sever settings” on page 60.</p>
Enable Fibre Transport for replication to other NetBackup Appliances	<p>This option lets you enable Fibre Transport for optimized duplication and Auto Image Replication to other NetBackup appliances that are used as target hosts.</p> <p>By default, this option is disabled and the appliance cannot communicate with a target appliance over FC.</p> <p>Note: To use this option, you must enable FC communication on the associated target NetBackup appliance.</p> <p>If you plan to use a NetBackup 5020 or 5030 appliance as the target, see the <i>NetBackup Deduplication Appliance Software Administrator's Guide</i></p> <p>If you plan to use a NetBackup 52xx or 5330 appliance as the target, see the following for configuration.</p> <p>See “Configuring Fibre Transport for optimized duplication and Auto Image Replication over FC” on page 62.</p>

Table 4-1 FT option descriptions (*continued*)

FT option	Description
Enable Fibre Transport Deduplication on this appliance as a replication target	<p>This option lets you configure FT on a NetBackup 52xx or 5330 appliance to use it as a target for optimized duplication and Auto Image Replication.</p> <p>When the option is enabled, the Port mode configuration table is activated, and then you can configure the HBA ports to be target ports for optimized duplication and Auto Image Replication.</p> <p>See “About the HBA port mode configuration table” on page 57.</p> <p>Note: To use this option, you must also enable FT for optimized duplication and Auto Image Replication to other NetBackup Appliances on the associated source appliance.</p> <p>See “Configuring Fibre Transport on a target appliance for optimized duplication and replication” on page 67.</p> <p>By default, this option is disabled and the other appliances cannot use this appliance as a target through FC connection.</p>

For more information about SAN Client and Fibre Transport support on NetBackup Appliance, see the *NetBackup Appliance Fibre Channel Guide*.

See [“Configuring Fibre Transport media server for SAN Client”](#) on page 59.

See [“Configuring Fibre Transport for optimized duplication and Auto Image Replication over FC”](#) on page 62.

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.

See [“Supported Fibre Channel port configuration for the NetBackup 5240 appliances”](#) on page 40.

About the HBA port mode configuration table

The port mode configuration table shows the details of the HBA ports that can be used for Fibre Transport Deduplication.

Fibre Transport Deduplication is a feature that enables you to use an appliance as a target host for optimized duplication and Auto Image Replication.

Note: The HBA port mode configuration table only shows information of the HBA ports for Fibre Transport Deduplication. The ports that are reserved for SAN Client Fibre Transport are not shown in this table.

You can configure an HBA port in the table to be in target mode or standard initiator mode.

[Table 4-2](#) describes the HBA port mode configuration table.

Table 4-2 HBA port mode configuration

Column Name	Description
Slot	This column shows the slot number of the HBA card on this appliance.
Port	This column shows the port number of the HBA ports.
Link Status	<p>This column shows whether the HBA port is connected to a fabric switch or another port.</p> <p>The link status on an HBA port can be the following:</p> <ul style="list-style-type: none">■ up - connected■ down - not connected
World Wide Name (WWN)	This column shows the port WWN. You can use the port WWN to identify a port on the appliance.
Port Mode	<p>This column shows the configured port mode of an HBA port.</p> <p>The available options for HBA port mode are the following:</p> <ul style="list-style-type: none">■ Initiator - Standard initiator mode■ Target (MSDP) - Target mode for optimized duplication and Auto Image Replication <p>You can click on the current port mode, and then change the port mode configuration. If you change the port mode, you can see the new port mode with a red earmark.</p> <p>You can click on the Restore FactoryDefaults option to restore the port configuration to the factory default state.</p> <p>See “About FTMS reserved HBA ports and the factory default port mode configuration” on page 29.</p> <p>See “Configuring Fibre Transport on a target appliance for optimized duplication and replication” on page 67.</p>

For more information about HBA port options, review the following topics:

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.

Configuring Fibre Transport media server for SAN Client

[Table 4-3](#) provides an overview of how to configure the Fibre Transport media server(FTMS) on the appliance.

Table 4-3 FT media server configuration process

Step	Action	Description
Step 1	Determine whether your appliance HBA configuration supports FTMS.	<p>Identify your appliance HBA configuration.</p> <p>See “About the NetBackup 5230 rear panel configurations” on page 18.</p> <p>See “NetBackup 5240 Appliance I/O configuration options” on page 20.</p> <p>See “NetBackup 5330 Appliance compute node PCIe slot I/O configuration options” on page 22.</p> <p>Determine whether your appliance HBA configuration supports FTMS.</p> <p>See “About Fibre Channel feature support with appliance HBA configurations” on page 14.</p>
Step 2	Learn about SAN Client and FTMS for NetBackup Appliance.	See “About NetBackup SAN Client and Fibre Transport” on page 10.
Step 3	Learn about HBA port reservation and default port mode for FTMS.	See “About FTMS reserved HBA ports and the factory default port mode configuration” on page 29.
Step 4	Create Fibre Transport (FT) backup zones.	<p>Select HBA ports and learn about zoning best practices.</p> <p>See “About zoning the SAN for NetBackup appliances” on page 48.</p> <p>Determine the appliance HBA WWPNs for zoning.</p> <p>See “How to determine appliance HBA WWPNs” on page 48.</p>
Step 5	Enable FTMS on the appliance.	<p>To use FT for backups to the appliance, you must enable FTMS on the appliance.</p> <p>See “Configuring Fibre Transport media sever settings” on page 60.</p>

See [“About Fibre Transport paths for NetBackup appliances”](#) on page 24.

Configuring Fibre Transport media sever settings

Note: Enabling or changing the SAN Client FT settings requires a restart of the appliance. Before you enable or change these settings, it is recommended that you first suspend or cancel all jobs.

The following describes the FC HBA cards that are affected:

- NetBackup 5220 - FC HBA cards in slots 2 and 4
- NetBackup 5230 and NetBackup 5330 - FC HBA cards in slots 5 and 6
- NetBackup 5240 - FC HBA cards in slots 5 and 6

To configure the SAN Client Fibre Transport option from the NetBackup Appliance Web Console

- 1 Log on to the NetBackup Appliance Web Console.
- 2 Click **Settings > Network**, then select **Fibre Transport**.
- 3 Click to enable the **Enable SAN Client Fibre Transport on the Media Server (use FT for backups to this appliance)**
- 4 To change the target port option for SAN Client FTMS, do one of the following:
 - Select **2 target port Fibre Channel connection**. Then, click **Save**.
 - Select **4 target port Fibre Channel connection**. Then, click **Save**.
 When the message appears to alert you that the appliance requires a restart, click **Reboot** to continue or click **Cancel** to exit without making changes.
- 5 If you want to disable the SAN Client Fibre Transport option, deselect the option to clear the check mark. Then, click **Save**.

When an alert appears to inform you that the deduplication storage daemons require a restart. Click **OK** to continue or click **Cancel** to prevent a restart. Click **Cancel** to exit without making changes.

- 6 After the appliance has been restarted, verify the SAN Client FTMS settings as follows:
 - Log on to the NetBackup Appliance Web Console.
 - Click **Settings > Network**, then select **Fibre Transport**.
 - Verify that the settings are correct.

To configure the SAN Client Fibre Transport option from the NetBackup Appliance Shell Menu

- 1** Log on to the NetBackup Appliance Shell Menu.
- 2** To enable the SAN Client FTMS feature, run the following command:


```
Main > Settings > FibreTransport SANClient Enable
```


When the message appears to alert you that the appliance requires a restart, type **yes** to continue or type **no** to exit without making changes.
- 3** To change the SAN Client FTMS settings, do one of the following:
 - To configure two ports as target ports, run the following command:

```
Main > Manage > FibreChannel > Configure 2
```
 - To configure four ports as target ports, run the following command:

```
Main > Manage > FibreChannel > Configure 4
```
- 4** If you want to disable the SAN Client FTMS feature, run the following command:


```
Main > Settings > FibreTransport SANClient Disable
```
- 5** After the appliance has been restarted, verify the SAN Client FTMS settings as follows:
 - Log on to NetBackup Appliance Shell Menu
 - Run the following two commands:

```
Main > Settings > FibreTransport SANClient Show
```
 - Verify that the settings are correct.
The following is the output when the feature is enabled:


```
- [Info] Fibre Transport Sever enabled.
```


The following is the output when the feature is disabled:


```
- [Info] Fibre Transport Sever disabled.
```

See [“Settings > Network > Fibre Transport”](#) on page 55.

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.

See [“Supported Fibre Channel port configuration for the NetBackup 5240 appliances”](#) on page 40.

Guidelines for changing NetBackup appliance FT target ports to receive data streams from multiple SAN Client FC initiator ports

If you want an appliance Fibre Transport (FT) target port to handle data streams from more than two SAN client Fibre Channel (FC) initiator ports concurrently, consider changing the following NetBackup master server setting:

```
nbftconfig -setconfig -ncp 4
```

Caution: This setting applies to all target ports on all FT media servers in your NetBackup domain. This setting should only be increased from the default (2) when all of the following conditions exist:

All FT target ports on all FT media servers are eight gBit/s link speeds.

The total mix of FT jobs is such that all of the FT media servers have unused FT pipes.

A large number of jobs from other SAN Client machines are waiting for resources.

The back-end storage units have a lot of unused throughput capacity.

If you increase the `-ncp` setting too high, the load balancing between multiple FT media servers when all SAN Client machines are zoned to all FT media servers could become highly imbalanced.

Note: A mix of SAN Client job loads where some clients use four or more FT pipes concurrently with several other SAN Clients that only attempt to use a single FT pipe at a time increases the odds that a higher `-ncp` setting may cause FT media server imbalance.

For four gBit/s links, there may be situations where overall throughput can degrade when some or all SAN Clients are using multiple concurrent data streams. This scenario may be especially true for NetBackup 5220 appliances. In those situations, `nbftconfig -setconfig -ncp 3` may be a better option.

Configuring Fibre Transport for optimized duplication and Auto Image Replication over FC

[Table 4-4](#) provides an overview of how to configure Fibre Transport(FT) on the appliance for optimized duplication and Auto Image Replication over FC.

Table 4-4 FT configuration process for optimized duplication and Auto Image Replication over FC

Step	Action	Description
Step 1	<p>Determine whether your appliance HBA configuration supports FT for optimized duplication and Auto Image Replication.</p> <p>Note: The HBA configuration of 5330 C and 5240 H support optimized duplication and Auto Image Replication over FC, but can only support using the appliance as a source.</p>	<p>Identify your appliance HBA configuration.</p> <p>See “About the NetBackup 5230 rear panel configurations” on page 18.</p> <p>See “NetBackup 5240 Appliance I/O configuration options” on page 20.</p> <p>See “NetBackup 5330 Appliance compute node PCIe slot I/O configuration options” on page 22.</p> <p>Determine whether your appliance HBA configuration supports FT for optimized duplication and Auto Image Replication.</p> <p>See “About Fibre Channel feature support with appliance HBA configurations” on page 14.</p>
Step 2	Learn about FT for optimized duplication and Auto Image Replication.	See “About Fibre Transport for optimized duplication and Auto Image Replication between appliances” on page 12.
Step 3	Learn about default HBA port mode for optimized duplication and Auto Image Replication over FC.	See “About FTMS reserved HBA ports and the factory default port mode configuration” on page 29.
Step 4	Create FT storage zones.	<p>Select HBA ports and learn about zoning best practices.</p> <p>See “About zoning the SAN for NetBackup appliances” on page 48.</p> <p>Determine the appliance HBA WWPNs for zoning.</p> <p>See “How to determine appliance HBA WWPNs” on page 48.</p>
Step 5	Configure FT settings for optimized duplication and Auto Image Replication.	<p>Configure FT settings on the source appliance.</p> <p>See “Configuring Fibre Transport to other NetBackup appliances” on page 64.</p> <p>Configure FT settings on the target 52xx and 5330 appliance.</p> <p>See “Configuring Fibre Transport on a target appliance for optimized duplication and replication” on page 67.</p> <p>Note: For configuring the NetBackup 5020 and 5030 appliances as the target appliance, see the <i>NetBackup Deduplication Appliance Software Administrator's Guide</i></p>

See [“How to configure two NetBackup 52xx or 5330 appliances in different domains for MSDP replication”](#) on page 71.

Configuring Fibre Transport to other NetBackup appliances

Use the following procedure to configure Fibre Transport (FT) to other NetBackup appliances.

Note: When the FT for replication to other NetBackup appliances is enabled or changed, the deduplication storage daemons require a restart. It is recommended that you first suspend or cancel all jobs before you enable or change this setting.

To configure Fibre Transport to other NetBackup appliances from the NetBackup Appliance Web Console

- 1 Log on to the NetBackup Appliance Web Console.
- 2 Click **Settings > Network**, then select **Fibre Transport**.
- 3 To enable Fibre Transport to other NetBackup appliances, click to select the **Enable Fibre Transport for replication to other NetBackup Appliances**. Then, click **Save**.

When the message appears to inform you of the required the appliance version, click **OK** to continue or click **Cancel** to exit without making changes.

Note: You must also enable FC communication on the associated NetBackup appliance.

On a target NetBackup 5020 or 5030, you must enable FC communication on that appliance. See the *NetBackup Deduplication Appliance Software Administrator's Guide*.

On a target NetBackup 52xx or 5330, you must enable that appliance as a replication target to use it as the storage destination.

See [“Configuring Fibre Transport on a target appliance for optimized duplication and replication”](#) on page 67.

- 4 To disable the **Fibre Transport to other NetBackup Appliances** option, deselect the check box to clear the check mark. Then, click **Save**.

To configure Fibre Transport to other NetBackup appliances from the NetBackup Appliance Shell Menu

- 1** Log on to the NetBackup Appliance Shell Menu.
- 2** Enable Fibre Transport for replication to other NetBackup appliances by running the following command:

```
Main > Settings > FibreTransport NBUAppliances Enable
```

- 3** If you want to disable Fibre Transport for replication to other NetBackup appliances, run the following command:

```
Main > Settings > FibreTransport NBUAppliances Disable
```

- 4** To verify that the settings are correct, run the following command:

```
Main > Settings > FibreTransport NBUAppliances Show
```

The following is the output when the feature is enabled:

```
fc transport enabled.
```

The following is the output when the feature is disabled:

```
fc transport disabled.
```

See [“Settings > Network > Fibre Transport”](#) on page 55.

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.

See [“Supported Fibre Channel port configuration for the NetBackup 5240 appliances”](#) on page 40.

See [“About the Fibre Transport chunk size”](#) on page 65.

About the Fibre Transport chunk size

The chunk size specifies the amount of data that is buffered before transmission over Fibre Transport (FT). It is an advanced setting on the sender side for optimized duplication and replication to other NetBackup appliances over FT.

By default, the chunk size is not set or used. The chunk size setting is not required for optimized duplication and replication over FT. It is highly dependent on user deployment and network status. If you find it necessary to improve backup performance, you can adjust the chunk size as needed to determine a proper value for your environment and the current network status.

Typically, the sender on the initiating appliance receives a block of data and starts the transmission regardless of its size. After this data block is transmitted, the sender waits for a confirmation from the receiver (or target appliance) before it transmits the next block. The transmission continues if the appliance receives confirmations without interruption. If the network latency is high, confirmation time also increases.

By setting the chunk size, you determine that data blocks must be delivered by using chunks of the specified size. In a single transmission session, if the sender receives a block of data that is greater than the specified chunk size, it fragments the data into chunks for transmission. The remaining data from the fragmentation is allocated to the next chunk. If a data block is smaller than the specified chunk size, the sender adds it into the buffer to link it together with data from the preceding or the following block. Data block linking continues until the buffered data has reached the chunk size, and then the appliance transmits the chunk. After transmitting, the sender waits for a confirmation from the receiver before it sends out the next chunk. If the session closes, the remaining data is transmitted.

A data block over FT is typically 128 KB or smaller. Setting the chunk size to a value equal to or greater than 128 KB allows the appliance to link together small data blocks into big chunks. Therefore, fewer confirmations are needed. The result may improve the transmission efficiency when the network latency is high. The data block linking also reduces the overhead that is generated with the data.

Network latency can be high in the following scenarios, and you can consider using the chunk size to see if anything improves.

- Data transmitted over a long distance and an IP network that is used for the transmission along with FC.
- Data transmitted over a long distance through an FC-only connection.

Note: If you observe a big downgrade on backup performance over a short-distance FC-only connection, try adjusting the chunk size and see if there is any improvement.

The default value for chunk size is "0", which means the chunk size is not set or used. If you set the chunk size to a value equal or greater than "1", you specify the size of each data chunk that is sent to the FC network. To enable and manage the chunk size setting, use the `Main > Support > FibreTransport > ChunkSize` command from the NetBackup Appliance Shell Menu. The available chunk size range is 1-2048 KB. The recommended values are 128 KB, 256 KB, 512 KB, 1024 KB, or 2048 KB. You may also need to test with other values to determine a proper value for your environment.

The chunk size may not work for the following reasons:

- A limited bandwidth
- Network congestion
- Not using a dedicated data network

Configuring Fibre Transport on a target appliance for optimized duplication and replication

The Fibre Transport Deduplication feature enables you to use a NetBackup 52xx or 5330 appliance as a target host for optimized duplication and Auto Image Replication over Fibre Channel (FC).

If you have configured one or more target ports for Fibre Transport Deduplication, and you do one of the following, you cause the physical state of one or more ports to change:

- Enabling the Fibre Transport Deduplication feature
- Disabling the Fibre Transport Deduplication feature
- Changing the port mode configuration when the feature is enabled

Note: You must restart all the appliances in the FC zone where the physical state of an HBA port is changed.

Note: To continue to use Fibre Transport Deduplication after a re-image operation, you must first restore the factory default port configuration or disable the feature. Then you can go on with other settings.

To configure a 52xx and 5330 appliance as a replication target using the NetBackup Appliance Web Console

- 1 Log on to the NetBackup Appliance Web Console.
- 2 Click **Settings > Network**, then select **Fibre Transport**.
- 3 To enable Fibre Transport Deduplication, click to select the **Enable Fibre Transport on this appliance as a replication target**.
- 4 If you want to keep the current port configuration, skip this step.

If you want to change the port mode on the appliance, do the following:

- In the **Port Mode** column, click on the current port mode of a port.
- From the drop-down menu, select **Initiator** or **Target (MSDP)** to configure the port mode.

- To restore the customized port configuration to the factory default state, click **Restore FactoryDefaults**.

The port mode change is reflected on a diagram on the right of the page.

- 5 Click **Save** to apply the changed settings.
- 6 Restart the appliances in the FC zone where a port mode change has occurred.
 To reduce the times of restarting, restart the appliances after you finish all the changes.

To configure a 52xx and 5330 appliance as a replication target using the NetBackup Appliance Shell Menu

- 1 Log on to the NetBackup Appliance Shell Menu.
- 2 To enable Fibre Transport Deduplication, run the following command:

```
Main > Settings > FibreTransport Deduplication Enable  
[Current|FactoryDefault]
```

- 3 To configure the port mode, run the following command:

```
Main > Manage > FibreChannel > Configure Deduplication <Initiator  
| Target> <HBAportid>
```

The `HBAportid` is slot number (1-6) and port number (1-2) of the HBA port.
 The format is `Slot:Port`.

- 4 To show the current port mode configuration, run the following command:

```
Main > Manage > FibreChannel > Show [Ports]
```

- 5 To disable the Fibre Transport Deduplication feature, run the following command:

```
Main > Settings > FibreTransport Deduplication Disable
```

- 6 Verify that the settings are correct by running the following command:

```
Main > Settings > FibreTransport Deduplication Show
```

This following is the output when the feature is enabled:

```
[Info] Fibre Transport Deduplication is enabled.
```

This following is the output when the feature is disabled:

```
[Info] Fibre Transport Deduplication is disabled.
```

- 7 Restart the appliances in the FC zone where the physical state of a port change has changed.

To reduce the times of restarting, restart the appliances after you finish all the changes.

See [“Settings > Network > Fibre Transport”](#) on page 55.

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.

See [“Supported Fibre Channel port configuration for the NetBackup 5240 appliances”](#) on page 40.

See [“About the HBA port mode configuration table”](#) on page 57.

See [“About FTMS reserved HBA ports and the factory default port mode configuration”](#) on page 29.

Configuring direct backups from a NetBackup 52xx or 5330 appliance to a NetBackup 50xx appliance using Fibre Channel

This topic describes how to configure a NetBackup 52xx or 5330 media server to send all backups directly to a NetBackup 5020 or 5030 deduplication appliance.

The target and the initiator configuration for the appliances must be set as follows:

- NetBackup 5020 or 5030
This appliance is set up as the disk pool (target). Any available target port on a Fibre Channel HBA card can be used.
- NetBackup 52xx or 5330

This appliance is set up as the backup image source (initiator). Any available initiator port on a Fibre Channel HBA card can be used.

Use the following procedure to configure direct backups from a NetBackup 52xx or 5330 appliance to a NetBackup 50xx using Fibre Channel.

To configure direct backups from a NetBackup 52xx or 5330 appliance to a NetBackup 50xx appliance using Fibre Channel

- 1 On the NetBackup 50xx, enable Fibre Channel communication as follows:

Note: If Fibre Channel communication is already enabled on this appliance, skip this step.

From the NetBackup Appliance Shell Menu:

- Use a Secure Shell (SSH) agent to connect to the 5020 deduplication appliance for which you want to enable Fibre Channel communication.
For example, you can use **PuTTY**, which is available as a free download.
- Log into the deduplication appliance.
By default, the user name is `sysadmin`, and the password is `P@ssw0rd`. In the preceding password, the sixth character is the numeral zero (0).
- At the system prompt, type **FC** and press **Enter**.
- To display the Fibre Channel connections that are currently in effect, type **show nodeip**.
For `nodeip`, type the IP address of the 5020 deduplication appliance for which you want to enable Fibre Channel communication.
- To enable Fibre Channel communication for this appliance, type **enable-ft**.

How to configure two NetBackup 52xx or 5330 appliances in different domains for MSDP replication

From the NetBackup
Appliance Web Console:

- Open a browser, and type the following URL to access the storage pool authority's opening panel:
https://URL
For **URL**, type the URL for the storage pool authority node.
- Log in as **root**.
- Click **Settings > Configuration**.
- In the left pane, under **Configuration**, click **Fibre Transport**.
- In the right pane, under the **Fibre Transport** heading, click in the box and click **Save**.

- 2 Set up the zones for the 50xx Fibre Channel ports to configure the 50xx as the target storage server.
- 3 Connect an available target port from any Fibre Channel card on the 50xx, to an available initiator port on any Fibre Channel card on the NetBackup 52xx or 5330.

See [“Supported Fibre Channel port configurations for the NetBackup 5330 appliances”](#) on page 44.

See [“Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances”](#) on page 33.

See [“Supported Fibre Channel port configuration for the NetBackup 5240 appliances”](#) on page 40.

How to configure two NetBackup 52xx or 5330 appliances in different domains for MSDP replication

This topic describes how to establish the replication relationship between a NetBackup 52xx or 5330 appliance in an originating domain and a NetBackup 52xx or 5330 appliance in a target domain. The process is very similar to traditional (non-appliance) NetBackup environments that use Media Server Deduplication Pool (MSDP) replication in different domains.

Successful configuration requires that you perform other tasks that are documented in the *NetBackup Deduplication Guide*.

The following table describes the steps to configure two NetBackup 52xx or 5330 appliances in different domains for MSDP replication. References to other tasks are also included.

Table 4-5

Steps to configure two NetBackup 52xx appliances in different domains for MSDP replication

Step	Task description
1	On one of the NetBackup 52xx or 5330 appliances, log in to the NetBackup Appliance Shell Menu.
2	Obtain the NetBackup deduplication password of the domain by running the following command: Main > Appliance > ShowDedupePassword Record this password for later use in Step 4.
3	On the local NetBackup master server, log in and start the NetBackup Administration Console.
4	Add the NetBackup 52xx or 5330 as a replication target by using the root user and the password that you recorded in Step 2. For complete details, see the <i>NetBackup Deduplication Guide</i> . Refer to the following topic in the chapter titled Configuring deduplication : "Configuring a target for MSDP replication".
5	On the primary side, do the following: <ul style="list-style-type: none"> Using the MSDP storage unit on the primary NetBackup 52xx or 5330 that is used for backups, create a storage lifecycle policy (SLP). Create a Replication storage operation for this SLP, using the remote NetBackup 52xx or 5330 appliance as the destination. For complete details, see the <i>NetBackup Deduplication Guide</i> . Refer to the following topic in the chapter titled Configuring deduplication : "Creating a storage lifecycle policy".
6	On the remote side, do the following: <ul style="list-style-type: none"> Create an SLP with the exact same name as the one that was created for the primary side. Create an Import storage operation for this SLP, using the MSDP on the remote NetBackup 52xx or 5330 appliance as the destination.

To use Fibre Transport for replication, you must log on the appliances on the primary and remote side using the NetBackup Appliance Web Console or NetBackup Appliance Shell Menu, and do the following:

- On the primary side, configure the appliance as a source host for replication over Fibre Transport (FT).
See [“Configuring Fibre Transport to other NetBackup appliances”](#) on page 64.

How to configure two NetBackup 52xx or 5330 appliances in different domains for MSDP replication

- On the remote side, configure the appliance as a target host for replication over FT.

See [“Configuring Fibre Transport on a target appliance for optimized duplication and replication”](#) on page 67.

About backup to tape support

This chapter includes the following topics:

- [About backup to tape support for NetBackup appliances](#)

About backup to tape support for NetBackup appliances

NetBackup appliances support backups to tape so that you can connect one or more tape libraries to them with Fibre Channel. The appliances use a Fibre Channel host bus adapter card (FC HBA) for connection to a TLD tape storage device.

On NetBackup 5330 appliances, slots 2 or 3 can be used for connection to a tape library (tape out).

If you use a tape library as storage, create a separate zone for that traffic. The tape storage zone should include the following FC HBA ports:

- A port or ports on the FC HBA card in slot 3 of a 52xx appliance.
- A port or ports on the FC HBA card in slots 2 or 3 of a 5330 appliance.
- A port or ports on the tape library.

If you duplicate backup images from a tape library to a NetBackup 5020 or 5030 deduplication appliance, traffic occurs as follows:

- Fibre Channel between the tape library and the 52xx or 5330 appliance.
- Fibre Transport between the 52xx or 5330 appliance and the 5020 or 5030 deduplication appliance.

The NetBackup Appliance software release 3.0 includes the NetBackup software release 8.0. For hardware compatibility list (HCL) for tape drives and tape libraries on the appliance, check the NetBackup hardware compatibility at the following link:

[NetBackup Appliance Compatibility Notes](#)

See “[Supported Fibre Channel port configurations for the NetBackup 5220 and 5230 appliances](#)” on page 33.

See “[Supported Fibre Channel port configurations for the NetBackup 5330 appliances](#)” on page 44.

VMware support

This chapter includes the following topics:

- [About NetBackup Appliance as a VMware backup host](#)
- [About appliance dynamic multi-pathing for VMware backups with SAN transport](#)

About NetBackup Appliance as a VMware backup host

NetBackup Appliance uses the VMware policy type to back up VMware virtual machines.

The following topics contain notes on the appliance as the backup host:


- For an overview of the appliance as backup host in a virtual environment:
See [“NetBackup Appliance as backup host: component overview”](#) on page 76.
- For a list of requirements and limitations:
See [“Notes on NetBackup Appliance as a VMware backup host”](#) on page 77.
- For further information, see the latest *NetBackup for VMware Administrator's Guide*:
<http://www.veritas.com/docs/DOC5332>

NetBackup Appliance as backup host: component overview

As [Figure 6-1](#) shows, the appliance can operate as the VMware backup host. A separate Windows backup host is not required.

The appliance as backup host can also run the NetBackup media server and master server.

Figure 6-1 NetBackup for VMware with appliance as backup host



NetBackup appliances support dynamic multi-pathing (DMP) in a SAN environment:

See [“About appliance dynamic multi-pathing for VMware backups with SAN transport”](#) on page 78.

Further information is available on the appliance as backup host:

See [“Notes on NetBackup Appliance as a VMware backup host”](#) on page 77.

Notes on NetBackup Appliance as a VMware backup host

Note the following requirements and limitations for the appliance as the backup host:


- The appliance must be version 2.5 or later. If the master server is on a separate host (not on the backup host), the master server must use NetBackup 7.5.0.1 or later.
- On the host that runs the NetBackup Administration Console or the Backup, Archive, and Restore interface, NetBackup must be at 7.5.0.1 or later.
- You must use the VMware policy type.
- The appliance supports iSCSI connections. Refer to the *NetBackup Appliance iSCSI Guide* for more information.

About appliance dynamic multi-pathing for VMware backups with SAN transport

NetBackup appliances support dynamic multi-pathing (DMP) in a SAN environment for VMware backups. DMP enhances I/O performance by distributing requests across all available paths. DMP on the Appliance can distinguish between the active paths and passive paths and make use of the active paths.

In a failover scenario, inputs and outputs are rerouted to healthy data paths. The failed paths are restored automatically when they become healthy. DMP also reduces the complexity of managing thousands of I/O paths in case they need to be temporarily disabled for array maintenance.

Figure 6-2 NetBackup appliance components for DMP on SAN



For more information on whether your system supports this function, see the *Hardware Compatibility List* at the following link:

<http://www.veritas.com/docs/000019707>

See “Notes on NetBackup Appliance as a VMware backup host” on page 77.

See the NetBackup VMware Guide for more information about VMware.

Index

A

- about
 - backup to tape support for appliances 74
 - Fibre Channel port configuration options 6, 40
- appliance
 - PCIe card configurations 18
- appliance compute node
 - PCIe options 22
- appliance configurations
 - available 20
- appliance FT target ports
 - guidelines for multiple SAN Client FC initiator ports 62
- appliance support
 - for backup to tape 74

B

- backup to tape
 - appliance support for 74

C

- configure direct backups using FC
 - from a NetBackup 52xx to a NetBackup 50xx 69
- configure MSDP replication
 - for two 52xx or 5330 appliances in different domains 71

D

- direct backups from a NetBackup 52xx to a NetBackup 50xx
 - configuring 69
- dynamic multipathing
 - VMware backups with SAN transport 78

F

- Fibre Channel
 - port configuration options 6, 40
- Fibre Transport
 - option descriptions 55

FTMS

- configurations 20

G

- guidelines for changing appliance FT target ports
 - for multiple SAN Client FC initiator ports 62

H

- hardware configurations
 - available 20
- HBA port 53
- HBA WWPN
 - how to determine for appliance 48

L

- Link status 53

N

- NetBackup 5330
 - supported PCIe card and Fibre Channel options 44

O

- option descriptions
 - for Fibre Transport 55

P

- PCIe add-in cards
 - appliance configurations 18
- PCIe options 22
- PCIe slot configurations 20, 22
- port configuration options
 - for Fibre Channel 6, 40

S

- supported data transfer methods
 - for NetBackup appliances 13
- supported PCIe card and Fibre Channel options
 - for NetBackup 5330 44

T

two 52xx appliances in different domains
 configure for MSDP replication 71

V

VMware backups with SAN transport
 dynamic multipathing 78