


MaxAir – Cooling Zones

MaxAir provides the capability to control temperature using a negative profile, that is to control a cooling device to reduce a zone temperature until it reaches a set point value.

This is achieved through the use of a 'Cooling' type zone.

 Add Zone

09:40

☒ Enable Zone Enable this Zone if you want this Zone to be controlled


Index Number In the List of Zones where you want to place this Zone on the home screen


Zone Name Zone display name

Zone Type Zone type i.e. Heating, Hot Water or Electrical Immersion

Temperature Sensor Node ID for the Sensor

Zone Controller ID Select Zone Controller Type and Number



Outside: 21° C  Clear - clear sky

'Cooling' type zones are allocated a sensor to determine the environment's temperature and a relay or relays to control the chilling device/s.

The zone is controlled through the use of a schedule as with other zone types.