

DepthVista

DepthVista Python User Manual



Version 1.1

e-con Systems

11/4/2022

Disclaimer

e-con Systems reserves the right to edit/modify this document without any prior intimation of whatsoever.

Contents

INTRODUCTION TO DEPTHVISTA	4
DESCRIPTION	4
INSTALLING DEPTHVISTASDK IN UBUNTU	6
INSTALLING DEPTHVISTASDK IN WINDOWS	7
USING DEPTHVISTA PYTHON	8
REQUIREMENTS	8
LAUNCHING LINUX DEPTHVISTA PYTHON SCRIPT	8
LAUNCHING WINDOWS DEPTHVISTA PYTHON SCRIPT	8
SELECTING THE CAMERA DEVICE	8
SELECTING CAMERA PROPERTIES	9
SELECTING STREAMING MODE	9
SELECTING DEPTH RANGE	10
SETTING PLANARIZATION	11
CAPTURING FRAMES	12
READING UNIQUE ID	12
READING FIRMWARE VERSION	ERROR! BOOKMARK NOT DEFINED.
EXITING APPLICATION	14
TROUBLESHOOTING	15
FAQ	16
GLOSSARY	19
SUPPORT	20

Introduction to DepthVista

DepthVista is a 3D camera based on Time of Flight (TOF) technology, USB Video Class (UVC) compliant, USB 3.2 Gen 1 SuperSpeed USB camera from e-con Systems, a leading Embedded Product Design Services Company which specializes in advanced camera solutions.

DepthVista is a RGB-D camera containing both RGB and TOF depth cameras. RGB camera has 1/2.6" AR0234CS CMOS digital image sensor with global shutter from onsemi™. It has dedicated high performance color image signal processor. TOF depth camera has 1/4" CCD sensor and dedicated depth processor. DepthVista is a two-board solution containing camera board with the USB 3.2 Gen 1 interface and laser board along with enclosure.

This document describes the special features of sample camera application when it is used with DepthVista.

Description

DepthVista has USB interface controller with USB Type-C connector to interface with the host PC. It is a ready-to-manufacture camera board with all the necessary firmware built-in and is compatible with the UVC version 1.0 standard. You can integrate this camera into the products, and this helps to cut short the time-to-market.

DepthVista is a UVC compatible and will work with the standard drivers available with Windows and Linux OS. There is no need for any additional driver installation. So, video streaming through UVC is possible without any special drivers on OSes that have built-in support for UVC standards.

Table 1: DepthVista supported Format, Resolutions, and Frame Rates

S.No	Format	Camera Mode	Resolution	Frame Rate (fps) USB 3.2 Gen 1
1	UYVY	RGB Mode	2.3MP (1920 x 1200)	30
			FHD (1920 x 1080)	30
			HD (1280 x 720)	60
			VGA (640 x 480)	60
2	Y16 (RAW 12-bit)	TOF Mode	Depth (640 x 480)	30
			IR (640 x 480)	30
			Depth + IR (640 x 960)	30
3		RGB-D Mode	1280 x 600 (RGB-D)	30
			1443 X 960 (RGB-D)	30

TOF camera in DepthVista can be used in two depth modes as follows:

- Far Mode: Effective depth range is between 1000 mm to 6500 mm.

- Near Mode: Effective depth range is between 200 mm to 1200 mm.

The TOF camera controls of DepthVista are as follows:

- TOF Data Mode
- TOF Depth Range
- TOF Mask
- TOF Gain

The RGB camera controls of DepthVista are as follows:

- Brightness
- Contrast
- Saturation
- Gamma
- Gain
- Sharpness
- White Balance
- Exposure
- Power line frequency

Installing DepthVistaSDK in Ubuntu

This section describes the installation of DepthVistaSDK which is essential for building DepthVista Application.

The steps to install the DepthVistaSDK are as follows:

1. Run the following command to extract the **package** file.

```
unzip <packageName.zip>
```

<Extracted

Directory>\linux\Bin\Ubuntu18.04\x64\SDK\DepthVistaSDKInstaller will have a install.sh file.

Note: For Ubuntu 20.04 the install.sh file will be present in **<Extracted Directory>**\linux\Bin\Ubuntu20.04\x64\SDK\DepthVistaSDKInstaller.


2. Open the folder containing install.sh in terminal.
3. Run the following command to give executable permission for install.sh file.

```
chmod +x install.sh
```

4. Run the following command to install the **DepthVistaSDK**.

```
sudo ./install.sh
```

Once installation is success, **Installation DepthVistaSDK success** message appears.



```
Installing DepthVistaSDK with prefix ...  
Share done\  
Include done\  
Lib done\  
Installing DepthVistaSDK success.
```

Fig 1: Installation success screenshot.

Installing DepthVistaSDK in Windows

The steps to install DepthVistaSDK in windows are as follows:

1. Extract the given package.

<Extracted Directory>/Windows/Bin/SDK/Dll/x64 will contain the DepthVistaSDK.dll file.

Note: Use x64 dll for x64 Python and x86 dll for X86 Python.

2. Copy the DepthVistaSDK.dll and place it in the Python Installation folder (root folder).

Using DepthVista Python

This section describes how to use the DepthVista Python Script.

Requirements

Install the below requirements to run the DepthVista Python Script.

- Python version 3.6 or 3.8
- OpenCV for python version 4.2 or 4.6
- Numpy package
- DepthVista SDK

Launching Linux DepthVista Python Script

The steps to launch linux DepthVista Python are as follows:

1. Open a terminal from the location where the main.py file is located
2. Run the following command to run the application.

```
sudo python3 main.py
```

Launching Windows DepthVista Python Script

The steps to launch windows DepthVista Python are as follows:

1. Open a command prompt from the location where the main.py file is located.
2. Run the following command to run the application.

```
python main.py
```

Selecting the Camera Device

Initially the command line displays the number of devices connected to the PC. You must select the camera device to explore their features through the command line application.

```
***** E-con's Depth Vista OpenCV Python Application *****
                                OpenCV Python App Version = 1.0.3
                                Running in Linux Platform

NUMBER OF DEPTH_VISTA (TOF) DEVICE CONNECTED: 1

    0.Exit
    1.See3CAM_TOF_25CUG
PICK A CAMERA DEVICE TO EXPLORE: 
```

Figure 1: Application Launch Screen

Selecting Camera Properties

Once the device is selected, camera properties that can be explored will be listed as shown below.

```
*****CAMERA PROPERTIES MENU*****
0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version
Pick a Relevant Type Of Camera Properties:
```

Figure 2: Selecting Camera Property

Selecting Streaming Mode

Enter **2** in **Pick a Relevant Choice of Camera Properties** to select the **Streaming Mode**.

After selecting the Streaming mode option, all the streaming modes supported by the device will be listed as shown below.

```
*****CAMERA PROPERTIES MENU*****
0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version
Pick a Relevant Type Of Camera Properties:2
Total Number of Streaming Modes Supported By the Camera: 9
*****STREAMING MODE MENU*****
0.Exit
1.Back
2.Main Menu
3.Depth IR Mode
4.Depth Mode
5.IR Mode
6.Depth IR RGB(VGA) Mode
7.Depth IR RGB(HD) Mode
8.RGB(VGA) Mode
9.RGB(HD) Mode
10.RGB(Full HD) Mode
11.RGB(1200p) Mode
SELECT YOUR STREAMING MODE:
```

Figure 3: Supported Streaming Modes

You can set the streaming mode using the following options:

- Option **0** to exit from the application.
- Option **1** to go back to the previous menu.
- Option **2** to return to main menu.
- Option **3** to set Depth IR streaming Mode.
- Option **4** to set Depth streaming Mode.
- Option **5** to set IR streaming Mode.

- Option **6** to set Depth IR RGB(VGA) streaming Mode.
- Option **7** to set Depth IR RGB(HD) streaming Mode.
- Option **8** to set RGB (VGA) streaming Mode.
- Option **9** to set RGB (HD) streaming Mode.
- Option **10** to set RGB (Full HD) streaming Mode.
- Option **11** to set RGB (1200p) streaming Mode.

After selecting the preferred streaming mode, you can view the preview based on the streaming mode as shown below.




Figure 4: Preview after selecting Streaming Mode

Selecting Depth Range

Enter **3** in **Pick a Relevant Choice of Camera Properties** to select the **Depth Range**.

After selecting the Depth range option, all the depth ranges supported by the device will be listed as shown below.

```

*****CAMERA PROPERTIES MENU*****

0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version

Pick a Relevant Type Of Camera Properties:3
*****DEPTH_RANGE MENU*****

0.Exit
1.Back
2.Main Menu
3.Near Mode
4.Far Mode

Pick a Relevant Depth Mode:

```

Figure 5: Supported Depth Ranges

You can set the depth range using the following options:

- Option **0** to exit from the application.
- Option **1** to go back to the previous menu.
- Option **2** to return to main menu.
- Option **3** to set Near Mode.
- Option **4** to set Far Mode.

After selecting the preferred depth range, streaming will be updated based on the depth range selected.

Setting Planarization

Enter **4** in **Pick a Relevant Choice of Camera Properties** to select **Planarization**.

After selecting the Planarization option, you can view the options listed as shown below.

```

*****CAMERA PROPERTIES MENU*****

0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version

Pick a Relevant Type Of Camera Properties:4
*****PLANARIZATION MODE MENU*****

0.Exit
1.Back
2.Main Menu
3.Planarization OFF
4.Planarization ON

SELECT PLANARIZATION MODE:

```

Figure 6: Planarization Mode

You can set the planarization using the following options:

- Option **0** to exit from the application
- Option **1** to go back to the previous menu
- Option **2** to return to main menu
- Option **3** to disable Planarization
- Option **4** to Enable Planarization

After selecting the preferred planarization, streaming will be updated.

Capturing Frames

Enter **5** in **Pick a Relevant Choice of Camera Properties** to capture images.

Images will be saved based on the streaming mode and the location of the images will be shown as follows.

```
*****CAMERA PROPERTIES MENU*****
0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version

Pick a Relevant Type Of Camera Properties:5

FRAME CAPTURED
```

Figure 7: Capturing Frames

The files will be saved with the name as shown below.

- RGB Frame – DepthVista_rgb_yyyy_mm_dd_hrs_min_sec.png
- IR Frame – DepthVista_IR_yyyy_mm_dd_hrs_min_sec.png
- Depth Raw Frame – DepthVista_Raw_yyyy_mm_dd_hrs_min_sec.raw
- Depth Color map - DepthVista_Depth_yyyy_mm_dd_hrs_min_sec.bmp

Reading Unique ID

Enter **6** in **Pick a Relevant Choice of Camera Properties** to read the Unique ID of that specific device.

Unique ID of the device will be displayed as shown below.

```
*****CAMERA PROPERTIES MENU*****

0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version

Pick a Relevant Type Of Camera Properties:6

UNIQUE ID OF THE CAMERA IS 871594987754555648
*****CAMERA PROPERTIES MENU*****

0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version

Pick a Relevant Type Of Camera Properties:
```

Figure 8: Reading Unique ID of Device

Reading Firmware Version

Enter **7** in **Pick a Relevant Choice of Camera Properties** to read the firmware version of that specific device.

Firmware version of the device will be displayed as shown below.

```
*****CAMERA PROPERTIES MENU*****

0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version

Pick a Relevant Type Of Camera Properties:7
FIRMWARE VERSION : 1.2.387.8
*****CAMERA PROPERTIES MENU*****

0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version

Pick a Relevant Type Of Camera Properties:
```

Figure 9: Reading Firmware Version of Device

Exiting Application

Enter **0** in **Pick a Relevant Choice of Camera Properties** to exit the application.

```
*****CAMERA PROPERTIES MENU*****
0.Exit
1.Back
2.Streaming Mode
3.Depth Range
4.Planarization
5.Capture Frames
6.Unique Id
7.Read Firmware Version
Pick a Relevant Type Of Camera Properties:0
Exit
```

Figure 10: Exiting Application

Troubleshooting

Error: error while loading shared libraries: libdc1394.so.25: cannot open shared object file: No such file or directory

Run the following command in terminal.

```
sudo apt-get install libdc1394-25
```

FAQ

1 Does external power supply require for this camera?

Yes, we need external power supply to get depth frames and it will be provided with the kit.

2 What is the supported external power supply current ratings?

The supported external power supply current ratings are listed below.

Input: AC 100-240v, 50/60HZ

Output: DC 12V, 4A

3 What is the current operating temperature range supported by DepthVista?

The current operating temperature range supported is 0°C to 50°C.

4 What is the light source used in this camera?

This camera uses two VCSEL laser diodes that work in the Near InfraRed (NIR) spectrum (850nm) and is safe for human eyes.

5 Can the depth range be improved further?

Yes. Depth range can be improved by changing the no of VCSEL LEDs and their intensity. This is going to involve a customization effort.

6 Is DepthVista suitable for outdoor environment?

As the laser diodes used in this camera operate in the 850nm NIR range, the likelihood of interference from sunlight is very high if you use it in outdoor applications. Hence, this camera is more suitable for indoor environments.

7 What is the maximum accuracy that can be achieved?

DepthVista offers an accuracy of <1%.

8 Is the DepthVista camera pre-calibrated?

Yes, this camera is factory calibrated. Do not disturb the casing or the lens, which would alter the calibration done.

9 What is the minimum distance that the lens could focus?

The minimum working distance (distance between the camera and the object) for this camera is 20 cm.

10 Are these ToF and RGB sensors synchronized?

Yes. Both these sensors work synchronously to make the best use of the depth and RGB data streams.

11 What is IMU?

Inertial Measurement Units (IMUs) is a self-contained system that measures linear and angular motion usually with a triad of gyroscopes and triad of accelerometers and sometimes the magnetic field surrounding the body, also magnetometers.

IMU chip used is a 6 DOF (degree of freedom) featured with triaxial accelerometer and triaxial gyroscope, supports different modes of configuration.

12 Why this camera is not supported in USB 2.0?

Due to bandwidth limitations of RGB-D streaming in USB 2.0, this camera supports only USB 3.2 Gen1 speed.

13 What is the depth resolution and frame rate supported by DepthVista?

DepthVista supports a resolution of 640x480 at a frame rate of 30 fps for depth measurement.

14 What are the output formats supported by DepthVista camera?

The output formats supported by DepthVista camera are listed in the below table.

Mode	Format
TOF	Y16(RAW 12-bit)
RGB	UYVY
RGB-D	Y16

15 What is the shutter type on the sensor?

Both the TOF and RGB camera sensors are global shutter sensor.

16 Does DepthVista comes with an enclosure?

Yes. The DepthVista camera comes with a metal enclosure.

17 What is the lens used in the DepthVista camera? – TOF and RGB

The lens used in the camera is S-mount (M12). The focal length and FOV are listed in the below table.

Description	RGB Camera Lens	Depth Camera Lens
Focal Length	3.252mm	2.16mm
Diagonal FOV	90.09	99.75

18 What is the lens mount used?

The lens mount used in the DepthVista Camera reference design is S-mount M12 lens holder (M12 P0.5 lenses are supported by default).

19 What is calibration? Why should I do that?

In DepthVista camera, the depth calibration are performed. Depth calibration process is carried out to get the accurate depth from the depth camera. Once the depth calibration is completed, calibration result parameters are programmed to the memory allotted for calibration in the SPI-flash.

20 What are the warranty terms of DepthVista camera?

For warranty, please refer the [warranty](#) page.

Glossary

ROI: Region of Interest.

USB: Universal Serial Bus

UVC Compliant: USB Video Class Compliant.

Support

Contact Us

If you need any support on DepthVista product, please contact us using the Live Chat option available on our website - <https://www.e-consystems.com/>

Creating a Ticket

If you need to create a ticket for any type of issue, please visit the ticketing page on our website - <https://www.e-consystems.com/create-ticket.asp>

RMA

To know about our Return Material Authorization (RMA) policy, please visit the RMA Policy page on our website - <https://www.e-consystems.com/RMA-Policy.asp>

General Product Warranty Terms

To know about our General Product Warranty Terms, please visit the General Warranty Terms page on our website - <https://www.e-consystems.com/warranty.asp>

Revision History

Rev	Date	Description	Author
1.0	17-October-2022	Initial Draft	Camera Products
1.1	04-November-2022	Changed steps for installation	Camera Products