

Tiva Based Daughter Board for Firebird V Hardware And Software Manual.

eRTS Lab IIT Bombay

June 27, 2017

1 Credits

Version 1.0
June 27, 2017

Documentation Author(Alphabetical Order):

1. Ayush Gaurav, Intern eYSIP 2017
2. Nagesh K, Intern eYSIP 2017

Credits(Alphabetical Order):

1. Prof Kavi Arya, CSE IIT Bombay
2. Nex Robotics Pvt. Ltd.
3. Piyush Manavar, Team e-Yantra
4. Saurav Shandilya, Team e-Yantra

2 Notice

The contents of this manual are subject to change without notice. All efforts have been made to ensure the accuracy of contents in this manual. However, should any errors be detected, e-yantra welcomes your corrections. You can send us your queries / suggestions at [Contact Us](#)

Table Of Content

1	Credits	2
2	Notice	3
3	Introduction	6
3.1	Safety precautions:	6
3.2	Inappropriate Operation:	6
4	Tiva Based Daughter Board	7
4.1	Technical Specification	
	7
5	Hardware Manual:	7
5.1	Voltage Regulation on the Daughter Board	
	7
5.1.1	Powering Micro-controller	8
5.1.2	Powering Servos	8
5.2	Level Converters	9
5.3	Sensors	9
5.3.1	3.3V sensors	9
5.3.2	5V sensors	10
5.4	Port Expander	10
5.5	External ADC	11
5.6	LCD Interfacing	12
5.7	USB Communication	13
5.8	Programing the Controller	14
5.9	Reset Switch	14
5.10	Servo Connectors	14
5.11	TM4C123GH6PM Micro-controller:	15
5.12	Pin Functionality	18

5.12.1	Pin of uC	18
5.12.2	Robot Main Board Connections	19
5.12.3	Pin Connection Of Plug And Play Board	21
6	Software Manual:	23
6.1	Code Composer Studio:	23
6.1.1	Download CC Studio:	23
6.1.2	Installing C C Studio:	23
6.1.3	Create a New Project	25
6.1.4	Add Path and Build Variables	25
6.2	driver.lib	30
6.3	Buzzer	30
6.4	Programming the Robot	31
6.5	Using Debugger of The Programmer	31
6.6	Simple I/O Operation	31
6.7	Robot Direction Control	33
6.8	Robot Position Control Using Interrupts	36
6.8.1	Calculation of position encoder resolution:	36
6.9	Timers and its Interrupts	41
6.10	Robot Speed Control	43
6.10.1	Pulse Width Modulation(PWM)	43
6.11	LCD Interfacing	47
6.12	Analog To Digital Converter	52
6.13	Serial Communication	56
6.14	I2C Communication	56

3 Introduction

Tiva Daughter board for Fire Bird V will help you gain exposure to the world of robotics and embedded systems with ARM Cortex M4. The board is designed with Open Source Philosophy in software and hardware design ,you will be able to create and contribute to complex applications that run on this platform, helping you acquire expertise as you spend more time with them.

3.1 Safety precautions:

- Robot's electronics is static sensitive. Use robot in static free environment.
- Read the assembling and operating instructions before working with the robot.
- If robot's battery low buzzer starts beeping, immediately charge the batteries.
- To prevent fire hazard, do not expose the equipment to rain or moisture.
- Refrain from dismantling the unit or any of its accessories once robot is assembled.
- Charge the NiMH battery only with the charger provided on the robot.
- Never allow NiMH battery to deep discharge.
- Mount all the components with correct polarity.
- Keep wheels away from long hair or fur.
- Keep the robot away from the wet areas. Contact with water will damage the robot.
- To avoid risk of fall, keep your robot in a stable position.
- Do not attach any connectors while robot is powered ON.
- Never leave the robot powered ON when it is not in use.
- Disconnect the battery charger after charging the robot.

3.2 Inappropriate Operation:

Inappropriate operation can damage your robot. Inappropriate operation includes, but is not limited to:

- Dropping the robot, running it off an edge, or otherwise operating it in irresponsible manner.
- Interfacing new hardware without considering compatibility.
- Overloading the robot above its payload capacity.
- Exposing the robot to wet environments.
- Continuing to run the robot after hair, yarn, string, or any other item is entangled in the robot's axles or wheels.
- All other forms of inappropriate operations.
- Using robot in areas prone to static electricity.
- Read carefully paragraphs marked with caution symbol.

4 Tiva Based Daughter Board

There are two daughter boards one with the launchpad and other one with the Arm Cortex M4 based uC. Almost all the specification are same unless mentioned otherwise.

4.1 Technical Specification

Microcontroller:

TM4C123gh6pm (ARM architecture based Microcontroller)

To know more about the microcontroller please refer to [datasheet](#).

Sensors:

Three white line sensors (extendable to 7)

Five Sharp GP2Y0A02YK IR range sensor (One in default configuration)

Eight analog IR proximity sensors

Two position encoders

Indicators:

2 x 16 Characters LCD

Buzzer

Communication:

USB Communication

Wireless ZigBee Communication (2.4GHZ) (if XBee wireless module is installed)

Bluetooth communication (Can be interfaced on external UART0 available on the board)

Simplex infrared communication (From infrared remote to robot)

I2C Communication

Battery Life:

2 Hours, while motors are operational at 75% of time

Locomotion:

Two DC geared motors in differential drive configuration and caster wheel at front as support

Top Speed: 24 cm / second

Wheel Diameter: 51mm

Position encoder: 30 pulses per revolution

Position encoder resolution: 5.44 mm

5 Hardware Manual:

5.1 Voltage Regulation on the Daughter Board

The voltage source available on the Firebird is 9.6V. But the TIVA platform works on 3.3V and the servos can operate upto 6V. So there must be 3 different voltage levels on the board. The uC based board has 2 voltage regulators and the plug and play board has 1 voltage regulator. In the uC based board the


5.1 Voltage Regulation on the Daughter Board

Manual for Tiva Based Daughter Board for Firebird V.

9.6 volts is 3.3V to power the microcontroller. In the plug and play board there is an inbuilt voltage regulator, so it is directly connected to 5V, 300mA source. The servo in both the boards has a separate 5V regulator.


5.1.1 Powering Micro-controller

The boards have different powering circuits. In the plug and play board is connected to 5V source on Pin 10. In the uC based board the 9.6V source available on Pin 29 is reduced to 3.3V. Refer to the schematic below for further details.




5.1.2 Powering Servos

The servo motors can operate safely up to 6V, beyond this voltage they get damaged. Also, the servos require high current. There is a separate power line for servos taken from Pin 29 and reduced to 5V using the voltage regulator. Refer the schematic for further details.



5.2 Level Converters

The TIVA platform operates at 3.3V and the Firebird operates at 5V. Directly connecting these pins to the TIVA may be fatal. So to interface these sensors, a level converter is used. A bidirectional MOS-FET based level converter is used. The level converter is necessary is for input pins. In the boards Level converter is used for interfacing the position encoders of the motors. Refer the schematic for further details.



NOTE: If the user wishes to interface extra sensors using the GPIOs provided on the board, then external level converters have to be used if the output of the sensor is above 3.3V.

5.3 Sensors

The firebird V has as many as 22 sensors, but maximum 12 sensors can be interfaced directly with the controller. The daughter board has interfaced 20 of those 22 sensors using external I2C based ADC. Sensors that were not included in the daughter board are current sensor and battery monitoring sensor. These sensors are working either on 3.3V or on 5V. Interfacing 3.3V sensors is simple and can be directly connected to the controller. On the other hand 5V can not be directly interfaced so a different approach is taken which will be mentioned in the 5V sensors sub heading.


5.3.1 3.3V sensors

The output white line sensors and IR Proximity sensors vary from 0 to 3.3V. Hence these sensors can be interfaced directly with the microcontroller. Refer the table below for pin connections.

IR Proximity Sensors	Pin Name(uC)	Pin Name(Plug and Play)
1	PE1	PB5
2	PE3	PD0
3	PE5	PD3
4	PE4	PD1
5	PB5	PE5
6	External ADC IN6	External ADC IN7
7	External ADC IN7	PE0
8	External ADC IN0	External ADC IN0
White Line Sensors	Pin Name(uC)	Pin Name(Plug and Play)
1	PD2	PE1
2	PD1	PE2
3	PD0	PE3
4	External ADC IN1	External ADC IN2
5	External ADC IN2	External ADC IN3
6	External ADC IN3	External ADC IN4
7	External ADC IN4	External ADC IN5

5.3.2 5V sensors

Sharp Sensors are the only sensors on board that works on 5V supply. The output of the sharp sensor ranges from 0-5V and according to the output we have a formula to calculate the distance. While uC has VREF as 3.3V so these sensors cannot be directly connected. The approach we followed is to feed the output of the sensor to a buffer and then using a voltage divider convert 0-5 range to 0-3V range. For better understanding refer to the schematic below. There is a also table which tells about the pin connection.




Sharp Sensors	Pin Name(uC)	Pin Name(Plug and Play)
1	PE0	PB4
2	PE2	External ADC IN1
3	PD3	PD2
4	External ADC IN5	External ADC IN6
5	PB4	PE4


5.4 Port Expander

TM4C123GH6PM has only 64 pins out which only 43 are GPIO pins. This limits our application to

read input and respond correspondingly. To increase the number of GPIO and there interrupts we have used I2C compatible a port expander MCP23017. It has 2 PORTS A and B, with each port having 8 Pins. The interrupts on each pin can also be monitored. To read more about it, download the datasheet from [here](#). The schematic of the connection is shown below. Keep in mind that I2C SCL and SDA have already been pulled up using 10K resistor.



Port Expander For Plug and Play





Port Expander For uC

5.5 External ADC

It has already been mentioned that adc channels on the microcontroller is limited to 12 while firebird has 22 sensors available. We have interfaced an external ADC which is also I2C compatible. It has 8 channel with 12 bit resolution. To read more about it, download the datasheet from [here](#). The schematic of the connection is shown below. Keep in mind that I2C SCL and SDA have already been pulled up using 10K

resistor.





5.6 LCD Interfacing

LCD can be interfaced in 8bit or 4 bit interfacing mode. In 8 bit mode it requires 3 control line and 8 data lines. To reduce number of I/Os required, Fire Bird V robot uses 4 bit interfacing mode which requires 2 control lines and 4 data lines. In this mode upper and lower nibble of the data/command byte needs to be sent separately. RW(Read/Write) control line of lcd is grounded so it can only work in write mode.

The EN line is used to tell the LCD that microcontroller has sent data to it or microcontroller is ready to receive data from LCD. This is indicated by a high-to-low transition on this line. To send data to the LCD, program should make sure that this line is low (0) and then set the other two control lines as required and put data on the data bus. When this is done, make EN high (1) and wait for the minimum amount of time as specified by the LCD datasheet, and end by bringing it to low (0) again.

When RS is low (0), data is treated as a command or special instruction by the LCD (such as clear screen, position cursor, etc.). When RS is high (1), data being sent is treated as text data which should be displayed on the screen.


written to the LCD.//



LCD	Pin Name(uC)	Pin Name(Plug and Play)
RS	PF0	PD6
EN	PF2	PD7
DB4	PD4	PA2
DB5	PD5	PA3
DB6	PD6	PA4
DB7	PD7	PA5

5.7 USB Communication


Fire Bird V's main board has USB port socket. Microcontroller accesses USB port via main board socket. All its pins are connected to the microcontroller adapter board via main board's socket connector. FT232 is a USB to TTL level serial converter. It is used for adding USB connectivity to the microcontroller adapter board. With onboard USB circuit Fire Bird V can communicate serially with the PC through USB port without the use of any external USB to Serial converter. Microcontroller socket uses USB port from the main board. Data transmission and reception is indicated using TX and RX LEDs which are located near the FT232 IC. This IC is only on the uC based board. Plug and play board has its own USB port on TIVA launchpad. The schematic of ft232 is shown below.



5.8 Programing the Controller


5.9 Reset Switch

The Plug and play board makes use of reset button present on the TIVA launchpad. The uC based has a switch connected to the reset the reset pin 38 of the microcontroller. The schematic is given below.




5.10 Servo Connectors

The microcontroller board has three Servo connectors. It can be used for driving servo motors of camera pod or any other attachment. Power for the servo connector is provided by the “5V servo supply” voltage regulator. Both the board have different pwm pins for servo which can be seen from the schematic.



Servo Connections for Plug and Play Board



Servo Connections for uC based Board

5.11 TM4C123GH6PM Micro-controller:

The Tiva™ C Series ARM Cortex-M4 microcontrollers provide top performance and advanced integration. The product family is positioned for cost-conscious applications requiring significant control processing and connectivity capabilities such as:


- Low power, hand-held smart devices
- Gaming equipment
- Home and commercial site monitoring and control
- Motion control
- Medical instrumentation
- Test and measurement equipment
- Factory automation
- Fire and security

- Smart Energy/Smart Grid solutions
- Intelligent lighting control
- Transportation

Schematic Of the connections is shown below.

TM4C123GH6PM Micro-controller:

Module 6: Firebird Basic Daughter Board for Firebird V.



5.12 Pin Functionality

5.12.1 Pin of uC

Pin No.	Pin	Complete Pin Connections
1	PB6	Servo Motor 1
2	VDDA	VDD filtered through capacitors
3	GNDA	Ground
4	PB7	Servo Motor 2
5	PF4	Pin 53 Right Motor 1
6	PE3	16 IR proximity Sensor 2
7	PE2	Output of Second OpAmp of lm324
8	PE1	12 IR Proximity Sensor 1
9	PE0	output of First OpAmp of lm324
10	PD7	28 DB7 of LCD Data
11	VDD	VDD filtered through capacitors
12	GND	Ground
13	PC7	13 Zigbee Rx
14	PC6	14 Zigbee Tx
15	PC5	FT232
16	PC4	FT232
17	PA0	External UART
18	PA1	External UART
19	PA2	Buzzer
20	PA3	63 Right Position Encoder Interrupt
21	PA4	64 Left Position Encoder Interrupt
22	PA5	55 Right Motor 2
23	PA6	54 Right Motor Pwm
24	PA7	Servo Motor 3
25	VDDC	Connected to VDDC on 56
26	VDD	VDD filtered through capacitors
27	GND	Ground
28	PF0	22 RS of LCD
29	PF1	INT A and B of to GPIO expander shorted and connected
30	PF2	24 EN of LCD
31	PF3	50 Left Motor PWM
32	WAKE	Ground
33	HIB	NC
34	XOSC0	32.7 KHz crystals(One End)
35	GNDX	Cap to crystal
36	XOSC1	32.7 KHz crystals(Other End)
37	VBAT	3.3 Volts
38	RST	Reset Switch
39	GND	Ground
40	OSC1	16 MHz crystal(One end)
41	OSC1	16 MHz crystal(Other end)
42	VDD	VDD filtered through capacitors
43	PD4	26 DB4 Of LCD
44	PD5	25 DB5 of LCD
45	PB0	51 Left Motor 1

46	PB1	52 Left Motor 2
47	PB2	I2C ADC SCL
48	PB3	I2C ADC SDA
49	PC3	JTAG TDO
50	PC2	JTAG TDI
51	PC1	JTAG TMS
52	PC0	JTAG TCK
53	PD6	27 DB6 Of LCD
54	VDD	VDD filtered through capacitors
55	GND	Ground
56	VDDC	Connected to VDDC on 25
57	PB5	46 IR Proximity Sensor 5
58	PB4	Output of First OpAmp of lm358
59	PE4	43 IR Proximity Sensor 4
60	PE5	42 IR Proximity Sensor 3
61	PD0	32 White Line Sensor 3
62	PD1	31 White Line Sensor 2
63	PD2	30 White Line Sensor 1
64	PD3	Output of Third OpAmp of lm324

5.12.2 Robot Main Board Connections

Pin Out	Pin Name	Functionality	PIN on DB	Pin on Pluggable B
1	Current sensor	Current sense analog value	Not Using	
2	IR Proximity sensor 8	IR Proximity sensor 8 analog value	External Adc INT0	
3	GND	Ground	Ground	
4	DATA+	USB connection going to the AT-MEGA2560 USB connection with uC	C4	
5	DATA-	microcontroller via FT232 USB to serial USB connection with uC	PC5	
6	VCC	USB converter. Connect TO VCC of FT232		
7	5V System	"5V System Voltage. Can be used for powering up any digital device with current limit of 400mA."		
8	5V System	"5V System Voltage. Can be used for powering up any digital device with current limit of 300mA."		
9	5V System	"5V System Voltage. Can be used for powering up any digital device with current limit of 300mA."		
10	5V System	"5V System Voltage. Can be used for powering up any digital device with current limit of 400mA."		
11	SHARP IR Range Sensor 1	Analog output of Sharp IR range Sensor 1	PE0(lm324 1)	
12	IR Proximity Sensor 1	Analog output of IR Proximity sensor 1	PE1	

13	XBee RXD	XBee wireless module Serial data in	PC7	
14	XBee TXD	XBee wireless module Serial data out	PC6	
15	SHARP IR Range Sensor 2	Analog output of Sharp IR range sensor 2	PE2(lm324 2)	
16	IR Proximity Sensor 2	Analog output of IR Proximity sensor 2	PE3	
17	RSSI	To capture the RSSI signal		
18	MOSI	MOSI of the Controller/NC create extra expansion headers		
19	MISO	MISO of controller/NC create extra expansion headers		
20	SCK	SCK of the controller/NC create extra expansion headers		
21	SSI	SS of the controller/ NC create extra expansion headers		
22	RS	connected to RS of LCD normal I/O	PF0	
23	RW	connected to RW of LCD normal I/O	GND	
24	EN	connected to EN of LCD normal I/O	PF2	
25	DB5	data pin of lcd normal I/O	PD5	
26	DB4	data pin of lcd normal I/O	PD4	
27	DB6	data pin of lcd normal I/O	PD6	
28	DB7	data pin of lcd normal I/O	PD7	
29	V Battery System	ADC to check the level of battery voltage		
30	WL1	Analog output of white line sensor 1	PD2	
31	WL2	Analog output of white line sensor 2	PD1	
32	WL3	Analog output of white line sensor 3	PD0	
33	"Sharp IR Sensors 1and 5 Disable"			
34	IR Proximity Sensor Disable			
35	5V System	"5V system Voltage. Can be used for powering	up any digital device. Current Limit: 400mA."	
36	WL4	Analog output of white line sensor 4	External Adc INT1	
37	WL5	Analog output of white line sensor 5	External Adc INT2	
38	WL6	Analog output of white line sensor 6	External Adc INT3	
39	WL7	Analog output of white line sensor 7	External Adc INT4	
40	White Line Sensors Disable			
41	Sharp IR Range Finder 3	Analog output of Sharp IR range sensor 3	PD3 (lm 324 3)	
42	IR Proximity Sensor 3	Analog output of IR Proximity sensor 3	PE5	
43	IR Proximity Sensor 4	Analog output of IR Proximity sensor 4	PE4	

44	Sharp IR Range Finder 4	Analog output of Sharp IR range sensor 4	in 5 ex (lm 324 5)	
45	Sharp IR Range Finder 5	Analog output of Sharp IR range sensor 5	PB4 (lm358 1)	
46	IR Proximity Sensor 5	Analog output of IR Proximity sensor 5	PB5	
47	C11	motor not present		
48	C1	PWM not present		
49	c12	not present		
50	PWM L	left motor PWM(timer pin in PWM mode)	PF3	
51	L1	left motor pin1 normal I/O	PB0	
52	L2	left motor pin2 normal I/O	PB1	
53	R1	right motor pin1 normal I/O	PF4	
54	PWM R2	right motor PWM(timer pin in PWM mode)	PA6	
55	R2	right motor pin2	PA5	
56	NC			
57	NC			
58	NC			
59	NC			
60	NC			
61	NC			
62	Position encoder left	Output of Left position encoder (0-5V) PA4		
63	Position encoder right	Output of Right position encoder (0-5V) PA3		
64	position enocder C2	Output of C2 position encoder (0-5V)		
65	Position encoder C1	Output of C1 position encoder (0-5V)		
66	C22	NC		
67	C21	NC		
68	C2	Pwm	NC	
69	IR Prox6	Analog output of IR Proximity sensor 6 External Adc	INT6	
70	IR Prox7	Analog output of IR Proximity sensor 7 External Adc	INT7	
71	Buzzer	Input, $V_{i0.65V}$ turns on the Buzzer	PA2	
72	DAC Out	NC		
73	RS232 TX	NC		
74	RS232 RX	NC		

5.12.3 Pin Connection Of Plug And Play Board

Pin Name	Pin Connection on Main Board	Function
PA0		Used for Programming
PA1		Used for Programming
PA2	26	DB4 of LCD
PA3	27	DB5 of LCD
PA4	28	DB6 of LCD
PA5	29	DB7 of LCD
PA6		I2C

PA7		I2C
PB0	14	Zigbee Tx
PB1	13	Zigbee RX
PB2	62	Position encoder of left motor
PB3	52	L2
PB4	11	Sharp IR1
PB5	12	IR 1
PB6		Servo
PC0		
PC1		
PC2		
PC3		
PC4	53	R1
PC5	54	PWM of right motor
PC6	55	R2
PC7		Interrupt of port expander
PD0	16	IR 2
PD1	43	IR Prox 4
PD2	41	Sharp IR 3
PD3	42	IR Prox 3
PD4		
PD5		
PD6	22	RS of LCD
PD7	24	EN of LCD
PE0	70	IR 7
PE1	30	WL1
PE2	31	WL2
PE3	32	WL3
PE4	45	Sharp IR 5
PE5	46	IR 5
PE6		
PE7		
PF0	63	Position encoder of right motor
PF1		Servo
PF2	50	PWM of left motor
PF3	51	L1
PF4	71	Buzzer

6 Software Manual:

6.1 Code Composer Studio:

Code Composer Studio is an integrated development environment (IDE) that supports TI's Microcontroller and Embedded Processors portfolio. Code Composer Studio comprises a suite of tools used to develop and debug embedded applications. It includes an optimizing C/C++ compiler, source code editor, project build environment, debugger, profiler, and many other features. The intuitive IDE provides a single user interface taking you through each step of the application development flow. Familiar tools and interfaces allow users to get started faster than ever before. Code Composer Studio combines the advantages of the Eclipse software framework with advanced embedded debug capabilities from TI resulting in a compelling feature-rich development environment for embedded developers. This description is directly taken from the website of Texas Instruments and click to know more [about CC Studio](#)


6.1.1 Download CC Studio:

At the time of writing this document Version 7 was the latest one. You can check for the latest at [Download CCS](#).(do not download any beta versions).There will be two installer files.The web installer will require Internet access until it completes. If the web installer version is unavailable or you can't get it to work, download, unzip and run the offline version. The offline download will be much larger than the installed size of CCS since it includes all the possible supported hardware.


6.1.2 Installing C C Studio:

After the installer has started follow the steps mentioned below:


1. Accept the Software License Agreement and click Next.




2. Select the destination folder and click next.



3. Select the processors that your CCS installation will support. You must select "TM4C12X Arm Cortex M4". You can select other architectures, but the installation time and size will increase.



4. Select debug probes and click finish



5. The installer process should take 15 - 30 minutes, depending on the speed of your connection. The offline installation should take 10 to 15 minutes. When the installation is complete, uncheck the "Launch Code Composer Studio v7" checkbox and then click Finish. There are several additional tools that require installation during the CCS install process. Click "Yes" or "OK" to proceed when these appear.
6. Install TivaWare for C Series (Complete). Download and install the latest full version of TivaWare from: [TivaWare](#). The filename is SW-TM4C-x.x.exe . This workshop was built using version 1.1. Your version may be a later one. If at all possible, please install TivaWare into the default location.

You can find additional information at these websites:

Main page: www.ti.com/launchpad

Tiva C Series TM4C123G LaunchPad:

<http://www.ti.com/tool/ek-tm4c123gxl>

TM4C123GH6PM folder:

<http://www.ti.com/product/tm4c123gh6pm>

BoosterPack webpage: www.ti.com/boosterpack

LaunchPad Wiki:


www.ti.com/launchpadwiki

For understanding the launchpad properly and to learn more about Tiva it is strongly recommended to go through the webpage [Tiva Workshops](#) and download and read the workbook


6.1.3 Create a New Project

To create new project follow the steps mentioned:

1. Click File then New and then CCS Projects



2. Select Target and connection as shown in the photo. Give a name to your project and save in a location. Click Finish. A main.c file will be open



6.1.4 Add Path and Build Variables

The path and build variables are used for:


- Path variable – when you ADD (link) a file to your project, you can specify a "relative to" path. The default is PROJECT_LOC which means that your linked resource (like a .lib file) will be linked relative to your project directory.
- Build variable – used for items such as the search path for include files associated with a library – i.e. it is used when you build your project.

Variables can either have a PROJECT scope (that they only work for this project) or a WORKSPACE scope (that they work across all projects in the workspace). In the next step, we need to add (link) a library file and then add a search path for include files. First, we'll add these variables MANUALLY as WORKSPACE variables so that any project in your workspace can use the variables. Refer to the workbook by TI for adding as PROJECT


6.1.4.1 Adding a Path Variable

To add a path variable,:


- Right-click on your Window Tab and select Preference.




- Expand General list in the upper left-hand corner as shown and then expand the Resource list and click on Linked Resources: We want to add a New variable to specify exactly where you installed TivaWare.




- Click New
- When the New Variable dialog appears, type TIVAWARE_INSTALL for the name.




- For the Location, click the Folder... button and navigate to your TivaWare installation. Click on the folder name and then click OK.






- Click OK. You should see your new variable listed in the Variables list.




6.1.4.2 Adding a Build Variable

Now let's add a build variable that we will use in the include search path for the INCLUDE files associated with the TivaWare driver libraries.


- Click on Code Composer Studio Build and then the Variables tab:



- Click the Add button. When the Define a New Build Variable dialog appears, insert TIVAWARE_INSTALL into the Variables name box.
- Change the Type to Directory and browse to your Tivaware installation folder.



- Click OK.
- Click OK again to save and close the Build Properties window.



6.2 driver.lib

6.3 Buzzer

Located in the folder “Buzzer.Beep” folder in the documentation. In this example, we will load buzzer beep code in Tiva based Fire Bird V. Now we will see in detail the structure of this code. This experiment demonstrates the simple operation of Buzzer ON/OFF with one second delay. Buzzer is connected to PORTF 4 pin of the Tiva Launchpad. If you have uC based board then it is connected to PORTA 2.

```

1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "inc/hw_types.h"
4  #include "inc/hw_memmap.h"
5  //This header File is important to Unlock GPIO Pins
6  #include "inc/hw_gpio.h"
7  #include "driverlib/sysctl.h"
8  #include "driverlib/gpio.h"
9
10 //**** Useful Macros Definition****/
11 //*****Remove the comments if you are using uC board*****
12 #define buzzerEnable    SYSCTL_PERIPH_GPIOA
13 #define buzzer          GPIO_PORTA_BASE
14 #define buzzerPin       GPIO_PIN_2
15 //*****/
16
17 //*****Remove the comments if you are using uC board*****/
18 #define buzzerEnable    SYSCTL_PERIPH_GPIOF
19 #define buzzer          GPIO_PORTF_BASE
20 #define buzzerPin       GPIO_PIN_4
21 //*****/
22
23 #define buzzerOn()      GPIOPinWrite(buzzer , buzzerPin ,255)
24 #define buzzerOff()     GPIOPinWrite(buzzer , buzzerPin ,0)
25 //*****/
26 void setupCLK();
27 void peripheralEnable();
28 void configIOPin();
29 void delay_ms(uint64_t delay);
30 void delay_ms(uint64_t delay);
31
32 int main(void) {

```

```

33     setupCLK();
34     peripheralEnable();
35     configIOPin();
36     while(1){
37         buzzerOn();
38         delay_ms(1000);
39         buzzerOff();
40         delay_ms(1000);
41     }
42 }
43 /*****
44 * This function is used to setup Clock frequency of the controller
45 * It can be changed through codes
46 * In this we have set frequency as 40Mhz
47 * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
48 *****/
49 void setupCLK(){
50     SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
51 }
52 /*****
53 * Enabling System Peripherals
54 * buzzer Port in this case
55 * buzzerPin for buzzer output
56 *****/
57 void peripheralEnable(){
58     SysCtlPeripheralEnable(buzzerEnable);
59     /***** Just in case you are not familiar with macros*****/
60     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
61     /***** This is enabling PORTF *****/
62 }
63 /*****
64 * Configuring Pin as Input Or Output
65 *****/
66 void configIOPin(){
67     GPIOPinTypeGPIOOutput(buzzer, buzzerPin);
68     /***** Just in case you are not familiar with macros*****/
69     GPIOPinTypeGPIOOutput(buzzer, GPIO_PIN_4);
70     /***** This is P4 output *****/
71 }
72 /*****
73 * Calculating Delays
74 * extern void SysCtlDelay(uint32_t ui32Count)
75 * waits until the counting has been completed
76 *****/
77 void delay_ms(uint64_t delay){
78     SysCtlDelay(delay*SysCtlClockGet()/3000.0);
79 }
80 void delay_us(uint64_t delay){
81     SysCtlDelay(delay*SysCtlClockGet()/3000000.0);
82 }
83

```

6.4 Programming the Robot

6.5 Using Debugger of The Programmer

6.6 Simple I/O Operation

This experiment demonstrates the simple I/O operations. This example is only for plug and play board, but this should not discourage the user from understanding the example as it provide very important example of I/O operation on TIVA platform.

In this lab you have to use switch SW1, SW2 and RGB LED present on Tiva C series board.

1. Use switch SW1 to Turn on Red LED on first switch press, Green LED on second switch press and Blue LED on third switch press. Repeat the same cycle next switch press onwards. Note that LED should remain on for the duration switch is kept pressed i.e. LED should turn off when switch is released.
2. Use switch SW2 and sw2Status (a variable). Your program should increment sw2Status by one, every time switch is pressed. Note how the value of sw2Status changes on each switch press. Use debugger and

add sw2Status to Watch Expression” window. (You will find Continuous Refresh button on top of the Expression Window). You can use step debugging or breakpoints to check the variable value. Hint: To add variable to Expression Window, select and right click the variable name and select Add Watch Expression”. To view Expression Window, click on View button from CCS menu bar and select Expressions.

```

1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "inc/hw_types.h"
4  #include "inc/hw_memmap.h"
5  #include "inc/hw_gpio.h" //To unlock locked pins for GPIO
6  #include "driverlib/sysctl.h"
7  #include "driverlib/gpio.h"
8  #define userSwitch1 GPIO_PIN_0
9  #define redLed GPIO_PIN_1
10 #define blueLed GPIO_PIN_2
11 #define greenLed GPIO_PIN_3
12 #define userSwitch2 GPIO_PIN_4
13 #define LOCK_F (*((volatile unsigned long *)0x40025520))
14 #define CR_F (*((volatile unsigned long *)0x40025524))
15 void setupCLK();
16 void configIOPin();
17 void delay_ms(uint64_t delay);
18 void delay_us(uint64_t delay);
19
20 int main() {
21     setupCLK();
22     SysCtlDelay(3);
23     configIOPin();
24     unsigned char pinData=1;
25     unsigned char state=2;
26     unsigned char countSwitch2=0;
27     unsigned char flagSW1=0;
28     unsigned char flagSW2=0;
29     while(1){
30         pinData=GPIOPinRead(GPIO_PORTF_BASE, userSwitch2 | userSwitch1);
31         if((pinData&0x01)==0)
32             flagSW1=1;
33         else if((flagSW1==1)&&(pinData&0x01)==1){
34             countSwitch2+=1;
35             flagSW1=0;
36         }
37         if((pinData&0x10)==0){
38             GPIOPinWrite(GPIO_PORTF_BASE, redLed | blueLed | greenLed, state);
39             flagSW2=1;
40         }
41         else if(((flagSW2==1)&&(pinData&0x10)==0x10)){
42             flagSW2=0;
43             GPIOPinWrite(GPIO_PORTF_BASE, redLed | blueLed | greenLed, 0);
44             state=state*2;
45             if(state>8)
46                 state=2;
47         }
48         delay_ms(5);
49     }
50 }
51
52 /*****
53  * This function is used to setup Clock frequency of the controller
54  * Enabling System Peripherals
55  * PORTF in this case
56  *****/
57 void setupCLK() {
58     SysCtlClockSet(SYSCTL_SYSDIV_4|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
59     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
60 }
61 /*****
62  * Configuring Pin as Input Or Output
63  * PF0 by default is locked and cannot
64  * be used as input unless it is unlocked
65  *****/
66 void configIOPin() {
67     GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, redLed | blueLed | greenLed);
68     HWREG(GPIO_PORTF_BASE + GPIO_O_LOCK) = GPIO_LOCK_KEY;
69     HWREG(GPIO_PORTF_BASE + GPIO_O_CR) |= 0x01;
70     HWREG(GPIO_PORTF_BASE + GPIO_O_LOCK) = 0;
71     GPIOPinTypeGPIOInput(GPIO_PORTF_BASE, userSwitch2 | userSwitch1);
72     GPIOPadConfigSet(GPIO_PORTF_BASE, userSwitch2 | userSwitch1, GPIO_STRENGTH_12MA,

```



```

72     GPIO_PIN_TYPE_STD_WPU);
73     }
74     /* *****
75     * Calculating Delays
76     ***** */
77     void delay_ms(uint64_t delay){
78         SysCtlDelay(delay*(SysCtlClockGet()/3000));
79     }
80     void delay_us(uint64_t delay){
81         SysCtlDelay(delay*(SysCtlClockGet()/3000000UL));
82     }

```

6.7 Robot Direction Control

Located in the folder “Experiments Motion Control Simple” folder. Robot’s motors are controlled by L293D motor controller. Using L293D, microcontroller can control direction and velocity of both of the motors. To change the direction appropriate logic levels (High/Low) are applied to IC L293D’s direction pins. Velocity control is done using pulse width modulation (PWM) applied to Enable pins of L293D IC.

The Motor connections are as shown below

Motor Pin	Pin Name(uC)	Pin Name(Plug and Play)
L1	PB0	PF3
L2	PB1	PB3
PWM L	PF3	PF2
R1	PF4	PC4
R1	PA5	PC6
PWM R	PA6	PC5

Code for Plug and Play Board:

```

1     #include <stdint.h>
2     #include <stdbool.h>
3     #include "inc/hw_types.h"
4     #include "inc/hw_memmap.h"
5     //This header File is important to Unlock GPIO Pins
6     #include "inc/hw_gpio.h"
7     #include "driverlib/sysctl.h"
8     #include "driverlib/gpio.h"
9     //Used for controlling Motor direction
10    #define right      0x41
11    #define left       0x18
12    #define softRight  0x10
13    #define softLeft   0x01
14    #define forward    0x11
15    #define backward   0x48
16
17    void setupCLK();
18    void peripheralEnable();
19    void configIOPin();
20    void delay_ms(uint64_t delay);
21    void delay_us(uint64_t delay);
22    void motion(uint8_t);
23
24    int main(void) {
25        setupCLK();
26        peripheralEnable();
27        configIOPin();
28        while(1){
29            motion(forward);
30            delay_ms(1000);
31            motion(right);
32            delay_ms(1000);
33            motion(left);
34            delay_ms(1000);
35            motion(backward);
36            delay_ms(1000);
37        }
38    }
39    /* *****
40    * This function is used to setup Clock frequency of the controller

```

```

41  * It can be changed through codes
42  * In this we have set frequency as 40Mhz
43  * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
44  *****/
45  void setupCLK() {
46      SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
47  }
48  /******
49  * Enabling System Peripherals
50  * PORTF,PORTB and PORTC in this case
51  *****/
52  void peripheralEnable() {
53      SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOB);
54      SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
55      SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOC);
56  }
57  /******
58  * Configuring Pin as Input Or Output
59  * And Setting PWM Pin to Always High
60  *****/
61  void configIOPin() {
62      GPIOPinTypeGPIOOutput(GPIO_PORTB_BASE, GPIO_PIN_3);
63      GPIOPinTypeGPIOOutput(GPIO_PORTC_BASE, GPIO_PIN_4|GPIO_PIN_5|GPIO_PIN_6);
64      GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, GPIO_PIN_3|GPIO_PIN_2);
65      GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_2, 255);
66      GPIOPinWrite(GPIO_PORTC_BASE, GPIO_PIN_5, 255);
67  }
68  /******
69  * Calculating Delays
70  *****/
71  void delay_ms(uint64_t delay) {
72      SysCtlDelay(delay*(SysCtlClockGet()/3000));
73  }
74  void delay_us(uint64_t delay) {
75      SysCtlDelay(delay*(SysCtlClockGet()/3000000UL));
76  }
77  /******
78  * This function is for giving the direction of motion
79  * Macros have been defined at starting
80  * Macros for directions are 8 bits
81  * Out of these 8 bits only 4 are used
82  * Bit 0 (LSB) corresponds to PB3
83  * Bit 3      corresponds to PF3
84  * Bit 4      corresponds to PC4
85  * Bit 6      corresponds to PF6
86  *****/
87  void motion(uint8_t direction) {
88      GPIOPinWrite(GPIO_PORTB_BASE, GPIO_PIN_3, direction << 3);
89      GPIOPinWrite(GPIO_PORTC_BASE, GPIO_PIN_4|GPIO_PIN_6, direction);
90      GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_3, direction);
91  }
92

```

Code for uC based Board:

```

1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "inc/hw_types.h"
4  #include "inc/hw_memmap.h"
5  //This header File is important to Unlock GPIO Pins
6  #include "inc/hw_gpio.h"
7  #include "driverlib/sysctl.h"
8  #include "driverlib/gpio.h"
9  //Used for control Motor direction
10 #define right      0x22
11 #define left       0x11
12 #define softRight  0x02
13 #define softLeft   0x10
14 #define forward    0x12
15 #define backward   0x21
16 #define stop       0x00
17
18 void setupCLK();
19 void peripheralEnable();
20 void configIOPin();
21 void delay_ms(uint64_t delay);
22 void delay_us(uint64_t delay);

```

```

23     void motion(uint8_t);
24
25     int main(void) {
26         setupCLK();
27         peripheralEnable();
28         configIOPin();
29         while(1){
30             motion(forward);
31             delay_ms(1000);
32             motion(right);
33             delay_ms(1000);
34             motion(left);
35             delay_ms(1000);
36             motion(backward);
37             delay_ms(1000);
38         }
39     }
40
41     /*
42     * This function is used to setup Clock frequency of the controller
43     * It can be changed through codes
44     * In this we have set frequency as 40Mhz
45     * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
46     */
47     void setupCLK() {
48         SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
49     }
50
51     /*
52     * Enabling System Peripherals
53     * PORTF, PORTB and PORTC in this case
54     */
55     void peripheralEnable() {
56         SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOB);
57         SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
58         SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOA);
59     }
60
61     /*
62     * Configuring Pin as Input Or Output
63     * And Setting PWM Pin to Always High
64     */
65     void configIOPin() {
66         GPIOPinTypeGPIOOutput(GPIO_PORTB_BASE, GPIO_PIN_0|GPIO_PIN_1);
67         GPIOPinTypeGPIOOutput(GPIO_PORTA_BASE, GPIO_PIN_6|GPIO_PIN_5);
68         GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, GPIO_PIN_4|GPIO_PIN_3);
69         GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_3, 255);
70         GPIOPinWrite(GPIO_PORTA_BASE, GPIO_PIN_6, 255);
71     }
72
73     /*
74     * Calculating Delays
75     */
76     void delay_ms(uint64_t delay) {
77         SysCtlDelay(delay*(SysCtlClockGet()/3000));
78     }
79
80     void delay_us(uint64_t delay) {
81         SysCtlDelay(delay*(SysCtlClockGet()/3000000UL));
82     }
83
84     /*
85     * This function is for giving the direction of motion
86     * Macros have been defined at starting
87     * Macros for directions are 8 bits
88     * Out of these 8 bits only 4 are used
89     * Bit 0 (LSB) corresponds to PB0
90     * Bit 1 corresponds to PF1
91     * Bit 4 corresponds to PF4
92     * Bit 5 corresponds to PA5
93     */
94     void motion(uint8_t direction) {
95         GPIOPinWrite(GPIO_PORTB_BASE, GPIO_PIN_0|GPIO_PIN_1, direction);
96         GPIOPinWrite(GPIO_PORTA_BASE, GPIO_PIN_5, direction);
97         GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_4, direction);
98     }

```

6.8 Robot Position Control Using Interrupts

Position encoders give position / velocity feedback to the robot. It is used in closed loop to control robot's position and velocity. Position encoder consists of optical encoder and slotted disc assembly. When this slotted disc moves in between the optical encoder we get square wave signal whose pulse count indicates position and time period indicates velocity.

Connections:

Plug and Play Board:

PB2 : External interrupt for left motor position encoder

PF0 : External interrupt for the right position encoder

uC Based Board:

PA4 : External interrupt for left motor position encoder

PA3 : External interrupt for the right position encoder

6.8.1 Calculation of position encoder resolution:

To be added later

Code for Plug and Play Board:

```

1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "inc/tm4c123gh6pm.h"
4  #include "inc/hw_memmap.h"
5  #include "inc/hw_types.h"
6  #include "inc/hw_gpio.h"
7  #include "driverlib/sysctl.h"
8  #include "driverlib/interrupt.h"
9  #include "driverlib/gpio.h"
10 //This header File is important to Unlock GPIO Pins
11 #include "inc/hw_gpio.h"
12 #include "driverlib/sysctl.h"
13 #include "driverlib/gpio.h"
14
15 #define right          0x41
16 #define left           0x18
17 #define softRight      0x10
18 #define softLeft       0x01
19 #define forward        0x11
20 #define backward       0x48
21 #define stop           0x00
22
23 void setupCLK();
24 void peripheralEnable();
25 void configIOPin();
26 void delay_ms(uint64_t delay);
27 void delay_us(uint64_t delay);
28 void motion(uint8_t);
29 void interruptEnable();
30 void encoderInterruptEncountered();
31 void encoderInterruptEncountered1();
32 void angleRotate(uint16_t Degrees);
33 void linearDistanceMM(unsigned int DistanceInMM);
34 void rightDegrees(unsigned int Degrees);
35 void leftDegrees(unsigned int Degrees);
36 void forwardMM(unsigned int DistanceInMM);
37 void backwardMM(unsigned int DistanceInMM);
38 volatile unsigned long int ShaftCountRight = 0;
39 volatile unsigned long int ShaftCountLeft = 0;
40
41 int main(void) {
42     setupCLK();
43     peripheralEnable();
44     configIOPin();
45     interruptEnable();
46     while(1){
47         forwardMM(100);

```

```
48     delay_ms(1000);
49     leftDegrees(90);
50     delay_ms(1000);
51 }
52 }
53 /*****
54 * This function is used to setup Clock frequency of the controller
55 * It can be changed through codes
56 * In this we have set frequency as 40Mhz
57 * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
58 *****/
59 void setupCLK() {
60     SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
61 }
62 /*****
63 * Enabling System Peripherals
64 * PORTF,PORTB and PORTC in this case
65 *****/
66 void peripheralEnable() {
67     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOB);
68     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
69     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOC);
70 }
71 /*****
72 * Configuring Pin as Input Or Output
73 * Unlocking PF0
74 * Setting PWM Pins to Always High
75 * Weak Pull to the Input Pins
76 *****/
77 void configIOPin() {
78     GPIOPinTypeGPIOOutput(GPIO_PORTB_BASE, GPIO_PIN_3);
79     GPIOPinTypeGPIOOutput(GPIO_PORTC_BASE, GPIO_PIN_4|GPIO_PIN_5|GPIO_PIN_6);
80     GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, GPIO_PIN_3|GPIO_PIN_2|GPIO_PIN_1);
81     GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_2, 255);
82     GPIOPinWrite(GPIO_PORTC_BASE, GPIO_PIN_5, 255);
83     HWREG(GPIO_PORTF_BASE + GPIO_O_LOCK) = GPIO_LOCK_KEY;
84     HWREG(GPIO_PORTF_BASE + GPIO_O_CR) |= 0x01;
85     HWREG(GPIO_PORTF_BASE + GPIO_O_LOCK) = 0;
86     GPIOPinTypeGPIOInput(GPIO_PORTF_BASE, GPIO_PIN_0);
87     GPIOPadConfigSet(GPIO_PORTF_BASE, GPIO_PIN_0, GPIO_STRENGTH_2MA, GPIO_PIN_TYPE_STD_WPU);
88     GPIOPinTypeGPIOInput(GPIO_PORTB_BASE, GPIO_PIN_2);
89     GPIOPadConfigSet(GPIO_PORTB_BASE, GPIO_PIN_2, GPIO_STRENGTH_2MA, GPIO_PIN_TYPE_STD_WPU);
90 }
91 /*****
92 * Calculating Delays
93 *****/
94 void delay_ms(uint64_t delay) {
95     SysCtlDelay(delay*(SysCtlClockGet()/3000));
96 }
97 void delay_us(uint64_t delay) {
98     SysCtlDelay(delay*(SysCtlClockGet()/3000000UL));
99 }
100 /*****
101 * This function is for giving the direction of motion
102 * Macros have been defined at starting
103 * Macros for directions are 8 bits
104 * Out of these 8 bits only 4 are used
105 * Bit 0 (LSB) corresponds to PB3
106 * Bit 3 corresponds to PF3
107 * Bit 4 corresponds to PC4
108 * Bit 6 corresponds to PF6
109 *****/
110 void motion(uint8_t direction) {
111     GPIOPinWrite(GPIO_PORTB_BASE, GPIO_PIN_3, direction<<3);
112     GPIOPinWrite(GPIO_PORTC_BASE, GPIO_PIN_4|GPIO_PIN_6, direction);
113     GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_3, direction);
114 }
115 /****For Enabling Interrupt on PORTF and PORTB****/
116 void interruptEnable() {
117     GPIOIntDisable(GPIO_PORTF_BASE, GPIO_PIN_0);
118     GPIOIntClear(GPIO_PORTF_BASE, GPIO_PIN_0);
119     GPIOIntRegister(GPIO_PORTF_BASE, encoderInterruptEncountered);
120     GPIOIntTypeSet(GPIO_PORTF_BASE, GPIO_PIN_0, GPIO_FALLING_EDGE);
121     GPIOIntEnable(GPIO_PORTF_BASE, GPIO_PIN_0);
122     GPIOIntDisable(GPIO_PORTB_BASE, GPIO_PIN_2);
123     GPIOIntClear(GPIO_PORTB_BASE, GPIO_PIN_2);
```

```
GPIOIntRegister(GPIO_PORTB.BASE, encoderInterruptEncountered1);
GPIOIntTypeSet(GPIO_PORTB.BASE, GPIO_PIN_2, GPIO_FALLING_EDGE);
GPIOIntEnable(GPIO_PORTB.BASE, GPIO_PIN_2);
}
/**** ISR For External Interrupt on PortF*****/
* Check on which pin of the PORTA has encountered an interrupt
* There is only one ISR for complete PORT
* No two PORTs can have same ISR
*****/
void encoderInterruptEncountered(){
    if(GPIOIntStatus(GPIO_PORTF.BASE, false)&GPIO_PIN_0){
        ShaftCountRight++;
        GPIOIntClear(GPIO_PORTF.BASE, GPIO_PIN_0);
    }
    if(GPIOIntStatus(GPIO_PORTB.BASE, false)&GPIO_PIN_2){
        ShaftCountLeft++;
        GPIOPinWrite(GPIO_PORTF.BASE, GPIO_PIN_1, 2);
        GPIOIntClear(GPIO_PORTB.BASE, GPIO_PIN_2);
    }
}
/*****
* Function to Rotate to desired Angle
* Resolution can be Change to Get Higher Precision
*****/
void angleRotate(uint16_t Degrees){
    unsigned long int ReqdShaftCountInt = 0;
    ReqdShaftCountInt = Degrees/ 4.09;// division by resolution to get shaft count
    ShaftCountRight = 0;
    while (1){
        if((ShaftCountRight>=ReqdShaftCountInt))
            break;
    }
    motion(stop);
}
/*****
* Function to Move in a Linear Distance
* Resolution can be Change to Get Higher Precision
*****/
void linearDistanceMM(unsigned int DistanceInMM){
    unsigned long int ReqdShaftCountInt = 0;
    ReqdShaftCountInt =DistanceInMM / 5.338;;
    ShaftCountRight=0;
    ShaftCountLeft=0;
    while(1){
        if((ShaftCountRight >=ReqdShaftCountInt)&&(ShaftCountLeft >= ReqdShaftCountInt))
            break;
        else if((ShaftCountRight > ReqdShaftCountInt))
            motion(softRight);
        else if((ShaftCountLeft > ReqdShaftCountInt))
            motion(softLeft);
    }
    motion(stop); //Stop robot
}
void forwardMM(unsigned int DistanceInMM){
    motion(forward);
    linearDistanceMM(DistanceInMM);
}

void backwardMM(unsigned int DistanceInMM){
    motion(backward);
    linearDistanceMM(DistanceInMM);
}
void leftDegrees(unsigned int Degrees){
    motion(left); //Turn left
    angleRotate(Degrees);
}
void rightDegrees(unsigned int Degrees){
    motion(right); //Turn right
    angleRotate(Degrees);
}
```

Code for uC based Board:

```
#include <stdint.h>
#include <stdbool.h>
#include "inc/tm4c123gh6pm.h"
```

```

4  #include "inc/hw_memmap.h"
5  #include "inc/hw_types.h"
6  #include "inc/hw_gpio.h"
7  #include "driverlib/sysctl.h"
8  #include "driverlib/interrupt.h"
9  #include "driverlib/gpio.h"
10
11 #define right          0x22
12 #define left           0x11
13 #define softRight      0x02
14 #define softLeft       0x10
15 #define forward        0x12
16 #define backward       0x21
17 #define stop           0x00
18
19 void setupCLK();
20 void peripheralEnable();
21 void gpioEnable();
22 void interruptEnable();
23 void encoderInterruptEncountered();
24 void linearDistanceMM(unsigned int);
25 void angleRotate(uint16_t);
26 void forwardMM(unsigned int);
27 void backwardMM(unsigned int);
28 void leftDegrees(unsigned int);
29 void rightDegrees(unsigned int);
30 void delay_ms(uint64_t delay);
31 void delay_us(uint64_t delay);
32 void motion(uint8_t direction);
33 volatile uint16_t ShaftCountRight=0,ShaftCountLeft=0;
34
35 int main(void) {
36     setupCLK();
37     peripheralEnable();
38     gpioEnable();
39     interruptEnable();
40     while(1){
41         forwardMM(100);
42         delay_ms(1000);
43         rightDegrees(90);
44         delay_ms(1000);
45     }
46 }
47
48 /*****
49 * This function is used to setup Clock frequency of the controller
50 * It can be changed through codes
51 * In this we have set frequency as 40Mhz
52 * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
53 *****/
54 void setupCLK() {
55     SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
56 }
57
58 /*****
59 * Enabling System Peripherals
60 * PORTF,PORTB and PORTA in this case
61 *****/
62 void peripheralEnable() {
63     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOB);
64     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
65     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOA);
66 }
67
68 /*****
69 * Configuring Pin as Input Or Output
70 * Setting PWM Pins to Always High
71 * Weak Pull to the Input Pins
72 *****/
73 void gpioEnable() {
74     GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, GPIO_PIN_1 | GPIO_PIN_2);
75     GPIOPinTypeGPIOOutput(GPIO_PORTB_BASE, GPIO_PIN_0 | GPIO_PIN_1);
76     GPIOPinTypeGPIOOutput(GPIO_PORTA_BASE, GPIO_PIN_6 | GPIO_PIN_5);
77     GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, GPIO_PIN_4 | GPIO_PIN_3);
78     GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_3, 255);
79     GPIOPinWrite(GPIO_PORTA_BASE, GPIO_PIN_6, 255);

```

```
80     GPIOPinTypeGPIOInput(GPIO_PORTA_BASE, GPIO_PIN_4|GPIO_PIN_3);
81     GPIOPadConfigSet(GPIO_PORTA_BASE, GPIO_PIN_4|GPIO_PIN_5, GPIO_STRENGTH_2MA, GPIO_PIN_TYPE_STD_WPU
);
82 }
83 /****For Enabling Interrupt on PortA****/
84 void interruptEnable(){
85     GPIOIntDisable(GPIO_PORTA_BASE, GPIO_PIN_4|GPIO_PIN_3);
86     GPIOIntClear(GPIO_PORTA_BASE, GPIO_PIN_4|GPIO_PIN_3);
87     GPIOIntRegister(GPIO_PORTA_BASE, encoderInterruptEncountered);
88     GPIOIntTypeSet(GPIO_PORTA_BASE, GPIO_PIN_4|GPIO_PIN_3, GPIO_FALLING_EDGE);
89     GPIOIntEnable(GPIO_PORTA_BASE, GPIO_PIN_4|GPIO_PIN_3);
90 }
91 /**** ISR For External Interrupt on PortA*****
92 * Check on which pin of the PORTA has encountered an interrupt
93 * There is only one ISR for complete PORT
94 * No two PORTs can have same ISR
95 *****/
96 void encoderInterruptEncountered(){
97     if(GPIOIntStatus(GPIO_PORTA_BASE, false)&GPIO_PIN_4){
98         ShaftCountLeft++;
99         GPIOIntClear(GPIO_PORTA_BASE, GPIO_PIN_4);
100     }
101     if(GPIOIntStatus(GPIO_PORTA_BASE, false)&GPIO_PIN_3){
102         ShaftCountRight++;
103         GPIOIntClear(GPIO_PORTA_BASE, GPIO_PIN_3);
104     }
105 }
106 /*****
107 * Calculating Delays
108 *****/
109 void delay_ms(uint64_t delay){
110     SysCtlDelay(delay*(SysCtlClockGet()/3000));
111 }
112 void delay_us(uint64_t delay){
113     SysCtlDelay(delay*(SysCtlClockGet()/3000000UL));
114 }
115 /*****
116 * This function is for giving the direction of motion
117 * Macros have been defined at starting
118 * Macros for directions are 8 bits
119 * Out of these 8 bits only 4 are used
120 * Bit 0 (LSB) corresponds to PB3
121 * Bit 3 corresponds to PF3
122 * Bit 4 corresponds to PC4
123 * Bit 6 corresponds to PF6
124 *****/
125 void motion(uint8_t direction){
126     GPIOPinWrite(GPIO_PORTB_BASE, GPIO_PIN_0|GPIO_PIN_1, direction);
127     GPIOPinWrite(GPIO_PORTA_BASE, GPIO_PIN_5, direction);
128     GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_4, direction);
129 }
130 /*****
131 * Function to Rotate to desired Angle
132 * Resolution can be Change to Get Higher Precision
133 *****/
134 void angleRotate(uint16_t Degrees){
135     unsigned long int ReqdShaftCountInt = 0; // division by resolution to get shaft count
136     ReqdShaftCountInt = Degrees/ 4.09;;
137     ShaftCountRight = 0;
138     ShaftCountLeft = 0;
139     while (1){
140         if((ShaftCountRight>=ReqdShaftCountInt)&&(ShaftCountLeft>=ReqdShaftCountInt))
141             break;
142     }
143     motion(stop);
144 }
145 /*****
146 * Function to Move in a Linear Distance
147 * Resolution can be Change to Get Higher Precision
148 *****/
149 void linearDistanceMM(unsigned int DistanceInMM){
150     unsigned long int ReqdShaftCountInt = 0;
151     ReqdShaftCountInt =DistanceInMM / 5.338;;
152     ShaftCountRight=0;
153     ShaftCountLeft=0;
154     while (1){
```



```

155         if((ShaftCountRight > ReqdShaftCountInt)&&(ShaftCountLeft > ReqdShaftCountInt))
156             break;
157         else if((ShaftCountRight > ReqdShaftCountInt))
158             motion(softRight);
159         else if((ShaftCountLeft > ReqdShaftCountInt))
160             motion(softLeft);
161     }
162     motion(stop); //Stop robot
163 }
164 void forwardMM(unsigned int DistanceInMM){
165     motion(forward);
166     linearDistanceMM(DistanceInMM);
167 }
168 void backwardMM(unsigned int DistanceInMM){
169     motion(backward);
170     linearDistanceMM(DistanceInMM);
171 }
172 void leftDegrees(unsigned int Degrees){
173     motion(left); //Turn left
174     angleRotate(Degrees);
175 }
176 void rightDegrees(unsigned int Degrees){
177     motion(right); //Turn right
178     angleRotate(Degrees);
179 }
180

```

6.9 Timers and its Interrupts

The TM4C123GH6PM General-Purpose Timer Module (GPTM) contains six 16/32-bit GPTM blocks and six 32/64-bit Wide GPTM blocks. Each 16/32-bit GPTM block provides two 16-bit timers/counters (referred to as Timer A and Timer B) that can be configured to operate independently as timers or event counters, or concatenated to operate as one 32-bit timer or one 32-bit Real-Time Clock (RTC). Each 32/64-bit Wide GPTM block provides 32-bit timers for Timer A and Timer B that can be concatenated to operate as a 64-bit timer.

Timers are mainly used for

- Velocity Control
- Servo Motor Control
- Event Scheduling
- Velocity Calculation

In this section the event scheduling application of timer is explained. To illustrate this the buzzer is switched On and OFF periodically. The remaining applications are explained in the further sections.

```

1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "inc/hw_types.h"
4  #include "inc/hw_memmap.h"
5  #include "inc/tm4c123gh6pm.h"
6  //This header File is important to Unlock GPIO Pins
7  #include "inc/hw_gpio.h"
8  #include "driverlib/sysctl.h"
9  #include "driverlib/gpio.h"
10 //Used for enabling the timer
11 #include "driverlib/timer.h"
12 //Used for enabling interrupt
13 #include "driverlib/interrupt.h"
14 /**** Useful Macros Definition*****/
15 /*****Remove the comments if you are using uC board*****/
16 #define buzzerEnable    SYSCTL_PERIPH_GPIOA
17 #define buzzer          GPIO_PORTA_BASE
18 #define buzzerPin       GPIO_PIN_2

```

```

19  *****/
20
21  /*****Remove the comments if you are using uC board*****/
22  #define buzzerEnable    SYSCTL_PERIPH_GPIOF
23  #define buzzer          GPIO_PORTF_BASE
24  #define buzzerPin       GPIO_PIN_4
25  *****/
26
27  #define buzzerOn()      GPIOPinWrite(buzzer , buzzerPin ,255)
28  #define buzzerOff()     GPIOPinWrite(buzzer , buzzerPin ,0)
29  *****/
30  void setupCLK();
31  void peripheralEnable();
32  void configIOPin();
33  void timerEnable();
34
35  uint32_t ui32Period;    // used for generating one second delay
36  volatile int flag = 0;  //used to monitor the state of buzzer
37
38  int main(void) {
39      setupCLK();
40      peripheralEnable();
41      configIOPin();
42      timerEnable();
43      flag = 0;
44      while(1){
45      }
46  }
47  /*****
48  * This function is used to setup Clock frequency of the controller
49  * It can be changed through codes
50  * In this we have set frequency as 40Mhz
51  * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
52  *****/
53  void setupCLK(){
54      SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
55  }
56  /*****
57  * Enabling System Peripherals
58  * buzzer Port in this case
59  * buzzerPin for buzzer output
60  * Enabling Timer 0
61  *****/
62  void peripheralEnable(){
63      SysCtlPeripheralEnable(buzzerEnable);
64      SysCtlPeripheralEnable(SYSCTL_PERIPH_TIMER0);
65      /***** Just in case you are not familiar with macros*****/
66      SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
67      /*****This is enabling PORTF*****/
68  }
69  /*****
70  * Configuring Pin as Input Or Output
71  *****/
72  void configIOPin(){
73      GPIOPinTypeGPIOOutput(buzzer , buzzerPin);
74  }
75  /*****
76  * Enabling Timer 0
77  * Timer is configured to be generate
78  interrupt every second
79  * Here sysCtlClockGet() is divided
80  by the on time of buzzer
81  *****/
82  void timerEnable(){
83      TimerConfigure(TIMER0_BASE, TIMER_CFG_PERIODIC);
84      ui32Period = (SysCtlClockGet() / 1) / 2;
85      TimerLoadSet(TIMER0_BASE, TIMER_A, ui32Period -1);
86      IntEnable(INT_TIMER0A);
87      TimerIntEnable(TIMER0_BASE, TIMER_TIMA_TIMEOUT);
88      IntMasterEnable();
89      TimerEnable(TIMER0_BASE, TIMER_A);
90  }
91  /*****
92  * This function is executed when the timer overflows
93  * In this example the buzzer is switched on and off alternatively
94  *****/

```

```

95 void Timer0IntHandler(void)
96 {
97     // Clear the timer interrupt
98     TimerIntClear(TIMER0_BASE, TIMER_TIMA_TIMEOUT);
99     flag = !flag;
100     if(flag == 0){
101         buzzerOn();
102     }
103     else{
104         buzzerOff();
105     }
106 }
107

```


6.10 Robot Speed Control

6.10.1 Pulse Width Modulation(PWM)

Pulse width modulation is a process in which duty cycle of constant frequency square wave is modulated to control power delivered to the load i.e. motor.

Duty cycle is the ratio of 'T-ON/ T'. Where 'T-ON' is ON time and 'T' is the time period of the wave. Power delivered to the motor is proportional to the 'T-ON' time of the signal. In case of PWM the motor reacts to the time average of the signal.

PWM is used to control total amount of power delivered to the load without power losses which generally occur in resistive methods of power control.



Above figure shows the PWM waveforms for motor velocity control. In case (A), ON time is 90 percent of time period. This wave has more average value. Hence more power is delivered to the motor. In case (B), the motor will run slower as the ON time is just 10 percent of time period.

The TM4C123GH6PM microcontroller contains two PWM modules, each with four PWM generator blocks and a control block, for a total of 16 PWM outputs. The control block determines the polarity of the PWM signals, and which signals are passed through to the pins. The connections of PWM motor pins are given in the section 6.7. The same code is modified to change the velocity of the motors.

Code for Plug and Play Board:

```

1  include <stdint.h>
2  #include <stdbool.h>
3  #include "inc/hw_types.h"
4  #include "inc/hw_memmap.h"
5  #include "driverlib/pin_map.h"
6  //This header File is important to Unlock GPIO Pins
7  #include "inc/hw_gpio.h"
8  #include "driverlib/sysctl.h"
9  #include "driverlib/gpio.h"
10 //Used for PWM
11 #include "driverlib/pwm.h"
12
13 #define right          0x41
14 #define left           0x18
15 #define softRight      0x10
16 #define softLeft       0x01
17 #define forward        0x11
18 #define backward       0x48

```

```

19 #define stop 0x00
20
21 void setupCLK();
22 void peripheralEnable();
23 void configIOPin();
24 void delay_ms(uint64_t delay);
25 void delay_ms(uint64_t delay);
26 void motion(uint8_t);
27 void enablePWM();
28 void Velocity(uint8_t lSpeed, uint8_t rSpeed);
29
30 int main(void) {
31     setupCLK();
32     peripheralEnable();
33     configIOPin();
34     enablePWM();
35     while(1){
36         Velocity(150, 150);
37         motion(forward);
38         delay_ms(2000);
39         motion(stop);
40         delay_ms(500);
41         Velocity(255, 255);
42         motion(backward);
43         delay_ms(800);
44         motion(stop);
45         delay_ms(500);
46         Velocity(255, 255);
47         motion(right);
48         delay_ms(1000);
49         motion(stop);
50         delay_ms(500);
51         Velocity(150, 150);
52         motion(left);
53         delay_ms(1000);
54         motion(stop);
55         delay_ms(500);
56         Velocity(150, 150);
57         motion(backward);
58         delay_ms(1000);
59     }
60 }
61
62 /******
63 * This function is used to setup Clock frequency of the controller
64 * It can be changed through codes
65 * In this we have set frequency as 40Mhz
66 * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
67 * The PWM module is clocked by the system clock through a divider, and that divider has
68 * a range of 2 to 64.
69 * By setting the divider to 64, it will run the PWM clock at 625 kHz.
70 *****/
71 void setupCLK() {
72     SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
73     SysCtlPWMClockSet(SYSCTL_PWMDIV_64); //625kHz PWM Clock
74 }
75
76 /******
77 * Enabling System Peripherals
78 * PORTF, PORTB and PORTC in this case
79 *****/
80 void peripheralEnable() {
81     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOB);
82     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
83     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOC);
84     SysCtlPeripheralEnable(SYSCTL_PERIPH_PWM0); // Enabling PWM0
85     SysCtlPeripheralEnable(SYSCTL_PERIPH_PWM1); // Enabling PWM1
86 }
87
88 /******
89 * Configuring Pin as Input Or Output
90 * And Setting PWM Pin to Always High
91 *****/
92 void configIOPin() {
93     GPIOPinTypeGPIOOutput(GPIO_PORTB_BASE, GPIO_PIN_3);
94     GPIOPinTypeGPIOOutput(GPIO_PORTC_BASE, GPIO_PIN_4|GPIO_PIN_5|GPIO_PIN_6);
95     GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, GPIO_PIN_3|GPIO_PIN_2);
96 }
97
98 /******

```

```

95  * Calculating Delays
96  *****/
97  void delay_ms(uint64_t delay){
98      SysCtlDelay(delay*(SysCtlClockGet()/3000));
99  }
100  void delay_us(uint64_t delay){
101      SysCtlDelay(delay*(SysCtlClockGet()/3000000UL));
102  }
103  /******
104  * This function is for giving the direction of motion
105  * Macros have been defined at starting
106  * Macros for directions are 8 bits
107  * Out of these 8 bits only 4 are used
108  * Bit 0 (LSB) corresponds to PB3
109  * Bit 3      corresponds to PF3
110  * Bit 4      corresponds to PC4
111  * Bit 6      corresponds to PF6
112  *****/
113  void motion(uint8_t direction){
114      GPIOPinWrite(GPIO_PORTB_BASE, GPIO_PIN_3, direction<<3);
115      GPIOPinWrite(GPIO_PORTC_BASE, GPIO_PIN_4|GPIO_PIN_6, direction);
116      GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_3, direction);
117  }
118  /******
119  * This function is for enabling the PWM Modules
120  * PWM can be enabled on a pin based on the datasheet
121  *****/
122  void enablePWM(){
123      GPIOPinTypePWM(GPIO_PORTF_BASE, GPIO_PIN_2);
124      GPIOPinConfigure(GPIO_PF2_M1PWM6);
125      GPIOPinTypePWM(GPIO_PORTC_BASE, GPIO_PIN_5);
126      GPIOPinConfigure(GPIO_PC5_M0PWM7);
127      //Count Down Mode
128      PWMGenConfigure(PWM0_BASE, PWM_GEN_3, PWM_GEN_MODE_DOWN | PWM_GEN_MODE_NO_SYNC);
129      PWMGenPeriodSet(PWM0_BASE, PWM_GEN_3, 255); //Load Count value
130      //Count Down Mode
131      PWMGenConfigure(PWM1_BASE, PWM_GEN_3, PWM_GEN_MODE_DOWN | PWM_GEN_MODE_NO_SYNC);
132      PWMGenPeriodSet(PWM1_BASE, PWM_GEN_3, 255); //Load Count value
133      PWMGenEnable(PWM0_BASE, PWM_GEN_3);
134      PWMGenEnable(PWM1_BASE, PWM_GEN_3);
135      PWMOutputState(PWM1_BASE, PWM_OUT_6_BIT, true);
136      PWMOutputState(PWM0_BASE, PWM_OUT_7_BIT, true);
137  }
138  /******
139  * This function is used to control the speed of the motors
140  * The speed can changed by the PWMPulseWidthSet() function
141  * lSpeed is used to control the speed of left motor
142  * rSpeed is used to control the speed of right motor
143  *****/
144  void Velocity(uint8_t lSpeed, uint8_t rSpeed){
145      lSpeed=(lSpeed>255)?255:lSpeed;
146      rSpeed=(rSpeed>255)?255:rSpeed;
147      PWMPulseWidthSet(PWM1_BASE, PWM_OUT_6, lSpeed);
148      PWMPulseWidthSet(PWM0_BASE, PWM_OUT_7, rSpeed);
149  }
150

```

Code for uC based Board:

```

1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "inc/hw_types.h"
4  #include "inc/hw_memmap.h"
5  #include "driverlib/pin_map.h"
6
7  //This header File is important to Unlock GPIO Pins
8  #include "inc/hw_gpio.h"
9  #include "driverlib/sysctl.h"
10 #include "driverlib/gpio.h"
11 //Used for PWM
12 #include "driverlib/pwm.h"
13
14 #define right          0x22
15 #define left           0x11
16 #define softRight      0x10
17 #define softLeft       0x02
18 #define forward        0x12

```

```

19 #define backward      0x21
20 #define stop          0x00
21
22 void setupCLK();
23 void peripheralEnable();
24 void configIOPin();
25 void delay_ms(uint64_t delay);
26 void delay_ms(uint64_t delay);
27 void motion(uint8_t);
28 void enablePWM();
29 void Velocity(uint8_t lSpeed, uint8_t rSpeed);
30
31 int main(void) {
32     setupCLK();
33     peripheralEnable();
34     configIOPin();
35     enablePWM();
36     while(1){
37         Velocity(150, 150);
38         motion(forward);
39         delay_ms(2000);
40         motion(stop);
41         delay_ms(500);
42         Velocity(255, 255);
43         motion(backward);
44         delay_ms(800);
45         motion(stop);
46         delay_ms(500);
47         Velocity(255, 255);
48         motion(right);
49         delay_ms(1000);
50         motion(stop);
51         delay_ms(500);
52         Velocity(150, 150);
53         motion(left);
54         delay_ms(1000);
55         motion(stop);
56         delay_ms(500);
57         Velocity(150, 150);
58         motion(backward);
59         delay_ms(1000);
60     }
61 }
62
63 /*****
64 * This function is used to setup Clock frequency of the controller
65 * It can be changed through codes
66 * In this we have set frequency as 40Mhz
67 * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
68 * * The PWM module is clocked by the system clock through a divider, and that divider has
69 a range of 2 to 64.
70 * By setting the divider to 64, it will run the PWM clock at 625 kHz.
71 *****/
72 void setupCLK() {
73     SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
74     SysCtlPWMClockSet(SYSCTL_PWMDIV_64); //625kHz PWM Clock
75 }
76
77 /*****
78 * Enabling System Peripherals
79 * PORTF, PORTB and PORTA in this case
80 *****/
81 void peripheralEnable() {
82     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOB);
83     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
84     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOA);
85     SysCtlPeripheralEnable(SYSCTL_PERIPH_PWM1); // Enabling PWM
86 }
87
88 /*****
89 * Configuring Pin as Input Or Output
90 * And Setting PWM Pin to Always High
91 *****/
92 void configIOPin() {
93     GPIOPinTypeGPIOOutput(GPIO_PORTB_BASE, GPIO_PIN_0|GPIO_PIN_1);
94     GPIOPinTypeGPIOOutput(GPIO_PORTA_BASE, GPIO_PIN_5);
95     GPIOPinTypeGPIOOutput(GPIO_PORTF_BASE, GPIO_PIN_4);
96 }

```

```

95  /*****
96  * Calculating Delays
97  *****/
98  void delay_ms(uint64_t delay){
99      SysCtlDelay(delay*(SysCtlClockGet()/3000));
100  }
101  void delay_us(uint64_t delay){
102      SysCtlDelay(delay*(SysCtlClockGet()/3000000UL));
103  }
104  /*****
105  * This function is for giving the direction of motion
106  * Macros have been defined at starting
107  * Macros for directions are 8 bits
108  * Out of these 8 bits only 4 are used
109  * Bit 0      corresponds to PB0
110  * Bit 1      corresponds to PB1
111  * Bit 4      corresponds to PF4
112  * Bit 5      corresponds to PA5
113  *****/
114  void motion(uint8_t direction){
115      GPIOPinWrite(GPIO_PORTB_BASE, GPIO_PIN_1|GPIO_PIN_0, direction);
116      GPIOPinWrite(GPIO_PORTF_BASE, GPIO_PIN_4, direction);
117      GPIOPinWrite(GPIO_PORTA_BASE, GPIO_PIN_5, direction);
118  }
119  /*****
120  * This function is for enabling the PWM Modules
121  * PWM can be enabled on a pin based on the datasheet
122  *****/
123  void enablePWM(){
124      GPIOPinTypePWM(GPIO_PORTF_BASE, GPIO_PIN_3);
125      GPIOPinConfigure(GPIO_PF3.M1PWM7);
126      GPIOPinTypePWM(GPIO_PORTA_BASE, GPIO_PIN_6);
127      GPIOPinConfigure(GPIO_PA6.M1PWM2);
128      //Count Down Mode
129      PWMGenConfigure(PWM1_BASE, PWM_GEN_3, PWM_GEN_MODE_DOWN | PWM_GEN_MODE_NO_SYNC);
130      PWMGenPeriodSet(PWM1_BASE, PWM_GEN_3, 255); //Load Count value
131      //Count Down Mode
132      PWMGenConfigure(PWM1_BASE, PWM_GEN_1, PWM_GEN_MODE_DOWN | PWM_GEN_MODE_NO_SYNC);
133      PWMGenPeriodSet(PWM1_BASE, PWM_GEN_1, 255); //Load Count value
134      PWMGenEnable(PWM1_BASE, PWM_GEN_3); //Enable the generators
135      PWMGenEnable(PWM1_BASE, PWM_GEN_1);
136      PWMOutputState(PWM1_BASE, PWM_OUT_7_BIT|PWM_OUT_2_BIT, true);
137  }
138  /*****
139  * This function is used to control the speed of the motors
140  * The speed can be changed by the PWMPulseWidthSet() function
141  * lSpeed is used to control the speed of left motor
142  * rSpeed is used to control the speed of right motor
143  *****/
144  void Velocity(uint8_t lSpeed, uint8_t rSpeed){
145      lSpeed=(lSpeed>255)?255:lSpeed;
146      rSpeed=(rSpeed>255)?255:rSpeed;
147      PWMPulseWidthSet(PWM1_BASE, PWM_OUT_7, lSpeed);
148      PWMPulseWidthSet(PWM1_BASE, PWM_OUT_2, rSpeed);
149  }
150

```

6.11 LCD Interfacing

To interface LCD with the microcontroller in default configuration requires 3 control signals and 8 data lines. This is known as 8 bit interfacing mode which requires total 11 I/O lines. To reduce the number of I/Os required for LCD interfacing we can use 4 bit interfacing mode which requires 3 control signals with 4 data lines. In this mode upper nibble and lower nibble of commands/data set needs to be sent separately. The three control lines are referred to as EN, RS, and RW. The LCD connections are given in section 5.6.

Code for Plug and Play Board:

```

1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "inc/hw_types.h"
4  #include "inc/hw_memmap.h"

```

```

5  #include "inc/hw_gpio.h" //To unlock locked pins for GPIO
6  #include "driverlib/sysctl.h"
7  #include "driverlib/gpio.h"
8  #include <math.h>
9  #include <stdlib.h>
10 #ifndef lcdPORT
11 #define lcdPORT GPIO_PORTD.BASE
12 #endif
13 #ifndef lcdDDR
14 #define lcdDDR GPIO_PORTA.BASE
15 #endif
16 #ifndef lcdPIN
17 #define lcdPIN PINC
18 #endif
19 #ifndef RS
20 #define RS GPIO_PIN_6
21 #endif
22 // #ifndef RW
23 // #define RW GPIO_PIN_1
24 // #endif
25 #ifndef EN
26 #define EN GPIO_PIN_7
27 #endif
28 #ifndef D4
29 #define D4 GPIO_PIN_2
30 #endif
31 #ifndef D5
32 #define D5 GPIO_PIN_3
33 #endif
34 #ifndef D6
35 #define D6 GPIO_PIN_4
36 #endif
37 #ifndef D7
38 #define D7 GPIO_PIN_5
39 #endif
40 unsigned char cursorPositionCheck=0;
41
42 void lcdInit();
43 void lcdCommand(unsigned char);
44 void lcdData(unsigned char);
45 void lcdString(char*);
46 void lcdGotoxy(unsigned char, unsigned char);
47 void lcdClear();
48 void lcdCheck();
49 void setupCLK();
50 void peripheralEnable();
51 void configIOPin();
52 void _delay_ms(uint64_t delay);
53 void _delay_us(uint64_t delay);
54
55 int main(){
56 setupCLK();
57 peripheralEnable();
58 configIOPin();
59 lcdInit();
60 lcdGotoxy(0,0);
61 lcdString("TIVA C Series");
62 while(1){
63 }
64 }
65 void setupCLK(){
66 SysCtlClockSet(SYSCTL_SYSDIV_4|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
67 }
68 void peripheralEnable(){
69 SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOA);
70 SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOD);
71 }
72 void configIOPin(){
73 HWREG(GPIO_PORTD_BASE + GPIO_O_LOCK) = GPIO_LOCK_KEY;
74 HWREG(GPIO_PORTD_BASE + GPIO_O_CR) |= (1<<7);
75 HWREG(GPIO_PORTD_BASE + GPIO_O_LOCK) = 0;
76 GPIOPinTypeGPIOOutput(GPIO_PORTD_BASE,EN|RS);
77 GPIOPinTypeGPIOOutput(GPIO_PORTA_BASE,D4|D5|D6|D7);
78 }
79 void lcdInit(){
80 lcdCommand(0x28);

```



```

81      /*****
82      0x30 8bit mode single line*
83      0x38 8bit mode double line*
84      0x20 4bit mode single line*
85      0x28 4bit mode double line*
86      *****/
87      lcdCommand(0x06); //entry mode and auto increment mode
88      lcdCommand(0x0F); //
89      /*****
90      Display off Cursor off      0x08*
91      Display on Cursor on        0x0E*
92      Display on Cursor off       0x0C*
93      Display on Cursor blinking  0x0F*
94      *****/
95  }
96  void lcdCommand(unsigned char command){
97      GPIOPinWrite(lcdPORT,RS|EN,0);
98      GPIOPinWrite(lcdDDR,D4|D5|D6|D7,0);
99      _delay_us(100);
100     GPIOPinWrite(lcdDDR,D4|D5|D6|D7,(command>>2));
101     _delay_ms(1);
102     GPIOPinWrite(lcdPORT,EN|RS,0x80);
103     _delay_us(100);
104     GPIOPinWrite(lcdPORT,EN,0);
105     _delay_us(100);
106     GPIOPinWrite(lcdDDR,D4|D5|D6|D7,(command<<2));
107     _delay_ms(1);
108     GPIOPinWrite(lcdPORT,EN|RS,0x80);
109     _delay_us(100);
110     GPIOPinWrite(lcdPORT,EN,0);
111     _delay_us(100);
112 }
113 void lcdData(unsigned char data){
114     lcdCheck();
115     GPIOPinWrite(lcdPORT,RS|EN,0);
116     GPIOPinWrite(lcdDDR,D4|D5|D6|D7,0);
117     GPIOPinWrite(lcdDDR,D4|D5|D6|D7,(data>>2));
118     _delay_us(100);
119     GPIOPinWrite(lcdPORT,EN|RS,0xc0);
120     _delay_ms(1);
121     GPIOPinWrite(lcdPORT,EN,0);
122     _delay_us(100);
123     GPIOPinWrite(lcdDDR,D4|D5|D6|D7,(data<<2));
124     _delay_us(100);
125     GPIOPinWrite(lcdPORT,EN|RS,0xc0);
126     _delay_us(100);
127     GPIOPinWrite(lcdPORT,EN,0);
128     cursorPositionCheck=(cursorPositionCheck+1)%32;
129 }
130 void lcdString(char* string){
131     unsigned char i=0;
132     while(string[i])
133         lcdData(string[i++]);
134 }
135 void lcdGotoxy(unsigned char x,unsigned char y)
136 {
137     cursorPositionCheck=y*16+x;
138     lcdCommand(0x80+x+(64*y));
139 }
140 void lcdClear(){
141     cursorPositionCheck=0;
142     lcdCommand(0x01);
143     _delay_ms(3);
144 }
145 void lcdCheck(){
146     if(cursorPositionCheck==16)
147         lcdGotoxy(0,1);
148     else if(cursorPositionCheck==0)
149         lcdGotoxy(0,0);
150 }
151 void _delay_ms(uint64_t delay){
152     SysCtlDelay(delay*(SysCtlClockGet()/3000));
153 }
154 void _delay_us(uint64_t delay){
155     SysCtlDelay(delay*(SysCtlClockGet()/3000000UL));
156 }

```

Code for uC based Board

```

1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "inc/hw_types.h"
4  #include "inc/hw_memmap.h"
5  #include "inc/hw_gpio.h" //To unlock locked pins for GPIO
6  #include "driverlib/sysctl.h"
7  #include "driverlib/gpio.h"
8  #include <math.h>
9  #include <stdlib.h>
10 #ifndef lcdPORT
11 #define lcdPORT GPIO_PORTF_BASE
12 #endif
13 #ifndef lcdDDR
14 #define lcdDDR GPIO_PORTD_BASE
15 #endif
16 #ifndef lcdPIN
17 #define lcdPIN PINC
18 #endif
19 #ifndef RS
20 #define RS GPIO_PIN_0
21 #endif
22 #ifndef EN
23 #define EN GPIO_PIN_2
24 #endif
25 #ifndef D4
26 #define D4 GPIO_PIN_4
27 #endif
28 #ifndef D5
29 #define D5 GPIO_PIN_5
30 #endif
31 #ifndef D6
32 #define D6 GPIO_PIN_6
33 #endif
34 #ifndef D7
35 #define D7 GPIO_PIN_7
36 #endif
37 unsigned char cursorPositionCheck=0;
38
39 void lcdInit();
40 void lcdCommand(unsigned char);
41 void lcdData(unsigned char);
42 void lcdString(char*);
43 void lcdGotoxy(unsigned char, unsigned char);
44 void lcdClear();
45 void lcdCheck();
46 void setupCLK();
47 void peripheralEnable();
48 void configIOPin();
49 void _delay_ms(uint64_t delay);
50 void _delay_us(uint64_t delay);
51
52 int main() {
53     setupCLK();
54     peripheralEnable();
55     configIOPin();
56     lcdInit();
57     lcdGotoxy(0,0);
58     lcdString("TIVA C Series");
59     while(1){
60     }
61 }
62 void setupCLK() {
63     SysCtlClockSet(SYSCTL_SYSDIV_4|SYSCTL_USE_PLL|SYSCTL_XTAL_16MHZ|SYSCTL_OSC_MAIN);
64 }
65 void peripheralEnable() {
66     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOF);
67     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOD);
68 }
69 void configIOPin() {
70     HWREG(GPIO_PORTF_BASE + GPIO_O_LOCK) = GPIO_LOCK_KEY;
71     HWREG(GPIO_PORTF_BASE + GPIO_O_CR) |= 0x01;
72     HWREG(GPIO_PORTF_BASE + GPIO_O_LOCK) = 0;
73     GPIOPinTypeGPIOOutput(lcdPORT, EN|RS);

```

```

74     GPIOPinTypeGPIOOutput (lcdDDR, D4|D5|D6|D7);
75 }
76 void lcdInit(){
77     lcdCommand(0x28);
78     /******
79     0x30 8bit mode single line*
80     0x38 8bit mode double line*
81     0x20 4bit mode single line*
82     0x28 4bit mode double line*
83     *****/
84     lcdCommand(0x06); //entry mode and auto increment mode
85     lcdCommand(0x0F); //
86     /******
87     Display off Cursor off      0x08*
88     Display on Cursor on       0x0E*
89     Display on Cursor off      0x0C*
90     Display on Cursor blinking 0x0F*
91     *****/
92 }
93 void lcdCommand(unsigned char command){
94     GPIOPinWrite(lcdPORT, RS|EN, 0);
95     GPIOPinWrite(lcdDDR, D4|D5|D6|D7, 0);
96     _delay_us(100);
97     GPIOPinWrite(lcdDDR, D4|D5|D6|D7, command);
98     _delay_us(100);
99     GPIOPinWrite(lcdPORT, EN|RS, 0x04);
100    _delay_ms(1);
101    GPIOPinWrite(lcdPORT, EN, 0);
102    _delay_us(100);
103    GPIOPinWrite(lcdDDR, D4|D5|D6|D7, (command<<4));
104    _delay_us(100);
105    GPIOPinWrite(lcdPORT, EN|RS, 0x04);
106    _delay_ms(1);
107    GPIOPinWrite(lcdPORT, EN, 0);
108    _delay_us(100);
109 }
110 void lcdData(unsigned char data){
111     lcdCheck();
112     GPIOPinWrite(lcdPORT, RS|EN, 0);
113     GPIOPinWrite(lcdDDR, D4|D5|D6|D7, 0);
114     GPIOPinWrite(lcdDDR, D4|D5|D6|D7, data);
115     _delay_us(100);
116     GPIOPinWrite(lcdPORT, EN|RS, 0x05);
117     _delay_ms(1);
118     GPIOPinWrite(lcdPORT, EN, 0);
119     _delay_us(100);
120     GPIOPinWrite(lcdDDR, D4|D5|D6|D7, (data<<4));
121     _delay_us(100);
122     GPIOPinWrite(lcdPORT, EN|RS, 0x05);
123     _delay_ms(1);
124     GPIOPinWrite(lcdPORT, EN, 0);
125     cursorPositionCheck=(cursorPositionCheck+1)%32;
126 }
127 void lcdString(char* string){
128     unsigned char i=0;
129     while(string[i])
130         lcdData(string[i++]);
131 }
132 void lcdGotoxy(unsigned char x, unsigned char y)
133 {
134     cursorPositionCheck=y*16+x;
135     lcdCommand(0x80+x+(64*y));
136 }
137 void lcdClear(){
138     cursorPositionCheck=0;
139     lcdCommand(0x01);
140     _delay_ms(3);
141 }
142 void lcdCheck(){
143     if(cursorPositionCheck==16)
144         lcdGotoxy(0,1);
145     else if(cursorPositionCheck==0)
146         lcdGotoxy(0,0);
147 }
148 void _delay_ms(uint64_t delay){
149     SysCtlDelay(delay*(SysCtlClockGet()/3000));

```

```
150 }
151 void _delay_us(uint64_t delay){
152     SysCtlDelay(delay*(SysCtlClockGet()/3000000UL));
153 }
154
```

6.12 Analog To Digital Converter

Fire Bird V has three white line sensors, one Sharp IR range sensor with four add-on sockets for additional Sharp IR range sensors, eight Analog IR proximity sensors. All these sensors give analog output. We need to use ADC (Analog to Digital Converter) to convert these analog values in to digital values.

The TM4C123GH6PM ADC module features 12-bit conversion resolution and supports 12 input channels, plus an internal temperature sensor. Each ADC module contains four programmable sequencers allowing the sampling of multiple analog input sources without controller intervention. Each sample sequencer provides flexible programming with fully configurable input source, trigger events, interrupt generation, and sequencer priority.

Due to limited number of sensors in TM4C123GH6PM, an external ADC(ADC128d818) is added to the daughter Board. Details about interfacing this module is given in the next section.

The Connections of internal ADC is as shown below

Plug and Play Board			uC Based Board	
ADC Channel no.	Port	Sensor	Port	Sensor
0	PE3	White line sensor 1	PE3	IR Proximity analog sensor 2
1	PE2	White line sensor 2	PE2	Sharp IR range sensor 2
2	PE1	White line sensor 3	PE1	IR Proximity analog sensor 1
3	PE0	IR Proximity analog sensor 7	PE0	Sharp IR range sensor 1
4	PD3	IR Proximity analog sensor 3	PD3	Sharp IR range sensor 3
5	PD2	Sharp IR range sensor 3	PD2	White line sensor 3
6	PD1	IR Proximity analog sensor 4	PD1	White line sensor 2
7	PD0	IR Proximity analog sensor 2	PD0	White line sensor 1
8	PE5	IR Proximity analog sensor 5	PE5	IR Proximity analog sensor 3
9	PE4	Sharp IR range sensor 5	PE4	IR Proximity analog sensor 4
10	PB4	Sharp IR range sensor 1	PB4	Sharp IR range sensor 5
11	PB5	IR Proximity analog sensor 1	PB5	IR Proximity analog sensor 5

Code for Plug and Play Board:

```
1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "stdlib.h"
4  #include "inc/hw_ints.h"
5  #include "inc/hw_memmap.h"
6  #include "inc/hw_uart.h"
7  #include "inc/hw_gpio.h"
8  #include "inc/hw_pwm.h"
9  #include "inc/hw_types.h"
10 #include "driverlib/adc.h"
11 #include "driverlib/timer.h"
12 #include "driverlib/gpio.h"
13 #include "driverlib/interrupt.h"
14 #include "driverlib/pin_map.h"
15 #include "driverlib/rom.h"
16 #include "driverlib/rom_map.h"
17 #include "driverlib/sysctl.h"
18 #include "driverlib/uart.h"
19 #include "driverlib/udma.h"
20 #include "driverlib/pwm.h"
21 #include "driverlib/ssi.h"
22 #include "driverlib/systick.h"
```

```

23 #include "driverlib/adc.h"
24 #include "utils/uartstdio.h"
25 #include "utils/uartstdio.c"
26 #include <string.h>
27
28 void configCLK();
29 void peripheralEnable();
30 void uartEnable();
31
32 void ADC0Enable();
33 unsigned int readADC();
34 void tranString(char * data, char delimiter);
35 void uartInteger(long long int integer, char delimiter);
36 void converter(unsigned int);
37 void _delay_ms(uint64_t delay);
38 uint32_t senval;
39
40 int main(){
41     configCLK();
42     peripheralEnable();
43     ADC0Enable();
44     uartEnable();
45     while(1){
46         senval = readADC();
47         converter(senval);
48         _delay_ms(1000);
49     }
50 }
51
52 /* *****
53  * This function is used to setup Clock frequency of the controller
54  * It can be changed through codes
55  * In this we have set frequency as 40Mhz
56  * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
57  * ***** */
58 void configCLK(){
59     SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_OSC_MAIN|SYSCTL_XTAL_16MHZ);
60 }
61
62 /* *****
63  * Enabling System Peripherals
64  * PortB and PortD in this case
65  * ***** */
66 void peripheralEnable(){
67     SysCtlPeripheralEnable(SYSCTL_PERIPH_UART1);
68     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOB); //Enabling TIMER0
69     SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOD);
70     SysCtlPeripheralEnable(SYSCTL_PERIPH_ADC0);
71     ADCHardwareOversampleConfigure(ADC0_BASE, 64);
72 }
73
74 /* *****
75  * This function is used to enable UART1
76  * The baudrate is set at 9600
77  * ***** */
78 void uartEnable(){
79     GPIOPinConfigure(GPIO_PB0_U1RX); //Configure Pin B0 as RX of U0
80     GPIOPinConfigure(GPIO_PB1_U1TX); //Configure Pin B1 as TX of U0
81     GPIOPinTypeUART(GPIO_PORTB_BASE, GPIO_PIN_0 | GPIO_PIN_1);
82     UARTConfigSetExpClk(UART1_BASE, SysCtlClockGet(), 9600, (UART_CONFIG_WLEN_8 |
83     UART_CONFIG_STOP_ONE | UART_CONFIG_PAR_NONE));
84 }
85
86 /* *****
87  * This function is used to enable ADC0
88  * 4 step sequencer is used
89  * Change the channel number to use any of the other ADCs
90  * ***** */
91 void ADC0Enable(){
92     ADCSequenceConfigure(ADC0_BASE, 1, ADC_TRIGGER_PROCESSOR, 0);
93     ADCSequenceStepConfigure(ADC0_BASE, 1, 0, ADC_CTL_CH4);
94     ADCSequenceStepConfigure(ADC0_BASE, 1, 1, ADC_CTL_CH4);
95     ADCSequenceStepConfigure(ADC0_BASE, 1, 2, ADC_CTL_CH4);
96     ADCSequenceStepConfigure(ADC0_BASE, 1, 3, ADC_CTL_CH4|ADC_CTL_IE|ADC_CTL_END);
97     ADCSequenceEnable(ADC0_BASE, 1);
98     GPIOPinTypeADC(GPIO_PORTD_BASE, GPIO_PIN_3);
99 }
100
101 /* *****
102  * This function is used to read the value from ADC
103  * Average of 4 values is returned to the calling function
104  * ***** */

```

```

98  *****/
99  unsigned int readADC() {
100      unsigned int Avg;
101      uint32_t ADC0Value[4];
102      ADCIntClear(ADC0.BASE, 1);
103      ADCProcessorTrigger(ADC0.BASE, 1);
104      while(!ADCIntStatus(ADC0.BASE, 1, false));
105      ADCSequenceDataGet(ADC0.BASE, 1, ADC0Value);
106      Avg = (ADC0Value[0] + ADC0Value[1] + ADC0Value[2] + ADC0Value[3] + 2)/4;
107      return (Avg);
108  }
109  /**
110   * This function is used to send the ADC values through UART
111   * Here the value is sent in reverse order
112   *****/
113  void converter(uint32_t q)
114  {
115      unsigned int p;
116      p=q;
117      do
118      {
119          p = (q % 10);
120          UARTCharPut(UART1.BASE,48+(int)p);
121          SysCtlDelay(400000);
122          q = q / 10;
123      }while(q != 0);
124      UARTCharPut(UART1.BASE, ' ');
125  }
126  /**
127   * Calculating Delays
128   *****/
129  void _delay_ms(uint64_t delay){
130      SysCtlDelay(delay*(SysCtlClockGet()/3000));
131  }
132

```

Code for uC based Board

```

1  #include <stdint.h>
2  #include <stdbool.h>
3  #include "stdlib.h"
4  #include "inc/hw_ints.h"
5  #include "inc/hw_memmap.h"
6  #include "inc/hw_uart.h"
7  #include "inc/hw_gpio.h"
8  #include "inc/hw_pwm.h"
9  #include "inc/hw_types.h"
10 #include "driverlib/adc.h"
11 #include "driverlib/timer.h"
12 #include "driverlib/gpio.h"
13 #include "driverlib/interrupt.h"
14 #include "driverlib/pin_map.h"
15 #include "driverlib/rom.h"
16 #include "driverlib/rom_map.h"
17 #include "driverlib/sysctl.h"
18 #include "driverlib/uart.h"
19 #include "driverlib/udma.h"
20 #include "driverlib/pwm.h"
21 #include "driverlib/ssi.h"
22 #include "driverlib/systick.h"
23 #include "driverlib/adc.h"
24 #include "utils/uartstdio.h"
25 #include "utils/uartstdio.c"
26 #include <string.h>
27 #include <math.h>
28
29 void configCLK();
30 void peripheralEnable();
31 void uartEnable();
32 unsigned int Sharp_GP2D12_estimation(uint16_t adc_reading);
33 void ADC0Enable();
34 unsigned int readADC();
35 void tranString(char * data,char delimiter);
36 void uartInteger(long long int integer,char delimiter);
37 void _delay_ms(uint64_t delay);
38 void itoa(long long a,char *arr);
39

```

```

40     int main(){
41         configCLK();
42         peripheralEnable();
43         ADC0Enable();
44         uartEnable();
45
46         while(1){
47             uartInteger(Sharp_GP2D12_estimation(readADC()), ' ');
48             _delay_ms(1000);
49         }
50     }
51     /*****
52     * This function is used to setup Clock frequency of the controller
53     * It can be changed through codes
54     * In this we have set frequency as 40Mhz
55     * Frequency is set by SYSDIV which can be found in data sheet for different frequencies
56     *****/
57     void configCLK(){
58         SysCtlClockSet(SYSCTL_SYSDIV_5|SYSCTL_USE_PLL|SYSCTL_OSC_MAIN|SYSCTL_XTAL_16MHZ);
59     }
60     /*****
61     * Enabling System Peripherals
62     * PortB and PortD in this case
63     *****/
64     void peripheralEnable(){
65         SysCtlPeripheralEnable(SYSCTL_PERIPH_UART1);
66         SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOC);
67         SysCtlPeripheralEnable(SYSCTL_PERIPH_GPIOE);
68         SysCtlPeripheralEnable(SYSCTL_PERIPH_ADC0);
69         ADCHardwareOversampleConfigure(ADC0_BASE, 64);
70     }
71     /*****
72     * This function is used to enable UART1
73     * The baudrate is set at 9600
74     *****/
75     void uartEnable(){
76         GPIOPinConfigure(GPIO_PC4_U1RX); //Configure Pin B0 as RX of U0
77         GPIOPinConfigure(GPIO_PC5_U1TX); //Configure Pin B1 as TX of U0
78         GPIOPinTypeUART(GPIO_PORTC_BASE, GPIO_PIN_5 | GPIO_PIN_4);
79         UARTConfigSetExpClk(UART1_BASE, SysCtlClockGet(), 9600, (UART_CONFIG_WLEN_8 |
UART_CONFIG_STOP_ONE | UART_CONFIG_PAR_NONE));
80     }
81     /*****
82     * This function is used to enable ADC0
83     * 4 step sequencer is used
84     * Change the channel number to use any of the other ADCs
85     *****/
86     void ADC0Enable(){
87         ADCSequenceConfigure(ADC0_BASE, 1, ADC_TRIGGER_PROCESSOR, 0);
88         ADCSequenceStepConfigure(ADC0_BASE, 1, 0, ADC_CTL_CH1);
89         ADCSequenceStepConfigure(ADC0_BASE, 1, 1, ADC_CTL_CH1);
90         ADCSequenceStepConfigure(ADC0_BASE, 1, 2, ADC_CTL_CH1);
91         ADCSequenceStepConfigure(ADC0_BASE, 1, 3, ADC_CTL_CH1 | ADC_CTL_IE | ADC_CTL_END);
92         ADCSequenceEnable(ADC0_BASE, 1);
93         GPIOPinTypeADC(GPIO_PORTC_BASE, GPIO_PIN_2);
94     }
95     /*****
96     * This function is used to read the value from ADC
97     * Average of 4 values is returned to the calling function
98     *****/
99     unsigned int readADC(){
100         unsigned int Avg;
101         uint32_t ADC0Value[4];
102         ADCIntClear(ADC0_BASE, 1);
103         ADCProcessorTrigger(ADC0_BASE, 1);
104         while(!ADCIntStatus(ADC0_BASE, 1, false));
105         ADCSequenceDataGet(ADC0_BASE, 1, ADC0Value);
106         Avg = (ADC0Value[0] + ADC0Value[1] + ADC0Value[2] + ADC0Value[3] + 2)/4;
107         return (Avg);
108     }
109     void itoa(long long a, char *arr){
110         int i=0,j=0;
111         long long tmp=a;
112         if(a<0){
113             arr[i++]='-';
114             tmp*=-1;

```

```

115         j=1;
116     }
117     for (; tmp>0; i++){
118         arr[i]=(tmp%10)+'0';
119         tmp/=10;
120     }
121     arr[i--]='\0';
122     for (; j<i; j++, i--){
123         tmp=arr[i];
124         arr[i]=arr[j];
125         arr[j]=tmp;
126     }
127 }
128 /*****
129 * Calculating Delays
130 *****/
131 void _delay_ms(uint64_t delay){
132     SysCtlDelay(delay*(SysCtlClockGet()/3000));
133 }
134 void uartInteger(long long int integer, char delimiter){
135     char ch[20];
136     itoa(integer, ch);
137     tranString(ch, delimiter);
138 }
139 void tranString(char *data, char delimiter){
140     int k=0;
141     while(data[k]){
142         UARTCharPut(UART1_BASE, data[k++]);
143     }
144     UARTCharPut(UART1_BASE, delimiter);
145 }
146 unsigned int Sharp_GP2D12_estimation(uint16_t adc_reading){
147     float distance;
148     unsigned int distanceInt;
149     distance = (int)(10.00*(2799.6*(1.00/(pow(adc_reading, 1.1546)))));
150     distanceInt = (int)distance;
151     if(distanceInt>800){
152         distanceInt=800;
153     }
154     return distanceInt;
155 }
156

```

6.13 Serial Communication

The Fire Bird V can communicate with other robots / devices serially using either wired link or wireless module. Serial communication is done in asynchronous mode. In the asynchronous mode, the common clock signal is not required at both the transmitter and receiver for data synchronization. As an example of serial communication code for interfacing Zigbee module is given below

6.14 I2C Communication