



Start here - Choose your procedure

ONTAP MetroCluster

NetApp

December 06, 2022

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/upgrade/concept_choosing_an_upgrade_method_mcc.html on December 06, 2022. Always check docs.netapp.com for the latest.

Table of Contents

- Start here - Choose your procedure 1
 - Start here: Choose between controller upgrade, system refresh, or expansion 1
 - Choose a controller upgrade procedure 1
 - Choosing a system refresh method 3

Start here - Choose your procedure

Start here: Choose between controller upgrade, system refresh, or expansion

Depending on the scope of the equipment upgrade, you chose a controller upgrade procedure, a system refresh procedure, or an expansion procedure.

- Controller upgrade procedures apply only to the controller modules. The controllers are replaced with a new controller model.

The storage shelf models are not upgraded.

- In switchover and switchback procedures, the MetroCluster switchover operation is used to provide nondisruptive service to clients while the controller modules on the partner cluster are upgraded.
- In an ARL-based controller upgrade procedure, the aggregate relocation operations are used to nondisruptively move data from the old configuration to the new, upgraded configuration.
- Refresh procedures apply to the controllers and the storage shelves.

In the refresh procedures, new controllers and shelves are added to the MetroCluster configuration, creating a second DR group, and then data is nondisruptively migrated to the new nodes.

The original controllers are then retired.

- Expansion procedures add additional controllers and shelves to the MetroCluster configuration without removing any.

The procedure you use depends on the type of MetroCluster and number of existing controllers.

Upgrade type	Go to...
Controller upgrade	Choose a controller upgrade procedure
System refresh	Choose a system refresh procedure
Expansion	<ul style="list-style-type: none">• Two-node MetroCluster to four• Four-node MetroCluster FC to eight• Four-node MetroCluster IP to eight

Choose a controller upgrade procudure

The controller upgrade procedure you use depends on the platform model, scope of the upgrade, and type of MetroCluster configuration.

Choosing a procedure that does not use aggregate relocation

Type of upgrade or refresh	MetroCluster type	ONTAP version	Procedure
<ul style="list-style-type: none"> Scope: Platform (controller modules) only Method: Automated switchover/switchback 	FC	9.10.1 and later	Upgrading controllers in a four-node MetroCluster FC configuration using switchover and switchback with "system controller replace" commands (ONTAP 9.10.1 and later)
<ul style="list-style-type: none"> Scope: Platform (controller modules) only Method: Automated switchover/switchback 	IP	9.10.1 and later	Upgrade controllers from AFF A700 to AFF A900 in a MetroCluster IP configuration using switchover and switchback (ONTAP 9.10.1 and later)
<ul style="list-style-type: none"> Scope: Platform (controller modules) only Method: Switchover/switchback 	FC	9.8 and later	Upgrading controllers in a MetroCluster FC configuration using switchover and switchback
<ul style="list-style-type: none"> Scope: Platform (controller modules) only Method: Switchover/switchback 	IP	9.8 and later	Upgrading controllers in a MetroCluster IP configuration using switchover and switchback (ONTAP 9.8 and later)

Choosing a procedure using aggregate relocation

Aggregate relocation procedure	MetroCluster type	ONTAP version	Procedure
Using system controller replace commands and swapping the controller module and NVM	FC	9.10.1 and later	Use "system controller replace" commands to upgrade AFF A700 to AFF A900 running ONTAP 9.10.1 RC2 or later
Using system controller replace commands	FC	9.8 and later	Using "system controller replace" commands to upgrade controller hardware running ONTAP 9.8 and later
Using system controller replace commands	FC	9.5 through 9.7	Using "system controller replace" commands to upgrade controller hardware running ONTAP 9.5 to ONTAP 9.7

Aggregate relocation procedure	MetroCluster type	ONTAP version	Procedure
Using manual ARL commands	FC	9.8	Manually upgrade controller hardware running ONTAP 9.8 and later
Using manual ARL commands	FC	9.7 and earlier	Manually upgrade controller hardware running ONTAP 9.7 and earlier

Choosing a system refresh method

The system refresh procedure you use depends on the platform model, scope of the upgrade, and type of MetroCluster configuration.

Scope	Config type	ONTAP support	Go to...
<ul style="list-style-type: none"> • Scope: Platform (controller modules) and storage shelves • Method: Expand the MetroCluster configuration and then remove the old nodes 	FC	9.6 and later	Refreshing a four-node MetroCluster FC configuration
<ul style="list-style-type: none"> • Scope: Platform (controller modules) and storage shelves • Method: Expand the MetroCluster configuration and then remove the old nodes 	IP	9.8	Refreshing a four-node MetroCluster IP configuration (ONTAP 9.8 and later)

Copyright information

Copyright © 2022 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.