



# **IP switch maintenance and replacement**

## **ONTAP MetroCluster**

NetApp  
March 28, 2022

This PDF was generated from [https://docs.netapp.com/us-en/ontap-metrocluster/maintain/task\\_replace\\_an\\_ip\\_switch.html](https://docs.netapp.com/us-en/ontap-metrocluster/maintain/task_replace_an_ip_switch.html) on March 28, 2022. Always check [docs.netapp.com](https://docs.netapp.com) for the latest.

# Table of Contents

- IP switch maintenance and replacement . . . . . 1
  - Replacing an IP switch . . . . . 1
  - Upgrading firmware on MetroCluster IP switches . . . . . 4
  - Upgrade RCF files on MetroCluster IP switches . . . . . 6
  - Renaming a Cisco IP switch. . . . . 8

# IP switch maintenance and replacement

## Replacing an IP switch

You might need to replace a failed switch, or upgrade or downgrade a switch. The new switch can be the same as the old switch when a switch has failed, or you can change the switch type (upgrade or downgrade the switch).

If you want to replace a failed switch with the same type of switch, you only need to replace the failed switch. If you want to upgrade or downgrade a switch, you need to adjust two switches that are in the same network. Two switches are in the same network if they are connected with an inter-switch link (ISL) and are not located at the same site. For example, Network 1 includes IP\_switch\_A\_1 and IP\_switch\_B\_1. Network 2 includes IP\_switch\_A\_2 and IP\_switch\_B\_2 as shown in the diagram below:



This procedure applies when you are using NetApp-validated switches. If you are using MetroCluster-compliant switches, refer to the switch vendor.

If you upgrade or downgrade the networks, you must repeat this procedure for the second network.

### Steps

1. Check the health of the configuration.
  - a. Check that the MetroCluster is configured and in normal mode on each cluster: **metrocluster show**

```
cluster_A::> metrocluster show
```

Cluster	Entry Name	State
Local: cluster_A	Configuration state	configured
	Mode	normal
	AUSO Failure Domain	auso-on-cluster-
disaster		
Remote: cluster_B	Configuration state	configured
	Mode	normal
	AUSO Failure Domain	auso-on-cluster-
disaster		

- b. Check that mirroring is enabled on each node: **metrocluster node show**

```
cluster_A::> metrocluster node show
```

DR	Group	Cluster	Node	Configuration State	DR	Mirroring Mode
	1	cluster_A	node_A_1	configured	enabled	normal
		cluster_B	node_B_1	configured	enabled	normal

2 entries were displayed.

- c. Check that the MetroCluster components are healthy: **metrocluster check run**

```
cluster_A::> metrocluster check run
```

```
Last Checked On: 10/1/2014 16:03:37
```

Component	Result
nodes	ok
lifs	ok
config-replication	ok
aggregates	ok

4 entries were displayed.

Command completed. Use the "metrocluster check show -instance" command or sub-commands in "metrocluster check" directory for detailed results.

To check if the nodes are ready to do a switchover or switchback operation, run "metrocluster switchover -simulate" or "metrocluster switchback -simulate", respectively.

d. Check that there are no health alerts: **system health alert show**

2. Configure the new switch before installation.



If you are upgrading or downgrading the switches, you must configure all the switches in the network.

Follow the steps in the section *Configuring the IP switches* in the [MetroCluster IP installation and configuration](#).

Make sure that you apply the correct RCF file for switch \_A\_1, \_A\_2, \_B\_1 or \_B\_2. If the new switch is the same as the old switch, you need to apply the same RCF file.

If you upgrade or downgrade a switch, apply the latest supported RCF file for the new switch.

3. Run the port show command to view information about the network ports:

```
network port show
```

4. Disconnect the ISL connections from the remote switch that connect to the old switch.

You should disconnect the ISL connections from the ports on the IP\_switch\_A\_1 that connect to IP\_switch\_B\_1.

5. Power off the switch, remove the cables and physically remove IP\_switch\_B\_1.

6. Install the new switch.

Cable the new switch first (including the ISLs) according to the steps in the *Cabling the IP switches* section in the [MetroCluster IP installation and configuration](#).



The used ports might be different from those on the old switch if the switch type is different. If you are upgrading or downgrading the switches, do **NOT** cable the local ISLs. Only cable the local ISLs if you are upgrading or downgrading the switches in the second network and both switches at one site are the same type.

#### 7. Power up the switch or switches.

If the new switch is the same, power up the new switch. If you are upgrading or downgrading the switches, then power up both switches. The configuration can operate with two different switches at each site until the second network is updated.

#### 8. Verify that the MetroCluster configuration is healthy by repeating step 1.

If you are upgrading or downgrading the switches in the first network, you might see some alerts related to local clustering.



If you upgrade or downgrade the networks, then repeat all of the steps for the second network.

## Upgrading firmware on MetroCluster IP switches

You might need to upgrade the firmware on a MetroCluster IP switch.

You must repeat this task on each of the switches in succession.

### Steps

#### 1. Check the health of the configuration.

- Check that the MetroCluster is configured and in normal mode on each cluster:

```
metrocluster show
```

```
cluster_A::> metrocluster show
Cluster              Entry Name              State
-----
Local: cluster_A     Configuration state      configured
                      Mode                      normal
                      AUSO Failure Domain      auso-on-cluster-
disaster
Remote: cluster_B     Configuration state      configured
                      Mode                      normal
                      AUSO Failure Domain      auso-on-cluster-
disaster
```

- Check that mirroring is enabled on each node:

```
metrocluster node show
```

```
cluster_A::> metrocluster node show
```

DR	Group	Cluster	Node	Configuration	DR	Mirroring	Mode
				State			
	-----			-----			
1		cluster_A					
			node_A_1	configured		enabled	normal
		cluster_B					
			node_B_1	configured		enabled	normal

2 entries were displayed.

c. Check that the MetroCluster components are healthy:

```
metrocluster check run
```

```
cluster_A::> metrocluster check run
```

Last Checked On: 10/1/2014 16:03:37

Component	Result
-----	-----
nodes	ok
lifs	ok
config-replication	ok
aggregates	ok

4 entries were displayed.

Command completed. Use the "metrocluster check show -instance" command or sub-commands in "metrocluster check" directory for detailed results.

To check if the nodes are ready to do a switchover or switchback operation, run "metrocluster switchover -simulate" or "metrocluster switchback -simulate", respectively.

d. Check that there are no health alerts:

```
system health alert show
```

2. Install the software on the first switch.



You must install the switch software on the switches in the following order: switch\_A\_1, switch\_B\_1, switch\_A\_2, switch\_B\_2.

Follow the steps for installing switch software in the relevant topic of the *MetroCluster IP Installation and Configuration* information depending on whether the switch type is Broadcom or Cisco:

- [Downloading and installing the Broadcom switch EFOS software](#)
- [Downloading and installing the Cisco switch NX-OS software](#)

3. Repeat the previous step for each of the switches.
4. Repeat Step 1 to check the health of the configuration.

## Upgrade RCF files on MetroCluster IP switches

You might need to upgrade an RCF file on a MetroCluster IP switch. For example, an ONTAP upgrade or a switch firmware upgrade both require a new RCF file.

### Ensure that the RCF file is supported

If you are changing the ONTAP version running on the switches, you should ensure that you have an RCF file that is supported for that version. If you use the RCF generator, the correct RCF file will be generated for you.

#### Steps

1. Use the following commands from the switches to verify the version of the RCF file:

From this switch...	Issue this command...
Brocade switch	(IP_switch_A_1) # show clibanner
Cisco switch	IP_switch_A_1# show banner motd

For either switch, find the line in the output that indicates the version of the RCF file. For example, the following output is from a Cisco switch, which indicates the RCF file version is “v1.80”.

```
Filename : NX3232_v1.80_Switch-A2.txt
```

2. To check which files are supported for a specific ONTAP version, switch, and platform, use the RcfFileGenerator. If you can generate the RCF file for the configuration that you have or that you want to upgrade to, then it is supported.
3. To verify that the switch firmware is supported, refer to the following:
  - [Hardware Universe](#)
  - [NetApp Interoperability](#)

### Upgrade RCF files

If you are installing new switch firmware, you must install the switch firmware before upgrading the RCF file.

#### About this task

This procedure disrupts traffic on the switch where the RCF file is upgraded. Traffic will resume once the new RCF file is applied.

#### Steps

1. Verify the health of the configuration.



- a. Verify that the MetroCluster components are healthy:

```
metrocluster check run
```

```
cluster_A::*> metrocluster check run
```

The operation runs in the background.

- a. After the `metrocluster check run` operation completes, run `metrocluster check show` to view the results.

After approximately five minutes, the following results are displayed:

```
-----
::*> metrocluster check show

Last Checked On: 4/7/2019 21:15:05

Component          Result
-----
nodes               ok
lifs                ok
config-replication ok
aggregates          warning
clusters            ok
connections         not-applicable
volumes             ok
7 entries were displayed.
```

- b. Check the status of the running MetroCluster check operation:

```
metrocluster operation history show -job-id 38
```

- c. Verify that there are no health alerts:

```
system health alert show
```

2. Prepare the IP switches for the application of the new RCF files.

Follow the steps for your switch vendor:

- [Resetting the Broadcom IP switch to factory defaults](#)
- [Resetting the Cisco IP switch to factory defaults](#)

3. Download and install the IP RCF file, depending on your switch vendor:

- [Downloading and installing the Broadcom IP RCF files](#)
- [Downloading and installing the Cisco IP RCF files](#)

Update the switches in the following order:

- a. Switch\_A\_1
- b. Switch\_B\_1
- c. Switch\_A\_2
- d. Switch\_B\_2

## Renaming a Cisco IP switch

You might need to rename a Cisco IP switch to provide consistent naming throughout your configuration.

In the examples in this task, the switch name is changed from `myswitch` to `IP_switch_A_1`.

1. Enter global configuration mode:

**configure terminal**

The following example shows the configuration mode prompt. Both prompts show the switch name of `myswitch`.

```
myswitch# configure terminal
myswitch(config) #
```

2. Rename the switch:

**switchname new-switch-name**

If you are renaming both switches in the fabric, use the same command on each switch.

The CLI prompt changes to reflect the new name:

```
myswitch(config) # switchname IP_switch_A_1
IP_switch_A_1(config) #
```

3. Exit configuration mode:

**exit**

The top-level switch prompt is displayed:

```
IP_switch_A_1(config) # exit
IP_switch_A_1#
```

4. Copy the current running configuration to the startup configuration file:

```
copy running-config startup-config
```

5. Verify that the switch name change is visible from the ONTAP cluster prompt.

Note that the new switch name is shown, and the old switch name (myswitch) does not appear.

- a. Enter advanced privilege mode, pressing **y** when prompted:

```
set -privilege advanced
```

- b. Display the attached devices:

```
network device-discovery show
```

- c. Return to admin privilege mode:

```
set -privilege admin
```

The following example shows that the switch appears with the new name, IP\_switch\_A\_1:

```
cluster_A::storage show> set advanced
```

Warning: These advanced commands are potentially dangerous; use them only when directed to do so by NetApp personnel.

Do you want to continue? {y|n}: y

```
cluster_A::storage show*> network device-discovery show
```

Node/ Protocol Platform	Local Port	Discovered Device	Interface	
-----				
node_A_2/cdp				
	e0M	LF01-410J53.mycompany.com (SAL18516DZY)	Ethernet125/1/28	N9K-
C9372PX				
	e1a	IP_switch_A_1 (FOC21211RBU)	Ethernet1/2	N3K-
C3232C				
	e1b	IP_switch_A_1 (FOC21211RBU)	Ethernet1/10	N3K-
C3232C				
.				
.				
.			Ethernet1/18	N9K-
C9372PX				
node_A_1/cdp				
	e0M	LF01-410J53.mycompany.com (SAL18516DZY)	Ethernet125/1/26	N9K-
C9372PX				
	e0a	IP_switch_A_2 (FOC21211RB5)	Ethernet1/1	N3K-
C3232C				
	e0b	IP_switch_A_2 (FOC21211RB5)	Ethernet1/9	N3K-
C3232C				
	e1a	IP_switch_A_1 (FOC21211RBU)		
.				
.				
.				

16 entries were displayed.

## Copyright Information

Copyright © 2022 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.