


## OpenStudio: HVAC

1. Add weather and climate info
  - a. Weather file (.epw) - CAN\_ON\_Ottawa-Macdonald-Cartier.Intl.AP.716280\_CWEC2016
  - b. Design day (.ddy) - CAN\_ON\_Ottawa-Macdonald-Cartier.Intl.AP.716280\_CWEC2016.ddy
  - c. More locations
    - i. <https://energyplus.net/weather>
    - ii. [https://climate.weather.gc.ca/prods\\_servs/engineering\\_e.html](https://climate.weather.gc.ca/prods_servs/engineering_e.html)
2. (add infiltration object – it's an internal load object, not HVAC)
  - a. Oddly, **Infiltration** objects can only be made by dragging an infiltration object from the library, and then editing the inputs




Whole building ELA = 134 cm<sup>2</sup>, assume cracks/gaps, evenly distributed based on volume

Zone	Volume (m <sup>3</sup> )	ELA (cm <sup>2</sup> )
Attic	259.01	51
First_storey	199.14	40
Second_storey	217.92	43

2 – storey house:  $C_s = 0.00029$

shelter class – 3:  $C_w = 0.000231$


- b. Add an always on schedule in the **Loads** tab (where the other internal gain objects are located)
3. Add thermostat – **first and second storey only**
  - By **default**, OpenStudio creates a dual setpoint thermostat; **at all times**, the **cooling** and **heating** setpoints are **active** and form upper (cooling setpoint) and lower (heating setpoint) limits for the zone temperature.
    - a. Create two schedules (Temperature, continuous)
      - i. heating setpoint of 21 °C
      - ii. cooling setpoint 24°C
    - b. In the thermal zones tab , drop the heating and cooling setpoints under their respective thermostat schedule columns
4. Turn on Ideal Air Loads

Thermal Zones							
HVAC Systems		Cooling Sizing Parameters	Heating Sizing Parameters	Custom			
Name	All	Rendering Color	Turn On Ideal Air Loads	Air Loop Name	Zone Equipment	Cooling Thermostat Schedule	Heating Thermostat Schedule
	<input type="checkbox"/>		<input type="checkbox"/>		<input type="text"/>	<input type="text"/>	<input type="text"/>
			Apply to Selected		Apply to Selected	Apply to Selected	Apply to Selected
attic	<input type="checkbox"/>		<input type="checkbox"/>		<input type="text"/>	<input type="text"/>	<input type="text"/>
first_storey	<input type="checkbox"/>		<input checked="" type="checkbox"/>		<input type="text"/>	cooling_setpoint	heating_setpoint
garage	<input type="checkbox"/>		<input type="checkbox"/>		<input type="text"/>	<input type="text"/>	<input type="text"/>
second_storey	<input type="checkbox"/>		<input checked="" type="checkbox"/>		<input type="text"/>	cooling_setpoint	heating_setpoint

- At every timestep, the load of each zone is estimated, and then the ideal air system will supply as much air at the supply air temperature (default 50°C and 13°C for heating and cooling respectively) needed to meet the demand.
- The ideal air system is used to estimate the heating/cooling demand of a zone/building. Based on the current zone temperature and the heating & cooling setpoint. No outdoor air; actual zone load.

#### 4.1 Select output variables


- Zone air heat balance system air transfer rate
- Zone air temperature




- Review output table
  - Total energy
  - End use


- Setpoint not met

5. Remove the ideal system and add a “packaged rooftop unit”



5.1

- Remove sizing period simulation runs
- Add the thermal zone to the demand side of the air loop (by default, the **Control zone** in the **SetpointManager:SingleZone:Reheat** (  ) object should be the **first\_storey**)
- Set heater efficiency to 96% and cooling coil COP to 3
- Set the outdoor air system's controller' outdoor air flowrate to **0**.
- Run the simulation and compare the results to the ideal system. Are the results different?
- Set the outdoor air system's controller' outdoor air flowrate to **Autosized**.
- Add **Design Specification Outdoor Air Objects** (based on ASHRAE 62.1)
  - outdoor air per person flowrate –  $0.0035 \text{ m}^3/\text{s}/\text{person}$
  - outdoor air per area flowrate –  $0.00015 \text{ m}^3/\text{s}$
- Set the system to size the **Total** load in the **Sizing:System** object (access it by clicking on the dotted line between the **Supply Equipment** and **Demand Equipment** in the air loop)



**OS:SizingSystem**

Type of Load to Size On  
☐ Total

Design Outdoor Air Flow Rate  
☐ Hard Sized  m³/s  
☒ Autosized Autosize

Central Heating Maximum System Air Flow Ratio  
☒ Hard Sized  1  
☐ Autosized Autosize

Preheat Design Temperature  
 7 °C

Preheat Design Humidity Ratio  
 0.008 kg<sub>water</sub>/kg<sub>air</sub>





Precool Design Temperature  
 12.8 °C

Precool Design Humidity Ratio  
 0.008 kg<sub>water</sub>/kg<sub>air</sub>

Central Cooling Design Supply Air Temperature  
 12.8 °C

Central Heating Design Supply Air Temperature  
 40 °C

Simulation Options

6. Run the simulation and validate the HVAC results
  - a. The energy results in the End Use Table doesn't seem out of the ordinary until you review the number of unmet hours ("Not met hours"). There is a bunch of hours where the cooling and heating setpoints aren't met because the first storey is the control zone and the second storey is the slave zone. The HVAC is controlled to turn on and off according to the needs of the first storey, which is usually appreciably thermally different from the needs of the second storey, so they're out of step from each other.
7. Switch **SetpointManager:SingleZone:Reheat** to **SetpointManager:Coldest** by selecting it from the Library tab on the right (scroll down until you start to see SetpointManager objects)
  - Set the min and max to 13°C and 40°C, respectively
    - Heating mode
      - Assume max flowrate
      - Calculates the setpoint required by each zone
      - Selects the highest setpoint
      - The result is the lowest setpoint temperature possible to meet all zones
    - Cooling mode
      - Uses minimum setpoint temperature
8. Add ERV, defrost air method: exhaust air recirculation
9. Adding domestic hot water
  - a. Create water load profile (schedule)
  - b. Create hot water temperature target – 60°C (schedule)
  - c. Create a **Water Use Equipment Definition** object in the **internal gains**  tab
    - i. Peak flowrate 0.000083 m³/s
    - ii. Drag and drop the hot water temperature target schedule
  - d. In the **HVAC**  tab, create a new **Service Hot Water Plant Loop**
    - i. On the demand side, click on the **Water Use Connection** 
    - ii. Delete the existing **Water Use Equipment Definition** 

- iii. Drag the **Water Use Equipment Definition** created in step c into the empty spot
  - iv. Select location and rate fraction schedule
  - e. Set the water tank's
    - i. Volume to autosize
    - ii. Deadband 2
    - iii. Heating capacity to 4 kW
    - iv. Fuel type to electricity
    - v. Thermal efficiency to 1
    - vi. On & off cycle parasitic fuel consumption to 0
      - 1. Pilot light, electronic control
      - 2. (default for commercial, resident 0)
    - vii. Ambient temperature indicator to ThermalZone
    - viii. Ambient temperature thermal zone name to first\_storey
    - ix. On/off cycle loss coefficient to ambient temperature
      - 1. Default 6 W/K is appropriate for a large tank
      - 2. For this exercise, 1.3 W/K is used for Skin loss, UA- factor (part of UEF, SL metric)
    - x. Loss fraction to ambient, 1 = all to zone
    - xi. Pump head ~ 200/300 Pa for a house
    - xii. OS:Waterheater:sizing
      - 1. Time for tank recovery – rule of thumb 2 hours for electric, 1 hour for gas
10. Overall TEUI 62 kWh/m<sup>2</sup> → very low

## Things to take note of

...look at PPT