

## Setup the clock

- 1.) Press and hold the MODE button (in the middle)
- 2.) Release the button quickly if the part you want to change is displayed!
- 3.) The parts are:
  - a. DATE „stay holding the button, you press the right one“ ☺
  - b. AL setup of alarm time
  - c. LED setup of led signalling
  - d. DIMM setup of dimmer
  - e. CL setup of clock time and date
- 4.) Use the PLUS button to change the value
- 5.) Use the MODE button to go on

AL: minute -> hour -> alarm on/off

LED: case 0...15 (try out)

DIMM: case 0...9 : 0=no dimming, 9=only dimming between 7 -19 o'clock

CL: year -> month -> day -> minute -> hour

## SWING-Mode:

In Swing-Mode clock changes the display between time, date, temperature after some time. If Swing-Mode is off you can change the display by pressing MODE/PLUS button.

How to change the swing-mode on/off?:

- Press the PLUS button AND the RESET button.
- Then release only the RESET button.
- After two seconds you can also release the PLUS button.

## US- or EU-MODE

You can switch between US or EU mode. That means MM/DD or DD/MM for the date and Fahrenheit or Celsius for the temperature.

How to switch US/EU mode ?:

- Press the PLUS + MODE + RESET button.
  - Then release only the RESET button.
  - After two seconds release the other buttons.
- (Sometimes that doesn't work, make sure LED and DIMMER are at value 0 then !)