

Marstek Device Open API (REV 0.5)

Draft Document for Internal Circulation

I . Preface

Welcome to this document! This document primarily introduces the Local API of Marstek devices, which you can use to obtain device information and control devices in a peer-to-peer (P2P) manner. This API is open to all users but is only applicable for local connections, effectively ensuring the security of your data and devices. For remote access to the devices, it is recommended to use the Marstek APP and its cloud services.

II. General Description

Marstek devices communicate with third-party devices over a Local Area Network (LAN). Therefore, before using this API, please ensure that the Marstek device has been correctly connected to the home network and that the Local API feature has been enabled in the Marstek APP. It should be noted that different Marstek devices have limitations in supporting the commands listed in the API documentation. Moreover, after enabling the Local API feature, some native functions of the device may be disabled to avoid command conflicts. For more detailed descriptions regarding the range of supported commands and functional deactivations for different devices, please refer to Chapter 4 of this document.

2.1 First-Time Use

2.1.1 API over UDP

When users first use the Local API service, they need to follow the configuration process below:

- Connect the device to power and turn it on;
- Use the Marstek APP to connect and bind the device, and configure the WiFi network for the device or connect it to the Ethernet;
- Enable the device's native API feature in the APP, and set the UDP port number. The default port number is 30000, and the recommended port number is between 49152 and 65535

After completing the above operations, the Marstek device can normally receive UDP commands from the same local area network.

2.1.2 API over MQTT

pending

2.1.3 API over TCP

pending

2.2 Protocol Format

The protocol utilizes the JSON format, with commands primarily categorized into query commands, configuration commands, and certain special commands.

Command Format

| Property | Type | Description |
|----------|------------------|-------------------------------------|
| id | number or string | Identifier of this request. |
| method | string | Name of the procedure to be called. |
| params | object | Parameters that the method takes. |

Example

```
{
  "id": 0,
  "method": "string",
  "params": {
    "id": 0
  }
}
```

Device Response Format

| Property | Type | Description |
|----------|------------------|------------------------------------|
| id | number or string | Identifier of this request. |
| src | string | Name of the source of the request. |
| result | object | Parameters that the method takes. |

Example

```
{
  "id": 0,
  "src": "device",
  "result": {
    "id": 0
  }
}
```

2.3 Discovering Devices

To discover Marstek devices within the LAN, a UDP broadcast is utilized. The broadcast content is as follows:

```
{
  "id": 0,
  "method": "Marstek.GetDevice",
  "params": {
    "ble_mac": "0"
  }
}
```

If there are Marstek devices within the LAN, taking Venus C as an example, the following response will be received

```
{
  "id": 0,
  "src": "VenusC-123456789012",
  "result": {
    "device": "VenusC",
    "ver": 111,
    "ble_mac": "123456789012",
    "wifi_mac": "123456789012",
    "wifi_name": "MY_HOME",
    "ip": "192.168.1.11"
  }
}
```

The device's IP address can be directly obtained from the Marstek APP or the home router. If this functionality is to be used on a long-term basis, it is recommended to configure the device with a static IP address.

III. Components

This chapter mainly introduces the components and services supported by the Marstek device.

3.1 Marstek

Marstek contains some basic information about the product, and is mainly used for discovering devices and querying basic device information.

- Marstek.GetDevice: Locate Marstek devices on the local area network;
- Marstek.GetStatus: Query the basic operating information of the device; *(pending)*

3.1.1 Marstek.GetDevice

Sending:

| Property (params) | Type | Description |
|-------------------|--------|---|
| ble_mac | string | Valid MAC, can be used to identify a specific device. |

Response:

| Property (result) | Type | Description |
|-------------------|--------|-------------------------|
| device | string | Device model |
| ver | number | Device firmware version |
| ble_mac | string | Bluetooth MAC |
| wifi_mac | string | WiFi MAC |
| wifi_name | string | WiFi name |
| ip | string | Device IP |

Example:

Sending

```
{
  "id": 0,
  "method": "Marstek.GetDevice",
  "params": {
    "ble_mac": "123456789012"
  }
}
```

Response:

```
{
  "id": 0,
  "src": "VenusC-123456789012",
  "result": {
    "device": "VenusC",
    "ver": 111,
    "ble_mac": "123456789012",
    "wifi_mac": "012123456789",
    "wifi_name": "MY_HOME",
    "ip": "192.168.1.11"
  }
}
```

3.2 WiFi

The WiFi component is mainly used for configuring the device's WiFi and obtaining the device's basic network information.

- `Wifi.GetStatus`: Obtain the device's basic network information;

3.2.1 Wifi.GetStatus

Sending:

| Property (params) | Type | Description |
|-------------------|---------------|----------------|
| id | <i>number</i> | ID of Instance |

Response:

| Property (result) | Type | Description |
|-------------------|-----------------------|----------------------|
| id | <i>number</i> | ID of Instance |
| wifi_mac | <i>string</i> | WiFi MAC |
| ssid | <i>string or null</i> | WiFi name |
| rssi | <i>number</i> | WiFi signal strength |
| sta_ip | <i>string or null</i> | Device IP |
| sta_gate | <i>string or null</i> | Gateway |
| sta_mask | <i>string or null</i> | Subnet mask |
| sta_dns | <i>string or null</i> | DNS |

Example:

Sending:

```
{
  "id": 1,
  "method": "Wifi.GetStatus",
  "params": {
    "id": 0
  }
}
```

Response:

```

{
  "id": 1,
  "src": "VenusC-mac",
  "result": {
    "id": 0,
    "ssid": "Hame",
    "rssi": -59,
    "sta_ip": "192.168.137.41",
    "sta_gate": "192.168.137.1",
    "sta_mask": "255.255.255.0",
    "sta_dns": "192.168.137.1"
  }
}

```

3.3 Bluetooth

The BLE (Bluetooth) component can view the Bluetooth-related information of the device.

- BLE.GetStatus: Check the Bluetooth connection status of the device;

3.3.1 BLE.GetStatus

Sending:

| Property (params) | Type | Description |
|-------------------|---------------|----------------|
| id | <i>number</i> | ID of Instance |

Response:

| Property (result) | Type | Description |
|-------------------|---------------|-----------------|
| state | <i>string</i> | Bluetooth state |
| ble_mac | <i>string</i> | Bluetooth MAC |

Example:

Sending:

```

{
  "id": 1,
  "method": "BLE.GetStatus",
  "params": {
    "id": 0
  }
}

```

Response:

```
{
  "id": 1,
  "src": "VenusC-mac",
  "result": {
    "id": 0,
    "state": "connect",
    "ble_mac": "50cf14640fac"
  }
}
```

3.4 Battery

The Bat (Battery) component contains basic information about the device's battery.

- Bat.GetStatus: Query the device's battery information and operating status.

3.4.1 Bat.GetStatus

Sending:

| Property (params) | Type | Description |
|-------------------|---------------|----------------|
| id | <i>number</i> | ID of Instance |

Response:

| Property (result) | Type | Description |
|-------------------|-----------------------|----------------------------------|
| id | <i>number</i> | ID of Instance |
| soc | <i>string</i> | soc |
| charg_flag | <i>boolean</i> | Charging permission flag |
| dischrg_flag | <i>boolean</i> | Discharge permission flag |
| bat_temp | <i>number or null</i> | Battery temperature, [°C] |
| bat_capacity | <i>number or null</i> | Battery remaining capacity, [Wh] |
| rated_capacity | <i>number or null</i> | Battery remaining capacity, [Wh] |

Example:

Sending:

```
{
  "id": 1,
  "method": "Bat.GetStatus",
  "params": {
    "id": 0
  }
}
```

Response:

```
{
  "id": 1,
  "src": "VenusC-mac",
  "result": {
    "id": 0,
    "soc": 90,
    "charg_flag": true,
    "dischrg_flag": true,
    "bat_temp": 25.0,
    "bat_capacity": 256.0,
    "rated_capacity": 2560.0,
    "error_code": "0x430"
  }
}
```

3.5 PV

The PV (Photovoltaic) component contains the photovoltaic information connected to the device.

- PV.GetStatus: Query the device's connected photovoltaic information and power generation status;

3.5.1 PV.GetStatus

Sending:

| property (params) | Type | Description |
|-------------------|---------------|----------------|
| id | <i>number</i> | ID of Instance |

Response:

| Property (result) | Type | Description |
|-------------------|---------------|------------------------------------|
| id | <i>number</i> | ID of Instance |
| pv_power | <i>number</i> | Photovoltaic charging power, [W] |
| pv_voltage | <i>number</i> | Photovoltaic charging voltage, [V] |

| Property (result) | Type | Description |
|-------------------|---------------|------------------------------------|
| pv_current | <i>number</i> | Photovoltaic charging current, [A] |

Example:

Sending:

```
{
  "id": 1,
  "method": "PV.GetStatus",
  "params": {
    "id": 0
  }
}
```

Response:

```
{
  "id": 1,
  "src": "VenusC-mac",
  "result": {
    "id": 0,
    "pv_power": 580.0,
    "pv_voltage": 40.0,
    "pv_current": 12.0
  }
}
```

3.6 ES

The ES (Energy System) component contains the device's basic power information and energy statistics, and can configure or monitor the device's operating status.

- ES.GetStatus: Query the device's basic electrical energy information;
- ES.SetMode: Configure the device's operating mode;
- ES.GetMode: Get information about the operating mode of the device;

3.6.1 ES.GetStatus

Sending:

| Property (params) | Type | Description |
|-------------------|-----------------------|----------------|
| id | <i>number or null</i> | ID of Instance |

Response:

| Property (result) | Type | Description |
|--------------------------|-----------------------|--|
| id | <i>number or null</i> | ID of Instance |
| bat_soc | <i>number or null</i> | Total battery SOC, [%] |
| bat_cap | <i>number or null</i> | Total battery capacity, [Wh] |
| pv_power | <i>number or null</i> | Solar charging power, [W] |
| ongrid_power | <i>number or null</i> | Grid-tied power, [W] |
| offgrid_power | <i>number or null</i> | Off-grid power, [W] |
| bat_power | <i>number or null</i> | Battery power, [W] |
| total_pv_energy | <i>number or null</i> | Total solar energy generated, [Wh] |
| total_grid_output_energy | <i>number or null</i> | Total grid output energy, [Wh] |
| total_grid_input_energy | <i>number or null</i> | Total grid input energy, [Wh] |
| total_load_energy | <i>number or null</i> | Total load (or off-grid) energy consumed, [Wh] |

Example:

Sending:

```
{
  "id": 1,
  "method": "ES.GetStatus",
  "params": {
    "id": 0
  }
}
```

Response:

```
{
  "id": 1,
  "src": "VenusE-24215edb178f",
  "result": {
    "id": 0,
    "bat_soc": 98,
    "bat_cap": 5120,
    "pv_power": 0,
    "ongrid_power": 100,
    "offgrid_power": 0,
    "bat_power": 501,
    "total_pv_energy": 0,
    "total_grid_output_energy": 2548,
    "total_grid_input_energy": 3273,
```

```
    "total_load_energy": 0
  }
}
```

3.6.2 ES.SetMode (*pending*)

Sending:

| Property (params) | Type | Description |
|-------------------|--------|----------------|
| id | number | ID of Instance |
| config | object | |

Object: config

| Property (config) | Type | Description |
|-------------------|---------------|---|
| mode | <i>string</i> | Device power generation mode, including the following modes: "Auto"; "AI"; "Manual"; "Passive". |
| auto_cfg | <i>object</i> | Configuration parameters for Auto mode |
| ai_cfg | <i>object</i> | Configuration parameters for AI mode |
| manual_cfg | <i>object</i> | Configuration parameters for Manual mode |
| passive_cfg | <i>object</i> | Configuration parameters for Passive mode |

Object: auto_cfg

| Property (auto_cfg) | Type | Description |
|---------------------|--------|------------------------------|
| enable | number | ON: 1; OFF: Set another mode |

Object: ai_cfg

| Property (ai_cfg) | Type | Description |
|-------------------|--------|------------------------------|
| enable | number | ON: 1; OFF: Set another mode |

Object: manual_cfg

| Property (manual_cfg) | Type | Description |
|-----------------------|--------|---|
| time_num | number | Time period serial number, Venus C/E supports 0-9 |

| Property (manual_cfg) | Type | Description |
|-----------------------|--------|---|
| start_time | string | Start time, hours: minutes, [hh:mm] |
| end_time | string | End time, hours: minutes, [hh:mm] |
| week_set | number | Week, a byte 8 bits, the low 7 bits effective, the highest invalid, 0000 0001 (1) on behalf of Monday open, 0000 0011 (3) on behalf of Monday and Tuesday open, 0111 1111 (127) on behalf of a week |
| power | number | Setting power, [W] |
| enable | number | ON: 1; OFF: 0 |

Object: passive_cfg

| Property (passive_cfg) | Type | Description |
|------------------------|--------|----------------------|
| power | number | Setting power, [W] |
| cd_time | number | Power countdown, [s] |

Response:

| Property (result) | Type | Description |
|-------------------|---------|---|
| id | number | ID of Instance |
| set_result | boolean | "true": succeeded in setting "false": failed in setting |

Example:

Sending:

```

/* Auto Mode Example */
{
  "id": 1,
  "method": "ES.SetMode",
  "params": {
    "id": 1,
    "config": {
      "mode": "Auto",
      "auto_cfg": {
        "enable": 1
      }
    }
  }
}

```

```

/* AI Mode Example */
{
  "id": 1,
  "method": "ES.SetMode",
  "params": {
    "id": 1,
    "config": {
      "mode": "AI",
      "ai_cfg": {
        "enable": 1
      }
    }
  }
}

/* Manual Mode Example */
{
  "id": 1,
  "method": "ES.SetMode",
  "params": {
    "id": 1,
    "config": {
      "mode": "Manual",
      "manual_cfg": {
        "time_num": 1,
        "start_time": "08:30",
        "end_time": "20:30",
        "week_set": 127,
        "power": 100,
        "enable": 1
      }
    }
  }
}

/* Passive Pattern Example */
{
  "id": 1,
  "method": "ES.SetMode",
  "params": {
    "id": 1,
    "config": {
      "mode": "Passive",
      "passive_cfg": {
        "power": 100,
        "cd_time": 300
      }
    }
  }
}

```

Response:

```

{
  "id": 1,
  "src": "Venus-mac",
  "result": {
    "id": 1,
    "set_result": ture
  }
}

```

3.6.3 ES.GetMode

Sending:

| Property (params) | Type | Description |
|-------------------|----------------|----------------|
| id | number or null | ID of Instance |

Response:

| Property (result) | Type | Description |
|-------------------|----------------|--|
| id | number or null | ID of Instance |
| mode | number or null | Auto: Auto mode; AI: AI mode; Manual: manual mode; Passive: Passive control mode |
| ongrid_power | number or null | Grid-tied power, [W] |
| offgrid_power | number or null | Off-grid power, [W] |
| bat_soc | number or null | SOC, [%] |

Example:

Sending:

```

{
  "id": 1,
  "method": "ES.GetMode",
  "params": {
    "id": 0
  }
}

```

Response:

```
{
  "id": 1,
  "src": "VenusE-24215edb178f",
  "result": {
    "id": 0,
    "mode": "Auto",
    "ongrid_power": 100,
    "offgrid_power": 0,
    "bat_soc": 98
  }
}
```

IV . Devices

This chapter will describe the extent of support for the components and services in this API documentation by different Marstek devices, as well as some proprietary information.

4.1 Venus C/E

- Marstek
- Battery
- ES

pending

V . Change Logs

This chapter explains the change log for the API documentation.

- 20250514 Add: Configuring automatic, manual, and AI mode information description and examples.
- 20250529 Modified: Version number REV 0.4
- 20250704 Modified: Version number REV 0.5