

**REL**  
ACOUSTICS LTD.

**AirShip  
Quick  
Start  
Guide**

## REL AirShip Quick Start Guide

For full manual, please visit [rel.net/AirShipManual](http://rel.net/AirShipManual)


- 1 Remove transmitter and receiver from packaging
- 2 Place transmitter near audio source
- 3 Place receiver near REL, note that this comes with a bracket to bolt onto the amplifier panel

### Transmitter Connections

High Level Connection

- Connect Supplied Neutrik SpeakOn High Level Interconnect

### Standard High Level



- If your system is a Class D, differential or mono block design, please consult the manual for your REL or the User Guides at REL.net

### **.1/LFE Connection**

- Connect RCA cable from the .1/LFE Input of the AirShip Transmitter to the Preamp Output or Sub LFE Output of the theater processor



### **Receiver Connections**



- Plug barrel connection into transmitter, then plug AC/DC converter into AC wall receptacle
- Turn on switch to power transmitter
- Plug barrel connection into receiver, then plug AC/DC converter into AC wall receptacle
- Turn on switch to power receiver
- When correctly paired, the LEDs on both units will stop flashing and stay solid
- In the event that the transmitter and receiver do not automatically pair, simply exercise the momentary "PAIR" button on the receiver until the LED flashes
- Then exercise the "PAIR" button on the transmitter

## **FCC STATEMENT**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

*Reorient or relocate the receiving antenna.*

*Increase the separation between the equipment and receiver.*

*Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*

*Consult the dealer or an experienced radio/TV technician for help.*

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

## **REL Acoustics Limited**

North Road, Bridgend Industrial Estate . Bridgend, CF31 3TP . United Kingdom

Telephone: +44 (0)1 656 768 777 . Fax: +44 (0) 1 656 766 093

Web: [www.rel.net](http://www.rel.net)