

User Manual

Ekster electronic wallet Senate


Congratulations with new your EKSTER® wallet.

TABLE OF CONTENTS

- Feature overview
- How to establish a connection?
- If you lose your wallet
- If you lose your phone
- How do I reset my wallet
- Battery & charging the wallet
- FAQ - Frequently Asked Questions




THE PARLIAMENT



1. Card slider system
2. USB charger port
3. Reset button
4. Extra card pockets
5. Phone home button
6. Hidden coin pocket
7. Card slider trigger

THE SENATE



1. USB charger port
2. Reset button
3. Segregated card distribution
4. Removable cash strap
5. Phone ringer button
6. Card slider trigger

How to establish a connection

1. Download the App



Download the TrackR app from the [Apple App Store](#) or the [Google Play Store](#).

2. Turn on Bluetooth




Make sure your phone's Bluetooth is turned ON, and open the TrackR app.

3. Register (optional)

A screenshot of the TrackR app's registration screen. At the top, there is a back arrow, the TrackR logo, and a home icon. Below the logo is the text "SIGN UP" and a note: "Register once the device is powered on and people are detected nearby". The screen contains four input fields: "Full Name", "Email address", "Password", and "Confirm Password". At the bottom is a "Register" button. The background of the screen is decorated with various icons representing different types of items that can be tracked, such as keys, a wallet, a phone, a car, a house, a dog, a cat, a backpack, a suitcase, a camera, a watch, a bike, a stroller, a shopping bag, a coffee cup, a book, a pen, a pencil, a ruler, a compass, a map, a clock, a calendar, a notepad, a folder, a trash can, a recycling symbol, a lightbulb, a gear, a wrench, a screwdriver, a hammer, a saw, a drill, a power drill, a saw blade, a drill bit, a screw, a nail, a bolt, a nut, a washer, a gasket, a seal, a plug, a socket, a switch, a fuse, a battery, a motor, a pump, a valve, a hose, a pipe, a wire, a cable, a cord, a plug, a socket, a switch, a fuse, a battery, a motor, a pump, a valve, a hose, a pipe, a wire, a cable, a cord.

Register for CrowdGPS. You will receive an email to confirm your account. When done, select "Register"

4. Select "Add new Device"




Select "Add new device" in the app.

5. Select Bravo Icon




Select Bravo Icon (top icon / option in the menu).

6. Turn on Bluetooth




Press the Ekster logo on the wallet. You should hear a beep and the LED light should blink.

7. Select device



Select the Ekster Wallet icon.

8. Item Settings



Name your wallet and set your personal preferences in the settings menu.

If you lose your wallet


1. Go to the application



2. Press the sound button




3. Wallet will ring




If you lose your phone

1. Go to the application



2. Press the sound button






Due to Bluetooth 4.0 technology, the maximum range between the wallet and the phone is approximately 30 meters or 90 feet.


How do I reset my wallet or pair a new device

1. Go to Settings



If you want to pair a new device to your tracker, or if you have deleted your device in your tracker item settings, you must reset your wallet.

2. Delete Device




Delete Device from TrackR app in item settings and close down the TrackR app.

3. Use the reset pin



Use the reset pin provided in the packaging and hold pin in reset hole.

4. Press button



When the device is reset, press the button on your wallet, you should hear a beep and the led light should blink.

Battery & charging

1. Battery life

We recommend you to fully charge your wallet battery upon receipt of the product in order to maximize it's battery life. When the battery is low, the LED light on the wallet will blink. Please note; the battery lasts longer than 6 months but we advise to fully charge every 6 months.

2. Whilst charging



When plugged in, the LED light is on to indicate charging. When the battery is fully charged, the LED light turns off. The tracker device will be fully charged within 2 hours.

FCC Caution Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a Particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

CAUTION:Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

IC Caution

This Class B digital apparatus complies with Canadian ICES-003 and RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.