



1201786
User's Guide



Bluetooth® Portable Transmitter

We hope you enjoy your Bluetooth Portable Transmitter from RadioShack. This transmitter allows you to turn your non-Bluetooth device into a Bluetooth-enabled device for wireless streaming. Please read this user's guide before using your transmitter.

Package Contents

- Bluetooth Portable Transmitter
- USB charging cable
- User's Guide

Specifications


Battery Type.....	Built-in 300 mAh lithium polymer
Bluetooth Protocol.....	Version 2.1
Support Profile.....	A2DP
Operating Distance.....	33 ft. (10 m)
Battery Charge Time.....	Approx. 3 Hours
Operating Time.....	Up to 5 Hours
Charging Port.....	Micro USB
Charging Cable Length.....	3 ft. (0.91m)

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.



2

Charge




Notes:

- You can charge the transmitter when it is idle or in use.
- Transmitter battery is low when the red LED flashes every 8 seconds. Charge the transmitter.
- A full charge takes about 3 hours, and provides up to 5 hours play time.
- Unplug the charging cable when charging is complete. Do not attempt to overcharge.
- Use only the supplied cable, or one with the same specification to charge. Use of any other cables may damage the transmitter.

3

Pairing



Bluetooth-enabled receiving devices

Plug the transmitter into the 1/8" (3.5 mm) audio output port on your stereo non-Bluetooth device before you start pairing.

Pair a new device:

1. Activate the Bluetooth function and enter pairing mode on your Bluetooth-enabled stereo receiver device. (Refer to your device's user's guide)
2. Press and hold the button on the transmitter for 3 seconds to turn on the transmitter. The transmitter enters pairing mode and the red and blue LED flashes alternatively as it searches to pair with a new device. When paired, the blue LED lights steadily.

Pair a previously paired device:

1. Activate the Bluetooth function on your Bluetooth-enabled stereo receiver device.
2. Press and hold the button on the transmitter for 3 seconds to turn on the transmitter. The LED flashes blue while reconnecting to the device for 20 seconds. When paired, the blue LED lights steadily.

4

Note:

- Turn off the transmitter when not in use. Press and hold the transmitter button until the red LED flashes three times.
- If your device is out of connection range and disconnects, move back within 20 seconds to reconnect automatically.
- If you cannot reconnect the transmitter to your device, restart the transmitter and repeat pairing mode again (see "Pair a new device").
- If connection between transmitter and device is lost for more than 20 seconds, the device will be deleted from the memory. Pair as a new device again.

Changing Bluetooth Devices

The transmitter automatically reconnects to the most recently paired device when switched on. To pair a new device, you must disconnect your current device's Bluetooth connection with the transmitter. With your transmitter and device connected (LED lights blue), press the transmitter button twice. The LEDs flash blue and red alternatively. Follow the instructions in "Pair a new device" to connect to a new device.

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

5

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your equipment. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

Go to www.radioshack.com/help for details. RadioShack Customer Relations
300 RadioShack Circle, Fort Worth, TX 76102

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by General Wireless Operations Inc. is under license.

RoHS Complies with the European Union's "Restriction of Hazardous Substances Directive," which protects the environment by restricting specific hazardous materials and products.



© 2016 General Wireless Operations Inc. All rights reserved. RadioShack is a registered trademark used by General Wireless Operations Inc. dba RadioShack. radioshack.com

12A16
1201786
Printed
in China

6