



BetterSpot

The Smart VPN Router
Manual Instruction

BetterSpot Technologies Inc.


Address: PO Box 42241 Vancouver Main, Vancouver BC, V6B 3Z7

Email: support@betterspot.com

www.betterspot.com

What's in the box?

1. Router
2. Ethernet cable
3. AC adaptor
4. USB cable
5. Instruction Manual



Specification

Interfaces:

Ethernet: 2x 100Mbps

Wireless: 802.11bgn 2T/2R (2x2:2)

Networking:

Data transfer rate up to 300Mbps on Wi-Fi

Wi-Fi operating band: 2.4 Ghz

Transmit Power: < 20 dBm

Power:

5V/1A microUSB power cable

Dimension & Weight:

Depth: 1.16 in (2.9 cm)

Width: 3.14 in (8 cm)

Height: 3.14 in (8 cm)

Weight: 0.7 lb (317g)

Betterspot App

Use Betterspot app for ease of use. You can install the app on iOS, Android, or use web admin

(by navigating to admin.betterspot.com in your browser).

The Betterspot app can be used for the followings:

Device Modes: VPN: Connect to increase your security and privacy and choose between multiple server locations.

Tor: You can switch to Tor anonymity network and surf anonymously. Direct: You can also turn the VPN off. Betterspot can function like a normal router. Server Location: Using

Betterspot app, you can select your

favorite server from the menu. Support:

Our support team is available to help you for as long as it takes! You can contact support@betterspot.com for assistance.




Download the app

Setting

You can connect your Betterspot to internet source via cable or Wi-Fi.

Connection via cable:

- ① Turn on Betterspot
- ② Plug in the input cable to connect Betterspot to the internet source.
- ③ Now connect your device to Betterspot using Wi-Fi and enter the password. (Default password is betterspot)



Default
password is:
betterspot

*"We are suggesting to
change your
access point password
after the first
connection."*





Connecting via Wi-Fi

- ① On your device, choose Settings >Wi-Fi>Betterspot XX
- ② Enter your access point or router password.
(Default password is betterspot)
- ③ Open admin.betterspot.com on your favorite browser or you can use the app.
- ④ Choose a password for your admin panel.
- ⑤ Click on the button labeled "Cable" on the top left of the panel, then choose your Wi-Fi source from the list.
- ⑥ Enter the Wi-Fi source's password.
- ⑦ Press Connect button.

***ATTENTION:** If you forget the admin panel password, you must do a factory reset. (press the reset button for 10 second then release the button). You will then need to connect your device to Betterspot and try the setup process again.

- 1 On your device Choose
Settings >Wi-Fi>Betterspot XX





Terms

You can check BetterSpot terms and policy at

www.betterspot.com/terms *



Read the terms

Please consider that:

Any changes to the router caused by not following the instruction will render the terms null and void.

Any changes to the router caused by modifying the PCBA, components or case will render the terms null and void.

Any changes to the router caused by inappropriate use, e.g. inappropriate voltage input, high temperature, power fluctuations, dropping in water or on the ground will render the terms null and void.

***By using the device you accept Betterstop Terms of Use and Terms of Service available at: Betterstop.com**

Warnings:

Never expose Betterspot to rain, snow, any liquid, dusty environment or in direct sunlight.

Never place Betterspot against wall or put anything on top of the Betterspot. This will obstruct heat dissipation.

Never unplug the device during the update (about 10 minutes). Place Betterspot in a secure place to avoid inadvertent use by children.

Cleaning

Do NOT wash Betterspot.

Dust Betterspot with a dry clean pad.

Environment

Operating Humidity: 10% to 90% non-condensing

Storage Humidity: 5% to 90% non-condensing

Operating Temperature: -5 to 40°C

Storage Temperature: -40 to 70°C

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the users' authority to operate the equipment.

FCC Caution

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
3. To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons.
4. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

IC Statement

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

This radio transmitter (identify the device by certification number, or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio (identifier le dispositif par son numéro de certification ou son numéro de modèle s'il fait partie du matériel de catégorie I) a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

IC Caution

The minimum separation generally be used is at least 20 cm, even if the calculations indicate that the MPE distance would be lesser.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

La séparation minimale généralement utilisée est d'au moins 20 cm, même si les calculs indiquent que la distance MPE serait moindre.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.