



# DRONOID™

## MODULAR DRONES



### INSTALLATION OF STARTER KIT



1. Attach 4 propeller guards to arms. Secure by screw, do not overtighten.
2. Install propellers.  
ATTENTION - Note diagram for installation of 2A and 2B. Propellers are marked A or B. A1/A2/A3/A4 are same; B1/B2/B3/B4 are same. Secure by screw. Do not overtighten.


3. Plug the Head, Landing Gear and Camera to body. Push firmly in place.
4. To remove head rotate 90° and pull out.
5. Plug installed Propeller Guard/Propellers to the Drone arm. Plug into Body. Push firmly in place.
6. If Dronoid does not fly properly recheck all attachments and make sure propellers are connected properly.



Do not mix old and new batteries.  
Do not mix alkaline, standard (carbon-zinc) or rechargeable(nickel-cadmium)batteries.

### Control Directions

1. Press 2 Buttons for emergency stop.  
All propellers will shut down
2. Power On/Off Button
3. Headless Function Button
4. Direction control stick
5. Photo Button
6. Video Button
7. Lean right Trimming
8. Backward trimming
9. Right Turn trimming
10. Left turn trimming
11. Accelerator
12. Speed control
13. One key return (long press)
14. Lean Left trimming
15. Forward trimming



1. Press the Power On/Off button to turn on the controller, Power Indicator will light up (Indication will flashing when controller battery is low) . when Pairing, 3 MODE LED light will flashing. And one of MODE LED will stay light up when pairing successfully. When received a single will have a beep sound). After pairing successfully, you can control your DRONE, TANK or ROVER now.
2. ONE KEY RETURN : When the drone is flying, press this ONE KEY Return, the drone will fly back to where it started.
3. left / right rotation trim  
As the Drone lifts off, if the drone rotation right, adjust the left trim rotation. If the drone rotation left, adjust the right trim rotation
4. Forward/backward rotation trim  
As the drone lifts off, if the drone moves forward, adjust the backward trim rotation, if the drone rotation move backward, adjust the forward trim rotation.
5. Lean left / right trim  
As the drone lifts off, if the drone rotates right, adjust the left trim rotation. If the drone rotates left, adjust the right trim rotation.
6. When the camera module is installed, press "take photo" button to take photo. Photos store on Micro SD

7. When the camera module is installed, press "take video" button to take video. Video stores on Micro SD card, press "take video" button again to stop recording.
8. Three different speed modes – slow/middle/high speed (works together with Accelerator)
9. Headless function : This button sets direction according to the direction of the remote control
10. Direction control stick –  
Controlling drone – forward,backward, lean left and lean right.  
Controlling Tank & Rover - forward / Backward , turn left and turn right.
11. Joy stick forward/backward, controls accelerator. Left and right controls right and left turn.
12. Pairing – LED is flashing when pairing. After connection, LED will stay on.
13. Speed control button + headless button - emergency stop (when in Drone mode)

### INSTALLATION OF ROVER KIT



#### Transform Drone to ROVER


1. Remove the arms and legs of the Dronoid from the body
2. Attach Rover wheels to the body (as shown)

#### Control ROVER

Control the Rover by using the Direction control stick (4). Set at three different speeds by Speed Control (12).



### INSTALLATION OF TANK KIT



#### Transform Drone to TANK

1. Remove the arms and legs of the Dronoid from the body
2. Attach Tank treads to the body (as shown)

#### Control TANK

Control the Tank by using the Direction control stick (4). Set at three different speeds by Speed Control (12).



### FOR WIFI CAMERA



For Android mobile, please scan QR code from mobile and download the APP.

For iPhone, please download JH WIFI from Apple Store. APP will appear as JH WIFI in mobile device.

PLUG the camera module as picture show :



Turn on the Drone, the LED on camera will flash for pairing.

When connected and paired you can view images from Dronoid using the APP on your mobile device.

Clip can hold mobile phone to view while operating.



# DRONOID™

## MODULAR DRONES

CAUTION:  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

PATENT PENDING/  
SERIAL #87/224-147  
TechnoLabs  
524 Broadway  
7th floor  
New York, NY 10012  
Contact us  
INFO@GODRONOID.COM