


# 1/10 Scale RC Vehicle Instruction Manual



## BATTERY INSTALLATION

### IMPORTANT

Please note the vehicle uses a 7.2V Rechargeable Battery Pack and the Battery Pack is charged by a charger

### BATTERY LOADING

Please charge the rechargeable battery for 4 hours prior to use  
(WARNING: Never over than 6 hours - overcharging will cause permanent damage to the battery.)

1. Plug the battery charger into wall outlet (See Diagram #1)
2. Connect the battery pack with the charger. Make sure the battery pack is secure with charger.
3. To disconnect, pull out the plug of the battery from the charger (See Diagram #1)
4. You should charge the battery pack for 6 hours the first two times. Then subsequent charges will only require 4 hours.
5. After charging for 4 hours, the battery will be warm. This condition is normal for fully charged batteries.
6. If the speed of the car slows down suddenly, it is time to recharge.
7. After use, the battery pack will be hot. Wait at least 20 minutes until it cools before recharging. Recharging a warm or hot battery pack will greatly shorten the use life of the battery.
8. The vehicle must be used with the recommended transmitter.
9. The transmitter is not a toy.

### BATTERY PACK CARE

- If battery pack and connector are wet, thoroughly dry before charging.
- We recommend unplugging the battery pack if battery pack will not be used for several days.

### ATTENTIONS PARENTS

It is recommended that this toy and all accessories to be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

### HOW TO INSTALL BATTERY IN VEHICLE

1. Turn over the vehicle and push the ON/OFF to "OFF" position. (See Diagram #2)
2. Insert the 7.2V battery pack into battery compartment.
3. Replace the battery cover

## HOW TO INSTALL BATTERY IN TRANSMITTER

1. Open the battery compartment and insert one 9V battery according to (+) and (-) symbols located in the battery compartment (See Diagram #3)
2. Replace the battery compartment cover ensuring that it closed securely  
Note: Remove battery after you have finished using your vehicle

## HOW TO PLAY

### START TO PLAY

1. Attach the antenna to the top of the transmitter ensuring that is screwed until fully secure (See Diagram #4)
2. Push the ON/OFF switch to the "ON" position of the vehicle (See Diagram #6)

### FORWARD & REVERSE RUNNING

3. To make the car forward and reverse, pull or push the trigger in the transmitter respectively. (See Diagram #7/8)

### FRONT WHEELS STEERING ADJUSTMENT

4. If the vehicle does not run straight forward, adjust the lever for satisfactory alignment on the underside of the vehicle (See Diagram #9)
5. If the vehicle runs towards left, turn "Steering Alignment Lever" towards "R".
6. If the vehicle runs towards right, turn "Steering Alignment Lever" towards "L"

### STEERING OPERATION

7. Turn the steering wheel forward or backward while pulling the trigger backward at the same time, the car will turn right or left and run forward. (See Diagram #10)
8. Turn the steering wheel forward or backward while pushing the trigger forward at the same time, the car will turn right or left and reverse. (See Diagram #11)

### STOP OPERATION

9. Release the trigger, the vehicle will stop (See Diagram #12)

### BATTERY CAUTIONS

1. For maximum performance, use rechargeable batteries.
2. Do not mix old and new batteries.
3. Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
4. Do not recharge non-rechargeable battery.
5. Ensure the batteries are inserted with the correct polarity.
6. Remove batteries when vehicle is not in use.

8. Rechargeable batteries should only be charged under adult supervision.
9. Remove rechargeable batteries from toy before charging.
10. The supply terminals are not to be short-circuited.
11. The antenna are not inserted into socket outlet.

## NOT SUITABLE FOR CHILDREN UNDER 3 YEARS OF AGE DUE TO SMALL PARTS

- (Diagram #1) <1> 7.2V battery pack  
<2> Wall outlet  
<3> Battery Charger  
<4> Connect battery pack and battery  
(Diagram #2) <5> On/Off switch  
<6> Battery Cover  
<7> Unscrew to open the battery compartment  
<8> 7.2V battery pack  
(Diagram #3) <9> Battery Panel of transmitter  
<10> 9V 6F22 battery  
(Diagram #4) <11> Antenna  
<12> Transmitter  
(Diagram #5) <13> LED  
(Diagram #6) <14> On  
(Diagram #7) <15> Trigger  
<16> Forward  
<17> Forward arrow  
(Diagram #8) <18> Backward  
<19> Reverse  
(Diagram #9) <20> Steering alignment lever  
(Diagram #10) <21> Steering Wheel  
(Diagram #11) <22> Steering Wheel  
(Diagram #12) <23> Stop



MADE IN CHINA



SPECIFICATIONS, COLORS AND CONTENTS MAY VARY FROM ILLUSTRATIONS.  
changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.