

Thank you for buying MS wireless set. In your set you will find: keyboard, mouse, nano receiver and 3xAAA batteries.

Fitting batteries in the keyboard

Turn the keyboard upside down and remove the battery compartment cover by putting pressure on the recess and carefully pushing the cover upwards. Insert the batteries (1 batteries, type AAA, 1.5 V) in the battery compartment of the keyboard. Ensure that the battery poles correspond to the "+" and "-" markings. Slide the battery compartment cover back on until it locks into place.

Fitting batteries in the mouse

Turn the mouse upside down and remove the battery compartment cover by putting pressure on the recess and carefully pushing the cover upwards. Insert the battery (type AAA x 2, 1.5 V) in the battery compartment of the mouse. Ensure that the battery poles correspond to the "+" and "-" markings. Slide the battery compartment cover back on until it locks into place.

USING KEYBOARD AND MOUSE

Connecting the receiver

Turn the computer On and insert the USB Nano receiver in the corresponding USB socket of your PC. Position both the keyboard and mouse so they are comfortable to use. Ensure that both the keyboard and mouse are less than 10m from the USB receiver dongle.

Mouse switch On/Off

Move switch to ON position when you want to use mouse. When you won't not use mouse for some time, turn switch to OFF position. This way you will save energy consumption.

TROUBLESHOOTING

If the mouse and keyboard stop working please try following:

- Check the polarity (+/-) on batteries, maybe they are not inserted correctly.
- Change batteries for new ones if necessary.
- If your mouse is not working well, try to use it on mouse pad.
- Make sure the USB Receiver is plugged into a USB and the computer is on.
- Connect the receiver into the USB port and press the mouse's middle & right buttons for about 5 seconds and release. The mouse will move the onscreen cursor to indicate a successful connection.
- Press the ESC+ = keys on the keyboard for another 5 seconds. The battery low indicator will flash to indicate a connection.

Cautions:

- Read all instructions carefully and keep this manual for future reference. Please install the appliance with the instruction guide to use.
- Risk of explosion if battery is replaced by an incorrect type and dispose of used batteries according to the instructions.
- Do not use water, detergents, abrasive cleaning liquids or chemical agents to clean the appliance.
- Before you clean the appliance, take the battery out.
- If the appliance is not used for a long time, please take the battery out.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.