



5F63E8B Instruction Manual



CAUTION-ELECTRIC TOY:

Not recommended for children under 8 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

CAUTION-SUPERVISION REQUIRED-

ELECTRIC TOY- UNPLUG WHEN NOT IN USE.



Contents

1. Vehicle x 1
2. Transmitter x 1
3. Truggy Shell with Straddle Bar x 1
4. Truggy Spoiler x 1
5. Truggy Wheels x 4
6. Rechargeable Battery Pack x 1
7. USB Charge Cable x 1
8. Wall charger x 1
9. Replacement Screw x 2
10. Screw Driver x 1
11. Clips x 2
12. Instruction Manual x 1






Transmitter Function & Battery Installation

Battery Charging & Installation




Driving Operation

Wheel Alignment



Note: If vehicle steers to the left, adjust trimmer to the right.
If vehicle steers to the right, adjust trimmer to the left.

Customizing Vehicle



ISSUE	CAUSE	CORRECTION
• Vehicle does not work, red LED on transmitter is flashing SLOWLY.	• Battery in transmitter is low.	• Replace batteries with new 4x 1.5V AA batteries (Alkaline batteries are recommended)
• Vehicle does not work, red LED on transmitter is ON, red LED on vehicle is OFF.	• Rechargeable battery is not well connected to the vehicle.	• Un-plug and plug rechargeable battery into the vehicle, ensure red LED on vehicle is ON.
• Vehicle does not work, red LED on transmitter is ON, red LED on vehicle flashes SLOWLY.	• Rechargeable battery is low.	• Re-charge the vehicle by following charging instruction on page 1. Make sure USB charging cable is well connected to the battery pack. Note: RED light in USB will turn ON while charging. RED light will turn OFF to indicate charge is complete.
• Vehicle runs by itself after vehicle and transmitter are turned ON.	• Trigger of transmitter is not in the correct position.	• Turn vehicle and transmitter OFF. Next, turn steering wheel of transmitter counter clockwise and turn transmitter ON at the same time. Note: Do not touch trigger of transmitter during this step.
• Vehicle can't be controlled after running a period of time.	• Interfered by other radio device nearby. • Vehicle out of range. • Low battery.	• Move to an open area with no interference. • Lift up transmitter and move close to vehicle. • Check battery light on vehicle. If RED light flashes, vehicle needs to be re-charged. If RED light is not flashing, check the batteries in the transmitter.
• Vehicle is not driving straight.	• Front wheel alignment is off.	• Refer to wheel alignment section on page 2 to adjust.
• Vehicle stops running suddenly.	• Vehicle safety feature triggered. • Low battery voltage.	• Release trigger immediately, then pull it again, vehicle should recover. • Turn vehicle and transmitter OFF, then turn ON.
• Vehicle starts to run very slowly and steering becomes difficult.	• Battery power is not enough.	• Charge rechargeable battery pack.
• Vehicle suspension is malfunctioning.	• Suspension hooks have detached.	• Re-attach and secure suspension hooks onto the chassis.
• If vehicle is not responding to the transmitter.	• Vehicle and transmitter need to be RESET and paired once again.	• Ensure both vehicle and transmitter are in the "OFF" position. Next, turn the transmitter's wheel clockwise and turn "ON" the transmitter all at the same time. Once the red light on the transmitter flashes quickly, reset is successful. Then turn ON the vehicle. RED light inside vehicle will flash. When lights on transmitter and vehicle stop flashing, they have been successfully paired. Note: If multiple vehicles are being paired at the same time and in the same area, there will be interference. As a result, each vehicle must be paired individually. Warning: Do not touch trigger of transmitter while pairing.

ATTENTION

For safe operation of your Vehicle, keep the wheels free from materials that can bind them, including hair, fibers dust, grit, etc., and keep the battery connection clean and dry. Wipe down your Vehicle if it gets dirty. It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced. Inspect the included battery charger (transformer) and the battery for damage to wiring, plugs, enclosures, and other parts before each operation. If any parts are damaged, the charger should be discarded or replaced.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

BATTERY CAUTIONS

• Non-rechargeable batteries are not to be recharged. • Rechargeable batteries are only to be charged under adult supervision. • Different types of batteries or new and used batteries are not to be mixed. • Only batteries of the same or equivalent type as recommended are to be used. • Battery chargers used with toy are to be regularly examined for damage to the cord, plug, enclosure and other parts, and that, in the event of such damage. • Batteries are to be inserted with the correct polarity. • Exhausted batteries are to be removed from the toy. • The supply terminals are not to be short-circuited. • The toy must not be used with this charger until the damage has been repaired. • Keep packaging and instruction manual because they contain important information.


DRIVING CAUTIONS



Do not drive Vehicle on public streets or highways, as this could cause serious accidents, personal injuries, and/or proper damage.



Do not drive the Vehicle in the water, as this could damage the vehicle.



Do not deliberately run into hard objects, as this may cause damage the Vehicle.



CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.
INPUT: 100-240VAC -60Hz MAX 0.2A
OUTPUT: 5VDC 500mA

Do not mix old and new batteries.
Do not charge old and new batteries (carbon-zinc), or rechargeable batteries.

