

User Manual

Dear Customer, Thank you for buying ZHEJIANG SUNSEA LIGHTING ELECTRICAL APPLIANCE CO., LTD RLF. Please read carefully the product instruction before using!

The models of SSBT5-28W-L011 ,SSBT5-21W-L011, SSBT5-14W-L011, SSBT5-13W-L011, use only on 120 volt, 60Hz circuit. The wattage marked on the lamp. And the operating Frequency is more than 40kHz and less than 60kHz

Features

Energy Saves up to 70% compared to common incandescent Lamps

Two years limited warrant;

Rapid on/off with silent operation;

Reduces Carbon Dioxide Electromagnetic Volume

Consumes natural resources

Generate less heat in the building

Note & Attention

Always turn-off power before re-lamping;

Avoid installing lamp by gripping the glass tube;

Do not use with electronic timers

Reliable operating temperature -15 ~55

Not suitable for damp surroundings or sealed occasions

Risk of electric shock-use in dry locations

For best result use in proper voltage range as mentioned on lamp base

Applications:

Home, Office, Hotel, Shop, Restaurant...and so on lighting

Warning:

This product do not dismantle two side plugs arbitrarily, replaces when the tube must shut off the power source. Dimmer is not compatible, does not have the waterproof function. The power source out-port connects identical model product 3 at most, otherwise burns out the live wire the danger.

FCC Information

1. This device complies with Part 18 of the FCC Rules.

2. Information on the following matters shall be provided to the user in the Instruction manual:


(a) The interference potential of the device or system;

(b) Maintenance of the system;


(c) Simple measures that can be taken by the user to correct interference;

(d) Manufacturers of RF lighting devices must provide an advisory statement, either on the product packaging or with other user documentation, similar to the following: This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating is between 40kHz and 60kHz. Variations of this language are permitted provided all the points of the statement are addressed and may be presented in any legible font or text style.

To Mount The Light Fixture in Horizontal Position




To Mount The Light Fixture in Vertical Position



To Mount The Light Fixture in Vertical Position


Fig. 1 (side view)



1. Prelocate the fixture with one (1) of the "L" mounting tap attached and premark the center. Remove mounting tap and secure onto the mounting surface by a screw provided. Secure the lamp by insert a mounting tap into the slot of the light fixture and slide the fixture forward until it come to a stop.


Mounting Surface

Fig. 2



2. Insert the remaining mounting tap into the slot at the other side of the light fixture at halfway and secure it with a screw provided, then slide the fixture back to even position.

To Link The Light Fixtures Together (skip this step if single (1) light is installed)



3. Mount the light within 10 inches apart (center to center of the mounting tap approximate 10-5/8 apart)

Fig. 3

4. SEE NOTE No. 3 Insert the extension cord

Power Cord