




TWS2

True Wireless stereo Earbuds

www.edifier.com

■ Product Description and Accessories



There are different size of ear tips attached in the package, please select the suitable ones to wear.

Note: Images are for illustrative purposes only and may differ from the actual product.

■ User Guide

● Charge the Earbuds

During using, if red light instead of blue light flashes, it indicates the earbuds are at low battery level, please use them after fully charged.

Charging: place the earbuds in the charging case


Red light steady lit=charging Red light off=fully charged

● Charge the Charging Case


If one single light on the left side flashes six times rapidly, it indicates the charging case has low battery capacity, please charge it in time.

Indicator lights respectively flashing and lighting up from left to right = charging

Indicator lights steady lit = fully charged



Rated input: 5V $\overline{\text{---}}$ 60mA(earbuds)



5V $\overline{\text{---}}$ 500mA(charging case)

Warning: The rechargeable batteries that provide power for this product must be disposed properly for recycling. Do not dispose of batteries in fire to prevent an explosion.

- **Power On/Off**

1. Power on

- Power on automatically when taken out of the charging case;
- When without charging case, press the multi-function button to power on.

2. Power off

- Power off automatically while placed in the charging case;
- When without charging case, press and hold the multi-function button for 7 seconds to power off.

- **Bluetooth Connection**

1. **Two Earbuds Mode**

- Open the charging case to take two earbuds out, they will automatically turn on and make TWS interconnection;
- Press and hold the multi-function button of the left earbud to enter pairing state, the red and blue lights will flash rapidly;
- Set mobile phone to search and connect to this product model, after pairing is successful, the blue light will flash slowly.

[Note: the earbuds will automatically enter Bluetooth pairing mode when used for the first time.](#)

2. **One Earbud Mode**

If use one earbud only, please take the left or right earbud out of the charging case, and refer to the procedures mentioned in “Two Earbuds Mode” to pair it with mobile phone.

- **TWS Pairing of the Left and Right Earbuds**

The left and right earbuds have finished TWS pairing before leaving factory. If the wireless connection fails to resume, please follow the steps below to re-pair:

- When not connected with mobile phone, take two earbuds out and respectively double press the multi-function buttons of the left and right earbuds to enter TWS pairing state, the blue lights will flash rapidly;
- Make two earbuds close to each other, after pairing is done the blue lights of both earbuds will flash slowly.

- **Clear pairing records**

Place the earbuds in the charging case, respectively press and hold the multi-function buttons of the left and right earbuds for six seconds until the blue lights flash six times rapidly, and then the pairing records have been cleared.

■ Functional Operation Instructions

● Music Playback Mode (same operation for the left and right earbuds)



Previous track: triple press

Next track: double press

Pause/play: single press

Enable voice assistant: press and hold for around 2 seconds

● Call Mode (same operation for the left and right earbuds)



Accept/end a call: single press

End a call: single press

Decline a call: press and hold for around 2 seconds

■ FAQs

Red light instead of blue light flashes.

- The earbuds are at low battery level, please recharge the earbuds.

Red light is off during charging.

- Ensure the earbuds are correctly placed in the charging case.
- When the earbuds have not been used for long periods of time, the battery will enter sleep state, it needs to charge about 30 minutes and then the red light will be lit.

No sound

- Check if the earbuds are operating.
- Check if the earbuds volume are at an appropriate level.
- Check if the earbuds are correctly connected with mobile phone.
- Check if the earbuds are operating within a normal working range.

The call quality of the earbuds are not good.

- Check if mobile phone is in an area with strong signal.
- Please ensure the earbuds are within effective distance (10m) and no obstacle between the earbuds and mobile phone.

When playing music, cannot control pause/play/previous track/next track via the earbuds.

- Ensure the paired device support AVRCP (Audio/Video Remote Control Profile) profile.

■ Maintenance

- Keep the product away from humid places to avoid affecting internal circuit. Do not use the product during intense exercise or with much sweat to prevent sweat from dropping into the product to make damage.
- Do not put the product in places exposed to sun or with high temperature. High temperature will shorten service life of electronic components, damage battery and deform plastic components.
- Do not put the product in cold places to avoid damaging internal circuit board.
- Do not dismantle the product. Non-professional personnel may damage the product.
- Do not drop, strongly vibrate, strike the product with hard object to avoid damaging internal circuit.
- Do not use drastic chemicals or cleaner to clean the product.
- Do not use sharp objects to scratch product surface to avoid damaging shell and affecting facade.