

36-22-11-991-03600-00-B / SHEET 2/2 - Right Inner Wing, Loop  
'B' - Fault Location Zone and Access Table (Short Circuit/Overheat)

LOC	FAULT LOCATION ZONE									ACCESS PANEL(S)
	START OF ZONE			MID POSITION			END OF ZONE			
	m	ft	ITEM	m	ft	ITEM	m	ft	ITEM	
053	2.58	8.46	379HF	3	9.84	379HF	0.03	0.10	380HF	621JB/621KB/621UB/621VB
054	2.78	9.12	379HF	3.20	10.50	379HF	0.23	0.75	380HF	621JB/621KB/621UB/621VB
055	2.98	9.78	379HF	3.40	11.15	379HF	0.42	1.38	380HF	621JB/621KB/621UB/621VB
056	3.18	10.43	379HF	0.20	0.66	380HF	0.62	2.03	380HF	621LB
057	3.37	11.06	379HF	0.40	1.31	380HF	0.82	2.69	380HF	621LB
058	0.18	0.59	380HF	0.60	1.97	380HF	1.02	3.35	380HF	621LB
059	0.38	1.25	380HF	0.80	2.62	380HF	1.21	3.97	380HF	621LB
060	0.58	1.90	380HF	0.99	3.25	380HF	1.41	4.63	380HF	621LB
061	0.77	2.53	380HF	1.19	3.90	380HF	1.61	5.28	380HF	621LB
062	0.97	3.18	380HF	1.39	4.56	380HF	1.80	5.91	380HF	621LB
063	1.17	3.84	380HF	1.58	5.18	380HF	2.00	6.56	380HF	621LB
064	1.36	4.46	380HF	1.78	5.84	380HF	0.03	0.10	381HF	621LB
065	1.56	5.12	380HF	1.98	6.50	380HF	0.23	0.75	381HF	621LB
066	1.76	5.77	380HF	2.18	7.15	380HF	0.42	1.38	381HF	621LB
067	1.96	6.43	380HF	0.20	0.66	381HF	0.62	2.03	381HF	621MB
068	2.15	7.05	380HF	0.40	1.31	381HF	0.82	2.69	381HF	621MB
069	0.18	0.59	381HF	0.60	1.97	381HF	1.01	3.31	381HF	621MB
070	0.38	1.25	381HF	0.79	2.59	381HF	1.21	3.97	381HF	621MB
071	0.57	1.87	381HF	0.99	3.25	381HF	1.41	4.63	381HF	621MB
072	0.77	2.53	381HF	1.19	3.90	381HF	1.61	5.28	381HF	621MB
073	0.97	3.18	381HF	1.39	4.56	381HF	0.09	0.30	382HF	621MB
074	1.17	3.84	381HF	1.58	5.18	381HF	0.29	0.95	382HF	621MB
075	1.36	4.46	381HF	0.07	0.23	382HF	0.49	1.61	382HF	622AT/622BT
076	1.56	5.12	381HF	0.27	0.89	382HF	0.69	2.26	382HF	622AT/622BT
077	0.05	0.16	382HF	0.46	1.51	382HF	0.88	2.89	382HF	622AT/622BT
078	0.24	0.79	382HF	0.66	2.17	382HF	1.08	3.54	382HF	622AT/622BT
079	0.44	1.44	382HF	0.86	2.82	382HF	1.28	4.20	382HF	622AT/622BT
080	0.64	2.10	382HF	1.06	3.48	382HF	1.47	4.82	382HF	622AT/622BT
081	0.84	2.76	382HF	1.25	4.10	382HF	1.67	5.48	382HF	622AT/622BT
082	1.03	3.38	382HF	1.45	4.76	382HF	0.16	0.52	383HF	622AT/622BT
083	1.23	4.04	382HF	1.65	5.41	382HF	0.36	1.18	383HF	622AT/622BT
084	1.43	4.69	382HF	0.14	0.46	383HF	0.55	1.80	383HF	473AL/473BL/473CL/473DL
085	1.63	5.35	382HF	0.33	1.08	383HF	0.75	2.46	383HF	473AL/473BL/473CL/473DL
086	0.11	0.36	383HF	0.53	1.74	383HF	0.95	3.12	383HF	473AL/473BL/473CL/473DL
087	0.31	1.02	383HF	0.73	2.40	383HF	1.14	3.74	383HF	473AL/473BL/473CL/473DL
088	0.51	1.67	383HF	0.92	3.02	383HF	1.34	4.40	383HF	473AL/473BL/473CL/473DL
089	0.70	2.30	383HF	1.12	3.67	383HF	0.04	0.13	399HF	473AL/473BL/473CL/473DL
090	0.90	2.95	383HF	1.32	4.33	383HF	0.24	0.79	399HF	473AL/473BL/473CL/473DL
091				0.89	2.92	399HF				473AL/473BL/473CL/473DL
092				3.21	10.53	755				
093				4.55	14.93	4060				
094				10.45	34.28	4060				
095				16.35	53.64	4060				
096				5.81	19.06	7554				
097				11.70	38.39	7554				
098				2.41	7.91	185				
099				8.31	27.26	185				
100				3.39	11.12	179				

**NOTE:** THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN).  
ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L\_TS\_362211\_2\_EAA\_02\_00

Figure 36-22-11-991-03600-B- / SHEET 2/2 - Right Inner Wing, Loop  
'B' - Fault Location Zone and Access Table (Short Circuit/Overheat)

\*\* ON A/C ALL