

36-22-11-991-03500-00-B / SHEET 2/2 - Right Inner Wing, Loop
'A' - Fault Location Zone and Access Table (Short Circuit/Overheat)

| LOC | FAULT LOCATION ZONE | | | | | | | | | ACCESS PANEL(S) |
|-----|---------------------|-------|-------|--------------|-------|-------|-------------|------|-------|-------------------------|
| | START OF ZONE | | | MID POSITION | | | END OF ZONE | | | |
| | m | ft | ITEM | m | ft | ITEM | m | ft | ITEM | |
| 053 | 2.64 | 8.66 | 354HF | 3.06 | 10.04 | 354HF | 0.08 | 0.26 | 355HF | 621JB/621KB/621UB/621VB |
| 054 | 2.84 | 9.32 | 354HF | 3.25 | 10.66 | 354HF | 0.28 | 0.92 | 355HF | 621JB/621KB/621UB/621VB |
| 055 | 3.03 | 9.94 | 354HF | 0.06 | 0.20 | 355HF | 0.48 | 1.57 | 355HF | 621LB |
| 056 | 3.23 | 10.60 | 354HF | 0.26 | 0.85 | 355HF | 0.67 | 2.20 | 355HF | 621LB |
| 057 | 0.04 | 0.13 | 355HF | 0.45 | 1.48 | 355HF | 0.87 | 2.85 | 355HF | 621LB |
| 058 | 0.23 | 0.75 | 355HF | 0.65 | 2.13 | 355HF | 1.07 | 3.51 | 355HF | 621LB |
| 059 | 0.43 | 1.41 | 355HF | 0.85 | 2.79 | 355HF | 1.26 | 4.13 | 355HF | 621LB |
| 060 | 0.63 | 2.07 | 355HF | 1.04 | 3.41 | 355HF | 1.46 | 4.79 | 355HF | 621LB |
| 061 | 0.82 | 2.69 | 355HF | 1.24 | 4.07 | 355HF | 1.66 | 5.45 | 355HF | 621LB |
| 062 | 1.02 | 3.35 | 355HF | 1.44 | 4.72 | 355HF | 1.85 | 6.07 | 355HF | 621LB |
| 063 | 1.22 | 4.00 | 355HF | 1.63 | 5.35 | 355HF | 2.05 | 6.73 | 355HF | 621LB |
| 064 | 1.41 | 4.63 | 355HF | 1.83 | 6.00 | 355HF | 0.08 | 0.26 | 356HF | 621LB |
| 065 | 1.61 | 5.28 | 355HF | 2.02 | 6.63 | 355HF | 0.28 | 0.92 | 356HF | 621LB |
| 066 | 1.80 | 5.91 | 355HF | 0.06 | 0.20 | 356HF | 0.48 | 1.57 | 356HF | 621MB |
| 067 | 2.00 | 6.56 | 355HF | 0.26 | 0.85 | 356HF | 0.67 | 2.20 | 356HF | 621MB |
| 068 | 0.04 | 0.13 | 356HF | 0.45 | 1.48 | 356HF | 0.87 | 2.85 | 356HF | 621MB |
| 069 | 0.23 | 0.75 | 356HF | 0.65 | 2.13 | 356HF | 1.07 | 3.51 | 356HF | 621MB |
| 070 | 0.43 | 1.41 | 356HF | 0.85 | 2.79 | 356HF | 1.26 | 4.13 | 356HF | 621MB |
| 071 | 0.63 | 2.07 | 356HF | 1.04 | 3.41 | 356HF | 1.46 | 4.79 | 356HF | 621MB |
| 072 | 0.82 | 2.69 | 356HF | 1.24 | 4.07 | 356HF | 1.66 | 5.45 | 356HF | 621MB |
| 073 | 1.02 | 3.35 | 356HF | 1.44 | 4.72 | 356HF | 0.15 | 0.49 | 357HF | 621MB |
| 074 | 1.22 | 4.00 | 356HF | 1.63 | 5.35 | 356HF | 0.35 | 1.15 | 357HF | 621MB |
| 075 | 1.41 | 4.63 | 356HF | 0.13 | 0.43 | 357HF | 0.55 | 1.80 | 357HF | 622AT/622BT |
| 076 | 1.61 | 5.28 | 356HF | 0.33 | 1.08 | 357HF | 0.74 | 2.43 | 357HF | 622AT/622BT |
| 077 | 0.11 | 0.36 | 357HF | 0.52 | 1.71 | 357HF | 0.94 | 3.08 | 357HF | 622AT/622BT |
| 078 | 0.30 | 0.98 | 357HF | 0.72 | 2.36 | 357HF | 1.13 | 3.71 | 357HF | 622AT/622BT |
| 079 | 0.50 | 1.64 | 357HF | 0.91 | 2.99 | 357HF | 1.33 | 4.36 | 357HF | 622AT/622BT |
| 080 | 0.69 | 2.26 | 357HF | 1.11 | 3.64 | 357HF | 1.53 | 5.02 | 357HF | 622AT/622BT |
| 081 | 0.89 | 2.92 | 357HF | 1.31 | 4.30 | 357HF | 1.72 | 5.64 | 357HF | 622AT/622BT |
| 082 | 1.09 | 3.58 | 357HF | 1.50 | 4.92 | 357HF | 0.16 | 0.52 | 358HF | 622AT/622BT |
| 083 | 1.28 | 4.20 | 357HF | 1.70 | 5.58 | 357HF | 0.36 | 1.18 | 358HF | 622AT/622BT |
| 084 | 1.48 | 4.86 | 357HF | 0.14 | 0.46 | 358HF | 0.55 | 1.80 | 358HF | 473AL/473BL/473CL/473DL |
| 085 | 1.68 | 5.51 | 357HF | 0.33 | 1.08 | 358HF | 0.75 | 2.46 | 358HF | 473AL/473BL/473CL/473DL |
| 086 | 0.11 | 0.36 | 358HF | 0.53 | 1.74 | 358HF | 0.95 | 3.12 | 358HF | 473AL/473BL/473CL/473DL |
| 087 | 0.31 | 1.02 | 358HF | 0.73 | 2.40 | 358HF | 1.14 | 3.74 | 358HF | 473AL/473BL/473CL/473DL |
| 088 | 0.51 | 1.67 | 358HF | 0.92 | 3.02 | 358HF | 1.34 | 4.40 | 358HF | 473AL/473BL/473CL/473DL |
| 089 | 0.70 | 2.30 | 358HF | 1.12 | 3.67 | 358HF | 0.04 | 0.13 | 374HF | 473AL/473BL/473CL/473DL |
| 090 | 0.90 | 2.95 | 358HF | 1.32 | 4.33 | 358HF | 0.23 | 0.75 | 374HF | 473AL/473BL/473CL/473DL |
| 091 | | | | 0.67 | 2.20 | 374HF | | | | 473AL/473BL/473CL/473DL |
| 092 | | | | 3.07 | 10.07 | 745 | | | | |
| 093 | | | | 4.24 | 13.91 | 4032 | | | | |
| 094 | | | | 10.11 | 33.17 | 4032 | | | | |
| 095 | | | | 15.99 | 52.46 | 4032 | | | | |
| 096 | | | | 5.44 | 17.85 | 7512 | | | | |
| 097 | | | | 11.31 | 37.11 | 7512 | | | | |
| 098 | | | | 2.72 | 8.92 | 106 | | | | |
| 099 | | | | 8.59 | 28.18 | 106 | | | | |
| 100 | | | | 3.57 | 11.71 | 100 | | | | |

NOTE: THE DIMENSIONS OF THE START, MID POSITION AND THE END OF THE FAULT LOCATION ZONE ARE MEASURED FROM THE START OF EACH APPLICABLE ITEM (WIRE OR FIN).
ALL THE WIRE IDENTs ARE PREFIXED WITH 3622. THE OVERHEAT DETECTION SYSTEM CANNOT CALCULATE A FAULT LOCATION ZONE FOR THE CONNECTING CABLES OR WIRING. THUS, ONLY THE MID POSITION OF A FAULT IS GIVEN TO HELP YOU DO THE TROUBLESHOOTING PROCEDURE FOR THESE ITEMS.

L_TS_362211_2_EQAA_02_00

Figure 36-22-11-991-03500-B- / SHEET 2/2 - Right Inner Wing, Loop
'A' - Fault Location Zone and Access Table (Short Circuit/Overheat)

** ON A/C ALL