

AVL Analysis Interface Module (AIM) Manual

Ed Alyanak and Ryan Durscher
AFRL/RQVC

May 28, 2021

0.1 Introduction	1
0.1.1 AVL AIM Overview	1
0.1.2 Assumptions	1
0.1.3 Examples	2
0.2 AVL AIM Examples	2
0.3 AIM Attributes	4
0.4 AIM Units	5
0.4.1 JSON String Dictionary	5
0.5 AIM Inputs	6
0.6 AIM Outputs	7
0.7 AIM Back Door	10
0.8 Vortex Lattice Surface	11
0.8.1 JSON String Dictionary	11
0.8.2 Single Value String	12
0.9 Vortex Lattice Control Surface	12
0.9.1 JSON String Dictionary	12
0.9.2 Single Value String	12

0.1 Introduction

0.1.1 AVL AIM Overview

The use of lower-dimensional design tools is clearly desirable in a multidisciplinary/multi-fidelity aero design optimization setting. This is the crux of the Computational Aircraft Prototype Syntheses (CAPS) program. In many ways describing geometry appropriate for AVL (the Athena Vortex Lattice) code is more cumbersome than higher fidelity codes that require an Outer Mold Line. The goal is to make a CAPS AIM (Analysis Input Module) that directly feeds input to AVL and extracts the output quantities of interest from AVL's execution. This needs to be consistent with a build description that is hierarchical and multi-fidelity. That is, the build description that generates the geometric data at this level can be further enhanced to produce the complete OML of the aircraft design under consideration. As for the geometric description, AVL requires airfoil section data specified at the appropriate locations that describe the *skeleton* of the aircraft. These sections when *lofted* as groups and finally *unioned* together builds the OML. Clearly, intercepting the state of the geometry before these higher-level operations are applied provides the data appropriate for AVL. This naturally constructs a hierarchical geometric view where a design can progress into higher fidelities and feedback can be achieved where we can go back to this level of description when need be.

An outline of the AIM's inputs and outputs are provided in [AIM Inputs](#) and [AIM Outputs](#), respectively. An alternative to the AIM's outputs for retrieving sensitivity information is provided in [AIM Back Door](#).

Details on the use of units are outlined in [AIM Units](#).

Geometric attribution that the AIM makes use is provided in [AIM Attributes](#).

Upon running preAnalysis the AIM generates two files, 1) "avlInput.txt" which contains the input information and control sequence for AVL to execute and 2) "caps.avl" which contains the geometry to be analyzed. To populate output data the AIM expects files, "capsTotalForce.txt", "capsStripForce.txt", "capsStabilityDeriv.txt", "capsBody↔AxisDeriv.txt", and "capsHingeMoment.txt" to exist after running AVL (see [AIM Outputs](#) for additional information).

An example execution for AVL looks like:

```
avl caps < avlInput.txt > avlOutput.txt"
```

0.1.2 Assumptions

The AVL coordinate system assumption (X – downstream, Y – out the right wing, Z – up) needs to be followed.

Within **OpenCSM** there are a number of airfoil generation UDPs (User Defined Primitives). These include NACA 4 series, a more general NACA 4/5/6 series generator, Sobieczky's PARSEC parameterization and Kulfan's CST parameterization. All of these UDPs generate **EGADS FaceBodies** where the *Face*'s underlying *Surface* is planar and the bounds of the *Face* is a closed set of *Edges* whose underlying *Curves* contain the airfoil shape. In all cases, there is a *Node* that represents the *Leading Edge* point and one or two *Nodes* at the *Trailing Edge* – one if the representation is for a sharp TE and the other if the definition is open or blunt. If there are 2 *Nodes* at the back, then there are 3 *Edges* all together and closed, even though the airfoil definition was left open at the TE. All of this information will be used to automatically fill in the AVL geometry description.

The AVL Sections are automatically generated, one from each *FaceBody* and the details extracted from the geometry. The *FaceBody* must contain at least two edges and two nodes, but may contain any number of *Edges* otherwise. If the *FaceBody* contains more nodes, the node with the smallest **x** value is used to define the leading edge, the node with the largest **x** defines the trailing edge. The airfoil may have a single *Edge* that defines a straight blunt trailing edge. **Xle**, **Yle**, and **Zle**, are taken from the *Node* associated with the *Leading Edge*. The **Chord** is computed by getting the distance between the LE and TE (if there is a blunt trailing *Edge* in the *FaceBody* the TE point is considered the mid-position on that *Edge*). **Ainc** is computed by registering the chordal direction of the *FaceBody* against the X-Z plane. The airfoil shapes are generated by sampling the *Curves* and put directly in the input file via the **AIRFOIL** keyword after being normalized.

It should be noted that general construction in either **OpenCSM** or even **EGADS** will be supported as long as the topology described above is used. But care should be taken when constructing the airfoil shape so that a

discontinuity (i.e., simply C^0) is not generated at the *Node* representing the *Leading Edge*. This can be done by splining the entire shape as one and then intersecting the single *Edge* to place the LE *Node*.

The rest of the information and options required to fill out the AVL geometry input file (**xxx.avl**) will be found in the attributes attached to the *FaceBody* itself. The conventions used will be described in the next section.

Also note that this first implementation is not intended to provide complete control over AVL. In particular, there is no mention above of the **BODY**, **DESIGN**, **CLAF**, or **CDCL** AVL keywords.

0.1.3 Examples

An example problem using the AVL AIM may be found at [AVL AIM Examples](#), which contains example *.csm input files and pyCAPS scripts designed to make use of the AVL AIM. These example scripts make extensive use of the [AIM Attributes](#), [AIM Inputs](#), and [AIM Outputs](#).

0.2 AVL AIM Examples

This example contains a set of *.csm and pyCAPS (*.py) inputs that uses the AVL AIM. A user should have knowledge on the generation of parametric geometry in Engineering Sketch Pad (ESP) before attempting to integrate with any AIM. Specifically, this example makes use of Design Parameters, Set Parameters, User Defined Primitive (UDP) and attributes in ESP.

The follow code details the process in a *.csm file that generates three airfoil sections to create a wing. Note to execute in serveCSM a dictionary file must be included "serveCSM \$ESP_ROOT/CAPSexamples/csmData/avl←Wing.csm"

The CSM script generates Bodies which are designed to be used by specific AIMs. The AIMs that the Body is designed for is communicated to the CAPS framework via the capsAIM string attribute. This is a semicolon-separated string with the list of AIM names. Thus, the CSM author can give a clear indication to which AIMs should use the Body. In this example, the list contains only the avlAIM:

```
attribute capsAIM      $avlAIM
```

Next we will define the design parameters to define the wing cross section and planform.

```
despmtr  thick      0.12      frac of local chord
despmtr  camber     0.04      frac of loacl chord
despmtr  area       10.0      Planform area of the full span wing
despmtr  aspect     6.00      Span^2/Area
despmtr  taper      0.60      TipChord/RootChord
despmtr  sweep      20.0      1/4 Chord Sweep
despmtr  washout    -5.00     deg (negative is down at tip)
despmtr  dihedral   4.00      deg
```

The design parameters will then be used to set parameters for use internally to create geometry.

```
set      span      sqrt(aspect*area)
set      croot     2*area/span/(1+taper)
set      ctip      croot*taper
set      dxtip     (croot-ctip)/4+span/2*tand(sweep)
set      dztip     span/2*tand(dihedral)
```

Finally, the airfoils are created using the User Defined Primitive (UDP) naca. The inputs used for this example to the UDP are Thickness and Camber. Cross sections are in the X-Y plane and are rotated to the X-Z plane. Reference quantities must exist on any body, otherwise AVL defaults to 1.0 for Area, Span, Chord and 0.0 for X,Y,Z moment

References

```
# left tip
udprim   naca      Thickness thick      Camber      camber
attribute capsGroup $Wing
attribute capsReferenceArea area
attribute capsReferenceSpan span
attribute capsReferenceChord croot
attribute capsReferenceX croot/4
scale    ctip
rotatex  90        0        0
```

```

rotatey   washout   0           ctip/4
translate dxtip     -span/2     dztip
# root
udprim    naca       Thickness thick   Camber   camber
attribute capsGroup $Wing
rotatex   90         0           0
scale     croot
# right tip
udprim    naca       Thickness thick   Camber   camber
attribute capsGroup $Wing
scale     ctip
rotatex   90         0           0
rotatey   washout   0           ctip/4
translate dxtip     span/2      dztip

```

An example pyCAPS script that uses the above csm file to run AVL is as follows.

First the pyCAPS and os module needs to be imported.

```

import pyCAPS
import os

```

Next the *.csm file is loaded and design parameter is changed - area in the geometry. Any despmtr from the avlWing.csm file is available inside the pyCAPS script. They are: thick, camber, area, aspect, taper, sweep, washout, dihedral...

```

geometryScript = os.path.join("../csmData", "avlWing.csm")
myProblem = pyCAPS.Problem(problemName=workDir,
                           capsFile=geometryScript,
                           outLevel=args.verbosity)
myProblem.geometry.despmtr.area = 10.0

```

The AVL AIM is then loaded with:

```

myAnalysis = myProblem.analysis.create(aim = "avlAIM", name = "avl")

```

After the AIM is loaded the Mach number and angle of attack are set, though all AIM Inputs are available.

```

myAnalysis.input.Mach = 0.5
myAnalysis.input.Alpha = 1.0
myAnalysis.input.Beta = 0.0
wing = {"groupName" : "Wing", # Notice Wing is the value for the capsGroup attribute
        "numChord" : 8,
        "spaceChord" : 1.0,
        "numSpanTotal" : 24,
        "spaceSpan" : 1.0}
myAnalysis.input.AVL_Surface = {"Wing": wing}

```

Once all the inputs have been set, preAnalysis needs to be executed. During this operation, all the necessary files to run AVL are generated and placed in the analysis working directory (analysisDir)

```

myAnalysis.preAnalysis()

```

An OS system call is then made from Python to execute AVL.

```

print ("Running AVL")
currentDirectory = os.getcwd() # Get our current working directory
os.chdir(myAnalysis.analysisDir) # Move into test directory
os.system("avl caps < avlInput.txt > avlOutput.txt");
os.chdir(currentDirectory) # Move back to working directory

```

A call to postAnalysis is then made to check to see if AVL executed successfully and the expected files were generated.

```

myAnalysis.postAnalysis()

```

Similar to the AIM inputs, after the execution of AVL and postAnalysis any of the AIM's output variables (AIM Outputs) are readily available; for example,

```

print ("CXtot ", myAnalysis.output["CXtot"].value)
print ("CYtot ", myAnalysis.output["CYtot"].value)
print ("CZtot ", myAnalysis.output["CZtot"].value)
print ("CLtot ", myAnalysis.output["CLtot"].value)
print ("Cmtot ", myAnalysis.output["Cmtot"].value)
print ("Cntot ", myAnalysis.output["Cntot"].value)
print ("Cl'tot ", myAnalysis.output["Cl'tot"].value)
print ("Cn'tot ", myAnalysis.output["Cn'tot"].value)
print ("CLtot ", myAnalysis.output["CLtot"].value)
print ("CDtot ", myAnalysis.output["CDtot"].value)
print ("CDvis ", myAnalysis.output["CDvis"].value)
print ("CLff ", myAnalysis.output["CLff"].value)
print ("CYff ", myAnalysis.output["CYff"].value)
print ("CDind ", myAnalysis.output["CDind"].value)
print ("CDff ", myAnalysis.output["CDff"].value)

```

```
print ("e", myAnalysis.output["e"].value)
```

results in

```
CXtot 0.00061
CYtot -0.0
CZtot -0.30129
CLtot -0.0
Cmtot -0.19449
Cntot -0.0
Cl'tot -0.0
Cn'tot -0.0
CLtot 0.30126
CDtot 0.00465
CDvis 0.0
CLff 0.30096
CYff -0.0
CDind 0.0046467
CDff 0.0049692
e 0.967
```

Additionally, besides making a call to the AIM outputs, sensitivity values may be obtained in the following manner,

```
#sensitivity = myAnalysis.output["CLtot"].deriv("Alpha")
```

The avlAIM supports the control surface modeling functionality inside AVL. Trailing edge control surfaces can be added to the above example by making use of the `vlmControlName` attribute (see [AIM Attributes](#) regarding the attribution specifics). To add a **RightFlap** and **LeftFlap** to the previous example *.csm file the naca UDP entries are augmented with the following attributes.

```
# left tip
udprim naca Thickness thick Camber camber
attribute vlmControl_LeftFlap 80 # Hinge line is at 80% of the chord
...
# root
udprim naca Thickness thick Camber camber
attribute vlmControl_LeftFlap 80 # Hinge line is at 80% of the chord
attribute vlmControl_RightFlap 80 # Hinge line is at 80% of the chord
...
# right tip
udprim naca Thickness thick Camber camber
attribute vlmControl_RightFlap 80 # Hinge line is at 80% of the chord
...
```

Note how the root airfoil contains two attributes for both the left and right flaps.

In the pyCAPS script the [AIM Inputs](#), **AVL_Control**, must be defined.

```
flap = {"controlGain" : 0.5,
        "deflectionAngle" : 10.0}
myAnalysis.input.AVL_Control = {"LeftFlap": flap, "RightFlap": flap}
```

Notice how the information defined in the **flap** variable is assigned to the `vlmControlName` portion of the attributes added to the *.csm file.

0.3 AIM Attributes

The following list of attributes drives the AVL geometric definition. Each *FaceBody* which relates to AVL **Sections** will be marked up in an appropriate manner to drive the input file construction. Many attributes are required and those that are optional are marked so in the description:

- **capsReferenceArea** [Optional: Default 1.0] This attribute may exist on any *Body*. Its value will be used as the SREF entry in the AVL input.
- **capsReferenceChord** [Optional: Default 1.0] This attribute may exist on any *Body*. Its value will be used as the CREF entry in the AVL input.
- **capsReferenceSpan** [Optional: Default 1.0] This attribute may exist on any *Body*. Its value will be used as the BREF entry in the AVL input.

- **capsReferenceX** [Optional: Default 0.0] This attribute may exist on any *Body*. Its value will be used as the Xref entry in the AVL input.
- **capsReferenceY** [Optional: Default 0.0] This attribute may exist on any *Body*. Its value will be used as the Yref entry in the AVL input.
- **capsReferenceZ** [Optional: Default 0.0] This attribute may exist on any *Body*. Its value will be used as the Zref entry in the AVL input.
- **capsGroup** This string attribute labels the *FaceBody* as to which AVL Surface the section is assigned. This should be something like: *Main_Wing*, *Horizontal_Tail*, etc. This informs the AVL AIM to collect all *FaceBodies* that match this attribute into a single AVL Surface.
- **vlmControl"Name"** This string attribute attaches a control surface to the *FaceBody*. The hinge location is defined as the double value between 0 or 1.0. The range as percentage from 0 to 100 will also work. The name of the control surface is the string information after vlmControl (or vlmControl_). For Example, to define a control surface named Aileron the following are identical (*attribute vlmControlAileron 0.8* or *attribute vlmControl_Aileron 80*) . Multiple *vlmControl* attributes, with different names, can be defined on a single *FaceBody*.

By default control surfaces with percentages less than 0.5 (< 50%) are considered leading edge flaps, while values greater than or equal to 0.5 (>= 50%) are considered trailing edge flaps. This behavior may be overwritten when setting up the control surface in "AVL_Control" (see [AIM Inputs](#)) with the keyword "leOrTe" (see [Vortex Lattice Control Surface](#) for additional details).

- **vlmNumSpan** This attribute may be set on any given airfoil cross-section to overwrite the number of spanwise horseshoe vortices placed on the surface (globally set - see keyword "numSpanPerSection" and "numSpan↔Total" in [Vortex Lattice Surface](#)) between two sections. Note, that the AIM internally sorts the sections in ascending y (or z) order, so care should be taken to select the correct section for the desired intent.

Note: The attribute **avlNumSpan** has been deprecated in favor of **vlmNumSpan**

- **vlmSspace** This attribute may be set on any given airfoil cross-section in the range [-1 .. 1] specify the spanwise distribution function.

0.4 AIM Units

A unit system may be optionally specified during AIM instance initiation. If a unit system is provided, all AIM input values which have associated units must be specified as well. If no unit system is used, AIM inputs, which otherwise would require units, will be assumed unit consistent. A unit system may be specified via a JSON string dictionary for example: `unitSys = {"mass": "kg", "length": "m", "time": "seconds", "temperature": "K"}`

0.4.1 JSON String Dictionary

The key arguments of the dictionary are described in the following:

- **mass = "None"**
Mass units - e.g. "kilogram", "k", "slug", ...
- **length = "None"**
Length units - e.g. "meter", "m", "inch", "in", "mile", ...
- **time = "None"**
Time units - e.g. "second", "s", "minute", ...
- **temperature = "None"**
Temperature units - e.g. "Kelvin", "K", "degC", ...

0.5 AIM Inputs

The following list outlines the AVL inputs along with their default value available through the AIM interface.

- **Mach = 0.0**
Mach number.
- **Alpha = NULL**
Angle of attack [degree]. Either CL or Alpha must be defined but not both.
- **Beta = 0.0**
Sideslip angle [degree].
- **RollRate = 0.0**
Non-dimensional roll rate.
- **PitchRate = 0.0**
Non-dimensional pitch rate.
- **YawRate = 0.0**
Non-dimensional yaw rate.
- **CDp = 0.0**
A fixed value of profile drag to be added to all simulations.
- **AVL_Surface = NULL**
See [Vortex Lattice Surface](#) for additional details.
- **AVL_Control = NULL**
See [Vortex Lattice Control Surface](#) for additional details.
- **CL = NULL**
Coefficient of Lift. AVL will solve for Angle of Attack. Either CL or Alpha must be defined but not both.
- **Moment_Center = NULL, [0.0, 0.0, 0.0]**
Array values correspond to the Xref, Yref, and Zref variables. Alternatively, the geometry (body) attributes "capsReferenceX", "capsReferenceY", and "capsReferenceZ" may be used to specify the X-, Y-, and Z-reference centers, respectively (note: values set through the AIM input will supersede the attribution values).
- **MassProp = NULL**
Mass properties used for eigen value analysis Structure for the mass property tuple = ("Name", "Value"). The "Name" of the mass component used for documenting the xxx.mass file. The value is a JSON dictionary with values with unit pairs for mass, CG, and moments of inertia information (e.g. "Value" = {"mass" : [mass,"kg"], "CG" : [[x,y,z],"m"], "massInertia" : [[Ixx, Iyy, Izz, Ixy, Ixz, Iyz], "kg*m^2"]}) The components Ixy, Ixz, and Iyz are optional may be omitted. Must be in units of kg, m, and kg*m^2 if unitSystem (see [AIM Units](#)) is not specified and no units should be specified in the JSON dictionary.
- **Gravity = NULL**
Magnitude of the gravitational force used for Eigen value analysis. Must be in units of m/s^2 if unitSystem (see [AIM Units](#)) is not specified.
- **Density = NULL**
Air density used for Eigen value analysis. Must be in units of kg/m^3 if unitSystem (see [AIM Units](#)) is not specified.
- **Velocity = NULL**
Velocity used for Eigen value analysis. Must be in units of m/s if unitSystem (see [AIM Units](#)) is not specified.

0.6 AIM Outputs

Optional outputs that echo the inputs. These are parsed from the resulting output and can be used as a sanity check.

- **Alpha** = Angle of attack.
- **Beta** = Sideslip angle.
- **Mach** = Mach number.
- **pb/2V** = Non-dimensional roll rate.
- **qc/2V** = Non-dimensional pitch rate.
- **rb/2V** = Non-dimensional yaw rate.
- **p'b/2V** = Non-dimensional roll acceleration.
- **r'b/2V** = Non-dimensional yaw acceleration.

Forces and moments:

- **CXtot** = X-component of total force in body axis
- **CYtot** = Y-component of total force in body axis
- **CZtot** = Z-component of total force in body axis
- **Cltot** = X-component of moment in body axis
- **Cmtot** = Y-component of moment in body axis
- **Cntot** = Z-component of moment in body axis
- **Cl'tot** = x-component of moment in stability axis
- **Cn'tot** = z-component of moment in stability axis
- **CLtot** = total lift in stability axis
- **CDtot** = total drag in stability axis
- **CDvis** = viscous drag component
- **CLff** = trefftz plane lift force
- **CYff** = trefftz plane side force
- **CDind** = induced drag force
- **CDff** = trefftz plane drag force
- **e** = Oswald Efficiency

Stability-axis derivatives - Alpha:

- **CLa** = z' force, CL, with respect to alpha.
- **CYa** = y force, CY, with respect to alpha.
- **Cl'a** = x' moment, Cl', with respect to alpha.

- **Cma** = y moment, C_m , with respect to α .
- **Cn'a** = z' moment, C_n' , with respect to α .

Stability-axis derivatives - Beta:

- **CLb** = z' force, C_L , with respect to β .
- **CYb** = y force, C_Y , with respect to β .
- **Cl'b** = x' moment, C_l' , with respect to β .
- **Cmb** = y moment, C_m , with respect to β .
- **Cn'b** = z' moment, C_n' , with respect to β .

Stability-axis derivatives - Roll rate, p' :

- **CLp'** = z' force, C_L , with respect to roll rate, p' .
- **CYp'** = y force, C_Y , with respect to roll rate, p' .
- **Cl'p'** = x' moment, C_l' , with respect to roll rate, p' .
- **Cmp'** = y moment, C_m , with respect to roll rate, p' .
- **Cn'p'** = z' moment, C_n' , with respect to roll rate, p' .

Stability-axis derivatives - Pitch rate, q' :

- **CLq'** = z' force, C_L , with respect to pitch rate, q' .
- **CYq'** = y force, C_Y , with respect to pitch rate, q' .
- **Cl'q'** = x' moment, C_l' , with respect to pitch rate, q' .
- **Cmq'** = y moment, C_m , with respect to pitch rate, q' .
- **Cn'q'** = z' moment, C_n' , with respect to pitch rate, q' .

Stability-axis derivatives - Yaw rate, r' :

- **CLr'** = z' force, C_L , with respect to yaw rate, r' .
- **CYr'** = y force, C_Y , with respect to yaw rate, r' .
- **Cl'r'** = x' moment, C_l' , with respect to yaw rate, r' .
- **Cmr'** = y moment, C_m , with respect to yaw rate, r' .
- **Cn'r'** = z' moment, C_n' , with respect to yaw rate, r' .

Body-axis derivatives - Axial velocity, u :

- **CXu** = x force, C_X , with respect to axial velocity, u .
- **CYu** = y force, C_Y , with respect to axial velocity, u .
- **CZu** = z force, C_Z , with respect to axial velocity, u .

- **Clu** = x moment, Cl, with respect to axial velocity, u.
- **Cmu** = y moment, Cm, with respect to axial velocity, u.
- **Cnu** = z moment, Cn, with respect to axial velocity, u.

Body-axis derivatives - Sideslip velocity, v:

- **CXv** = x force, CX, with respect to sideslip velocity, v.
- **CYv** = y force, CY, with respect to sideslip velocity, v.
- **CZv** = z force, CZ, with respect to sideslip velocity, v.
- **Clv** = x moment, Cl, with respect to sideslip velocity, v.
- **Cmv** = y moment, Cm, with respect to sideslip velocity, v.
- **Cnv** = z moment, Cn, with respect to sideslip velocity, v.

Body-axis derivatives - Normal velocity, w:

- **CXw** = x force, CX, with respect to normal velocity, w.
- **CYw** = y force, CY, with respect to normal velocity, w.
- **CZw** = z force, CZ, with respect to normal velocity, w.
- **Clw** = x moment, Cl, with respect to normal velocity, w.
- **Cmw** = y moment, Cm, with respect to normal velocity, w.
- **Cnw** = z moment, Cn, with respect to normal velocity, w.

Body-axis derivatives - Roll rate, p:

- **CXp** = x force, CX, with respect to roll rate, p.
- **CYp** = y force, CY, with respect to roll rate, p.
- **CZp** = z force, CZ, with respect to roll rate, p.
- **Clp** = x moment, Cl, with respect to roll rate, p.
- **Cmp** = y moment, Cm, with respect to roll rate, p.
- **Cnp** = z moment, Cn, with respect to roll rate, p.

Body-axis derivatives - Pitch rate, q:

- **CXq** = x force, CX, with respect to pitch rate, q.
- **CYq** = y force, CY, with respect to pitch rate, q.
- **CZq** = z force, CZ, with respect to pitch rate, q.
- **Clq** = x moment, Cl, with respect to pitch rate, q.
- **Cmq** = y moment, Cm, with respect to pitch rate, q.
- **Cnq** = z moment, Cn, with respect to pitch rate, q.

Body-axis derivatives - Yaw rate, r :

- **CXr** = x force, CX, with respect to yaw rate, r .
- **CYr** = y force, CY, with respect to yaw rate, r .
- **CZr** = z force, CZ, with respect to yaw rate, r .
- **Clr** = x moment, Cl, with respect to yaw rate, r .
- **Cmr** = y moment, Cm, with respect to yaw rate, r .
- **Cnr** = z moment, Cn, with respect to yaw rate, r .

Geometric output:

- **Xnp** = Neutral Point
- **Xcg** = x CG location
- **Ycg** = y CG location
- **Zcg** = z CG location

Controls:

- **ControlStability** = a (or an array of) tuple(s) with a structure of ("Control Surface Name", "JSON Dictionary") for all control surfaces in the stability axis frame. The JSON dictionary has the form = {"CLtot":value,"CYtot":value,"Cl'tot":value,"Cmtot":value,"Cn'tot":value}
- **ControlBody** = a (or an array of) tuple(s) with a structure of ("Control Surface Name", "JSON Dictionary") for all control surfaces in the body axis frame. The JSON dictionary has the form = {"CXtot":value,"CYtot":value,"CZtot":value,"Cl'tot":value,"Cmtot":value,"Cn'tot":value}
- **HingeMoment** = a (or an array of) tuple(s) with a structure of ("Control Surface Name", "HingeMoment")
- **StripForces** = a (or an array of) tuple(s) with a structure of ("Surface Name", "JSON Dictionary") for all surfaces. The JSON dictionary has the form = {"cl":[value0,value1,value2],"cd":[value0,value1,value2]...}
- **EigenValues** = a (or an array of) tuple(s) with a structure of ("case #", "Array of eigen values"). The array of eigen values is of the form = [[real0,imaginary0],[real0,imaginary0],...]

0.7 AIM Back Door

The back door function of this AIM may be used as an alternative to retrieve sensitivity information produced by the AIM. The JSONin string should be of the following form '{"mode": "sensitivity", "inputVar": "Name of Input Variable", "outputVar": "Name of Output Variable"}', while the JSONout string will look like '{"sensitivity": value}'. Important: the JSONout string is freeable! Invalid combinations of input and output variables returns a CAPS_MISMATCH error code.

Acceptable values for the "Name of Input Variable" are as follows (definitions are consistent, where appropriate, with [AIM Inputs](#)):

- "Alpha"
- "Beta"

- "RollRate"
- "PitchRate"
- "YawRate"
- "AxialVelocity"
- "SideslipVelocity"
- "NormalVelocity"
- "AVL_Control:Name_of_Control_Surface", where Name_of_Control_Surface should be replaced with name of the desired control surface

Acceptable values for the "Name of Output Variable" are as follows (definitions are consistent with [AIM Outputs](#)):

- "CLtot"
- "CYtot"
- "Cl'tot"
- "Cmtot"
- "Cn'tot"
- "CXtot"
- "CZtot"
- "Cltot"
- "Cntot"

0.8 Vortex Lattice Surface

Structure for the Vortex Lattice Surface tuple = ("Name of Surface", "Value"). "Name of surface defines the name of the surface in which the data should be applied. The "Value" can either be a JSON String dictionary (see Section [JSON String Dictionary](#)) or a single string keyword string (see Section [Single Value String](#)).

0.8.1 JSON String Dictionary

If "Value" is a JSON string dictionary (eg. "Value" = {"numChord": 5, "spaceChord": 1.0, "numSpan": 10, "space↔Span": 0.5}) the following keywords (= default values) may be used:

- **groupName = "(no default)"**
Single or list of *capsGroup* names used to define the surface (e.g. "Name1" or ["Name1","Name2",...]). If no groupName variable is provided an attempted will be made to use the tuple name instead;
- **noKeyword = "(no default)"**
"No" type. Options: NOWAKE, NOALBE, NOLOAD.
- **numChord = 10**
The number of chordwise horseshoe vortices placed on the surface.

- **spaceChord = 1.0**
The chordwise vortex spacing parameter.
- **numSpanTotal = 0**
Total number of spanwise horseshoe vortices placed on the surface. The vortices are 'evenly' distributed across sections to minimize jumps in spacings. numSpanPerSection must be zero if this is set.
- **numSpanPerSection = 0**
The number of spanwise horseshoe vortices placed on each section the surface. The total number of spanwise vortices are (numSection-1)*numSpanPerSection. The vortices are 'evenly' distributed across sections to minimize jumps in spacings. numSpanTotal must be zero if this is set.
- **spaceSpan = 0.0**
The spanwise vortex spacing parameter.
- **yMirror = False**
Mirror surface about the y-direction.

0.8.2 Single Value String

If "Value" is a single string the following options maybe used:

- (NONE Currently)

0.9 Vortex Lattice Control Surface

Structure for the Vortex Lattice Control Surface tuple = ("Name of Control Surface", "Value"). "Name of control surface defines the name of the control surface in which the data should be applied. The "Value" must be a JSON String dictionary (see Section [JSON String Dictionary](#)).

0.9.1 JSON String Dictionary

If "Value" is a JSON string dictionary (e.g. "Value" = {"deflectionAngle": 10.0}) the following keywords (= default values) may be used:

- **deflectionAngle = 0.0**
Deflection angle of the control surface.
- **leOrTe = (no default)**
Is the control surface a leading (= 0) or trailing (> 0) edge effector? Overrides the assumed default value set by the geometry: If the percentage along the airfoil chord is < 50% a leading edge flap is assumed, while >= 50% indicates a trailing edge flap.
- **controlGain = 1.0**
Control deflection gain, units: degrees deflection / control variable
- **hingeLine = [0.0 0.0 0.0]**
Alternative vector giving hinge axis about which surface rotates
- **deflectionDup = 0**
Sign of deflection for duplicated surface

0.9.2 Single Value String

If "Value" is a single string, the following options maybe used:

- (NONE Currently)