



## ***Xtensa Audio Framework (Hostless)***

### **Programmer's Guide**

For HiFi DSPs



Cadence Design Systems, Inc.  
2655 Seely Ave.  
San Jose, CA 95134  
[www.cadence.com](http://www.cadence.com)

Copyright © 2024 Cadence Design Systems, Inc.

Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Trademarks: Trademarks and service marks of Cadence Design Systems, Inc. (Cadence) contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 1-800-862-4522.

All other trademarks are the property of their respective holders.

Restricted Print Permission: This publication is protected by copyright and any unauthorized use of this publication may violate copyright, trademark, and other laws. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. This statement grants you permission to print one (1) hard copy of this publication subject to the following conditions:

1. The publication may be used solely for personal, informational, and noncommercial purposes;
2. The publication may not be modified in any way;
3. Any copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement;
4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration; and
5. Cadence reserves the right to revoke this authorization at any time, and any such use shall be discontinued immediately upon written notice from Cadence.

Disclaimer: Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. The information contained herein is the proprietary and confidential information of Cadence or its licensors, and is supplied subject to, and may be used only by Cadence's customer in accordance with, a written agreement between Cadence and its customer. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Restricted Rights: Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor.  
For further assistance, contact Cadence Online Support at <https://support.cadence.com/>.

**Version:** 3.3

**Last Updated:** February 2024

Cadence Design Systems, Inc.  
2655 Seely Ave.  
San Jose, CA 95134  
[www.cadence.com](http://www.cadence.com)

# Contents

Contents .....	iii
Figures .....	vi
Tables .....	vii
1. Introduction to Xtensa Audio Framework .....	1
1.1 Document Overview .....	1
1.2 Xtensa Audio Framework Terminology .....	2
1.2.1 Terminology .....	2
1.2.2 Port Numbering of Components in XAF .....	4
1.3 Xtensa Audio Framework Specifications .....	5
1.3.1 Feature Set .....	5
1.4 Xtensa Audio Framework Performance .....	7
1.4.1 Memory (NCORES=1) .....	7
1.4.2 Timings (NCORES=1) .....	8
1.4.3 Memory (NCORES=2) .....	9
1.4.4 Timings (NCORES=2) .....	10
2. Xtensa Audio Framework Architecture Overview .....	12
2.1 Application Software Architecture with Xtensa Audio Framework .....	12
2.1.1 Application .....	13
2.1.2 Xtensa Audio Framework Building Blocks .....	14
2.1.3 Multicore XAF .....	15
2.1.4 RTOS .....	18
2.1.5 Audio Components .....	18
2.2 Internal Architecture Details of Xtensa Audio Framework .....	19
2.2.1 Control and Data Flow in XAF .....	19
2.2.2 Control and Data Flow in Multicore XAF .....	22
2.2.3 Audio Component Processing Details in DSP Interface Layer .....	24
2.2.4 Audio Component Management .....	26
2.2.5 Event Communication .....	28
2.2.6 Extended set and get Config with Variable Parameter Length .....	29
2.2.7 Input Port Bypass Mode .....	30
2.2.8 Multiple Memory Pools .....	30
2.2.9 Component Connect without buffer allocation .....	33
3. Xtensa Audio Framework Developer APIs .....	34
3.1 Files Specific to XAF Developer APIs .....	40
3.2 XAF Developer API-Specific Error Codes .....	40

3.2.1	Common API Errors.....	40
3.2.2	Specific Errors .....	41
3.2.3	Component Processing Errors .....	41
3.3	XAF Developer APIs.....	42
3.3.1	xaf_adev_open API.....	42
3.3.2	xaf_adev_config_default_init API.....	46
3.3.3	xaf_adev_close API.....	48
3.3.4	xaf_comp_create API .....	48
3.3.5	xaf_comp_config_default_init API.....	51
3.3.6	xaf_comp_delete API .....	52
3.3.7	xaf_comp_set_config API.....	53
3.3.8	xaf_comp_get_config API.....	54
3.3.9	xaf_comp_set_config_ext API.....	55
3.3.10	xaf_comp_get_config_ext API.....	58
3.3.11	xaf_connect API .....	60
3.3.12	xaf_disconnect API.....	62
3.3.13	xaf_comp_process API .....	64
3.3.14	xaf_comp_get_status API.....	66
3.3.15	xaf_pause API.....	67
3.3.16	xaf_resume API .....	68
3.3.17	xaf_probe_start API .....	69
3.3.18	xaf_probe_stop API.....	70
3.3.19	xaf_create_event_channel API.....	70
3.3.20	xaf_delete_event_channel API.....	71
3.3.21	xaf_adev_set_priorities API .....	72
3.3.22	xaf_get_verinfo API .....	74
3.3.23	xaf_get_mem_stats API .....	75
3.3.24	xaf_dsp_open API.....	76
3.3.25	xaf_dsp_close API.....	77
3.4	XAF Configuration Parameters.....	78
4.	Xtensa Audio Framework Package.....	82
4.1	XAF Sample Applications .....	82
4.2	XAF Package Directory Structure.....	90
4.3	Build and Execute using .tgz Package .....	92
4.3.1	Making the Executable .....	92
4.3.2	Usage .....	94
4.3.3	Creating Components on a Worker-Core .....	96
4.4	Build and Execute using .xws Package.....	97
4.4.1	Working with XAF .xws Package.....	97
4.4.2	Switching to FreeRTOS with XAF .xws Package .....	103
4.5	Special Build Options .....	105
4.6	Building FreeRTOS for XAF .....	106
4.7	Building TFLM for XAF .....	106
4.8	Building Multicore Subsystem .....	107

4.8.1	Core Configuration Requirements .....	108
4.8.2	Updating the Shared Memory .....	109
4.8.3	Custom Core-Configuration .....	109
5.	Integration of New Audio Components with XAF .....	115
5.1	Component Modification .....	115
5.2	Component Integration .....	115
5.3	Component Integration – Examples .....	118
6.	Known Limitations .....	120
7.	Appendix: Memory Guidelines .....	121
7.1	Memory Usage and Calculation .....	121
7.2	Memory-related Constants .....	133
8.	Appendix: OSAL APIs .....	137
9.	References .....	140

## Figures

---

Figure 1-1 XAF Terminology .....	3
Figure 1-2 Port Numbered Audio Component.....	4
Figure 2-1 Application Software Stack Diagram (single core).....	12
Figure 2-2 Application Software Stack Diagram (multi core) .....	13
Figure 2-3 Example Music Playback Processing Chain.....	14
Figure 2-4 Multicore-XAF Software Architecture.....	16
Figure 2-5 Multicore-XAF Memory Architecture .....	17
Figure 2-6 XAF Command and Response Flow.....	19
Figure 2-7 XAF Developer API <code>xaf_comp_set_config</code> Control Flow .....	20
Figure 2-8 XAF Developer API <code>xaf_comp_process</code> Control Flow.....	20
Figure 2-9 XAF Control Flow Between Audio Components .....	21
Figure 2-10 Command Flow for Component Creation on Master DSP.....	22
Figure 2-11 Command Flow for Component Creation on Worker DSP .....	23
Figure 2-12 Command Flow for data processing between components on different DSPs ...	24
Figure 2-13 DSP Interface Layer Audio Component Architecture .....	25
Figure 2-14 XAF Audio Codec Class Process Sequence .....	26
Figure 2-15 XAF Audio Components at Creation.....	27
Figure 2-16 XAF Connected Audio Components .....	27
Figure 3-1 Flowgraph Sequence for API Calls on Master Core .....	37
Figure 3-2 Flowgraph Sequence for API Calls of Testbench on Worker DSP.....	39
Figure 4-1 Testbench 1 (pcm-gain) Block Diagram.....	82
Figure 4-2 Testbench 2 (mp3-dec) Block Diagram .....	82
Figure 4-3 Testbench 3 (dec-mix) Block Diagram.....	83
Figure 4-4 Testbench 4 (full-duplex-opus) Block Diagram.....	83
Figure 4-5 Testbench 5 (amr-wb-dec) Block Diagram .....	84
Figure 4-6 Testbench 6 (mp3-dec-renderer) Block Diagram .....	84
Figure 4-7 Testbench 7 (pcm-gain-renderer) Block Diagram.....	84
Figure 4-8 Testbench 8 (capturer-pcm-gain) Block Diagram .....	84
Figure 4-9 Testbench 9 (capturer-mp3-enc) Block Diagram.....	85
Figure 4-10 Testbench 10 (mimo-mix) Block Diagram.....	85
Figure 4-11 Testbench 11 (playback-usecase) Block Diagram .....	86
Figure 4-12 Testbench 12 (renderer-ref-port) Block Diagram.....	87
Figure 4-13 Testbench 13 (capturer-tflite-microspeech) Block Diagram.....	87
Figure 4-14 Testbench 14 (tflite-person-detect) Block Diagram .....	87
Figure 4-15 Testbench 15 (person-detect-microspeech) Block Diagram .....	88

## Tables

Table 1-1 Library Memory .....	7
Table 1-2 Runtime Memory .....	8
Table 1-3 MCPS .....	8
Table 1-4 Library Memory .....	9
Table 1-5 Runtime Memory .....	10
Table 1-6 MCPS .....	11
Table 2-1 Audio Component Types .....	18
Table 2-2 MEM_ID .....	31
Table 2-3 MEM_TYPE .....	32
Table 2-4 MEM_ID stats array offsets for peak memory usage .....	32
Table 3-1 XAF Developer APIs .....	34
Table 3-2 xaf_adev_open API .....	42
Table 3-3 xaf_adev_config_default_init API .....	46
Table 3-4 xaf_adev_close API .....	48
Table 3-5 xaf_comp_create API .....	48
Table 3-6 xaf_comp_config_default_init API .....	51
Table 3-7 xaf_comp_delete API .....	52
Table 3-8 xaf_comp_set_config API .....	53
Table 3-9 xaf_comp_get_config API .....	54
Table 3-10 xaf_comp_set_config_ext API .....	55
Table 3-11 xaf_comp_get_config_ext API .....	58
Table 3-12 xaf_connect API .....	60
Table 3-13 xaf_disconnect API .....	62
Table 3-14 xaf_comp_process API .....	64
Table 3-15 xaf_comp_get_status API .....	66
Table 3-16 xaf_pause API .....	67
Table 3-17 xaf_resume API .....	68
Table 3-18 xaf_probe_start API .....	69
Table 3-19 xaf_probe_stop API .....	70
Table 3-20 xaf_create_event_channel API .....	70
Table 3-21 xaf_delete_event_channel API .....	71
Table 3-22 xaf_adev_set_priorities API .....	72
Table 3-23 xaf_get_verinfo API .....	74
Table 3-24 xaf_get_mem_stats API .....	75
Table 3-25 xaf_dsp_open API .....	76
Table 3-26 xaf_dsp_close API .....	77

Table 3-27	XAF_COMP_CONFIG_PARAM_PROBE_ENABLE Configuration Parameter .....	78
Table 3-28	XAF_COMP_CONFIG_PARAM_RELAX_SCHED Configuration Parameter .....	79
Table 3-29	XAF_COMP_CONFIG_PARAM_PRIORITY Configuration Parameter .....	79
Table 3-30	XAF_COMP_CONFIG_PARAM_DEC_INIT_WO_INP Configuration Parameter .....	80
Table 3-31	XAF_COMP_CONFIG_PARAM_INPORT_BYPASS Configuration Parameter .....	80
Table 4-1	Component Dependencies for Testbenches .....	88
Table 4-2	XWS Test Project List .....	97
Table 4-3	Disable class code build flags .....	106
Table 5-1	Example Components .....	119
Table 7-1	List of Buffers .....	122
Table 7-2	Memory-related Constants .....	133
Table 8-1	OSAL APIs .....	137
Table 8-2	Multicore IPC APIs .....	139



## Document Change History

Version	Changes
1.0	Initial release
1.1	Known issues (Section 6) in Release 1.0 fixed. Minor changes in API (Section 3). Mixer, audio encoder and speech decoder components with the corresponding testbenches added (Section 4).
1.2	Real-time capturer and renderer components added. Xtensa tool chain v6.0.3 (RF-2015.3) supported only.
1.3	Updated Software Stack Diagram (Figure 2.1). Modified library inclusion step in Xtensa-Xplorer (section 4.2). Updated Memory Guidelines (Section 7, Appendix) and added examples.
1.4	Updated Feature Set (Section 1.3.1) and Known Issues (Section 6) about fast functional “TurboXim” ISS mode restriction with XAF. Sample Rate Converter component wrapper is updated to work with Sample Rate Converter v1.9 library.
1.5	Added support for Ogg-Vorbis component sample application. Added xaf_get_mem_info API support. Updated Memory and Timings tables for pcm_gain application on 7.0.5 tools.
2.0	Added new XAF Developer APIs: xaf_pause, xaf_resume, xaf_disconnect, xaf_probe_start and xaf_probe_stop. Updated prototype for XAF Developer API: xaf_connect. Added support for FreeRTOS in XAF. Added support for pre-emptive scheduling of components in XAF. Added support for Multi-Input, Multi-Output (MIMO) processing class in XAF. Added three samples applications to demonstrate use of new XAF Developer APIs. Updated XAF Architecture details in Section 1.4.3. Updated Memory and Timings tables on Xtensa tools chain version RI-2019.2. Added support for Opus encoder plugin component.
2.3	Maintenance release. Added support for Fusion F1 DSP. Renamed App Side XAF to App Interface Layer and DSP Side XAF to DSP Interface Layer. Updated XAF error codes. Updated parameters range for xaf_comp_set_config, xaf_comp_get_config, and xaf_connect APIs. Renamed PCM Mixer component plugin to MIMO Mixer.
2.6	General Availability release.

	<p>Added asynchronous event communication support between two components, between a component and application and between framework and application.</p> <p>Added support for components to request self-scheduling.</p> <p>Added new XAF Developer APIs for event communication: <code>xaf_create_event_channel</code>, <code>xaf_delete_event_channel</code>.</p> <p>Added new XAF Developer APIs to initialize default configuration parameters <code>xaf_adev_config_default_init</code>, <code>xaf_comp_config_default_init</code>.</p> <p>Updated prototype for XAF Developer API: <code>xaf_adev_open</code>, <code>xaf_comp_create</code>.</p> <p>Renamed XAF Developer APIs for backward compatibility: <code>xaf_adev_open_deprecated</code>, <code>xaf_comp_create_deprecated</code>.</p> <p>Updated Memory and Timings tables on Xtensa tools chain version RI-2019.2.</p>
2.10	<p>Added new XAF Developer APIs <code>xaf_comp_set_config_ext</code>, <code>xaf_comp_get_config_ext</code></p> <p>Added support for input-port bypass</p> <p>Added support for decoder initialization without input</p> <p>Added Component Processing Errors section</p> <p>Updated XAF software stack diagram</p> <p>Updated Memory and Timings tables on Xtensa tools chain version RI-2021.6 with XT-CLANG compiler</p> <p>Added support for Opus decoder</p> <p>Added full-duplex Opus test example</p> <p>Removed standalone testbenches of AAC decoder, SRC post-proc, Ogg-Vorbis decoder</p> <p>Added TFLM support, library build steps, test examples and reference</p> <p>Updated steps for 'Working with XAF xws Package' (section 4.4.1)</p> <p>Updated XAF Sample Applications (section 4.1), Component Dependencies for Testbenches (Table 4-1), Example Components (Table 5-1)</p>
3.1	<p>Changes to have a common code base for both XAF-hostless and Multicore XAF solutions.</p> <p>Added software-stack diagrams for Multicore</p> <p>Extended multicore support up to 256 cores (8 bits of message-ID)</p> <p>Updated <code>xaf_adev_config_t</code> added <code>cb_compute_cycles</code> call-back function to collect execution cycles of worker DSPs and added <code>cb_stats</code> shared object pointer passed to the call-back function above.</p> <p>Added shared structure <code>xaf_perf_stats_s</code> consists of shared memory and execution cycle variables for each worker DSP.</p> <p>Added support for level triggered interrupt.</p> <p>Added support for global mutex locks using L32EX/S32EX instructions when <code>XCHAL_HAVE_EXCLUSIVE</code> is set which is mutually exclusive to the other type of instruction S32C1I.</p> <p>Added changes in <code>xaf_adev_config</code> structure for passing separate shared memory pointers for framework buffers and dsp shared buffers.</p> <p>Updated the terminology section 1.2.1 with Multicore specific terms.</p>

	<p>Updated Flowgraph Sequence for API Calls (Figure 3-2)</p> <p>Added the diagrams for Multicore-XAF: Application software stack diagram (Figure 2-2), Software architecture diagram (Figure 2-4), Memory architecture diagram (Figure 2-5).</p> <p>Added the APIs: <code>xaf_dsp_open</code>, <code>xaf_dsp_close</code>.</p> <p>Updated the APIs <code>xaf_adev_open</code>, <code>xaf_adev_close</code>, <code>xaf_get_mem_stats</code> for multicore changes.</p> <p>Updated the examples for <code>xaf_comp_get_config_ext</code>/<code>xaf_comp_set_config_ext</code>.</p> <p>Updated Xtensa Audio Framework Package, Build and Execute using XWS and TGZ Package sections, Memory guidelines for multicore-XAF.</p> <p>Added section 4.7 Building Multicore Subsystem.</p> <p>Added Multicore IPC abstraction API List to Appendix: OSAL APIs.</p>
3.2	<p>XAF-Hostless v3.5 release.</p> <p>Added section 2.2.8 Multiple Memory Pools.</p> <p>Added section 2.2.9 Component connect without buffer allocation.</p> <p>Added alternate flowgraph sequence 3-1(a2) for component connect without initialization support.</p> <p>Compile out options provided to disable specific component classes during XAF library compilation.</p> <p>FreeRTOS version upgraded from v10.2.1-xaf to 10.4.4-stable.</p> <p>Scratch memory alignment updated to 16 bytes.</p> <p>Updated section 7 Memory Guidelines with multiple memory pool related changes and examples.</p> <p>Updated section 1.4 with dec-mix usecase MCPS numbers for NCORES=1 and NCORES=2.</p> <p>Changes in XAF developer APIs:</p> <ol style="list-style-type: none"> <li>1. Removed the following parameters from <code>xaf_adev_config_t</code>: <pre> xaf_mem_malloc_fxn_t *pmem_malloc xaf_mem_free_fxn_t *pmem_free void *pshmem_frmwk </pre> </li> <li>2. Added support for configurable DSP worker thread stack size.</li> <li>3. The following API structures are updated to support multiple memory pools. <pre> xaf_adev_config_t xaf_comp_config_t p_mem_stats (used in xaf_get_mem_stats) </pre> </li> </ol>
3.3	<p>XAF-Hostless v3.6 release.</p> <ul style="list-style-type: none"> <li>• Moved the “Limitations” section to chapter 6.</li> <li>• Removed mixer class-related information as mixer class is removed. In chapter 4, the Mixer component in the figures now refers to MIMO class mixer component.</li> <li>• Updated the figure 2-13 DSP Interface Layer Audio Component Architecture DSP Interface Layer Audio Component Architecture</li> <li>• Updated memory and performance numbers in chapter 1.</li> </ul>

	<ul style="list-style-type: none"><li>• Updated section 2.2.7 Input Bypass Mode and configuration parameter <code>XAF_COMP_CONFIG_PARAM_INPORT_BYPASS</code> related information in chapter 3.</li><li>• Updated section 2.2.8 Multiple Memory Pools and corresponding API-related changes in chapter 3.</li><li>• Added section 4.5 “Special Build Options” to explain the additional build options.</li><li>• Updated latest TFLM library paths in section 4.7.</li><li>• Added information about a new component type “XAF_MIMO_PROC_NN” and its usage details in the table 3-5 <code>xaf_comp_create</code> API</li><li>• Updated supported Xtensa tools version from RI-2022.9 to RI-2023.11</li><li>• Renamed chapter 6 as “Known Limitations” and removed negative MCPS issue with XOS as it is resolved with RI-2023.11 tools.</li><li>• Updated chapter 7 “Memory Guidelines” for memory calculations.</li><li>• Added section 7.2 to explain about the macros that affect memory usage.</li></ul>
--	---

# 1. Introduction to Xtensa Audio Framework

---

Xtensa Audio Framework (XAF) is a framework designed to accelerate the development of audio processing applications for the HiFi family of DSP cores. Application developers may choose components from the rich portfolio of audio and speech libraries already developed by Cadence® and its ecosystem partners. In addition, customers can also package their proprietary algorithms and components and integrate them into the framework. Towards this goal, a simplified “Developer API” is defined, which enables application developers to rapidly create an end application and focus more on using the available components. XAF is designed to work on both the instruction set simulator as well as actual hardware.

The multicore version of XAF described in this guide is designed to work with a subsystem having single or multiple DSPs.

---

<b>Note</b>	It does not assume any Host or controller core and it is a Hostless multicore solution in that sense.
-------------	---

---

## 1.1 Document Overview

This guide covers all the information required to create, configure, and run audio processing chains using XAF Developer APIs.

- Section 2 briefly describes the XAF architecture
- Section 3 provides details about XAF Developer APIs available for the application developer.
- Section 4 provides details about building and running a sample application, which illustrates usage of the XAF Developer APIs.
- Section 5 provides a “How To” guide for adding support for a new component in XAF.
- Section 6 lists known issues.
- Section 7 provides memory allocation guidelines.
- Section 8 lists Operating System Abstraction Layer APIs.
- Section 9 provides references.

---

## 1.2 *Xtensa Audio Framework Terminology*

### 1.2.1 Terminology

The following terms are used within this guide.

**Audio Device:** The software abstraction of a digital signal processor (DSP) core.

**Component:** A software module that conforms to a specified interface and runs on the audio device. It would implement some audio processing functionality.

**Port:** An interface through which a component can connect to other components and exchange data. Each port may be connected to only one port of another component. A component must have at least one port.

**Input Port:** A port through which a component can receive data from another component. A component may have 0 or more input ports.

**Output Port:** A port through which a component can send data to another component. A component may have 0 or more output ports.

**Probe:** Probe is the XAF mechanism for exporting to application, the processed data of specified ports on each process or execution call of the component.

**Link:** The connection between the output port of one component and the input port of another component.

**Buffer:** Memory block containing data that is transferred over a link between two ports which can be either local-memory or global shared-memory.

**Chain:** A graph formed by connecting different components by links.

**Framework:** A software entity that enables the creation of an audio processing chain. It manages the transfer of buffers between components as well as the scheduling of different components in the chain.

**Application:** A software entity that uses the framework to create a chain. It is the responsibility of the application to provide input data to the chain and consume the output data generated by the chain.

**OSAL APIs:** Operating System Abstraction Layer (OSAL) APIs defined to abstract RTOS dependency of XAF through common interfaces.

**Event:** An asynchronous message raised by a component to another component, or to application or to the framework.

**Worker thread:** OS threads running on the DSP Interface layer at various priority levels supported by XAF.

**NCORES:** Number of cores in the subsystem.

Figure 1-1 shows the preceding terms in a diagrammatic form, with an example chain.




Figure 1-1 XAF Terminology

**Multicore XAF:** A subsystem with more than one core with a core designated as Master-DSP and remaining cores as Worker-DSPs. Each worker-DSP communicates with the application via Master-DSP.

---

**Inter Core IPC:** Inter-Core Communication is an abstraction layer which facilitates communication between any two DSPs in the subsystem using interrupts, global shared memory and global locks provided by the subsystem.

**Master DSP:** The DSP or core that has the Application-Interface-Layer. The test application and Worker-DSPs communicate through this Master-DSP.

**Worker DSP:** The DSP or core in the subsystem which is other than the Master-DSP. The Worker-DSPs communicate with the test application with the help of Inter-core IPC-layer and Master-DSP.

**Cache Management:** The Inter-core IPC layer carries out the necessary invalidation, writeback for memory synchronization when the cache is enabled on a DSP.

## 1.2.2 Port Numbering of Components in XAF

In XAF, port numbering of an audio component starts with 0 for the first input port and is incremented for consecutive input ports, followed by output ports.

A component with **n** input ports and **m** output ports has port numbering as shown in Figure 1-2.




Figure 1-2 Port Numbered Audio Component



---

## 1.3 *Xtensa Audio Framework Specifications*

This section provides XAF specifications.

### 1.3.1 Feature Set

#### API Features:

- Ability to create components on a given DSP in the subsystem and connect them in a processing chain.
- Ability to read and write component configuration parameters.
- Ability to read component status and trigger component processing.
- Ability to pause and resume ports of components in a chain at runtime.
- Ability to disconnect and delete or re-connect components in a chain at runtime.
- Ability to probe components at runtime.
- Ability to prioritize components for execution.
- Ability to raise and communicate events between components, or from a component to the application or from a component to the framework.

#### XAF Features:

- Manages the scheduling of components in the chain. There is no explicit restriction on the complexity of the component chain, that is, the number of components/links is restricted only by the hardware resources such as available memory/MHz, and not by XAF.
- Manages the allocation of memory for data buffers for sharing data between application and audio components as well as between any two connected audio components.
- Manages the allocation and deallocation of memory for itself and created components. Dynamic memory allocation within XAF is done through an allocation function registered by the application. This allows the application to control the memory type/region for the allocation.
- Manages the data transfer between components. The buffering of data to match the different block sizes between two connected components is also managed by XAF. Because XAF merely transfers the data between components, there is no restriction on the actual format of the data.  
**Note:** As XAF merely transfers the data between components, application programmers must ensure data format compatibility (sample rate, number of channels, PCM width) between connected components.
- Allows for prioritization of components for execution. At runtime, component instances with higher priority preempts the processing performed by components with lower

---

priority. This feature is useful to ensure timely execution of components with real-time behavior (for example, microphone capture or speaker playback).

- Allows the creation and deletion of event communication channels between two components and between a component and application. Components can send asynchronous messages to application or to another component. Also, component execution errors can be communicated to the application using event channels.
- Allows component to request scheduling for itself.  
**Note:** If component is already scheduled this request is ignored.
- Various component types supported (see Table 2-1), depending on the number of ports and the type of data transferred across the ports (PCM or non-PCM).
- Supports multicore DSP subsystem of a combination of DSPs. The number of cores in the subsystem is configurable between 1 and 16, which is the maximum.

### Example Applications in XAF package:

- Fifteen test applications are provided to demonstrate various use-cases.
- Example code to demonstrate the integration of seven Cadence audio libraries (MP3 decoder, MP3 encoder, AMR-WB decoder, Sample Rate Converter, AAC decoder, Opus decoder and Opus encoder) into XAF is included in this package.  
**Note:** The actual audio libraries must be licensed separately and are not part of this package.
- Optional support for trace prints and cycles profiling is provided for detailed analysis of XAF execution.
- TFLM inference support: With XAF, you can construct and execute TFLM (TensorFlow<sup>[13]</sup> Lite Micro) inference models with different types of inference engines for audio and image input data. The inference model libraries which are downloaded and built using XTENSA tools, are made readily usable by writing appropriate wrapper code (component plugins) which then interacts with the example application through XAF. The test application can provide the input data to the plugins through XAF and retrieve the outputs or inference results seamlessly. This is demonstrated by working examples like micro-speech inference and person-detect inference.

### Supported Configurations:

- HiFi cores: HiFi 3, HiFi 4, and HiFi 5.
- Xtensa Tools Chain: Version RI-2023.11
- Compiler: XT-CLANG
- RTOS: Cadence XOS <sup>[1]</sup> or FreeRTOS (Version 10.4.4) <sup>[12]</sup> (for more information, see Section 2.1.4)

---

<b>Note</b>	XAF is only tested with supported configurations mentioned above with up to NCORES=8.
-------------	---

---

---

## 1.4 Xtensa Audio Framework Performance

The performance is characterized on the 5-stage HiFi DSP processor cores. The memory usage and performance figures are provided for design reference.

### 1.4.1 Memory (NCORES=1)

Table 1-1 Library Memory

Text (Kbytes)			Data
HiFi 3	HiFi 4	HiFi 5	(Kbytes)
51.4	57	57	0.7

---

<b>Note</b>	Other than for Text and Data, XAF uses 2.3 Kbytes for bss. The measurements exclude the memory required by RTOS and the standard C library. The measurements are done with Version RI-2023.11 of the Xtensa tool chain with XOS and compiled with XT-CLANG.
-------------	---

---

The size of the total runtime memory allocated by XAF depends mainly on two types of memory pools – one for buffers required by audio components and another for buffers required for communication. In terms of API, the two parameters are, `mem_pool` indexed between `XAF_MEM_ID_DEV` to `XAF_MEM_ID_DEV_MAX` and `XAF_MEM_ID_COMP` to `XAF_MEM_ID_COMP_MAX` of type `xaf_mem_pool_type_t` in the `xaf_adev_config_t` structure that is passed to the `xaf_adev_open()` function. For more information on the guidelines for setting these parameters, see section 7.

The total runtime memory allocated can be divided into three categories:

1. Local memory allocated by XAF for use by audio components: This is the memory that is allocated by XAF for usage by audio components and it is controlled by `mem_pool[XAF_MEM_ID_COMP]` to `mem_pool[XAF_MEM_ID_COMP_MAX]` parameters of type `xaf_mem_pool_type_t` in the `xaf_adev_config_t` structure passed to the `xaf_adev_open()` function.
2. Shared memory allocated by XAF for communication between application and audio components: This is the memory allocated by XAF to transfer data and messages between application and audio components and it is controlled by `mem_pool[XAF_MEM_ID_DEV]` to `mem_pool[XAF_MEM_ID_DEV_MAX]` parameter of type `xaf_mem_pool_type_t` in the `xaf_adev_config_t` structure passed to the `xaf_adev_open()` function.
3. Memory used by XAF structures: This memory is allocated by XAF for its internal data structures.

Table 1-2 shows the runtime memory allocated by XAF for Testbench 1 as shown in Figure 4-1 (a simple processing chain consisting of single PCM gain component).

Table 1-2 Runtime Memory

No	Memory breakup	RAM (Kbytes)		
		HiFi 3	HiFi 4	HiFi 5
1	Local memory allocated by XAF for use by audio components	83.4	83.4	83.4
2	Shared memory allocated by XAF for communication between application and audio components	40	40	40
3	Memory used by XAF structures	44.9	44.9	44.9
	Total	168.3	168.3	168.3

**Note** The measurements are done with Version RI-2023.11 of the Xtensa tool chain.

**Note** For Testbench 1, `mem_pool[XAF_MEM_ID_DEV].size = 128 KB` and `mem_pool[XAF_MEM_ID_COMP].size = 256 KB` are passed during the `xaf_adev_open()` function call. The actual memory used by XAF for Testbench 1 processing chain is shown in Table 1-2.

## 1.4.2 Timings (NCORES=1)

Table 1-3 contains details for the MCPS usage for the processing function. The “Total” MCPS are the MHz consumed by the entire system. The “XAF” MCPS are the MCPS consumed by XAF. This is measured by subtracting the MCPS consumed by the application and the audio components from the total MCPS.

Table 1-3 MCPS

Use Case		Average CPU Load (MHz)		
		HiFi 3	HiFi 4	HiFi 5
Testbench 1 – PCM Gain (Mono, 44.1KHz, Buffer size = 4096 samples)	XAF	0.4	0.3	0.3
	Total	3.7	2.5	0.6
Testbench 3 – Dec Mix (MIMO mixer with 2 channels at 44.1 KHz, buffer size of 2048 bytes)	XAF	1.4	1.2	1.1
	Total	24.4	17.6	5.9

**Note** The XAF MCPS depends on the complexity of the audio processing chain — this measurement is done for Testbench 1 (a simple processing chain consisting of single PCM gain component) and Testbench 3 (Two instances of Mp3 decoders and a MIMO mixer) with XOS as RTOS, as shown in Figure 4-1.

**Note** Performance specification measurements are carried out on a cycle-accurate simulator assuming an ideal memory system (that is, one with zero memory wait states) for HiFi 3/HiFi 4/HiFi 5 cores. This is equivalent to running with all code and

---

data in local memories or using an infinite-size, pre-filled cache model. The measurements are done with Version RI-2023.11 of the Xtensa tool chain with XOS and compiled with XT-CLANG.

---

### 1.4.3 Memory (NCORES=2)

Table 1-4 Library Memory

Text (Kbytes)			Data (Kbytes)
HiFi 3	HiFi 4	HiFi 5	
59.3	65.6	65.7	0.7

---

**Note** Other than for Text and Data, XAF uses ~2.3 Kbytes for bss. The measurements are per DSP and exclude the memory required by RTOS and the standard C library. The measurements are done with Version RI-2023.11 of the Xtensa tool chain with XOS and compiled with XT-CLANG.

---

The size of the total runtime memory allocated by XAF depends mainly on the three parameters, `mem_pool` indexed between `XAF_MEM_ID_DEV` to `XAF_MEM_ID_DEV_MAX`, `XAF_MEM_ID_COMP` to `XAF_MEM_ID_COMP_MAX`, and `XAF_MEM_ID_DSP` to `XAF_MEM_ID_DSP_MAX` of type `xaf_mem_pool_type_t` in the `xaf_adev_config_t` structure that is passed to the `xaf_adev_open()` function. For more information on the guidelines for setting these parameters, see section 7.

The total runtime memory allocated can be divided into four categories:

1. Local memory allocated by XAF for use by audio components: This is the memory that is allocated by XAF for usage by audio components and it is controlled by `mem_pool[XAF_MEM_ID_COMP]` to `mem_pool[XAF_MEM_ID_COMP_MAX]` parameters of type `xaf_mem_pool_type_t` in the `xaf_adev_config_t` structure passed to the `xaf_adev_open()` function.
2. Shared memory allocated by XAF for communication between application and audio components: This is the memory allocated by XAF to transfer data and messages between application and audio components and it is controlled by `mem_pool[XAF_MEM_ID_DEV]` to `mem_pool[XAF_MEM_ID_DEV_MAX]` parameters of type `xaf_mem_pool_type_t` in the `xaf_adev_config_t` structure passed to the `xaf_adev_open()` function.
3. Shared memory allocated by XAF for communication between audio components on different DSPs: This is the memory allocated by XAF to transfer data and messages between audio components created on different DSPs and it is controlled by `mem_pool[XAF_MEM_ID_DSP]` to `mem_pool[XAF_MEM_ID_DSP_MAX]` parameters of type `xaf_mem_pool_type_t` in the `xaf_adev_config_t` structure passed to the `xaf_adev_open()` function.
4. Memory used by XAF structures: This memory is allocated by XAF for its internal data structures on each DSP in the subsystem.

Table 1-5 shows the runtime memory allocated by XAF for Testbench 1 as shown in Figure 4-1 (a simple processing chain consisting of single PCM gain component created on worker-DSP in a 2-core subsystem with XCHAL\_HAVE\_EXCLUSIVE configuration option enabled).

Table 1-5 Runtime Memory

No	Memory breakup	RAM (Kbytes)		
		HiFi 3	HiFi 4	HiFi 5
1	Local memory allocated by XAF for use by audio components	69.8	69.7	69.9
2	Shared memory allocated by XAF for communication between application and audio components	40.0	40.0	40.0
3	Shared memory allocated by XAF for communication between audio components on different DSPs	34.0	34.0	34.0
4	Memory used by XAF structures	53.8	53.8	53.8
	Total	197.6	197.5	197.7

**Note** The measurements are done with Version RI-2023.11 of the Xtensa tool chain.

**Note** For Testbench 1, `mem_pool[XAF_MEM_ID_DEV].size = 128 KB`, `mem_pool[XAF_MEM_ID_DSP].size = 2432 KB`, and `mem_pool[XAF_MEM_ID_COMP].size = 256 KB` are passed as parameters of the `xaf_adev_config_t` structure during `xaf_adev_open()` call. The actual memory used by XAF for Testbench 1 processing chain is shown in Table 1-5.

## 1.4.4 Timings (NCORES=2)

Table 1-6 contains details for the MCPS usage for the processing function. The “Total” MCPS are the MHz consumed by the entire system. The “XAF” MCPS are the MCPS consumed by XAF. This is measured by subtracting the MCPS consumed by the application and the audio components from the total MCPS.

**Note** The XAF MCPS depends on the complexity of the audio processing chain — this measurement is done for Testbench 1 as shown in Figure 4-1 (a simple processing chain consisting of single PCM gain component created on worker-DSP in a 2-core subsystem with XCHAL\_HAVE\_EXCLUSIVE configuration option enabled) with XOS.

Table 1-6 MCPS

Use Case		Average CPU Load (MHz)		
		HiFi 3	HiFi 4	HiFi 5
Testbench 1 – PCM Gain (Mono, 44.1KHz, Buffer size = 4096 samples)	XAF	0.8	0.7	0.3
	Total	4.1	3.4	0.9
Testbench 3 – Dec Mix (MIMO mixer with 2 channels at 44.1 KHz, buffer size of 2048 bytes)	XAF	3.0	2.6	2.3
	Total	30.9	22.6	9.6

**Note** Performance specification measurements are carried out on a cycle-accurate Xtensa System-C (XTSC) execution environment with 1 cycle-delay/wait-state for memory access for HiFi 3/HiFi 4/HiFi 5 cores. This is nearly equivalent to running with all code and data in local memories or using an infinite-size, pre-filled cache model. The measurements are done with Version RI-2023.11 of the Xtensa tool chain with XOS and compiled with the XT-CLANG compiler.

**Note** For Testbench 3, both the PCM-gain components are on DSP-0, and mimo\_mix4 component is on DSP-1

## 2. Xtensa Audio Framework Architecture Overview

### 2.1 Application Software Architecture with Xtensa Audio Framework

Figure 2-1 and Figure 2-2 show various building blocks of application software based on XAF in single core and multicore subsystems respectively.

**Note** In these figures the application, RTOS, and audio components are not part of XAF. These building blocks are briefly described in the following sections.




Figure 2-1 Application Software Stack Diagram (single core)






Figure 2-2 Application Software Stack Diagram (multi core)

## 2.1.1 Application

In the application, an application developer leverages the XAF Developer APIs to create a processing chain. The XAF Developer API is the interface between the application and XAF, and it enables chains to be set up, configured, and run. XAF Developer APIs also can be used to control and modify the processing chains at runtime. In a multicore subsystem, the processing chains can be partitioned between multiple DSPs.

The maximum number of components in a processing chain depends on the available memory and CPU bandwidth of the system hardware. Figure 2-3 shows an example music playback processing chain that can be created using XAF. Fifteen sample applications (testbenches) are provided with XAF package, which implement fifteen different audio processing chains. Details of these sample applications are described in section 4.




Figure 2-3 Example Music Playback Processing Chain

## 2.1.2 Xtensa Audio Framework Building Blocks

Xtensa Audio Framework (XAF) is responsible for creating, configuring, and running the processing chains through XAF Developer API. Memory management of components, data movement between components, and scheduling of components is all done by XAF internally and is completely abstracted from the application.

As shown in Figure 2-1, XAF architecture includes three major building blocks:

- App Interface Layer
- Inter-Process Connect (IPC)
- DSP Interface Layer

### App Interface Layer

App (Application) Interface Layer is responsible for building and maintaining audio processing chains as per application's need. There is no actual audio processing done at this layer. Instead, it is a control code that runs in application thread context at highest priority with respect to the other two building blocks. App Interface Layer manages the operation of underlying DSP Interface Layer by sending commands and receiving responses from it. App Interface Layer also creates an IPC thread that receives responses from the DSP Interface Layer for the commands sent from the application. This thread runs at higher priority than the DSP Interface Layer thread.

### IPC

Inter-Process Connect (IPC) is the communication link between App Interface Layer and DSP Interface Layer. It passes commands and responses between two layers and it has no knowledge about information being passed.

### DSP Interface Layer

DSP Interface Layer does the actual audio processing based on commands received from App Interface Layer and sends responses back to App Interface Layer after command completion.

---

Based on commands received from App Interface Layer, it creates, configures, and connects components to create processing chain and executes the components to perform audio processing. The DSP Interface Layer runs in a separate thread context at lowest priority with regard to the other two building blocks. In DSP Interface Layer, by default all components execute in the single thread context at same priority and there is no pre-emption of one component execution by another. For advanced applications, some components may be required to execute at higher priority than others and it is supported in XAF by a separate developer API (see Table 3-22 for details).

---

**Note** In this case, multiple DSP worker threads are created based on the number of different priority components. An example application for pre-emption could be where capturer and renderer components are configured with higher priority with respect to other data processing components so that processing of captured microphone data or playback of output PCM data is done in timely fashion without any gaps.

---

## 2.1.3 Multicore XAF

### Multicore XAF Requirements

- Inter-core communication takes place through the shared memory which must be accessible by all the cores.
- Local memories of a core must be accessible from other cores through the in-bound PIF.
- Interrupts must be supported by all DSPs for inter-core communication. Each core needs at least one edge-triggered or level-triggered interrupt ( $\leq$  EXCM Level) dedicated for inter-processor notification.
- The cores must be configured with Processor ID option.
- All cores must have same byte ordering.
- For inter-core synchronization, all cores must be enabled with exclusive load/store instructions (L32EX/S32EX) with XCHAL\_HAVE\_EXCLUSIVE enabled. Alternately, all cores must have conditional stores (S32C1I) feature enabled.
- For cores with XCHAL\_HAVE\_EXCLUSIVE, global lock object must be located in a memory region with attributes: non-cacheable, shareable, bufferable.
- Cache-line size must be identical for all the cores.

In addition to the building blocks described in section 2.1.2, multicore XAF subsystem includes the following changes as shown in Figure 2-2.

### Inter Core Communication Interface

Inter Core communication (Inter Core IPC) interface is the communication link between available DSP cores. This is a thin IPC layer implemented using software linked list. The message and

payload buffers are allocated on the DSP shared memory pool. Interrupt notification mechanism to other cores is done using edge-triggered or level-triggered interrupt. Interrupt numbers (XA\_EXTERNAL\_INTERRUPT\_NUMBER) for all the cores is identical. The interrupted core resumes processing if it was blocked on the interrupt event. All messages and payloads for Inter Core IPC MSGQ must be cache-line size aligned.

## Message Communication in Multicore Scenario

Application pipeline is created by the master DSP. Any command (Developer API call from application) from the App Interface Layer is sent to the DSP Interface Layer of the Master DSP through RTOS IPC channel. The App Interface Layer runs only on the Master DSP. DSP Interface Layer on the Master DSP, either routes the messages to self (its local message queue) or enqueues it into the destination core's Inter Core IPC MSGQ by using IPC locks and then interrupts the destination core. DSP Interface Layer runs on all DSPs. Processing of commands and responses by DSP Interface Layer on each DSP core is identical. Figure 2-4 shows the multicore software architecture and inter core IPC message communication details.




Figure 2-4 Multicore-XAF Software Architecture

DSP Interface Layer on each DSP checks for any messages in its Inter Core IPC MSGQ or from its Local MSGQ. If a message is available, it is processed by the DSP Interface Layer. Once the message is processed successfully, depending on the destination, the response is sent to either Proxy IPC MSGQ on the Master DSP if the destination is App Interface Layer or is enqueued

into another core's Inter Core IPC MSGQ if the destination is a component on another core or enqueued into its own Local MSGQ if the destination component is within the same core.

## Memory Architecture

Three different types of memory pools are required in multicore XAF:

- Application shared memory pool:

To allocate buffers that interact with the application. Only the Master DSP allocate these buffers.

- DSP shared memory pool:

To allocate the connect buffers between components on different DSP cores. Any DSP core can allocate buffers from this DSP shared memory pool. Allocate and free operations from this pool is protected by platform specific global lock.

- DSP local memory pool:

To allocate memory for input, persistent, scratch, stack, component buffers, event buffers and connect buffers between audio components on the same DSP core.

Figure 2-5 shows an example pipeline in which the blocks A, B, C, D are the audio components in the subsystem consisting of Master DSP-0, worker DSP-1 and worker DSP2.




Figure 2-5 Multicore-XAF Memory Architecture

## 2.1.4 RTOS

XAF uses RTOS to create multiple threads required for its functioning as described in section 2.1.2. The application may also require threads to feed input and/or consume output data for components connected to it. Also, Inter-Process Connect is implemented using RTOS message queues and mutex. Cadence XOS <sup>[1]</sup> and Xtensa port of FreeRTOS V10.4.4 <sup>[12]</sup> are supported with XAF. Operating System Abstraction Layer (OSAL) is defined for all RTOS functionality requirements in XAF. The OSAL APIs are described in section 8.

<b>Note</b>	XOS is released with the Xtensa tools SDK and is not a part of the XAF release package.
<b>Note</b>	Xtensa port of FreeRTOS is not a part of the XAF release package. See section 4.6 for details about downloading and building FreeRTOS for XAF.

## 2.1.5 Audio Components

Audio components are the actual data processing modules. XAF interacts with audio components using Cadence Audio Codec API (DSP Developer API). Cadence Audio Codec APIs are described in detail in <sup>[2]</sup>. Section 5 contains details on how to add a new audio component in XAF. Table 2-1 lists various audio component types supported by XAF in the current release. Component types are defined by data processing functionality and number of input and output ports.

Table 2-1 Audio Component Types

Component Type	Input		Output		Component Description
	Ports	PCM	Ports	PCM	
Decoder	1	N	1	Y	Decodes input compressed data to generate output PCM data.
Encoder	1	Y	1	N	Encodes input PCM data to generate output compressed data.
Pre-processing	1	Y	1	Y	Pre-processes input PCM data to generate output PCM data.
Post processing	1	Y	1	Y	Post-processes input PCM data to generate output PCM data.
Renderer	1	Y	1 <sup>1</sup>	NA	Plays input PCM data to a speaker/headphone.
Capturer	0	NA	1	Y	Captures output PCM data from a microphone.
MIMO	4 <sup>2</sup>	Y	4 <sup>3</sup>	Y	Multi-Input Multi-Output (MIMO) component process input PCM data to generate output PCM data.

<sup>1</sup> Renderer component has one optional output port (can be used as feedback path for echo cancellation).

<sup>2</sup> Maximum number of input ports for MIMO components is 4.

<sup>3</sup> Maximum number of output ports for MIMO component is 4.

---

## 2.2 Internal Architecture Details of Xtensa Audio Framework

This section provides detailed information about the internal architecture and implementation details of XAF.

### 2.2.1 Control and Data Flow in XAF

As briefly discussed in section 2.1.2, XAF architecture includes three major building blocks: App Interface Layer, Inter-Process Connect (IPC), and DSP Interface Layer. App Interface Layer and DSP Interface Layer pass control and data using commands and responses through Inter-Process Connect as shown in Figure 2-6.




Figure 2-6 XAF Command and Response Flow

All of the XAF Developer API calls except `xaf_comp_process` and `xaf_probe_start` API calls are blocking or synchronous; that is, the API call waits for response from DSP Interface Layer for command completion. A synchronous example of XAF Developer API is `xaf_comp_set_config` API (see Table 3-8 for details). Figure 2-7 shows the control flow sequence for `xaf_comp_set_config`.




Figure 2-7 XAF Developer API xaf\_comp\_set\_config Control Flow




Figure 2-8 XAF Developer API xaf\_comp\_process Control Flow



XAF Developer APIs `xaf_comp_process` (see Table 3-14 for API details) and `xaf_probe_start` (see Table 3-18 for API details) are non-blocking or asynchronous. Specifically, the API call does not wait for response from DSP Interface Layer for command completion, rather the response from DSP Interface Layer can be queried for by `xaf_comp_get_status` API (see Table 3-15 for API details) at any later point of time. Figure 2-8 shows control flow sequence for these API calls where application feeds input data to audio component id-0. When audio component id-0 consumes the input data, it sends the response to the application.

**Note** The `xaf_comp_get_status` API call blocks if there is any pending response on the component.

Audio components connected with each other on DSP Interface Layer also use commands and responses to share data with each other through local message queue. Note, this local message queue is internal to DSP Interface Layer and different from IPC, the API between App Interface Layer and DSP Interface Layer. The audio component communication is shown in Figure 2-9 where the application feeds input data to audio component id-0, which is then connected to audio component id-1 and output of audio component id-1 is sent back to application.

**Note** For simplification and ease of understanding, Figure 2-8 and Figure 2-9 do not show all transactions.




Figure 2-9 XAF Control Flow Between Audio Components

## 2.2.2 Control and Data Flow in Multicore XAF

Section 2.2.1 provides a generic overview of control and data flow in XAF. This section aims to provide illustrations of how components are created on master and worker DSPs in a multicore subsystem and how data flow occurs between two components that are created on two different DSP cores.

Figure 2-10 shows how components are created on the master DSP (DSP0) using `xaf_comp_create` API.




Figure 2-10 Command Flow for Component Creation on Master DSP

Figure 2-11 shows how components are created on a worker DSP (DSP1) using `xaf_comp_create` API.




Figure 2-11 Command Flow for Component Creation on Worker DSP

Figure 2-12 shows how data flow occurs between two DSPs, namely DSP0 and DSP1.




Figure 2-12 Command Flow for data processing between components on different DSPs

This diagram explains how data is processed and communicated between components on different DSPs. Like command flow described in Figure 2-9, the source component on DSP-0 sends data to the destination component on DSP-1 (EMPTY\_THIS\_BUFFER) and after consuming this input data, the destination component returns the buffer back to the source component (FILL\_THIS\_BUFFER). Here the red dotted lines denote Inter-DSP communication.

## 2.2.3 Audio Component Processing Details in DSP Interface Layer

DSP Interface Layer uses an object-oriented class like architecture for managing, scheduling, and executing various audio components as shown in Figure 2-13. Generic base class provides the functionality common to all components (for example, memory allocations or deallocations). Various derived classes that inherit the base class are defined based on input-output ports and data processing pattern of components. Each derived class implementation defines handling of input and output data on its I/O ports. It also defines pause, resume, connect, and disconnect functionality for the class. The following derived classes are defined in the current XAF version.

- Audio Codec Class – Supports components with one input port and one output port. Suitable for audio decoders, encoders, and pre/post-processing modules.

- Multi-Input Multi-Output (MIMO) Class – Supports components with multiple input ports and multiple output ports. Suitable for PCM processing modules with multiple input, output ports, such as PCM Splitter, Mixer, or Acoustic Echo Canceler. Maximum number of input or output ports is defined to four in current version of XAF.
- Capturer Class – Supports components with zero input port and one output port. Defined for microphone capture modules.
- Renderer Class – Supports components with one input port and zero or one optional output port. Defined for speaker playback modules. Optional output port is defined for feedback or reference data which can be used for echo cancellation.




Figure 2-13 DSP Interface Layer Audio Component Architecture

The generic base class and derived class use Cadence Audio Codec API to interact with audio component plugins, hence it is required that any audio component for XAF must support Cadence Audio Codec API.

**Note** The actual component plugin libraries are not part of XAF and must be provided to the application at link time.

Each derived class implements process or execution function for its components with a three-step function:

- First step is pre-process, which prepares input and output ports for execution
- Second step is actual processing of data by the component plugin library
- Third step is post-process, which manages input and output data after execution

---

Figure 2-14 shows process function for Audio Codec Class with highlighting calls made to audio component plugin library using Cadence Audio Codec API.

---

**Note** The pre-process also passes input-over message to component plugin library when input is over, and post-process also flushes output ports when execution-complete message is received from component plugin library.

---

EDF (Earliest Deadline First) scheduling policy used in post-process for rescheduling of the component is described in section 2.2.4.




Figure 2-14 XAF Audio Codec Class Process Sequence

## 2.2.4 Audio Component Management

To explain XAF audio component I/O buffer management, scheduling, etc., this section uses a simple audio processing pipeline where PCM Gain component (applies gain on input PCM data) receives input data from the application and is connected to MP3 Encoder, and output of MP3 Encoder is sent back to the application. When PCM Gain component is created with two input buffers to receive data from the application and MP3 Encoder is created with one output buffer to send data back to the application, various buffers are allocated in XAF as shown in Figure 2-15.




Figure 2-15 XAF Audio Components at Creation

Both PCM Gain and MP3 Encoder components have one input port and one output port, and are created as Audio Codec Class components. Normally, one internal input buffer and one internal persistent buffer is always allocated for each component. In this example, it is assumed that both components are at the same priority, hence they run in the same thread context and share the scratch buffer.

**Note** XAF requires scratch memory size to be largest of scratch memory requirement of all components running in the same thread context (that is, same priority). The sizes of input, output, persistent, and scratch buffers are queried from component library by XAF using Cadence Audio Codec API.

**Note** No output buffer is allocated for PCM Gain component yet.




Figure 2-16 XAF Connected Audio Components

When PCM Gain component output port is connected to MP3 Encoder input port using `xaf_connect` API with two buffers (see Table 3-12 for API details), connect buffers are

---

allocated by XAF (BUF1 and BUF2) as shown in Figure 2-10. The size of these two buffers would be equal to output buffer size requirement of PCM Gain component.

---

<b>Note</b>	In XAF, when buffer arrives at input port of a component either from preceding component or application, input data is copied into component's internal input buffer if the buffer exists and during processing, output data is always produced in the received output buffer at output port either from succeeding component or application. Buffer arrived at input port is sent back only after all input data is consumed and buffer received at output port is sent back whenever output data of non-zero size is produced in it.
-------------	--

---

XAF uses “Earliest Deadline First” (EDF) scheduler to manage scheduling of various audio components in the processing chain. When input port is ready (input data is available at input port) and when output port is ready (output buffer is available at output port), the component is scheduled for data processing or execution. Each component execution consumes some input data and produces some output data. If input and output ports are still ready after one execution, the component is scheduled for next execution based on its next deadline. The timestamp computed using output PCM samples produced or input PCM samples consumed and sample rate of data is used as the deadline measure by EDF scheduler in XAF.

With XAF, audio components with different frame sizes can be seamlessly connected with each other at application level. XAF internal design with EDF scheduler manages audio components operating with different frame sizes. For example, if PCM Gain component processes 1024 PCM samples in one execution and MP3 encoder processes 4096 samples in one execution as shown in Figure 2-10, PCM Gain would get scheduled and executed four times for each execution of MP3 Encoder automatically in XAF. Note that XAF allows processing with partial input data and it is the responsibility of the component to decide whether to process or wait for more input data.

## 2.2.5 Event Communication

XAF supports asynchronous event communication between two components, or between a component and application, or between framework and application. To enable event communication, an event channel is established using the `xaf_create_event_channel` API (Table 3-20) , and such a channel can be deleted using `xaf_delete_event_channel` API (Table 3-21). Event communication between two components can be established independent of a routed port between them.

A callback function is registered during component creation with the configuration parameter `XAF_COMP_CONFIG_PARAM_EVENT_CB`. At runtime, when source component detects an event, it notifies the framework through the callback function. Framework then queries for the associated payload from the source component using `get-config-param` API call. It then forms a notification message with the acquired payload and sends it to the destination component or application (as set-up by application programmer). The common message passing infrastructure already available in XAF is used for event communication as well. If the event destination is another component, upon receiving such notification message, the framework passes it to the destination component by `set-config-param` API call. Finally, the message (and the associated buffer) is sent back to framework (source component) for reuse. If the event destination is application, the message is received by proxy / IPC thread in App Interface Layer. Application



---

may register a separate callback function to receive events during device creation. If the callback function is available, application is notified of the event and associated payload, else the event is ignored without raising any error. In either case, the message (and the associated buffer) is returned to the source.

The event channels are also used to communicate component processing errors to the application. Application developer must configure error channel creation with the configuration parameter `error_channel_ctl` during component creation with appropriate value, where `XAF_ERR_CHANNEL_DISABLE` indicates no error reporting (the default), `XAF_ERR_CHANNEL_FATAL` indicates only fatal error reporting, and `XAF_ERR_CHANNEL_ALL` indicates both fatal and non-fatal error reporting. Also between 1 and 4 error buffers of size 4 bytes each can be configured with the configuration parameter `num_err_msg_buf`.

For event to application channels (including error channels), event buffers are created at the App Interface Layer and are sent to the DSP Interface Layer during event channel creation. If an error occurs during event message handling, the error is updated onto its error field.

---

**Note** Every message has an error field which is used to report errors back to the sender.

---

Upon receiving such an error, the App Interface Layer communicates it to the application via the callback function and avoids sending the event buffer back to the DSP Interface Layer. If the event channel is an error channel, then the error code is also copied into the error buffer provided by the application. For non-error channels, the App Interface Layer sets the error flag which indicates to the application that the component is in error and any appropriate action can be taken by the application.

---

**Note** For `NCORES>1`, the event channel buffers are allocated from shared memory for an event from component to application and for an event between components with source and destination on different DSPs.

---

The components can use the event callback function to request self-scheduling using `XAF_COMP_CONFIG_PARAM_SELF_SCHED` configuration parameter.

## 2.2.6 Extended set and get Config with Variable Parameter Length

XAF provides support to set and get the configuration parameters of variable length between the application and the component plugins through `xaf_set_config_ext` API (Table 3-10) and `xaf_get_config_ext` API (Table 3-11). The length of the parameter value can be more than 4 bytes and up to a maximum of 8 KB. These two APIs use a pair containing the configuration parameter ID and the pointer to `xaf_ext_buffer_t` structure.

There are two modes of using the extended set or get config API. In one mode (non-zero-copy), the parameter value from the application is copied into an internal framework buffer that is passed to the component plugin at DSP Interface Layer. In the other “zero-copy” mode, the pointer provided by the application is directly passed to the component plugin. The zero-copy mode can be activated by setting a flag (`XAF_EXT_PARAM_FLAG_OFFSET_ZERO_COPY`) in

---

`ext_config_flags`. Two macros are provided to set and clear the flag, namely `XAF_EXT_PARAM_SET_FLAG` and `XAF_EXT_PARAM_CLEAR_FLAG`.

In the normal mode (non-zero-copy), the application can configure the buffer size using `cfg_param_ext_buf_size_max` variable of the component config structure `xaf_comp_config_t` during component creation. The buffer size is used to allocate a dedicated buffer specifically for these two extended config APIs.

---

**Note** Each call of `xaf_set_config_ext` or `xaf_get_config_ext` API supports up to eight configuration parameter IDs, so the size of `cfg_param_ext_buf_size_max` must be configured by the application accordingly.

---

## 2.2.7 Input Port Bypass Mode

By default, an input buffer is allocated to each of the component's input ports and its size is queried from the component. However, certain use cases may require that the connect-buffer pointer is set as input buffer pointer for the component during each execution call, thus avoiding the input-buffer copy overhead and the input buffer memory allocation. To enable the input bypass mode, the component needs to be configured with `XAF_COMP_CONFIG_PARAM_INPORT_BYPASS` config parameter during initial setup.

For input bypass mode to work, the following is assumed: the output frame size of the preceding component must be equal to or multiple of input frame size of this component and this component must consume the data when presented for processing, even when the input length is less than input frame size (partial frame). The Input bypass mode is not supported for components that do not consume partial data.

---

**Note** An input port cannot be probed if the bypass mode is enabled.

---

## 2.2.8 Multiple Memory Pools

A memory pool is a block or chunk of memory of data type `xaf_mem_pool_type_t` as shown in the below table (in API header file `xaf-api.h`), and the values of pointer, size, and ID should be allocated by the application. The array of this structure type is passed to the XAF library through the `xaf_adev_config_t` structure to `xaf_adev_open` and `xaf_dsp_open` APIs. These memory pools are then used to allocate and manage memory for components (persistent, scratch, input, output, or connect buffers), shared framework, and DSP buffers.

Each memory pool is distinguished and indexed by an enumerator constant of `XAF_MEM_ID` type (defined in the user configurable API header file `xaf-config-user.h`). The default pool types are `XAF_MEM_ID_DEV` and `XAF_MEM_ID_COMP`.

```
typedef struct xaf_mem_pool_type_s {
    pVOID      pmem;      /* ...memory pool pointer. */
    UWORD32    size;      /* ...memory pool size.    */
    XAF_MEM_ID mem_id;     /* ...memory pool id.      */
}xaf_mem_pool_type_t;
```

**XAF\_MEM\_ID\_DEV to XAF\_MEM\_ID\_DEV\_MAX:** Memory allocated by application for shared buffers and shared structures between the App Interface Layer and DSP Interface Layer. The size must be aligned to 64 bytes and the minimum size is 16 kB (for XAF structures). For NCORES>1, the pointer should point to the global shared memory accessible by all the DSPs in the subsystem. For more information on memory guidelines, see section 7.

**XAF\_MEM\_ID\_COMP to XAF\_MEM\_ID\_COMP\_MAX:** Memory allocated by application for various audio component buffers and structures required by the DSP Interface Layer. The size must be aligned to 64 bytes and the minimum size is 73 kB (includes 56 kB for scratch and 17 kB for XAF structures). For more information on memory guidelines, see section 7.

**XAF\_MEM\_ID\_DSP to XAF\_MEM\_ID\_DSP\_MAX:** Global shared memory allocated by application to allocate connect buffers and event buffers between DSPs and the shared structures required for DSP-DSP IPC. The pointer and size be aligned to XCHAL\_DCACHE\_LINESIZE (or minimum 64 bytes) and the minimum size of the memory is 35 KB. For more information on memory guidelines, see section 7.

Table 2-2 MEM\_ID

<b>XF_MEM_ID</b>	<b>Variables in xaf_adev_config_t</b>
XAF_MEM_ID_DEV  XAF_MEM_ID_DEV_FAST  XAF_MEM_ID_DEV_MAX = XAF_MEM_ID_DEV_FAST	xaf_mem_pool_type_t mem_pool[XAF_MEM_ID_DEV] xaf_mem_pool_type_t mem_pool[XAF_MEM_ID_DEV_FAST]
XAF_MEM_ID_COMP  XAF_MEM_ID_COMP_FAST  XAF_MEM_ID_COMP_MAX = XAF_MEM_ID_COMP_FAST	xaf_mem_pool_type_t mem_pool[XAF_MEM_ID_COMP] xaf_mem_pool_type_t mem_pool[XAF_MEM_ID_COMP_FAST]
XAF_MEM_ID_DSP  XAF_MEM_ID_DSP_FAST  XAF_MEM_ID_DSP_MAX = XAF_MEM_ID_DSPP_FAST	xaf_mem_pool_type_t mem_pool[XAF_MEM_ID_DSP] xaf_mem_pool_type_t mem_pool[XAF_MEM_ID_DSP_FAST]

These memory pools can have different characteristics such as speed or latency.

The following table describes XAF\_COMP\_MEM\_TYPE enumerator constant.

Table 2-3 MEM\_TYPE

XAF_COMP_MEM_TYPE	Description
XAF_MEM_POOL_TYPE_COMP_INPUT = 0 XAF_MEM_POOL_TYPE_COMP_OUTPUT = 1 XAF_MEM_POOL_TYPE_COMP_PERSIST = 2 XAF_MEM_POOL_TYPE_COMP_SCRATCH = 3	Component memory-types (Input, Output, Persistent, Scratch)
XAF_MEM_POOL_TYPE_COMP_APP_INPUT = 4 XAF_MEM_POOL_TYPE_COMP_APP_OUTPUT = 5	memory-types of output buffer to application for edge components

Each memory type of a component can be from a different memory pool. Memory types to memory pool association is user-configurable during component creation by updating the variable `mem_pool_type` in the `xaf_comp_config_t` structure. The enumerator type `XAF_MEM_ID` can be modified to add more memory pools as required. The additional memory pools for component memory can be defined as values between `XAF_MEM_ID_COMP` and `XAF_MEM_ID_COMP_MAX`. Similarly, you can define additional memory pools for the framework memory (between `XAF_MEM_ID_DEV` and `XAF_MEM_ID_DEV_MAX`), for DSP-DSP shared memory (between `XAF_MEM_ID_DSP` and `XAF_MEM_ID_DSP_MAX`). All the worker DSPs also should provide valid memory-pool pointers, sizes, and IDs for `XAF_MEM_ID_COMP` to `XAF_MEM_ID_COMP_MAX` and `XAF_MEM_ID_DSP` to `XAF_MEM_ID_DSP_MAX` since `XAF_MEM_ID` is a common enumeration for all the DSPs and the memory pool type indexes should be in sync.

The API `xaf_get_mem_stats` can be called at the end of the execution to get memory usage info, that is, the peak usage in number of bytes for each of the memory pools configured by you at the offsets shown in Table 2-4.

**Note** There can be up to a maximum of 8 distinct memory pools of each ID type, exceeding which a fatal `XAF_INVALIDVAL_ERR` is returned by the library.

Table 2-4 MEM\_ID stats array offsets for peak memory usage

XAF_MEM_ID	Offset in the array of integer
<code>XAF_MEM_ID_COMP</code>	0
<code>XAF_MEM_ID_DEV</code>	1
Local Memory used by Framework (App interface Layer)	2
<code>XAF_MEM_ID_COMP + 1 ... XAF_MEM_ID_COMP_MAX</code>	k=5 ... k++
<code>XAF_MEM_ID_DEV + 1 ... XAF_MEM_ID_DEV_MAX</code>	k ... k++
<code>XAF_MEM_ID_DSP + 1 ... XAF_MEM_ID_DSP_MAX</code>	k ... k++

---

## 2.2.9 Component Connect without buffer allocation

XAF supports connecting components without initializing them, that is, a complete pipeline can be set up by creating and connecting the components even when input data is not available. In this case, when the API `xaf_connect` is called before calling `xaf_comp_process (XAF_START_FLAG)`, only the connect buffer structures are allocated. The actual buffers are allocated at the end of successful initialization of the component. This feature can be enabled with the API call sequence explained in Figure 3-1 (a2).

---

**Note** Only one of the API sequences in Figure 3-1 (a1) or Figure 3-1 (a2) is required.

---

---

## 3. Xtensa Audio Framework Developer APIs

---

This section discusses XAF Developer APIs that are available for the application programmer to create, configure, and run audio processing chains.


XAF Developer APIs are summarized in Table 3-1.

Table 3-1 XAF Developer APIs


API Type	XAF Developer API	Can be called at runtime?
Startup API	xaf_adev_open	No
	xaf_dsp_open#	No
	xaf_comp_create	Yes
Configuration API	xaf_comp_set_config	Yes
	xaf_comp_get_config	Yes
	xaf_adev_set_priorities	No
	xaf_comp_set_config_ext	Yes
	xaf_comp_get_config_ext	Yes
Connect API	xaf_connect	Yes
	xaf_disconnect	Yes
Process API	xaf_comp_process	Yes
	xaf_comp_get_status	Yes
Control API	xaf_pause	Yes
	xaf_resume	Yes
Probe API	xaf_probe_start	Yes
	xaf_probe_stop	Yes
Closure API	xaf_adev_close	No
	xaf_dsp_close#	No
	xaf_comp_delete	Yes
Information API	xaf_get_verinfo	Yes
	xaf_get_mem_stats	Yes
Event Communication API	xaf_create_event_channel	Yes
	xaf_delete_event_channel	Yes
Default Configuration API	xaf_adev_config_default_init	No
	xaf_comp_config_default_init	No

# xaf\_dsp\_open, xaf\_dsp\_close APIs must be used by worker core application. These APIs are available only with NCORES > 1.

Figure 3-1 shows the flow graph for a typical application.




(a1) Flowgraph sequence for API calls of testbench



(a2) Flowgraph sequence for API calls of testbench for connect without initialization





(b) Flowgraph sequence for API calls for each input and output component in the graph

Figure 3-1 Flowgraph Sequence for API Calls on Master Core

The following is a brief description of the flowgraph sequence on master core:

- **Initialize XAF:** The XAF is initialized by calling `xaf_adev_config_default_init`, which updates the default values for `xaf_adev_config_t` structure parameters. This is followed by a call to `xaf_adev_open`. The framework memory allocation is performed at this stage.
- **Create Processing Chain:** The various components in the chain are instantiated by calling `xaf_comp_config_default_init` which updates the default values for `xaf_comp_config_t` structure parameters. This is followed by a call to

---

`xaf_comp_create` for each component. Then, the component configuration parameters (if any) are set using `xaf_comp_set_config`. The components are initialized using `xaf_comp_process` with the `XAF_START_FLAG` flag and are connected using `xaf_connect`.

---

**Note** In general, audio decoder components require input data during initialization to determine input stream parameters, such as sample rate or number of channels. So, the initialization loop shown in Figure 3-1 (a1) that feeds input data to the component during initialization is required only for those audio decoder components which need input data to initialize, and such loop is not required for encoder or PCM data processing components or for the audio decoder components that can be initialized without input data. An alternate control flow shown in Figure 3-1 (a2), allows to construct the full pipeline without requiring input data (for more information, see section 2.2.9).

---

- **Process Data:** Input and output data is passed to the components using `xaf_comp_process`. This must be performed only for components that must be supplied with input/output data (typically the edge components of the chain). The component status must be queried using `xaf_comp_get_status`. This stage continues until all the data has been processed.
- **Delete Processing Chain:** The various components of the chain are deleted by calling `xaf_comp_delete`.
- **Terminate XAF:** The XAF is terminated by calling `xaf_adev_close`. The memory allocated by the framework is freed at this stage.
- The following features are available in XAF at runtime:
  - **Pause or resume ports:** Consumption or production of data on a port can be paused by using `xaf_pause` API. A paused port can be resumed by using `xaf_resume` API.
  - **Probe components:** Probing of data on input and/or output ports of a component can be started by using `xaf_probe_start` API and probing can be stopped by using `xaf_probe_stop` API.  
**Note:** The component needs to be configured to enable probe feature before these APIs can be used run time.
  - **Disconnect and reconnect components:** Any connected output ports of a component can be dynamically disconnected by using `xaf_disconnect` API. Components also can be connected or reconnected dynamically by using `xaf_connect` API.
  - **Event communication:** An asynchronous event communication channel can be established between two components or between a component and application with `xaf_create_event_channel` API and the same can be deleted with `xaf_delete_event_channel` API.

- 
- Self-scheduling: The components can request self-scheduling by raising the `XAF_COMP_CONFIG_PARAM_SELF_SCHED` event to framework.




Figure 3-2 Flowgraph Sequence for API Calls of Testbench on Worker DSP

The following is a brief description of the flowgraph sequence on worker DSP cores:

- Open worker DSP: The worker DSP is initialized by calling `xaf_adev_config_default_init`, which updates the default values for `xaf_adev_config_t` structure parameters. This is followed by a call to `xaf_dsp_open`. All the required memory is allocated at this stage. A DSP-thread is created in this step.
- Close worker DSP: In the execution sequence, the worker core application blocks on the join call to the DSP-thread in `xaf_dsp_close`. Once the DSP-thread is joined, all the allocated memory is freed.

---

## 3.1 Files Specific to XAF Developer APIs

### XAF Developer API Header File (/include/)

- `xaf-api.h`
- `xaf-config-user.h`

## 3.2 XAF Developer API-Specific Error Codes

The errors in this section can result from the XAF Developer API call of the Xtensa Audio Framework. All errors are fatal (unrecoverable) errors. In response to an error, the function `xaf_adev_close(p_adev, XAF_ADEV_FORCE_CLOSE)` may be called to close the device and release resources used by XAF.

### 3.2.1 Common API Errors

- **XAF\_INVALIDPTR\_ERR**  
This error indicates that a null pointer was passed to the XAF Developer API where a valid pointer was expected.
- **XAF\_INVALIDVAL\_ERR**  
This error code indicates that an invalid value (out of valid range) was passed to the XAF Developer API.
- **XAF\_RTOS\_ERR**  
This error code indicates an internal error, typically caused when one of the RTOS calls made within XAF returns an error.
- **XAF\_API\_ERR**  
This error code generally indicates that the XAF Developer API is called out of order, for example, `xaf_comp_create()` is called before `xaf_adev_open()`.  
**Note:** This error is also returned if an incorrect response is received from the DSP Interface Layer for command sent by the XAF Developer API.
- **XAF\_MEMORY\_ERR**  
This error code indicates an internal error, caused due to memory allocation failure or availability issue.

---

## 3.2.2 Specific Errors

The following errors are specific to some APIs.

- **XAF\_ROUTING\_ERR**  
This error code indicates that the XAF Developer API `xaf_connect()` or `xaf_disconnect()` did not successfully connect or disconnect the two requested components.
- **XAF\_TIMEOUT\_ERR**  
This error code is returned if XAF Developer API `xaf_comp_get_status()` does not receive pending response from DSP Interface Layer within defined wait time limit. The maximum wait time is defined by `MAXIMUM_TIMEOUT` (10000 ms) in current version of XAF.

## 3.2.3 Component Processing Errors

The following APIs can return component processing error when it occurs:

```
xaf_comp_get_config, xaf_comp_set_config,  
xaf_comp_get_config_ext, xaf_comp_set_config_ext,  
xaf_pause, xaf_resume,  
xaf_connect, xaf_disconnect
```

---

<b>Note</b>	For <code>xaf_comp_set_config</code> , <code>xaf_comp_get_config</code> , <code>xaf_comp_set_config_ext</code> , and <code>xaf_comp_get_config_ext</code> APIs, the error returned is the first non-fatal error from the component when there are multiple parameters being queried and if multiple non-fatal errors occur.
-------------	---

---

## 3.3 XAF Developer APIs

This section contains tables describing the XAF Developer APIs.

### 3.3.1 xaf\_adev\_open API

Table 3-2 xaf\_adev\_open API

API	XAF_ERR_CODE xaf_adev_open(pVOID *pp_adev, xaf_adev_config_t *pconfig);										
Description	This API opens and initializes the audio device structure, which is a parent structure for all XAF operations. It starts the processing thread that performs all the audio processing on the DSP Interface Layer and starts the IPC thread. It also allocates local memory to be used by the audio components on the DSP Interface Layer and shared memory for communication between the App Interface Layer and the DSP Interface Layer.										
Actual Parameters	pp_adev Address of a pointer to the audio device. This API call allocates memory for the audio device and updates this pointer with it.										
	pconfig Pointer to an initialized structure that contains the necessary parameters for this API. The structure members are as follows:										
	<table><tr><th>Parameter</th><th>Description</th></tr><tr><td>xaf_mem_pool_type_t mem_pool[XAF_MEM_ID_MAX]</td><td>Array of memory pools of type xaf_mem_pool_type_t containing pointer, size and ID (of type XAF_MEM_ID enumerator) which is allocated by the application for all the defined enumerators of type XAF_MEM_ID.</td></tr><tr><td>void *pframework_local_buffer</td><td>Pointer to the memory allocated by the application for local structures required in the App Interface Layer.</td></tr><tr><td>UWORD32 framework_local_buffer_size</td><td>Size of pframework_local_buffer. This size must be greater than 5 KB for FreeRTOS and 26 KB for XOS.</td></tr><tr><td>UWORD32 proxy_thread_priority</td><td>Priority level for the proxy thread at the App Interface Layer. This value</td></tr></table>	Parameter	Description	xaf_mem_pool_type_t mem_pool[XAF_MEM_ID_MAX]	Array of memory pools of type xaf_mem_pool_type_t containing pointer, size and ID (of type XAF_MEM_ID enumerator) which is allocated by the application for all the defined enumerators of type XAF_MEM_ID.	void *pframework_local_buffer	Pointer to the memory allocated by the application for local structures required in the App Interface Layer.	UWORD32 framework_local_buffer_size	Size of pframework_local_buffer. This size must be greater than 5 KB for FreeRTOS and 26 KB for XOS.	UWORD32 proxy_thread_priority	Priority level for the proxy thread at the App Interface Layer. This value
	Parameter	Description									
	xaf_mem_pool_type_t mem_pool[XAF_MEM_ID_MAX]	Array of memory pools of type xaf_mem_pool_type_t containing pointer, size and ID (of type XAF_MEM_ID enumerator) which is allocated by the application for all the defined enumerators of type XAF_MEM_ID.									
	void *pframework_local_buffer	Pointer to the memory allocated by the application for local structures required in the App Interface Layer.									
UWORD32 framework_local_buffer_size	Size of pframework_local_buffer. This size must be greater than 5 KB for FreeRTOS and 26 KB for XOS.										
UWORD32 proxy_thread_priority	Priority level for the proxy thread at the App Interface Layer. This value										

		must be greater than dsp_thread_priority.
	UWORD32 dsp_thread_priority	Priority level for the DSP thread at the DSP Interface Layer. This value must be lower than proxy_thread_priority.
	UWORD32 proxy_thread_stack_size	Stack size of Proxy-thread.
	UWORD32 dsp_thread_stack_size	Stack size of DSP-thread.
	UWORD32 worker_thread_stack_size[XAF_MAX_WORKER_THREADS]	Array of stack size of DSP-worker-threads. The 0 <sup>th</sup> index of the array defines the stack size of the background priority worker thread. The Subsequent index corresponds to the stack size of threads from base priority onwards.
	UWORD32 worker_thread_scratch_size[XAF_MAX_WORKER_THREADS]	Array of scratch memory sizes for worker threads. 0 <sup>th</sup> index of the array defines the scratch size of background priority worker thread. The Subsequent index corresponds to the scratch size of threads from base priority onwards.
	xaf_app_event_handler_fxn_t app_event_handler_cb	<p>Callback function is registered by the application to receive events. If no application events are required, this can be set to NULL. If so, the events, if any, are dropped at the App Interface Layer.</p> <p>WORD32 (*xaf_app_event_handler_fxn_t) (pVOID comp_ptr, UWORD32 config_param_id, pVOID config_buf_ptr, UWORD32 buf_size, UWORD32 comp_error_flag)</p> <p>comp_ptr: Component handle associated with the event.</p>

		<p><code>config_param_id:</code> Configuration parameter id for the event to application.</p> <p><code>config_buf_ptr:</code> Event buffer pointer.</p> <p><code>buf_size:</code> Size of the event buffer in bytes.</p> <p><code>comp_error_flag:</code> Indicates whether the event is an error message (1) or not (0). For non-error event channels, it indicates that the component are in fatal error.</p>
	UWORD32 core	Core ID of master core
	<p>int</p> <p>(*cb_compute_cycles)</p>	<p>Function pointer to the computation routine that calculates the worker-thread cycles for all DSPs and framework cycles for worker-DSP. This must have prototype</p> <pre>int cb_total_frmwrk_cycles (xaf_perf_stats_t *cb_stats);</pre> <ol style="list-style-type: none"> <li>1. Called during execution of <code>xaf_adev_close</code> to calculate worker-thread cycles for all DSPs</li> <li>2. Called from <code>xaf_dsp_close</code> to calculate worker DSP cycles.</li> </ol> <p>For more information, refer to <code>cb_total_frmwrk_cycles</code> function in <code>test/src/xaf-clk-test.c</code>.</p>
	<p><code>xaf_perf_stats_t</code></p> <p>*cb_stats</p>	<p>Pointer to a <code>xaf_perf_stats_t</code> structure that contains necessary parameters for calculating MCPS and memory consumption for a particular core.</p> <p>The application must provide a valid structure pointer.</p> <p>This is updated by <code>xaf_dsp_close</code> with Worker-DSP memory stats.</p>



		The structure members are as follows:	
		<b>Parameter</b>	<b>Description</b>
		long long tot_cycles	Total cycles consumed by all rtos threads
		long long frmwk_cycles	Cycles consumed by the framework
		long long dsp_comps_cycles	Cycles consumed by DSP components
		int dsp_comp_buf_size_peak [XAF_MEM_ID_MAX]	Peak usage of component buffer of a memory pool types XAF_MEM_ID_COMP to XAF_MEM_ID_COMP_MAX memory pool index on a worker-DSP.
		int dsp_shmem_buf_size_peak [XAF_MEM_ID_MAX]	Peak usage of DSP-DSP shared memory buffer of a memory pool type XAF_MEM_ID_DSP to XAF_MEM_ID_DSP_MAX in the subsystem.
		int dsp_framework_local_buf_size_peak	Local Memory used by framework structures on the worker-DSP.

<b>Restrictions</b>	<p><b>Prerequisite:</b> The RTOS startup procedure must be invoked before calling this function. The procedures for XOS and FreeRTOS are as follows.</p> <ul style="list-style-type: none"> <li>For XOS: <ol style="list-style-type: none"> <li><code>xos_set_clock_freq()</code> to set the core clock frequency.</li> <li><code>xos_start_main()</code> to start the scheduler.</li> <li><code>xos_start_system_timer()</code> to start the timer for scheduling.</li> </ol> <p>Refer to the function <code>start_rtos()</code> under <code>#if defined (HAVE_XOS)</code> in the <code>test/src/xaf-utils-test.c</code> file for an example.</p> </li> <li>For FreeRTOS: <p>The start-up procedure for FreeRTOS involves starting the main thread and starting the scheduler by calling the function <code>vTaskStartScheduler()</code>.</p> <p>For an example, refer to the function <code>init_rtos()</code> under <code>#ifdef HAVE_FREERTOS</code> in the <code>test/src/xaf-utils-test.c</code> file.</p> <p>Only one instance of XAF can run at a time.</p> </li> </ul>
---------------------	---

## Example

```
ret = xaf_adev_open(&p_adev, &adev_config);
```

## Errors

- Common API Errors

### 3.3.2 xaf\_adev\_config\_default\_init API

Table 3-3 xaf\_adev\_config\_default\_init API

<b>API</b>	XAF_ERR_CODE <code>xaf_adev_config_default_init(xaf_adev_config_t *pconfig)</code>
<b>Description</b>	This API sets default values for audio device configuration.
<b>Actual Parameters</b>	<code>p_config</code> Pointer to an initialized <code>xaf_adev_config_t</code> structure.

	Structure variable	Default value
	mem_pool[XAF_MEM_ID_COMP ... XAF_MEM_ID_COMP_MAX].size	512 KB
	pVOID mem_pool[0 ... XAF_MEM_ID_MAX].pmem	NULL
	mem_pool[XAF_MEM_ID_DEV].size	272 KB
	pVOID mem_pool[XAF_MEM_ID_DEV+1 ... XAF_MEM_ID_DEV_MAX].size	512 KB
	pVOID mem_pool[0 ... XAF_MEM_ID_MAX].pmem	NULL
	mem_pool[XAF_MEM_ID_DSP ... XAF_MEM_ID_DSP_MAX].size	512 KB
	UWORD32 framework_local_buffer_size	26 KB for XOS, 5 KB for FreeRTOS
	void *pframework_local_buffer	NULL
	proxy_thread_priority	XAF_PROXY_THREAD_PRIORITY (6)
	dsp_thread_priority	XAF_DSP_THREAD_PRIORITY (5)
	proxy_thread_stack_size	8 KB
	dsp_thread_stack_size	8 KB
	worker_thread_stack_size[0 ... XAF_MAX_WORKER_THREADS]	8 KB
	worker_thread_scratch_size	56 KB
	app_event_handler_cb	NULL
	core	MASTER_CORE_ID
	cb_compute_cycles	NULL
	cb_stats	NULL
<b>Restrictions</b>	Must be called before xaf_adev_open API	

## Example

```
ret = xaf_adev_config_default_init(&adev_config);
```

## Errors

- Common API Errors

---

### 3.3.3 xaf\_adev\_close API

Table 3-4 xaf\_adev\_close API

API	XAF_ERR_CODE xaf_adev_close(pVOID p_adev, xaf_comp_flag flag)
Description	This API closes the audio device and frees up allocated memory. It also stops DSP thread and IPC thread execution.
Actual Parameters	<p>p_adev Pointer to the audio device</p> <p>flag</p> <ul style="list-style-type: none"><li>• XAF_ADEV_FORCE_CLOSE: Forces close of the audio device, even when there are existing components. This option can be used to close the device following a fatal error.</li><li>• XAF_ADEV_NORMAL_CLOSE: Returns an error if there are active components in the chain. This option can be used to close the device in the normal sequence of operation.</li></ul>
Restrictions	Must not be called before xaf_adev_open API. All components must be deleted before closing the audio device. The device must be force closed <i>only</i> for a fatal error condition (that is, with the XAF_ADEV_FORCE_CLOSE flag, even when all components are not deleted).

#### Example

```
ret = xaf_adev_close(p_adev, XAF_ADEV_NORMAL_CLOSE);
```

#### Errors

- Common API Errors

### 3.3.4 xaf\_comp\_create API

Table 3-5 xaf\_comp\_create API

API	XAF_ERR_CODE xaf_comp_create(pVOID p_adev, pVOID *pp_comp, xaf_comp_config_t *pconfig);
Description	This API creates the audio component. The audio component is identified by comp_id and comp_type. You can specify the number of input and output buffers for the component. The I/O buffer requirement is dependent upon the position of the component in the audio processing chain; see the parameter description for details.

Actual Parameters	<code>p_adev</code> Pointer to the audio device structure																																	
	<code>pp_comp</code> Address of pointer to the audio component structure																																	
	<p><code>p_config</code> Pointer to an initialized structure that contains the necessary parameters for this API. The structure members are as below:</p> <table> <tr> <th>Parameter</th><th>Description</th></tr> <tr> <td><code>xf_id_t</code> <code>comp_id</code></td><td>Component identifier string. e.g. "mimo41/mimo-mix4", "audio-decoder/mp3", etc. It must match with <code>class_ids</code> defined under the constant definition of <code>xf_component_id</code> in <code>xa-factory.c</code> file (For more information on how to add a new audio component in XAF, see section 5.</td></tr> <tr> <td><code>xaf_comp_type</code> <code>comp_type</code></td><td>           Type of audio component. Following are valid values:           <table> <tr> <th>Type</th><th>Description</th></tr> <tr> <td><code>XAF_DECODER</code></td><td>Decoder component</td></tr> <tr> <td><code>XAF_ENCODER</code></td><td>Encoder component</td></tr> <tr> <td><code>XAF_PRE_PROC</code></td><td>Preprocessing component</td></tr> <tr> <td><code>XAF_POST_PROC</code></td><td>Post processing component</td></tr> <tr> <td><code>XAF_RENDERER</code></td><td>Renderer component</td></tr> <tr> <td><code>XAF_CAPTURER</code></td><td>Capturer component</td></tr> <tr> <td><code>XAF_MIMO_PROC_12</code></td><td>MIMO component with 1 input and 2 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_21</code></td><td>MIMO component with 2 input and 1 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_41</code></td><td>MIMO component with 4 input and 1 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_22</code></td><td>MIMO component with 2 input and 2 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_23</code></td><td>MIMO component with 2 input and 3 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_10</code></td><td>MIMO component with 1 input and 0 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_11</code></td><td>MIMO component with 1 input and 1 output ports</td></tr> </table> </td></tr> </table>	Parameter	Description	<code>xf_id_t</code> <code>comp_id</code>	Component identifier string. e.g. "mimo41/mimo-mix4", "audio-decoder/mp3", etc. It must match with <code>class_ids</code> defined under the constant definition of <code>xf_component_id</code> in <code>xa-factory.c</code> file (For more information on how to add a new audio component in XAF, see section 5.	<code>xaf_comp_type</code> <code>comp_type</code>	Type of audio component. Following are valid values: <table> <tr> <th>Type</th><th>Description</th></tr> <tr> <td><code>XAF_DECODER</code></td><td>Decoder component</td></tr> <tr> <td><code>XAF_ENCODER</code></td><td>Encoder component</td></tr> <tr> <td><code>XAF_PRE_PROC</code></td><td>Preprocessing component</td></tr> <tr> <td><code>XAF_POST_PROC</code></td><td>Post processing component</td></tr> <tr> <td><code>XAF_RENDERER</code></td><td>Renderer component</td></tr> <tr> <td><code>XAF_CAPTURER</code></td><td>Capturer component</td></tr> <tr> <td><code>XAF_MIMO_PROC_12</code></td><td>MIMO component with 1 input and 2 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_21</code></td><td>MIMO component with 2 input and 1 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_41</code></td><td>MIMO component with 4 input and 1 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_22</code></td><td>MIMO component with 2 input and 2 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_23</code></td><td>MIMO component with 2 input and 3 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_10</code></td><td>MIMO component with 1 input and 0 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_11</code></td><td>MIMO component with 1 input and 1 output ports</td></tr> </table>	Type	Description	<code>XAF_DECODER</code>	Decoder component	<code>XAF_ENCODER</code>	Encoder component	<code>XAF_PRE_PROC</code>	Preprocessing component	<code>XAF_POST_PROC</code>	Post processing component	<code>XAF_RENDERER</code>	Renderer component	<code>XAF_CAPTURER</code>	Capturer component	<code>XAF_MIMO_PROC_12</code>	MIMO component with 1 input and 2 output ports	<code>XAF_MIMO_PROC_21</code>	MIMO component with 2 input and 1 output ports	<code>XAF_MIMO_PROC_41</code>	MIMO component with 4 input and 1 output ports	<code>XAF_MIMO_PROC_22</code>	MIMO component with 2 input and 2 output ports	<code>XAF_MIMO_PROC_23</code>	MIMO component with 2 input and 3 output ports	<code>XAF_MIMO_PROC_10</code>	MIMO component with 1 input and 0 output ports	<code>XAF_MIMO_PROC_11</code>
Parameter	Description																																	
<code>xf_id_t</code> <code>comp_id</code>	Component identifier string. e.g. "mimo41/mimo-mix4", "audio-decoder/mp3", etc. It must match with <code>class_ids</code> defined under the constant definition of <code>xf_component_id</code> in <code>xa-factory.c</code> file (For more information on how to add a new audio component in XAF, see section 5.																																	
<code>xaf_comp_type</code> <code>comp_type</code>	Type of audio component. Following are valid values: <table> <tr> <th>Type</th><th>Description</th></tr> <tr> <td><code>XAF_DECODER</code></td><td>Decoder component</td></tr> <tr> <td><code>XAF_ENCODER</code></td><td>Encoder component</td></tr> <tr> <td><code>XAF_PRE_PROC</code></td><td>Preprocessing component</td></tr> <tr> <td><code>XAF_POST_PROC</code></td><td>Post processing component</td></tr> <tr> <td><code>XAF_RENDERER</code></td><td>Renderer component</td></tr> <tr> <td><code>XAF_CAPTURER</code></td><td>Capturer component</td></tr> <tr> <td><code>XAF_MIMO_PROC_12</code></td><td>MIMO component with 1 input and 2 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_21</code></td><td>MIMO component with 2 input and 1 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_41</code></td><td>MIMO component with 4 input and 1 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_22</code></td><td>MIMO component with 2 input and 2 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_23</code></td><td>MIMO component with 2 input and 3 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_10</code></td><td>MIMO component with 1 input and 0 output ports</td></tr> <tr> <td><code>XAF_MIMO_PROC_11</code></td><td>MIMO component with 1 input and 1 output ports</td></tr> </table>	Type	Description	<code>XAF_DECODER</code>	Decoder component	<code>XAF_ENCODER</code>	Encoder component	<code>XAF_PRE_PROC</code>	Preprocessing component	<code>XAF_POST_PROC</code>	Post processing component	<code>XAF_RENDERER</code>	Renderer component	<code>XAF_CAPTURER</code>	Capturer component	<code>XAF_MIMO_PROC_12</code>	MIMO component with 1 input and 2 output ports	<code>XAF_MIMO_PROC_21</code>	MIMO component with 2 input and 1 output ports	<code>XAF_MIMO_PROC_41</code>	MIMO component with 4 input and 1 output ports	<code>XAF_MIMO_PROC_22</code>	MIMO component with 2 input and 2 output ports	<code>XAF_MIMO_PROC_23</code>	MIMO component with 2 input and 3 output ports	<code>XAF_MIMO_PROC_10</code>	MIMO component with 1 input and 0 output ports	<code>XAF_MIMO_PROC_11</code>	MIMO component with 1 input and 1 output ports					
Type	Description																																	
<code>XAF_DECODER</code>	Decoder component																																	
<code>XAF_ENCODER</code>	Encoder component																																	
<code>XAF_PRE_PROC</code>	Preprocessing component																																	
<code>XAF_POST_PROC</code>	Post processing component																																	
<code>XAF_RENDERER</code>	Renderer component																																	
<code>XAF_CAPTURER</code>	Capturer component																																	
<code>XAF_MIMO_PROC_12</code>	MIMO component with 1 input and 2 output ports																																	
<code>XAF_MIMO_PROC_21</code>	MIMO component with 2 input and 1 output ports																																	
<code>XAF_MIMO_PROC_41</code>	MIMO component with 4 input and 1 output ports																																	
<code>XAF_MIMO_PROC_22</code>	MIMO component with 2 input and 2 output ports																																	
<code>XAF_MIMO_PROC_23</code>	MIMO component with 2 input and 3 output ports																																	
<code>XAF_MIMO_PROC_10</code>	MIMO component with 1 input and 0 output ports																																	
<code>XAF_MIMO_PROC_11</code>	MIMO component with 1 input and 1 output ports																																	

		XAF_MIMO_PROC_NN	MIMO component with 1 input and 1 output ports												
		<b>Note:</b> The type XAF_MIMO_PROC_NN is suggested for components which operate on frame-rate (frames per second) basis (TFLM examples) instead of sample-rate used by other component types.													
	UWORD32 num_input_buffers	Unsigned integer containing the number of input buffers. This is the number of buffers that the testbench needs to pass to the component. For components connected in the chain where it receives input from other components, this must be configured as zero (0). Valid values: 0, 1, 2.													
	UWORD32 num_output_buffers	Unsigned integer containing the number of output buffers. This is the number of buffers that the component passes to the testbench as output. For components connected in the chain where the output is passed to another component, this must be configured as zero (0). Valid values: 0, 1.													
	pVOID (*pp_inbuf) [XAF_MAX_INBUFS]	Pointer to the array to hold ninbuf input buffer addresses that have been allocated within XAF. If the pointer is NULL, the input buffer addresses are be returned.													
	UWORD32 error_channel_ctl	Variable to indicate what type of error channel to be created. <table><tr><th>Enum</th><th>Numeric al value</th><th>Type of error channel</th></tr><tr><td>XAF_ERR_CHANNEL_DISABLE</td><td>0</td><td>Does not create error channel</td></tr><tr><td>XAF_ERR_CHANNEL_FATAL</td><td>1</td><td>Error channel only reports fatal error</td></tr><tr><td>XAF_ERR_CHANNEL_ALL</td><td>2</td><td>Error channel only reports fatal and non-fatal error</td></tr></table>		Enum	Numeric al value	Type of error channel	XAF_ERR_CHANNEL_DISABLE	0	Does not create error channel	XAF_ERR_CHANNEL_FATAL	1	Error channel only reports fatal error	XAF_ERR_CHANNEL_ALL	2	Error channel only reports fatal and non-fatal error
Enum	Numeric al value	Type of error channel													
XAF_ERR_CHANNEL_DISABLE	0	Does not create error channel													
XAF_ERR_CHANNEL_FATAL	1	Error channel only reports fatal error													
XAF_ERR_CHANNEL_ALL	2	Error channel only reports fatal and non-fatal error													
	UWORD32 num_err_msg_buf	Unsigned integer indicating the number of error buffers that are allocated to capture fatal or non-fatal errors. Valid values: 1, 2, 3, 4. Default value: 2													

	UWORD32 cfg_param_ext_buf_size_max	Maximum size required for all values of the extended configuration parameter in one call of xaf_comp_set_config_ext or xaf_comp_get_config_ext for the component. For more information, see section 2.2.6.
	UWORD32 core	Core ID of the component.
	UWORD32 mem_pool_type[XAF_MEM_POOL_TYPE_COMPONENT_MAX]	Array of memory pools of the component's memory types. For more information, see section 2.2.8.
<b>Restrictions</b>	Must not be called before the xaf_adev_open API	

## Example

```
ret = xaf_comp_create(p_adev, pp_comp, &comp_config);
```

## Errors

- Common API Errors

## 3.3.5 xaf\_comp\_config\_default\_init API

Table 3-6 xaf\_comp\_config\_default\_init API

<b>API</b>	XAF_ERR_CODE xaf_comp_config_default_init(xaf_comp_config_t *pconfig)	
<b>Description</b>	This API sets default values for component configuration.	
<b>Actual Parameters</b>	p_config Pointer to an initialized xaf_comp_config_t structure.	
	<b>Structure variable</b>	<b>Default value</b>
	comp_id	"post-proc/pcm_gain"
	comp_type	XAF_POST_PROC
	num_input_buffers	2
	num_output_buffers	1
	error_channel_ctl	XAF_ERR_CHANNEL_DISABLE(0)
	num_err_msg_buf	2
	pp_inbuf	NULL
	cfg_param_ext_buf_size_max	0

	core	XF_CORE_ID_MASTER
	mem_pool_type[XAF_MEM_POOL_TYPE_COMP_APP_INPUT, XAF_MEM_POOL_TYPE_COMP_APP_OUTPUT]	XAF_MEM_ID_DEV
	mem_pool_type[XAF_MEM_POOL_TYPE_COMP_INPUT ... XAF_MEM_POOL_TYPE_COMP_SCRATCH]	XAF_MEM_ID_COMP
Restrictions	Must be called before xaf_comp_create API	

### Example

```
ret = xaf_comp_config_default_init(&comp_config);
```

### Errors

- Common API Errors

## 3.3.6 xaf\_comp\_delete API

Table 3-7 xaf\_comp\_delete API

API	XAF_ERR_CODE xaf_comp_delete(pVOID p_comp)
Description	This API deletes the audio component and frees the memory associated with it.
Actual Parameters	p_comp Pointer to the audio component structure
Restrictions	<p>Must not be called before xaf_comp_create API.</p> <p>Must not be called while application has thread waiting for pending responses from the component.</p> <p>Must be called once all the application threads have exited under normal execution conditions (after __xf_thread_join API). To force close the device, xaf_adev_close API with XAF_ADEV_FORCE_CLOSE flag must be used.</p> <p><b>Note:</b> This API deletes any associated event channel with the component before initiating component deletion.</p>

### Example

```
ret = xaf_comp_delete(p_audioComp);
```



---

## Errors

- Common API Errors

### 3.3.7 xaf\_comp\_set\_config API

Table 3-8 xaf\_comp\_set\_config API

<b>API</b>	<code>XAF_ERR_CODE xaf_comp_set_config(pVOID p_comp, WORD32 num_param, pWORD32 p_param)</code>
<b>Description</b>	<p>This API sets (writes) configuration parameters to the audio component.</p> <p><code>num_param</code> provides the number of configuration parameters to be set. <code>p_param</code> points to an array containing ID/value pairs for all <code>num_param</code> parameters.</p> <p>For example, for two parameters, <code>p_param</code> contains ID1, VAL1, ID2, and VAL2.</p> <p>This API can also set (write) three configuration parameters to the XAF. These three parameters are discussed in detail in section 3.4.</p>
<b>Actual Parameters</b>	<p><code>p_comp</code> Pointer to the audio component structure</p> <p><code>num_param</code> Integer containing the number of parameters to be set. The maximum limit is 32.</p> <p><code>p_param</code> Pointer to an integer array containing ID/Value pairs – that is, parameter ID followed by parameter value.</p>
<b>Restrictions</b>	<p>Must not be called before <code>xaf_comp_create</code> API.</p> <p>Each parameter value must be of size 4 bytes.</p>

## Example

```
ret = xaf_comp_set_config(p_comp,  
                          N_PARAMS,  
                          &param[0]);
```

## Errors

- Common API Errors
- Non-fatal errors from component.

### 3.3.8 xaf\_comp\_get\_config API

Table 3-9 xaf\_comp\_get\_config API

<b>API</b>	XAF_ERR_CODE xaf_comp_get_config(pVOID p_comp, WORD32 num_param, pWORD32 p_param)
<b>Description</b>	<p>This API gets (reads) configuration parameters from the audio component. num_param provides the number of configuration parameters to get. p_param points to an array containing ID/value pairs for all num_param parameters.</p> <p>For example, for two parameters, p_param contains ID1, VAL1, ID2, VAL2. VAL1 and VAL2 can contain any arbitrary value, as they are over-written when the function returns.</p> <p>Upon successful execution of this API, the value field of the ID/value pair is set to the value received from audio component.</p>
<b>Actual Parameters</b>	<p>p_comp Pointer to the audio component structure</p> <p>num_param Integer containing the number of parameters to get. The maximum limit is 32.</p> <p>p_param Pointer to an integer array containing ID/Value pairs – that is, parameter ID followed by parameter value.</p>
<b>Restrictions</b>	<p>Must not be called before xaf_comp_create API.</p> <p>Each parameter value is of size 4 bytes.</p>

#### Example

```
ret = xaf_comp_get_config(p_comp,  
                          N_PARAMS,  
                          &param[0]);
```

#### Errors

- Common API Errors
- Non-fatal error from component.

### 3.3.9 xaf\_comp\_set\_config\_ext API

Table 3-10 xaf\_comp\_set\_config\_ext API

API	XAF_ERR_CODE xaf_comp_set_config_ext (pVOID p_comp, WORD32 num_param, WORD32 *p_param)										
Description	<p>This API sets (writes) configuration parameters to the audio component of variable length.</p> <p>num_param provides the number of configuration parameters to be set.</p> <p>p_param points to an integer array containing ID and pointer to xaf_ext_buffer_t structure pairs for all num_param parameters.</p> <p>For example, for two parameters, p_param contains ID1, EXT_BUF_PTR1, ID2, and EXT_BUF_PTR 2.</p> <p><b>Note:</b> This API is intended for variable length data transfer between application and component plugins and not a replacement for the xaf_comp_set_config API used for component initialization or framework specific configuration parameters as discussed in Section 3.4.</p>										
Actual Parameters	<p>p_comp Pointer to the audio component structure</p> <p>num_param Integer containing the number of parameters to be set. The maximum number of parameters allowed per API call is 8.</p> <p>p_param Pointer to an integer array containing ID and a pointer to xaf_ext_buffer_t structure pairs.</p> <p>xaf_ext_buffer_t structure has following members</p> <table><tr><th>Parameter</th><th>Description</th></tr><tr><td>UWORD32 max_data_size</td><td>Maximum data size that can be read or written</td></tr><tr><td>UWORD32 valid_data_size</td><td>Valid data size that can be read or written</td></tr><tr><td>UWORD32 ext_config_flags</td><td>XAF_EXT_PARAM_FLAG_OFFSET_ZERO_COPY (bit offset 0) to indicate zero copy mode. For more information, see section 2.2.5.</td></tr><tr><td>UWORD8 *data</td><td>Pointer to data buffer</td></tr></table>	Parameter	Description	UWORD32 max_data_size	Maximum data size that can be read or written	UWORD32 valid_data_size	Valid data size that can be read or written	UWORD32 ext_config_flags	XAF_EXT_PARAM_FLAG_OFFSET_ZERO_COPY (bit offset 0) to indicate zero copy mode. For more information, see section 2.2.5.	UWORD8 *data	Pointer to data buffer
Parameter	Description										
UWORD32 max_data_size	Maximum data size that can be read or written										
UWORD32 valid_data_size	Valid data size that can be read or written										
UWORD32 ext_config_flags	XAF_EXT_PARAM_FLAG_OFFSET_ZERO_COPY (bit offset 0) to indicate zero copy mode. For more information, see section 2.2.5.										
UWORD8 *data	Pointer to data buffer										
Restrictions	Must not be called before xaf_comp_create API.										

---

## Example

```
/*... Test Application Part */
int data0[4], data1[6];          /*...      Variable      length
parameters */
WORD32 param_ext [N_PARAMS * 2 ]; /*... N_PARAMS = 2 */
bool is_shared_mem = false;      /* ...flag for cache management */
int *p_shared_data0 = NULL;
int shared_mem_used=0;           /* ...cumulative bytes used */
extern void *p_shared_mem;      /* ...global shared memory pointer */
if((NCORES>1) && (XA_ZERO_COPY)) /*... XA_ZERO_COPY=1 if 'Zero
copy mode' feature is to be used for any one of the parameter */
{
    /*...shared memory is required only if parameter is to be set
    on component on another DSP. */
    xaf_ext_buffer_t      *ext_buf=(xaf_ext_buffer_t      *)
    p_shared_mem;
    shared_mem_used += (N_PARAMS *sizeof(xaf_ext_buffer_t));
    is_shared_mem = true;

    p_shared_data0 = (int) p_shared_mem + shared_mem_used;
    shared_mem_used += sizeof(data0);
    memcpy(p_shared_data0, &data0, sizeof(data0));
    XF_IPC_FLUSH(p_shared_data0, sizeof(data0)); /* ...flush
    shared memory before sending */
}
else
    xaf_ext_buffer_t ext_buf [N_PARAMS];

    ext_buf[0].max_data_size = sizeof(data0);
    ext_buf[0].valid_data_size = sizeof(data0);
    ext_buf[0].ext_config_flags |= XAF_EXT_PARAM_SET_FLAG
(XAF_EXT_PARAM_FLAG_OFFSET_ZERO_COPY);
    if(p_shared_data0)
        ext_buf[0].data = (UWORD8 *)p_shared_data0; /* ...pass the
    pointer to component */
    else
        ext_buf[0].data = (UWORD8 *)data0;

    /* ...data1 is usefor non-ZERO_COPY example */
    ext_buf[1].max_data_size = sizeof(data1);
    ext_buf[1].valid_data_size = sizeof(data1);
    ext_buf[1].ext_config_flags &= XAF_EXT_PARAM_CLEAR_FLAG
(XAF_EXT_PARAM_FLAG_OFFSET_ZERO_COPY);
    ext_buf[1].data = (UWORD8 *)data1;
```

---

```

param_ext[0] = CONFIG_PARAM_ID0;
param_ext[1] = (WORD32)&ext_buf[0];
param_ext[2] = CONFIG_PARAM_ID1;
param_ext[3] = (WORD32)&ext_buf[1];

if(is_shared_mem == true)
    XF_IPC_FLUSH(ext_buf, sizeof(xaf_ext_buffer_t));

ret = xaf_comp_set_config_ext(p_comp,
                             N_PARAMS,
                             &param_ext[0]);

/*... Plugin or component part */
#include "api.h"
xa_set_param (WORD32 param_id, void *p_val)
{
    if(param_id == CONFIG_PARAM_ID0)
    {
        xaf_ext_buffer_t *ext_buf = p_val;
        if((NCORES>1) && (XA_ZERO_COPY)){
            XF_IPC_INVALIDATE(ext_buf, sizeof(xaf_ext_buffer_t));
            XF_IPC_INVALIDATE(ext_buf->data, ext_buf->
>valid_data_size));
        }
        /* ...copy parameters from ext_buf for further use in the
plugin */
    }
}

```

## Errors

- Common API Errors
- Non-fatal error from component.

### 3.3.10 xaf\_comp\_get\_config\_ext API

Table 3-11 xaf\_comp\_get\_config\_ext API

<b>API</b>	XAF_ERR_CODE xaf_comp_get_config_ext (pVOID p_comp, WORD32 num_param, WORD32 *p_param)
<b>Description</b>	<p>This API gets (reads) configuration parameters of variable length from the component.</p> <p>num_param provides the number of configuration parameters to get. p_param points to an integer array containing ID and a pointer to xaf_ext_buffer_t structure pairs for all num_param parameters.</p> <p>For example, for two parameters, p_param contains ID1, EXT_BUF_PTR1, ID2, and EXT_BUF_PTR 2.</p> <p>Upon successful execution of this API, xaf_ext_buffer_t structure field of p_param is updated with values received from the component.</p>
<b>Actual Parameters</b>	<p>p_comp Pointer to the audio component structure</p> <p>num_param Integer containing the number of parameters to get. The maximum limit is 8.</p> <p>p_param Pointer to an integer array containing ID and a pointer to xaf_ext_buffer_t structure pairs.</p> <p>For the xaf_ext_buffer_t structure details, refer to Table 3-10 xaf_comp_set_config_ext API.</p>
<b>Restrictions</b>	Must not be called before xaf_comp_create API.

#### Example

```
/* ... Test Application Part */
int data0[4], data1[6];           /*... Variable length Data */
WORD32 param_ext [N_PARAMS * 2 ]; /*... N_PARAMS = 2 */

bool is_shared_mem = false;       /* ...flag for cache management */
int *p_shared_data0 = NULL;
int shared_mem_used=0;            /* ...cumulative bytes used */
extern void *p_shared_mem;       /* ...global shared memory pointer */
```

---

```

        if((NCORES>1) && (XA_ZERO_COPY)) /*... XA_ZERO_COPY=1 if 'Zero
copy mode' feature is to be used for any of the parameter */
        {
            /*...shared memory is required only if parameter is to be set
on component on another DSP. */
            xaf_ext_buffer_t      *ext_buf=(xaf_ext_buffer_t      *)
            p_shared_mem;
            shared_mem_used += (N_PARAMS * sizeof(xaf_ext_buffer_t));
            is_shared_mem = true;

            p_shared_data0 = (int) p_shared_mem + shared_mem_used;
            shared_mem_used += sizeof(data0);
        }
        else
            xaf_ext_buffer_t ext_buf [N_PARAMS];
            ext_buf[0].max_data_size = sizeof(data0);
            ext_buf[0].valid_data_size = 0;
            ext_buf[0].ext_config_flags |= XAF_EXT_PARAM_SET_FLAG
(XAF_EXT_PARAM_FLAG_OFFSET_ZERO_COPY);
            if(p_shared_data0)
                ext_buf[0].data = (UWORD8 *) p_shared_data0;
            else
                ext_buf[0].data = (UWORD8 *)data0;

            /* ...data1 is usefor non-ZERO_COPY example
*/ext_buf[1].max_data_size = sizeof(data1);
            ext_buf[1].valid_data_size = 0;
            ext_buf[1].ext_config_flags &= XAF_EXT_PARAM_CLEAR_FLAG
(XAF_EXT_PARAM_FLAG_OFFSET_ZERO_COPY);
            ext_buf[1].data = (UWORD8 *)data1;

            param_ext[0] = CONFIG_PARAM_ID0;
            param_ext[1] = (WORD32)&ext_buf[0];
            param_ext[2] = CONFIG_PARAM_ID1;
            param_ext[3] = (WORD32)&ext_buf[1];
            if(is_shared_mem == true)
                XF_IPC_FLUSH(ext_buf, sizeof(xaf_ext_buffer_t));

            ret = xaf_comp_get_config_ext(p_comp,
                                         N_PARAMS,
                                         &param_ext[0]);

            if(p_shared_data0){
                XF_IPC_INVALIDATE(ext_buf[0].data, ext_buf[0].valid_data_size);
            }

            /* ... copy the parameters from ext_buf for further use here on */

```

---

---

```

/*... Plugin or component part */
#include "xaf-api.h"
xa_get_param (WORD32 param_id, void *p_val)
{
    if(param_id == CONFIG_PARAM_ID0)
    {
        xaf_ext_buffer_t *ext_buf = p_val;
        XF_IPC_INVALIDATE(ext_buf, sizeof(xaf_ext_buffer_t));
        memcpy(ext_buf->data, local_data0, sizeof(local_data0));
        XF_IPC_FLUSH(ext_buf->data, ext_buf->valid_data_size);
        XF_IPC_FLUSH(ext_buf, sizeof(xaf_ext_buffer_t));
    }
}

```

## Errors

- Common API Errors
- Non-fatal error from component.

## 3.3.11 xaf\_connect API

Table 3-12 xaf\_connect API

<b>API</b>	XAF_ERR_CODE xaf_connect(pVOID p_src, WORD32 src_out_port, pVOID p_dest, WORD32 dest_in_port, WORD32 num_buf)
<b>Description</b>	<p>This API connects the output port <code>src_out_port</code> of audio component <code>p_src</code> to the input port <code>dest_in_port</code> of audio component <code>p_dest</code> with <code>num_buf</code> connect buffers between them. The size of each connect buffer is equal to the size of the output buffer of <code>p_src</code>.</p> <p>For port numbering convention, refer to Section 1.2.2.</p> <p>For MIMO Class components, <code>xaf_connect</code> API call passes the output port connect information to component plugin through <code>XA_MIMO_PROC_CONFIG_PARAM_PORT_CONNECT</code> configuration parameter.</p> <p>This API fails if it is called for an invalid port or already connected port. Audio components have input and output ports as follows.</p>



**Note:** The renderer component has one optional output port (can be used as feedback path for echo cancellation).

Component Type	Input Ports	Output Ports
XAF_DECODER or XAF_ENCODER or XAF_PRE_PROC or XAF_POST_PROC	1	1
XAF_RENDERER	1	1 (optional, default 0)
XAF_CAPTURER	0	1
XAF_MIMO_PROC_12	1	2
XAF_MIMO_PROC_21	2	1
XAF_MIMO_PROC_41	4	1
XAF_MIMO_PROC_22	2	2
XAF_MIMO_PROC_23	2	3
XAF_MIMO_PROC_10	1	0
XAF_MIMO_PROC_11	1	1
XAF_MIMO_PROC_NN	1	1

Processing frame sizes of connecting components must be considered for choosing number of connect buffers. For example, higher number of connect buffers between source component of very small frame size and destination component of higher frame size would reduce framework overhead cycles. If pre-emptive scheduling is enabled, priority of source component must also be considered for choosing number of connect buffers. For example, if capturer source component at higher priority is producing output data at every 1 millisecond and processing time of destination AEC component is 3 milliseconds, the connect buffers must be at least 3 in this case. Shared memory is used as connect buffers between components on different DSPs.

#### Actual Parameters

`p_src`  
Pointer to the source audio component structure

`src_out_port`  
Output port number of `p_src` audio component

`p_dest`  
Pointer to the destination audio component structure

`dest_in_port`  
Input port number of `p_dest` audio component

`num_buf`  
Number of connect buffers to be added between components  
Valid values: 1 to 1024

<b>Restrictions</b>	Must not be called before at least two audio components are created using <code>xaf_comp_create</code> API and source component has been initialized.
---------------------	---

## Example

```
ret = xaf_connect(p_audioComp1,
                 SRC_OUT_PORT_NUM,
                 p_audioComp2,
                 DEST_INP_PORT_NUM,
                 N_BUFFS);
```

## Errors

- Common API Errors
- XAF\_ROUTING\_ERR
- Indicates that the API failed to connect the two requested components (due to invalid port numbers, already connected ports, or uninitialized source audio component, etc.)
- Non-fatal error from component.

## 3.3.12 xaf\_disconnect API

Table 3-13 xaf\_disconnect API

<b>API</b>	<code>XAF_ERR_CODE xaf_disconnect(pVOID p_src, WORD32 src_out_port, pVOID p_dest, WORD32 dest_in_port)</code>
<b>Description</b>	<p>This API destroys the data link between output port <code>src_out_port</code> of audio component <code>p_src</code> and input port <code>dest_in_port</code> of audio component <code>p_dest</code> by deallocating data buffers and message pool created during <code>xaf_connect</code> API call. Any unprocessed data between the ports is dropped during disconnect. This API has Class specific implementation as described below.</p> <p><b>Audio Codec Class:</b></p> <p><b>Capturer Class:</b> Audio Codec Class or Mixer Class or Capturer Class component has only one output port. <code>xaf_disconnect</code> API call on its output port would cancel any pending processing of the component, flush the output port (drop unprocessed data between ports) and free buffers and message pool between ports.</p>

	<p><b>MIMO Class:</b> MIMO Class component has multiple output ports. If MIMO Class component has only one output port, <code>xaf_disconnect</code> API behavior is same as Audio Codec Class. If MIMO Class component has multiple output ports, <code>xaf_disconnect</code> API call flushes the output port and frees buffers and message pool between ports but does not cancel any pending processing of the component. Furthermore, it would pass the output port disconnect information to component plugin through <code>XA_MIMO_PROC_CONFIG_PARAM_PORT_DISCONNECT</code> configuration parameter. Component plugin implementation must manage processing or execution with disconnected output port as they see fit.</p> <p><b>Renderer Class:</b> Renderer Class component also has one optional output port (used as feedback path for echo cancellation etc.). <code>xaf_disconnect</code> API behavior on its output port is the same as Audio Codec Class.</p>
<b>Actual Parameters</b>	<p><code>p_src</code> Pointer to the source audio component structure</p> <p><code>src_out_port</code> Output port number of source component (to be disconnected)</p> <p><code>p_dest</code> Pointer to the destination audio component structure</p> <p><code>dest_in_port</code> Input port number of destination component (to be disconnected from output port of source component)</p>
<b>Restrictions</b>	<p>Must not be called before ports (to be disconnected) are connected using <code>xaf_connect</code> API.</p> <p>Application must properly handle disconnected components and pipeline, otherwise the processing pipeline may get stalled.</p>

## Example

```
ret = xaf_disconnect (p_audioComp1,
                     SRC_OUT_PORT_NUM,
                     p_audioComp2,
                     DEST_INP_PORT_NUM) ;
```

## Errors

- Common API Errors
- XAF\_ROUTING\_ERR

Indicates that the API failed to disconnect the two requested ports (due to invalid port numbers, invalid components, or uninitialized source component, etc.)

- Non-fatal error from component.

### 3.3.13 xaf\_comp\_process API

Table 3-14 xaf\_comp\_process API

<b>API</b>	<code>XAF_ERR_CODE xaf_comp_process(pVOID p_adev, pVOID p_comp, pVOID p_buf, UWORD32 length, xaf_comp_flag flag)</code>
<b>Description</b>	<p>This API is the main process function for the audio component; it does audio component initialization, execution, and wrap-up based on the <code>process_flag</code> provided to it. During pipeline execution, this API needs to be called only for components that must be supplied with input/output data, typically the edge components of the chain and also for the components which are being probed.</p> <p>After processing has started, this API must be called until end of stream, alternatively along with <code>xaf_comp_get_status</code> API. The value to be set for the parameter 'flag' depends on the status returned by the <code>xaf_comp_get_status</code> API.</p> <p><b>Note:</b> This API is asynchronous; that is, it delivers the process command to the audio component and returns. The audio component processes this request when all required resources (I/O buffers, CPU, etc.) from the processing chain are available. The status of this process command can be queried by the <code>xaf_comp_get_status</code> API described in Table .</p> <p><b>Note:</b> The pointer to an audio device (<code>p_adev</code>) is not required and can be passed as NULL during the execution phase of the audio component (after the component is initialized).</p>
<b>Actual Parameters</b>	<p><code>p_adev</code> Pointer to the audio device structure</p> <p><code>p_comp</code> Pointer to the audio component structure</p> <p><code>p_buf</code> Pointer to the input buffer with the input data or output buffer to be filled</p> <p><code>length</code> Unsigned integer containing the length of buffer in bytes</p> <p><code>process_flag</code> – Process flag</p>

	Following are valid values:	
	<b>Flag</b>	<b>Description</b>
	XAF_START_FLAG	Use this flag to initialize processing, to be called only once for each component, during initialization. After this API call, initialization status must be queried using <code>xaf_comp_get_status</code> API.
	XAF_EXEC_FLAG	Use this flag to start execution, to be called only once for each component to start processing.
	XAF_INPUT_OVER_FLAG	Use this flag to indicate input is complete when <code>xaf_comp_get_status</code> API returns XAF_NEED_INPUT, and input stream is exhausted.
	XAF_INPUT_READY_FLAG	Use this flag to indicate input buffer availability when <code>xaf_comp_get_status</code> API returns XAF_NEED_INPUT, and input data is available.
	XAF_NEED_OUTPUT_FLAG	Use this flag to request for output when <code>xaf_comp_get_status</code> API returns XAF_OUTPUT_READY.
	XAF_NEED_PROBE_FLAG	Use this flag to request for probe output when <code>xaf_comp_get_status</code> API returns XAF_PROBE_READY.
<b>Restrictions</b>	Must not be called before <code>xaf_comp_create</code> API	

## Example

```
ret = xaf_comp_process( p_aDEV,
                       p_audioComp,
                       &Buff,
                       length,
                       compFlag);
```

## Errors

- Common API Errors

### 3.3.14 xaf\_comp\_get\_status API

Table 3-15 xaf\_comp\_get\_status API

API	XAF_ERR_CODE xaf_comp_get_status(pVOID p_adev, pVOID p_comp, xaf_comp_status *p_status, pVOID p_info)																											
Description	<p>This API returns the status of the audio component and associated information. p_adev and p_comp must point to the valid audio device and audio component structures, respectively. This API returns one of the following status and associated information.</p> <p><b>Note:</b> This API is a blocking API; that is, it may block for status from the DSP Interface Layer for a previously issued process command.</p>																											
Actual Parameters	<p>p_adev Pointer to the audio device structure</p> <p>p_comp Pointer to the audio component structure</p> <p>p_status Pointer to get the audio component status The valid values are as follows:</p> <table><tr><th>p_status</th><th>Description</th><th>p_info</th></tr><tr><td>XAF_STARTING</td><td>Created and initializing</td><td></td></tr><tr><td>XAF_INIT_DONE</td><td>Initialization complete</td><td></td></tr><tr><td>XAF_NEED_INPUT</td><td>Component needs data</td><td>Buffer pointer, size in bytes</td></tr><tr><td>XAF_OUTPUT_READY</td><td>Component has generated output</td><td>Buffer pointer, size in bytes</td></tr><tr><td>XAF_EXEC_DONE</td><td>Execution done</td><td></td></tr><tr><td>XAF_PROBE_READY</td><td>Component has generated probe data</td><td>Buffer pointer, size in bytes</td></tr><tr><td>XAF_PROBE_DONE</td><td>Probe is complete</td><td></td></tr><tr><td>XAF_INIT_NEED_IN PUT</td><td>Need more data for initialization</td><td>Buffer pointer, size in bytes</td></tr></table> <p>p_info Pointer to array of size two WORD32 data types (pointer, size) to get information from the audio component associated with its status. When the p_status returned is XAF_STARTING or XAF_INIT_DONE, this buffer is not updated.</p>	p_status	Description	p_info	XAF_STARTING	Created and initializing		XAF_INIT_DONE	Initialization complete		XAF_NEED_INPUT	Component needs data	Buffer pointer, size in bytes	XAF_OUTPUT_READY	Component has generated output	Buffer pointer, size in bytes	XAF_EXEC_DONE	Execution done		XAF_PROBE_READY	Component has generated probe data	Buffer pointer, size in bytes	XAF_PROBE_DONE	Probe is complete		XAF_INIT_NEED_IN PUT	Need more data for initialization	Buffer pointer, size in bytes
p_status	Description	p_info																										
XAF_STARTING	Created and initializing																											
XAF_INIT_DONE	Initialization complete																											
XAF_NEED_INPUT	Component needs data	Buffer pointer, size in bytes																										
XAF_OUTPUT_READY	Component has generated output	Buffer pointer, size in bytes																										
XAF_EXEC_DONE	Execution done																											
XAF_PROBE_READY	Component has generated probe data	Buffer pointer, size in bytes																										
XAF_PROBE_DONE	Probe is complete																											
XAF_INIT_NEED_IN PUT	Need more data for initialization	Buffer pointer, size in bytes																										
Restrictions	Must not be called before the xaf_comp_create API																											

---

## Example

```
WORD32 Info[2];  
ret = xaf_comp_get_status(p_adev,  
                           p_audioComp,  
                           &compStatus,  
                           &Info[0]);
```

## Errors

- Common API Errors

### 3.3.15 xaf\_pause API

Table 3-16 xaf\_pause API

API	XAF_ERR_CODE xaf_pause(pVOID p_comp, WORD32 port)
Description	<p>This API pauses the processing of data on specified port <code>port</code> of audio component <code>p_comp</code>. That is, if input port is paused, input data consumption is paused on that port, and if output port is paused, output data production is paused on that port. This API has Class specific implementation as described below.</p> <p><b>Audio Codec Class:</b> Audio Codec Class component has one input port and one output port, so <code>xaf_pause</code> API call on any port would simply pause the processing or execution of the component. <b>Note:</b> This may in turn pause the preceding and/or following pipeline processing.</p> <p><b>MIMO Class:</b> MIMO Class component has multiple input ports and multiple output ports. <code>xaf_pause</code> API call on any port would only pass paused port information to the component plugin using <code>XA_MIMO_PROC_CONFIG_PARAM_PORT_PAUSE</code> configuration parameter and component plugin implementation must manage processing or execution with paused port as it sees fit. <b>Note:</b> This may in turn pause the preceding and/or following pipeline processing.</p> <p><b>Capturer Class:</b> <b>Renderer Class:</b> Being hardware specific, Capturer or Renderer Class do not support <code>xaf_pause</code> API. The pause feature can be implemented by component plugin through configuration parameter.</p> <p><b>Note:</b> Attempts to pause an already paused port is ignored and no error is returned.</p>

<b>Actual Parameters</b>	<code>p_comp</code> Pointer to the audio component structure
	<code>port</code> Port number of the input or output port to be paused
<b>Restrictions</b>	Must not be called before <code>xaf_comp_create</code> API

## Example

```
ret = xaf_pause (p_audioComp, port_num);
```

## Errors

- Common API Errors
- Non-fatal error from component.

## 3.3.16 xaf\_resume API

Table 3-17 xaf\_resume API

<b>API</b>	<code>XAF_ERR_CODE xaf_resume (pVOID p_comp, WORD32 port)</code>
<b>Description</b>	<p>This API resumes processing of data on specified port <code>port</code> of audio component <code>p_comp</code>. That is, if input port is resumed, input data consumption is resumed on that port, and if output port is resumed, output data production is resumed on that port.</p> <p>For MIMO Class components, <code>xaf_resume</code> API call passes the port resume information to component plugin through <code>XA_MIMO_PROC_CONFIG_PARAM_PORT_RESUME</code> configuration parameter.</p> <p>Being hardware specific, Capturer or Renderer Class do not support <code>xaf_resume</code> API. The resume feature can be implemented by component plugin through configuration parameter.</p> <p><b>Note:</b> Attempts to resume a port that is not paused is ignored and no error is returned.</p>
<b>Actual Parameters</b>	<p><code>p_comp</code> Pointer to the audio component structure</p> <p><code>port</code> Port number of the input or output port to be resumed</p>
<b>Restrictions</b>	Must not be called before <code>xaf_comp_create</code> API



---

## Example

```
ret = xaf_resume(p_audioComp, port_num);
```

## Errors

- Common API Errors
- Non-fatal error from component.

### 3.3.17 xaf\_probe\_start API

Table 3-18 xaf\_probe\_start API

<b>API</b>	XAF_ERR_CODE xaf_probe_start (pVOID p_comp)
<b>Description</b>	<p>This API starts probe operation on audio component <code>p_comp</code>. Probe operation enables exporting of processed data for specified ports to application on each process or execution call of the audio component. Ports to be probed for an audio component must be configured using the configuration parameter <code>XAF_COMP_CONFIG_PARAM_PROBE_ENABLE</code> during audio component initialization.</p> <p><b>Note:</b> The application may require creating a separate thread to query status and consume data exported through probe operation if it does not already have one for feeding input to and/or consuming output from the probed audio component.</p> <p>Being hardware specific, Capturer or Renderer Class do not support <code>xaf_probe_start</code> API.</p>
<b>Actual Parameters</b>	<p><code>p_comp</code> Pointer to the audio component structure</p>
<b>Restrictions</b>	Must not be called before <code>xaf_comp_create</code> API

## Example

```
param[0] = XAF_COMP_CONFIG_PARAM_PROBE_ENABLE ;  
param[1] = 0x3; // for probing port 0 and port 1  
xaf_comp_set_config(p_audioComp, 1, param);  
ret = xaf_probe_start (p_audioComp);
```

## Errors

- Common API Errors

---

### 3.3.18 xaf\_probe\_stop API

Table 3-19 xaf\_probe\_stop API

<b>API</b>	XAF_ERR_CODE xaf_probe_stop(pVOID p_comp)
<b>Description</b>	<p>This API stops probe operation on audio component p_comp.</p> <p><b>Note:</b> If the application has created a separate thread to consume data exported through probe operation, it must be deleted by application after xaf_probe_stop API call.</p> <p>Being hardware specific, Capturer or Renderer Class do not support xaf_probe_stop API.</p>
<b>Actual Parameters</b>	<p>p_comp</p> <p>Pointer to the audio component structure</p>
<b>Restrictions</b>	Must not be called before xaf_comp_create API

#### Example

```
ret = xaf_probe_stop (p_audioComp);
```

#### Errors

- Common API Errors

### 3.3.19 xaf\_create\_event\_channel API

Table 3-20 xaf\_create\_event\_channel API

<b>API</b>	XAF_ERR_CODE xaf_create_event_channel(pVOID p_src, UWORD32 src_config_param, pVOID p_dest, UWORD32 dst_config_param, UWORD32 nbuf, UWORD32 buf_size)
<b>Description</b>	<p>This API creates an event communication channel.</p> <p><b>Note:</b> Event communication channel can be created either between two components or between a component and the application.</p>
<b>Actual Parameters</b>	<p>p_src</p> <p>Pointer to the source audio component</p> <p>src_config_param</p> <p>Configuration parameter ID of the source component</p> <p>p_dest</p> <p>Pointer to the destination audio component. NULL indicates the event is for the application.</p>

	<p><code>dst_config_param</code> Configuration parameter ID of the destination(sink) component. NULL indicates the event is for the application.</p> <p><code>n_buf</code> Number of message buffers between the components (per channel) to deliver event and receive response. Valid values: 1 to 16</p> <p><code>buf_size</code> Size of each data buffer in the channel. Application programmer must ensure to provide right buffer size with regard to <code>src_config_param</code> configuration parameter</p>
<b>Restrictions</b>	Must not be called before <code>xaf_comp_create</code> API

## Example

1. Channel between two components

```
ret = xaf_create_event_channel(p_audioComp1,
                              XA_COMP1_CONFIG_PARAM,
                              p_audioComp2,
                              XA_COMP2_CONFIG_PARAM,
                              4, 4);
```

2. Channel between a component and application

```
ret = xaf_create_event_channel(p_audioComp1,
                              XA_COMP1_CONFIG_PARAM,
                              NULL, NULL,
                              4, 4);
```

## Errors

- Common API Errors

### 3.3.20 xaf\_delete\_event\_channel API

Table 3-21 xaf\_delete\_event\_channel API

<b>API</b>	XAF_ERR_CODE xaf_delete_event_channel(pVOID p_src, UWORD32 src_config_param, pVOID p_dest, UWORD32 dst_config_param)
<b>Description</b>	This API deletes an event communication channel.

<b>Actual Parameters</b>	<p><code>p_src</code> Pointer to the source audio component</p> <p><code>src_config_param</code> Configuration parameter ID of the source component</p> <p><code>p_dest</code> Pointer to the destination audio component</p> <p><code>dst_config_param</code> Configuration parameter ID of the destination(sink) component</p>
<b>Restrictions</b>	<p>Must not be called before channel (which is to be deleted) is created using <code>xaf_create_event_channel</code>.</p> <p>Must not be called before <code>xaf_comp_create</code> API</p> <p><b>Note:</b> If component deletion is attempted before calling this API, then the associated event channels are deleted automatically.</p>

## Example

```
ret = xaf_delete_event_channel(p_audioComp1,
                              XA_COMP1_CONFIG_PARAM,
                              p_audioComp2,
                              XA_COMP2_CONFIG_PARAM);
```

## Errors

- Common API Errors

### 3.3.21 xaf\_adev\_set\_priorities API

Table 3-22 xaf\_adev\_set\_priorities API

<b>API</b>	<code>XAF_ERR_CODE xaf_adev_set_priorities(pVOID p_adev,</code> <code>WORD32 n_rt_priorities,</code> <code>WORD32 rt_priority_base,</code> <code>WORD32 bg_priority,</code> <code>UWORD32 core)</code>
<b>Description</b>	<p>This API enables preemptive scheduling of audio components on the DSP Interface Layer.</p> <p>By default, DSP Interface Layer creates only one DSP worker thread for processing or execution of all audio components, and preemption of one audio component processing by another is not supported.</p>

	<p>With <code>xaf_adev_set_priorities</code> API, preemptive scheduling is enabled, and a higher priority audio component processing request can preempt lower priority audio component processing. This is achieved using different priority RTOS threads for different priority audio components. These RTOS threads are created with <code>xaf_adev_set_priorities</code> API as described below. XAF priority for an audio component is set using the <code>XAF_COMP_CONFIG_PARAM_PRIORITY</code> configuration parameter and it can be changed at runtime.</p> <p><code>xaf_adev_set_priorities</code> API call sets up audio device <code>p_adev</code> for preemptive scheduling and creates <math>(n\_rt\_priorities + 1)</math> DSP worker threads. One DSP worker thread is dedicated to processing or execution of unprioritized audio components, and it is assigned RTOS priority specified by <code>bg_priority</code>. Remaining <code>n_rt_priorities</code> threads are dedicated to processing or execution of audio components with XAF priorities from 0 to <math>(n\_rt\_priorities - 1)</math> and are assigned RTOS priorities from <code>rt_priority_base</code> to <math>(rt\_priority\_base + n\_rt\_priorities - 1)</math> respectively.</p> <p><b>Note:</b> The higher number indicates higher priority, and vice versa.</p>
Actual Parameters	<p><code>p_adev</code> pointer to the audio device structure</p> <p><code>n_rt_priorities</code> number of real time priority levels</p> <p><code>rt_priority_base</code> lowest real time priority level</p> <p><code>bg_priority</code> background priority level</p> <p><code>core</code> core ID on which DSP worker threads are to be created if <code>NCORES&gt;1</code>.</p>
Restrictions	<p>Must not be called before <code>xaf_adev_open</code> API.</p> <p>Must be called only once after <code>xaf_adev_open</code> API.</p> <p>Priority of DSP worker threads must not exceed the priority of DSP thread. That is, <math>(rt\_priority\_base + n\_rt\_priorities - 1)</math> must be less than or equal to DSP thread priority.</p> <p><code>rt_priority_base</code> must be at-most DSP-thread priority.</p> <p><code>bg_priority</code> must be at-most DSP-thread priority.</p>

## Example

```
/* following call creates two DSP worker threads with priorities 3 and
```

---

```

    * 4 respectively for processing of prioritized components, and creates
    * one DSP worker thread with priority 1 for unprioritized components
    * on a core with core ID 1.
    */
    ret = xaf_adev_set_priorities(p_adev, 2, 3, 1, 1);

```

## Errors

- Common API errors

### 3.3.22 xaf\_get\_verinfo API

Table 3-23 xaf\_get\_verinfo API

<b>API</b>	XAF_ERR_CODE xaf_get_verinfo(pUWORD8 ver_info[3])						
<b>Description</b>	<p>This API gets the version information from the XAF library. It returns an array of the following three strings.</p> <table> <tr> <td>ver_info[0]</td><td>Library name</td></tr> <tr> <td>ver_info[1]</td><td>Library version</td></tr> <tr> <td>ver_info[2]</td><td>API version</td></tr> </table>	ver_info[0]	Library name	ver_info[1]	Library version	ver_info[2]	API version
ver_info[0]	Library name						
ver_info[1]	Library version						
ver_info[2]	API version						
<b>Actual Parameters</b>	<p>ver_info</p> <p>Pointer to array of three strings</p>						
<b>Restrictions</b>	None						

## Example

```
ret = xaf_get_verinfo(&versionInfo[0]);
```

## Errors

- Common API Errors

### 3.3.23 xaf\_get\_mem\_stats API

Table 3-24 xaf\_get\_mem\_stats API

API	XAF_ERR_CODE xaf_get_mem_stats(pVOID p_adev, UWORD32 core, WORD32 *p_mem_stats)	
Description	This API returns the information about the memory usage statistics of the audio components, framework, and XAF. p_adev must point to the valid audio device structure. This API updates the pointer contents with memory usage statistics.	
Actual Parameters	p_adev Pointer to the audio device structure	
	core core ID number	
	p_mem_stats Pointer to an array of five WORD32 data types to get information from the API about the memory usage statistics in bytes.	
	Array values	Description
	p_mem_stats[0]	Peak usage of local Memory by Audio Components (XAF_MEM_ID_COMP)
	p_mem_stats[1]	Peak usage of shared Memory by Audio Components and Framework (XAF_MEM_ID_DEV)
	p_mem_stats[2]	Local Memory used by Framework structures
	p_mem_stats[3]	Peak usage of shared Memory by Audio Components if NCORES>1 Current usage of local memory by Audio Components if NCORES=1 (XAF_MEM_ID_COMP)
	p_mem_stats[4]	Current usage of shared memory by Audio Components and Framework if NCORES=1 (XAF_MEM_ID_DEV)
P_mem_stats[5...]	Peak usage of local Memory by Audio Components for memory pools of types of XAF_MEM_ID_COMP+1 to XAF_MEM_ID_COMP_MAX.	
P_mem_stats[5 + (XAF_MEM_ID_COMP_MAX-	Peak usage of shared Memory by Audio Components and Framework for memory pools of types of XAF_MEM_ID_DEV+1 to XAF_MEM_ID_DEV_MAX.	

	XAF_MEM_ID_COM P) ...]	
<b>Restrictions</b>	The API is recommended to be used at the end of application execution and before closing the device (using <code>xaf_adev_close</code> API call) for the memory statistics to be reliable. It can be called from the Master DSP only.	

### Example

```
WORD32 mem_stats[5];
ret = xaf_get_mem_stats(p_adev, 0,
                        &mem_stats[0]);
```

### Errors

- Common API Errors

## 3.3.24 xaf\_dsp\_open API

Table 3-25 xaf\_dsp\_open API

<b>API</b>	XAF_ERR_CODE xaf_dsp_open(pVOID *pp_adev, xaf_adev_config_t *pconfig)
<b>Description</b>	This API opens and initializes the audio device structure on worker cores. It starts the DSP thread that performs all audio processing on DSP Interface Layer on worker core. It also allocates local memory to be used by the audio components. It passes DSP-DSP shared memory pointer, size, and id of memory pool types, XAF_MEM_ID_DSP to XAF_MEM_ID_DSP_MAX from which the common shared structure across DSPs is allocated.
<b>Actual Parameters</b>	pp_adev Address of pointer to audio device. This API call allocates memory for audio device and updates this pointer with it.  pconfig Pointer to an initialized structure that contains the necessary parameters for this API. Refer to Table 3-2 xaf_adev_open API for description of xaf_adev_config_t structure variables.
<b>Restrictions</b>	<b>Prerequisite:</b> The RTOS startup procedure must be invoked before calling this function. Procedures for XOS and FreeRTOS are as follows.



	<ul style="list-style-type: none"> <li>For XOS: <ol style="list-style-type: none"> <li><code>xos_set_clock_freq()</code> to set the core clock frequency.</li> <li><code>xos_start_main()</code> to start the scheduler.</li> <li><code>xos_start_system_timer()</code> to start the timer for scheduling.</li> </ol> <p>Refer to the function <code>start_rtos()</code> under <code>#if defined (HAVE_XOS)</code> in the file <code>test/src/xaf-utils-test.c</code> for an example.</p> </li> <li>For FreeRTOS: <p>The start-up procedure for FreeRTOS involves starting the main thread and starting the scheduler by calling the function <code>vTaskStartScheduler()</code>.</p> <p>Refer to the function <code>init_rtos()</code> under <code>#ifdef HAVE_FREERTOS</code> in the file <code>test/src/xaf-utils-test.c</code> for an example.</p> <p>This API must not be called from Master core testbench.</p> </li> </ul>
--	---

## Example

```
ret = xaf_dsp_open(&p_adev,
                  &adev_config);
```

## Errors

- Common API Errors

### 3.3.25 xaf\_dsp\_close API

Table 3-26 xaf\_dsp\_close API

API	XAF_ERR_CODE xaf_dsp_close(pVOID p_adev)
Description	<p>This API waits on the worker core for DSP-thread to finish.</p> <p>It populates <code>cb_stats</code> structure with memory stats and calls <code>cb_compute_cycles</code> which updates the execution cycles.</p> <p>It frees the memory allocated during <code>xaf_dsp_open</code>.</p>
Actual Parameters	<p><code>p_adev</code> Address of pointer to audio device.</p>

<b>Restrictions</b>	<ul style="list-style-type: none"> <li>• Must not be called before xaf_dsp_open API.</li> <li>• This API must not be called from the Master core testbench.</li> </ul>
---------------------	--

## Example

```
ret = xaf_dsp_close(p_adev);
```

## Errors

- Common API Errors

## 3.4 XAF Configuration Parameters

This section describes configuration parameters that are supported by XAF. These parameters must be used with xaf\_comp\_set\_config API described in Table 3-8.

Table 3-27 XAF\_COMP\_CONFIG\_PARAM\_PROBE\_ENABLE Configuration Parameter

Configuration Parameter	XAF_COMP_CONFIG_PARAM_PROBE_ENABLE							
Description	<p>Probe operation enables exporting of processed data for specified ports to the application on each process or execution call of the audio component.</p> <p>This configuration parameter is used to specify ports for probe operation using a port mask value. Port mask is a 32-bit unsigned integer where bit 0 (LSB) corresponds to port number 0, bit 1 corresponds to port number 1 and so on. If a bit is set, the corresponding port is enabled for probe operation.</p>							
Values	<table><tr><td>Value Type</td><td>UWORD32</td></tr><tr><td>Default Value</td><td>0 (All ports disabled)</td></tr><tr><td>Example value</td><td>0x3 (port 0 and port 1 are enabled for probe operation)</td></tr></table>		Value Type	UWORD32	Default Value	0 (All ports disabled)	Example value	0x3 (port 0 and port 1 are enabled for probe operation)
Value Type	UWORD32							
Default Value	0 (All ports disabled)							
Example value	0x3 (port 0 and port 1 are enabled for probe operation)							
Restrictions	<p>This configuration parameter is only supported during audio component initialization (as it results in one-time probe buffer allocation during initialization); that is, probe specification cannot be changed at runtime.</p> <p>For an input port with input-bypass mode active, the <code>xaf_comp_set_config</code> API with this parameter returns <code>XAF_INVALIDVAL_ERR</code> fatal error.</p>							

Table 3-28 XAF\_COMP\_CONFIG\_PARAM\_RELAX\_SCHED Configuration Parameter

Configuration Parameter	XAF_COMP_CONFIG_PARAM_RELAX_SCHED						
Description	<p>By default, each processing or execution call of MIMO Class component requires that all the necessary ports are ready; that is, at least one of the active input ports has data and all active output ports have buffer available.</p> <p>This configuration parameter is used to specify ports on which this readiness check must be relaxed using a port mask value. Port mask is a 32-bit unsigned integer where bit 0 (LSB) corresponds to port number 0, bit 1 corresponds to port number 1 and so on. If a bit is set, the corresponding port readiness check must be relaxed during MIMO Class component processing.</p> <p><b>Note:</b> If this configuration parameter is used, it is the responsibility of respective component plugin implementation to manage execution without readiness of specified ports.</p>						
Values	<table> <tr> <td>Value Type</td><td>UWORD32</td></tr> <tr> <td>Default Value</td><td>0 (All ports disabled)</td></tr> <tr> <td>Example value</td><td>0x3 (port 0 and port 1 readiness checks are relaxed)</td></tr> </table>	Value Type	UWORD32	Default Value	0 (All ports disabled)	Example value	0x3 (port 0 and port 1 readiness checks are relaxed)
Value Type	UWORD32						
Default Value	0 (All ports disabled)						
Example value	0x3 (port 0 and port 1 readiness checks are relaxed)						
Restrictions	This configuration parameter is only supported for MIMO Class components, and it can be used at component initialization as well as at runtime.						

Table 3-29 XAF\_COMP\_CONFIG\_PARAM\_PRIORITY Configuration Parameter

Configuration Parameter	XAF_COMP_CONFIG_PARAM_PRIORITY				
Description	<p>By default, DSP Interface Layer creates only one DSP worker thread for processing or execution of all audio components and preemption of one audio component processing by another is not supported. With <code>xaf_adev_set_priorities</code> API, preemptive scheduling is enabled, and a higher priority audio component processing request can preempt lower priority audio component processing.</p> <p>This configuration parameter is used to specify relative priority of audio component w.r.t <code>base_priority</code>. It accepts values from 0 to <math>(\max(\text{UWORD32}) - 1)</math>.</p> <p><b>Note:</b> Higher number indicates higher priority and vice versa. A value higher than the highest possible priority, which is determined from <code>set_priority</code> API parameters, results in fatal error.</p>				
Values	<table> <tr> <td>Value Type</td><td>UWORD32</td></tr> <tr> <td>Example value</td><td>0x3 (audio component runs at priority base priority + 3)</td></tr> </table>	Value Type	UWORD32	Example value	0x3 (audio component runs at priority base priority + 3)
Value Type	UWORD32				
Example value	0x3 (audio component runs at priority base priority + 3)				

<b>Restrictions</b>	<p>This configuration parameter is supported at component initialization as well as at runtime.</p> <p>For this configuration parameter to have effect, <code>xaf_adev_set_priorities</code> API must be used to create different priority RTOS threads during audio device creation, otherwise this parameter would be ignored.</p>
---------------------	--

Table 3-30 XAF\_COMP\_CONFIG\_PARAM\_DEC\_INIT\_WO\_INP Configuration Parameter

Configuration Parameter	XAF_COMP_CONFIG_PARAM_DEC_INIT_WO_INP					
Description	<p>Generally, decoders which use speech APIs do not require input data for initialization but those which use audio APIs require input data for initialization. By setting this configuration parameter, a decoder can attempt initialization without input data.</p> <p>If initialization without input data succeeds, XAF_INIT_DONE status is returned to application.</p> <p>If initialization without input fails, then XAF_INIT_NEED_INPUT status is returned after which the application can re-attempt initialization by providing input data.</p> <p><b>Note:</b> Since the output buffer would have returned to the application after the first initialization attempt, the same needs to be sent back again using XAF_START_FLAG.</p>					
Values	<table><tr><td>Value Type</td><td>UWORD32</td></tr><tr><td>Example value</td><td>1 (To allow attempt initialization without providing input data)</td></tr></table>		Value Type	UWORD32	Example value	1 (To allow attempt initialization without providing input data)
Value Type	UWORD32					
Example value	1 (To allow attempt initialization without providing input data)					
Restrictions	<p>This configuration parameter is supported for 'XAF_DECODER' type components. For other components 'XAF_INVALIDVAL_ERR' error is returned.</p>					

Table 3-31 XAF\_COMP\_CONFIG\_PARAM\_INPORT\_BYPASS Configuration Parameter

<b>Configuration Parameter</b>	XAF_COMP_CONFIG_PARAM_INPORT_BYPASS	
<b>Description</b>	<p>If this configuration parameter is set, the component's input buffer will not be allocated by framework and the connect buffer would be used as</p>	

	input buffer. This helps reduce memory as well as mem-copy overheads.	
<b>Values</b>		
	Value Type	UWORD32
	Example value	1 (To enable input port bypass mode)
<b>Restrictions</b>	<ul style="list-style-type: none"> <li>• This configuration parameter must be provided before component initialization.</li> <li>• This configuration parameter is meant for components that satisfy the following criteria: The output frame size of the preceding component must be equal to or multiple of input frame size of this component and this component must consume the data when presented for processing, even when the input length is less than input frame size (partial frame). Not supported for components that do not consume partial input data.</li> </ul>	

---

## 4. Xtensa Audio Framework Package

---

The XAF package is released in the following two forms. The contents of XAF release package and steps to build and execute in both forms are described in the following sections.

1. .tgz package for linux / makefile based usage
2. .xws package for Xtensa Xplorer based usage

### 4.1 XAF Sample Applications

Fifteen sample applications (testbenches) are provided, which implement fifteen different audio processing chains as described below. Audio components and links are shown in blue in the following diagrams.

---

**Note** All the audio component libraries used in this document's example testbenches are not included in the XAF release package. They must be separately licensed.

---

Testbench 1 (`xa_af_hostless_test`) applies gain to PCM streams.




Figure 4-1 Testbench 1 (pcm-gain) Block Diagram

Testbench 2 (`xa_af_dec_test`) decodes MP3 streams.




Figure 4-2 Testbench 2 (mp3-dec) Block Diagram

---

Testbench 3 (`xa_af_dec_mix_test`) decodes two MP3 streams and mixes the output. The mixer used in this testbench is a MIMO class component with 4 input ports and 1 output port.

---

**Note** Mixer component used in this testbench allows start of processing (schedule for execution) when at least one of the input ports is connected and valid input is available (among the 4 input ports). The connections and data arrival instances on input ports can vary between single core and multicore execution, which means the output of the mixer can differ.

---




Figure 4-3 Testbench 3 (dec-mix) Block Diagram

Testbench 4 (`xa_af_full_duplex_opus_test`) encodes an OPUS stream and simultaneously decodes an OPUS stream. The Opus decoder supports both OGG and RAW encoded input data. OGG and RAW mode can be altered by enabling/disabling `#define ENABLE_RAW_OPUS_SET_CONFIG` in the testbench.

This testbench demonstrates usage of extended set config (`xaf_set_config_ext`) and get config (`xaf_get_config_ext`) APIs.




Figure 4-4 Testbench 4 (full-duplex-opus) Block Diagram

---

Testbench 5 (`xa_af_amr_wb_dec_test`) decodes AMR-WB speech streams.

This testbench demonstrates decoder initialization without input functionality by using the configuration parameter `XAF_COMP_CONFIG_PARAM_DEC_INIT_WO_INP`.




Figure 4-5 Testbench 5 (amr-wb-dec) Block Diagram

Testbench 6 (`xa_af_mp3_dec_rend_test`) decodes MP3 streams and renders it on the audio output device (hardware case). For the simulator case, the output is written to a file.




Figure 4-6 Testbench 6 (mp3-dec-renderer) Block Diagram

Testbench 7 (`xa_af_gain_rend_test`) applies gain to PCM streams and renders it on the audio output device (hardware case). For the simulator case, the output is written to a file.




Figure 4-7 Testbench 7 (pcm-gain-renderer) Block Diagram

Testbench 8 (`xa_af_capturer_pcm_gain_test`) captures a PCM stream from the audio input device (hardware case) and applies a gain to it. For the simulator case, the input is read from a file.




Figure 4-8 Testbench 8 (capturer-pcm-gain) Block Diagram



Testbench 9 (`xa_af_capturer_mp3_enc_test`) captures data from the audio input device (hardware case) and encodes it to an MP3 stream. For the simulator case, the input is read from a file.




Figure 4-9 Testbench 9 (capturer-mp3-enc) Block Diagram

Testbench 10 (`xa_af_mimo_mix_test`) applies gain to two PCM streams and mixes them to produce the output. For this testbench, the mixer is a MIMO class component with 2 input ports and 1 output port.

**Note** This testbench demonstrates runtime pause, resume, probe start, and probe stop operations. Refer to testbench help for details on how to exercise these operations at runtime.

This testbench also demonstrates event communication functionality using the `xaf_create_event_channel` and `xaf_delete_event_channel` APIs. Here, the MIMO Mixer component communicates with PCM Gain components to change their gain factor after producing certain amount of data. Here the orange arrows represent event communication channel. The input port bypass feature is also demonstrated in this testbench. To enable it, refer to section 2.2.7 and Table 3-31.

**Note** MIMO-Mixer component used in this testbench has two input-ports. The component waits for inputs to be available on both the ports before consuming.




Figure 4-10 Testbench 10 (mimo-mix) Block Diagram

Testbench 11 (`xa_af_playback_usecase_test`) decodes two MP3 streams and one AAC stream and mixes the output. This mixer output is split into (copied to) two PCM streams, gain

is applied on one stream and sample rate is converted on another stream. Second AAC decoder can be created and connected to mixer at runtime. The mixer in this testbench is a MIMO class component with 4 input ports and 1 output port.

**Note** This testbench demonstrates runtime pause, resume, disconnect, re-connect, probe start, and probe stop operations. Refer to testbench help for details on how to exercise these operations at runtime.

This testbench also demonstrates propagation and handling of component execution errors to the application. This is enabled using the component configuration parameter `error_channel_ctl` during component creation, which creates an error channel between framework and the application. The errors received, if any, are handled gracefully in the testbench. For more information, see the error handler example implementation in the testbench code. The the input port bypass feature is also demonstrated in this testbench. To enable it, refer to section 2.2.7 and Table 3-31.

**Note** Mixer component used in this testbench allows start of processing (schedule for execution) when at least one of the input ports is connected and valid input is available (among the 4 input ports). The connections and data arrival instances on input ports can vary between single core and multicore execution, which means the output of the mixer can differ, and thus the final outputs.




Figure 4-11 Testbench 11 (playback-usecase) Block Diagram

Testbench 12 (`xa_af_renderer_ref_port_test`) demonstrates use of renderer optional port as feedback or reference path for echo cancellation type of applications. It demonstrates the connection between two independent audio-processing chains. One chain is PCM-Gain1, RENDERER, the other being PCM-Gain2, AEC23, PCM-Gain3 and PCM-Gain 4.




Figure 4-12 Testbench 12 (renderer-ref-port) Block Diagram

Testbench 13 (`xa_af_tflite_microspeech_test`) captures a PCM stream from the audio input device (in case of a hardware platform) and detects Yes/No keyword and outputs the corresponding Yes/No score in the cases where Yes/No keyword is recognized. For the simulator case, the input is read from a file.




Figure 4-13 Testbench 13 (capturer-tflite-microspeech) Block Diagram

Testbench 14 (`xa_af_tflite_person_detect_test`) detects the presence or absence of a person as person/no person for the given input data. It prints the person/no person inference score.




Figure 4-14 Testbench 14 (tflite-person-detect) Block Diagram

Testbench 15 (`xa_af_person_detect_microspeech_test`) detects and prints Yes/No keyword for the capturer input and simultaneously detects person/no person and provides inference score for the given input.




Figure 4-15 Testbench 15 (person-detect-microspeech) Block Diagram

Table 4-1 summarizes component header file, component wrapper file, and component library dependencies for each of fifteen testbenches included in XAF package. The testbench sources use a set of preprocessor symbols (see section 4.4.1) to enable inclusion of respective component plugins into compilation.

Table 4-1 Component Dependencies for Testbenches

No	Testbench source file	Component wrapper files	Component header files	Component libraries
1	xaf-pcm-gain-test.c	xa-pcm-gain.c	xa-pcm-gain-api.h	-
2	xaf-dec-test.c	xa-mp3-decoder.c	xa_mp3_dec_api.h	xa_mp3_dec.a
3	xaf-dec-mix-test.c	xa-mp3-decoder.c xa-mimo-mix4.c	xa_mp3_dec_api.h xa-mimo-mix-api.h	xa_mp3_dec.a
4	xaf-full-duplex-opus-test.c	xa-opus-decoder.c xa-opus-encoder.c	xa_opus_codec_api.h xa_opus_encoder_api.h xa_opus_decoder_api.h xa_ogg_lib_api.h opus_header.h	xa_opus_codec.a
5	xaf-amr-wb-dec-test.c	xa-amr-wb-decoder.c	xa_amr_wb_codec_api.h xa_amr_wb_dec_definitions.h	xa_amr_wb_codec.a
6	xaf-mp3-dec-rend-test.c	xa-mp3-decoder.c xa-renderer.c	xa_mp3_dec_api.h xa-renderer-api.h	xa_mp3_dec.a
7	xaf-gain-renderer-test.c	xa-pcm-gain.c xa-renderer.c	xa-pcm-gain-api.h xa-renderer-api.h	-
8	xaf-capturer-pcm-gain-test.c	xa-capturer.c xa-pcm-gain.c	xa-capturer-api.h xa-pcm-gain-api.h	-

No	Testbench source file	Component wrapper files	Component header files	Component libraries
9	xaf-capturer-mp3-enc-test.c	xa-capturer.c xa-mp3-encoder.c	xa-capturer-api.h xa_mp3_enc_api.h	xa_mp3_enc.a
10	xaf-mimo-mix-test.c	xa-pcm-gain.c xa-mimo-mix.c	xa-pcm-gain-api.h xa-mimo-mix-api.h	-
11	xaf-playback-usecase-test.c	xa-mp3-decoder.c xa-aac-decoder.c xa-mimo-mix4.c xa-pcm-split.c xa-pcm-gain.c xa-src-pp.c	xa_mp3_dec_api.h xa_aac_dec_api.h xa-mimo-mix-api.h xa-pcm-split-api.h xa-pcm-gain-api.h xa_src_pp_api.h	xa_mp3_dec.a xa_aac_dec.a xa_src_pp.a
12	xaf-renderer-ref-port-test.c	xa-pcm-gain.c xa-renderer.c xa-aec23.c	xa-pcm-gain-api.h xa-renderer-api.h xa-aec23-api.h	-
13	xaf-capturer-tflite-microspeech-test.c	xa-capturer.c tflm-inference-api.cpp xa-tflm-inference-api.c xa-microspeech-frontend.c microspeech_model_data.c microspeech-frontend-wrapper-api.cpp microspeech-inference-wrapper-api.cpp	xa-capturer-api.h xa-microspeech-frontend-api.h xa-microspeech-inference-api.h microspeech_model_data.h tflm-inference-api.h	libtensorflow-microlite.a libmicro_speech_frontend.a
14	xaf-tflite-person-detect-test.c	tflm-inference-api.cpp xa-tflm-inference-api.c person_detect_model_data.c person-detect-wrapper-api.cpp	person_detect_model_data.h xa-person-detect-inference-api.h tflm-inference-api.h	libtensorflow-microlite.a
15	xaf-person-detect-microspeech-test.c	xa-capturer.c tflm-inference-api.cpp xa-tflm-inference-api.c xa-microspeech-frontend.c	xa-capturer-api.h xa-microspeech-frontend-api.h xa-microspeech-inference-api.h microspeech_model_data.h	libtensorflow-microlite.a libmicro_speech_frontend.a

---

No	Testbench source file	Component wrapper files	Component header files	Component libraries
		microspeech_model_data.c microspeech-frontend-wrapper-api.cpp microspeech-inference-wrapper-api.cpp person_detect_model_data.c person-detect-wrapper-api.cpp	tflm-inference-api.h person_detect_model_data.h xa-person-detect-inference-api.h	

## 4.2 XAF Package Directory Structure

### Testbench specific source files (/test/src/)

- xaf-pcm-gain-test.c
- xaf-dec-test.c
- xaf-dec-mix-test.c
- xaf-full-duplex-opus-test.c
- xaf-amr-wb-dec-test.c
- xaf-mp3-dec-rend-test.c
- xaf-gain-renderer-test.c
- xaf-capturer-pcm-gain-test.c
- xaf-capturer-mp3-enc-test.c
- xaf-mimo-mix-test.c
- xaf-playback-usecase-test.c
- xaf-renderer-ref-port-test.c
- xaf-capturer-tflite-microspeech-test.c
- xaf-tflite-person-detect-test.c
- xaf-person-detect-microspeech-test.c

---

**Note** For the testbench `xaf-src-test.c`, execution is repeated 32 times with the same parameters, demonstrating consistency of the framework.

---

### Common testbench source files (`/test/src/`)

- `xaf-clk-test.c` – Clock functions used for MCPS measurements.
- `xaf-mem-test.c` – Memory allocation functions.
- `xaf-utils-test.c` – Other shared utility functions.
- `xaf-fio-test.c` – File read and write support.

### Other directories (in `/test/`)

- `include/audio` – API header files for different audio components.
- `plugins/` – Wrappers for the different audio components.
- `test_inp/` – Input data for the test execution.
- `test_out/` – Output data from test execution are be written here.
- `test_ref/` – Reference data against which the generated output can be compared.

### XAF library directories (`/algo/`)

- `hifi-dpf/` – DSP Interface Layer source and include files.
- `host-apf/` – App Interface Layer source and include files. Includes XAF Developer APIs implementation.
- `xa_af_hostless/` – XAF common internal header files.

### XAF include directories (`/include/`)

- `audio/` – XAF processing class specific header files. Also includes API, error, memory, type definition standard header files.
- `sysdeps/freertos` – FreeRTOS OSAL API definition header files.
- `sysdeps/xos` – XOS OSAL API definition header files.
- `sysdeps/mc_ipc` – Multicore-XAF IPC lock, interrupt and reset-sync definition header files.
- `xaf-api.h` – XAF Developer APIs header file.
- `xaf-config-user.h` – User-configurable parameters header file
- `xf-debug.h` – XAF debug trace support header file.

---

## XAF shared memory directory (/xf\_shared/)

- `src/xf-shared.c` – IPC shared memory buffer definitions (for NCORES>1).
- `include/xf-shared.h` – IPC shared memory buffer macro definition and references.

## XAF system file directories (/xtsc/)

- `xaf_xtsc_sys_2c.xtsys`, `xaf_xtsc_sys_2c.yml` – System specification files for 2 core system (NCORES=2)
- `xaf_xtsc_sys_3c.xtsys`, `xaf_xtsc_sys_3c.yml` – System specification files for 3 core system (NCORES=3)
- `xaf_xtsc_sys_4c.xtsys`, `xaf_xtsc_sys_4c.yml` – System specification files for 4 core system (NCORES=4)

## 4.3 Build and Execute using .tgz Package

### 4.3.1 Making the Executable

Unpack the source .tgz package which generates “xa\_af\_hostless”. Call it <BASE\_DIR>.

Before building the executable, ensure the `$XTENSA_CORE` environment variable is set correctly. The make commands mentioned below build the XAF Library and testbenches with XOS.

To build XAF Library and testbenches with FreeRTOS as RTOS:

1. Follow the steps mentioned in section 4.6 to build FreeRTOS library.
2. Use the make commands mentioned below with the options specified in square brackets [].  
**Note:** The `FREERTOS_BASE` directory must be <BASE\_DIR>/FreeRTOS from step 1 above.

### Build XAF Library:

If source code distribution is available, the library must be built before building the testbench application. To build the XAF library, follow these steps:

For NCORES=1:

1. In the command prompt, navigate to the <BASE\_DIR>/build/ directory.
2. Enter the following command:

```
$ xt-make clean all install [XA_RTOS=freertos FREERTOS_BASE=<dir>]
```



---

For NCORES>1: (Example commands for NCORES=2)

1. In the command prompt, navigate to the <BASE\_DIR>/build/ directory.
2. Enter the following command:

```
$ xt-make sysbuild NCORES=2
```

**Note:** At this point, the XTENSA\_SYSTEM environment variable must be set to the following:

```
<Absolute path of the BASE_DIR>/xtsc/mbuild/package/config
```

3. Enter the following command:

```
$ xt-make clean all install NCORES=2 [XA_RTOS=freertos  
FREERTOS_BASE=<dir>]
```

This builds the XAF library and it is copied to the /lib/ folder.

### Build only Testbench 1:

To build the pcm-gain testbench application (shown in Figure 4-1 above), follow these steps:

1. In the command prompt, navigate to the <BASE\_DIR>/test/build directory.
2. Enter the following command:

```
$ xt-make -f makefile_testbench_sample clean af_hostless  
[NCORES=<num cores> XA_RTOS=<freertos> FREERTOS_BASE=<dir>]
```

---

<b>Note</b>	The NCORES parameter is optional for NCORES=1.
-------------	--

---

This builds the pcm-gain example test application.

### Build all Testbenches:

**Prerequisites:** To build other testbenches, the Cadence MP3 decoder <sup>[4]</sup>, MP3 encoder <sup>[5]</sup>, AMR-WB decoder <sup>[6]</sup> <sup>[7]</sup>, Sample rate converter <sup>[8]</sup>, AAC decoder <sup>[9]</sup>, Ogg-Vorbis <sup>[10]</sup> libraries, and the respective API header files are required.

Copy these libraries to the following directories.

```
/test/plugins/cadence/mp3_dec/lib/xa_mp3_dec.a  
/test/plugins/cadence/mp3_enc/lib/ xa_mp3_enc.a  
/test/plugins/cadence/amr_wb/lib/xa_amr_wb_codec.a  
/test/plugins/cadence/src-pp/lib/xa_src_pp.a  
/test/plugins/cadence/aac_dec/lib/xa_aac_dec.a  
/test/plugins/cadence/opus_enc/lib/xa_opus_codec.a
```

---

```
/test/plugins/cadence/opus_dec/lib/xa_opus_codec.a
```

Copy these API header files to the following directory.

```
/test/include/audio/xa_mp3_dec_api.h  
/test/include/audio/xa_mp3_enc_api.h  
/test/include/audio/xa_amr_wb_codec_api.h  
/test/include/audio/xa_src_pp_api.h  
/test/include/audio/xa_aac_dec_api.h  
/test/include/audio/xa_opus_codec_api.h
```

1. In the command prompt, navigate to the <BASE\_DIR>/test/build directory.
2. Enter the following command:

```
$ xt-make -f makefile_testbench_sample clean all-dec  
[NCORES=<num cores> XA_RTOS=freertos FREERTOS_BASE=<rtos_dir>]
```

This builds all the testbench applications except the TFLM testbench applications.

The TFLM testbench applications can be generated independently using the following command:

```
$ xt-make -f makefile_testbench_sample clean <target> [NCORES=<num  
cores> XA_RTOS=freertos FREERTOS_BASE=<rtos_dir>  
TFLM_BASE=<dir>/tensorflow]
```

Where, the target can be one of the following: af\_tflm\_microspeech, af\_tflm\_pd, or af\_tflm\_microspeech\_pd.

---

<b>Note</b>	The TFLM libraries must be built before building the TFLM testbenches. Refer to section 4.7 for steps to build the TFLM library and for additional build settings for TFLM test examples refer libxa_af_hostless/build/readme_tflm.txt.
-------------	---

---

## 4.3.2 Usage

The sample application executables can be run as described below using the cycle-accurate mode of the Instruction Set Simulator (ISS) for NCORES=1 and using cycle accurate Xtensa System C (XTSC) simulator for NCORES>1. The input files for the applications are stored in the test/test\_inp folder. The generated output files are available in the test/test\_out folder. These can be compared against the reference output files in the test/test\_ref folder. Refer to individual testbench help to get more details on command line options to run different test cases.

---

<b>Note</b>	There is no difference in run commands for XAF with XOS or FreeRTOS.
-------------	--

---

---

## Run only Testbench 1:

To run only the pcm-gain test application, at the prompt (in `test/build`), enter:

```
$ xt-make -f makefile_testbench_sample run_af_hostless [NCORES=<num cores>]
```

## Run all Testbenches:

To run all the testbenches (except the TFLM testbenches), at the prompt (in `test/build`), use the following command. The TFLM testbenches can be run independently.

```
$ xt-make -f makefile_testbench_sample run-dec [NCORES=<num cores>]
```

---

**Note** In Instruction Set Simulator (ISS) mode, the renderer testbench output is stored to the output file `renderer_out.pcm` in the execution directory. Similarly, the input for capturer testbench is read from the input file `capturer_in.pcm` and is expected to be present in the execution directory.

**Note** NCORES parameter is optional for NCORES=1.

---

## Run Individual Testcase:

The script `xaf_xtsc_run.sh` accepts the identical command line to that of Hostless XAF and renders it to the multicore simulator `xtsc-run`.

```
./xaf_xtsc_run.sh NCORES [1,2(default),3,4,...,N] xt-run
xa_af_playback_usecase_test -
infile:../test_inp/hihat_1ch_16b_192kbps_cbr.mp3 -
infile:../test_inp/hihat_1ch_16b_192kbps_cbr.mp3 -
infile:../test_inp/hihat_1ch_16b_44.1kHz.adts -
infile:../test_inp/hihat_1ch_16b_44.1kHz.adts -outfile:out0.pcm -
outfile:out1.pcm -core-cfg:1,1 -core-cfg:2,2 -core-cfg:3,4
```

1. The binary names provided must be without the name `_coreX` (the binaries get generated with `<test-name>_core0`, `_core1` -etc.)

Example: if the testcase binaries generated are  
`xa_af_playback_usecase_test_core0`,  
`xa_af_playback_usecase_test_core1` then provide  
`./xaf_xtsc_run.sh xt-run xa_af_playback_usecase_test -`  
`infile:<> -infile:<> -outfile:<>`

2. One can also use the command directly without the script `xaf_xtsc_run.sh` with appropriate comma separated arguments

Example: `xtsc-run --`  
`define=core0_BINARY=xa_af_playback_usecase_test_core0 --`  
`define=core0_BINARY_ARGS=`

---

```
infile:../test_inp/hihat_1ch_16b_192kbps_cbr.mp3,-
infile:../test_inp/hihat_1ch_16b_192kbps_cbr.mp3,-
infile:../test_inp/hihat_1ch_16b_44.1kHz.adts,-
outfile:out0.pcm,-outfile:out1.pcm,-core-cfg:1,1 --
define=core1_BINARY=xa_af_playback_usecase_test_core1 --
define=XTSC_LOG=0 --include=../../xtsc/sysbuilder/xtsc-
run/multicore2c.inc
```

### 4.3.3 Creating Components on a Worker-Core

By default, all the components are created on core-0 that is the master DSP with `XF_CORE_ID=0`.

To create a component on a different core `-core-cfg:<core>`, use the `<component id or comp_id>` command-line option.

For example:

```
./xaf_xtsc_run.sh NCORES 4 xt-run xa_af_playback_usecase_test -
infile:../test_inp/hihat_1ch_16b_192kbps_cbr.mp3 -
infile:../test_inp/hihat_1ch_16b_192kbps_cbr.mp3 -
infile:../test_inp/hihat_1ch_16b_44.1kHz.adts -
infile:../test_inp/hihat_1ch_16b_44.1kHz.adts -outfile:out0.pcm -
outfile:out1.pcm -core-cfg:1,1 -core-cfg:2,2 -core-cfg:3,4
```

In the above example, there are seven components with id ranging from 0 to 6.

`-core-cfg:1,1` component 1 is created on worker core 1

`-core-cfg:2,2` component 2 is created on worker core 2

`-core-cfg:3,4` component 4 is created on worker core 3

Rest of the components 0,3,5 and 6 are created on core 0 (master DSP)

---

**Note** In System C Simulator (XTSC) mode, the renderer testbench output is stored to the output file `renderer_out.pcm` in the execution directory. Similarly, the input for capturer testbench is read from the input file `capturer_in.pcm` and is expected to be present in the execution directory.

**Note** The `xt-run` command token is parsed by the shell script `xaf_xtsc_run.sh` in the `test/build` folder into comma separated tokens as required by the SystemC simulator `xtsc-run` for the execution of the testcase.

**Note** The command argument parsing of “`-core-cfg:<core-id>,<comp-id>,<comp-id>,...,<comp-id>`” is supported by the `testxa_af_gain_renderer_test`, `testxa_af_playback_usecase_test`, `testxa_af_mimo_mix_test`,

---

testxa\_af\_renderer\_ref\_port\_test projects. Other project testbenches can be updated in a similar way as required.

---

## 4.4 Build and Execute using .xws Package

### 4.4.1 Working with XAF .xws Package

The XAF .xws package can be used in both single core(NCORES=1) and multicore(NCORES>1) subsystems. The xws contains the XAF library project “libxa\_af\_hostless” and 15 testbench projects as shown in Table-4.2.

Table 4-2 XWS Test Project List

S No	Test project	Testbench
1	testxa_af_hostless	xa_af_hostless_test
2	testxa_af_mimo_mix	xa_af_mimo_mix_test
3	testxa_af_gain_renderer	xa_af_gain_rend_test
4	testxa_af_capturer_gain	xa_af_capturer_pcm_gain_test
5	testxa_af_renderer_ref_port	xa_af_renderer_ref_port_test
6	testxa_af_dec*	xa_af_dec_test
7	testxa_af_dec_mix*	xa_af_dec_mix_test
8	testxa_af_amr_wb_dec*	xa_af_amr_wb_dec_test
9	testxa_af_mp3_dec_rend*	xa_af_mp3_dec_rend_test
10	testxa_af_capturer_mp3_enc*	xa_af_capturer_mp3_enc_test
11	testxa_af_playback_usecase*	xa_af_playback_usecase_test
12	testxa_af_full_duplex_opus*	xa_af_full_duplex_opus_test
13	testxa_af_tflm_microspeech*	xa_af_tflite_microspeech_test
14	testxa_af_tflm_pd*	xa_af_tflite_person_detect_test
15	testxa_af_tflm_microspeech_pd*	xa_af_person_detect_microspeech_test

(\* These test projects have library dependencies, hence it does not build and run out-of-the-box. Refer to step 5 of “Single core XAF” section below to build these test-projects.)

---

**Note** The above testbenches require Xtensa Xplorer version 8.0.16 or later.

---

The following are the steps for importing to Xtensa Xplorer and building testbenches. By default, XAF Library and testbenches are built with XOS. To use FreeRTOS, refer to instructions in Section 4.4.2. Xtensa Xplorer supports two build modes “Release” and “Debug”, which can be

---

selected with “Target (T:)”. “Release” mode uses default build options whereas “Debug” mode uses build options defined under “DEBUG=1” in the Makefiles.

### **Single core XAF (NCORES=1):**

1. To import the XAF workspace file (extension .xws) into Xplorer, click **File → Import...**. The Import wizard opens. Select **Import Xtensa Xplorer Workspace**. Click **Next >**. Browse for the Xtensa workspace file and click **Next >**.
  - a) Select project ‘libxa\_af\_hostless’.
  - b) Select project ‘testxa\_af\_hostless’.
  - c) Select any one or all projects among the 15 available test-projects.
  - d) Click **Finish** (Ignore the warning: “There are unimported items.”).
2. Select a test project from 2 to 14 from Table 4-2 XWS Test Project List as the active project. For example, select “testxa\_af\_hostless” (PCM-gain) as the active project and any of the compatible HiFi cores as the configuration.
3. Build by clicking the **Build Active** button.
4. To run the selected Testbench (example: testxa\_af\_hostless\_test, that is, PCM gain), from the “Run configurations” menu, select the launch corresponding to the active project available under “Xtensa Single Core Launch” and click the **Run** button.

**Note:** One must choose the cycle-accurate simulation launch <test project>\_cycle (see Known Issues) to run the test.

The default input or output file settings can be changed, from the “Run configurations” menu under “Arguments” tab in “Program Arguments” text box by modifying the command text.

For example, in testxa\_af\_hostless modify the following as required:

```
-infile:<input PCM file> -outfile:<output PCM file>
```

5. To build and run other testbenches with library dependencies, follow these steps:
  - a. Copy the library binary and API header file of the component (if required) to the location test/plugins/cadence/<component>/lib/ and test/include/audio, respectively. Refer to Table 4-1 for component dependencies of various testbenches.
  - b. In the “**Build Properties**” wizard, under “**Add Linker**” tab, in the “**Additional linker options**”, add the component library name and the path of the library required by the testbench. The path can either be absolute path or relative path (for example,  
`${workspace_loc:testxa_af_hostless/test/plugins/cadence/aac_dec/lib}/xa_aac_dec.a`).
  - c. Follow steps 2 to 4 as given above, with appropriate command-line arguments.
  - d. For any custom testbenches other than those mentioned in Table 4-2 XWS Test Project List, ensure that the required symbols among the following are defined in “Build Properties” under “Symbols” tab.

```
XA_PCM_GAIN=1
```

---

```

XA_MP3_DECODER=1
XA_MP3_ENCODER=1
XA_SRC_PP_FX=1
XA_AAC_DECODER=1
XA_MIMO_MIX4=1
XA_AMR_WB_DEC=1
XA_RENDERER=1
XA_CAPTURER=1
XA_AEC22=1
XA_AEC23=1
XA_PCM_SPLIT=1
XA_MIMO_MIX=1
XA_OPUS_ENCODER=1
XA_OPUS_DECODER=1
XA_TFLM_MICROSPEECH=1
XA_TFLM_PERSON_DETECT=1

```

These symbols enable inclusion of respective component plugins into compilation. While most of the symbol names are self-explanatory, following is a brief list of some of these symbols and their respective component plugin.

XA_SRC_PP_FX	Sample rate converter
XA_AEC22	Dummy acoustic echo canceler, 2 in 2 out MIMO component
XA_AEC23	Dummy acoustic echo canceler, 2 in 3 out MIMO component
XA_PCM_SPLIT	PCM splitter, 1 in 2 out MIMO component
XA_MIMO_MIX	MIMO class mixer component, 2 in 1 out
XA_MIMO_MIX4	MIMO class mixer component, 4 in 1 out

**Note:** If more than required components are enabled in `test/plugins/xa-factory.c` (for example, due to default enabled “Symbols” as mentioned in step *d* above) and respective component wrappers and libraries are not included in compilation, a dummy wrapper function can be defined in testbenches to avoid compilation errors. For example, a dummy wrapper function for MP3 Decoder can be defined as follows in the testbench.

```

XA_ERRORCODE xa_mp3_decoder(xa_codec_handle_t var1,
WORD32 var2, WORD32 var3, pVOID var4) {return 0;}

```

- To enable trace prints for analysis or debugging, add `XF_TRACE = <TRACE_LEVEL>` in the “Symbols” tab for both 'libxa\_af\_hostless' and 'testxa\_af\_hostless' projects. Refer to Special Build Settings for details about available TRACE levels.

---

<b>Note</b>	The project <code>testxa_af_hostless</code> has a common <code>test_inp</code> directory that contains the test input files required for all the test projects in the package and a common <code>test_out</code> directory containing any output files generated for all the test projects. Hence one must also import this project into the workspace.
<b>Note</b>	For <code>testxa_af_full_duplex_opus</code> , in step 5.b it is required to provide the path of <code>xa_opus_codec.a</code> of either of the <code>opus_enc</code> or <code>opus_dec</code> , but not both.
<b>Note</b>	Refer to section 4.7 for steps to build the TFLM library and for additional build settings for TFLM test examples refer <code>libxa_af_hostless/build/readme_tflm.txt</code> .

---

### ***Multicore XAF (NCORES>1):***

---

<b>Note</b>	The previous section about importing and building testbench projects into Xplorer is same for multicore.
-------------	--

---

Only the additional steps specific to multicore are mentioned here. Note that only playback testbench is included in the .xws package for NCORES>2 configurations.

1. Perform the following steps:
  - a. Select the 'project xws' (ex: `xa_hifi_af_hostless_lib_3_1_Beta_api_3_0_src.xws`),
  - b. Select project '`libxa_af_hostless`'
  - c. Select project '`testxa_af_hostless`'
  - d. Select project '`xf_shared`'
  - e. Select any other or all projects among the 15 test-projects available
  - f. Click **Next**
  - g. Select required project launch configuration (ex: `BMap0_af_hostless_2c`) for one or more projects selected above
  - h. Click **Next**
  - i. Select required subsystem from the package multicore2c for NCORES=2, multicore3c for NCORES=3, multicore4c for NCORES=4
  - j. Click **Finish**
2. The test projects need to be re-imported with different names, for as many cores in the system (NCORES). For example, if NCORES=2, the testbench project `testxa_af_hostless` needs to be imported twice. Since Xplorer would not allow importing the same project with same name again, it needs to be renamed (say `testxa_af_hostless2`) before importing.
  - a. Click **File** → **Import...**  
The Import wizard opens.
  - b. Select **Import Xtensa Xplorer Workspace**. Click **Next** >.
  - c. Browse for the Xtensa workspace file and click **Next** >.
  - d. Select one of the test projects from the available project checkboxes, on the right side there is option to rename. Rename the project and click "apply".



- 
- e. Repeat the same for all the test projects that need to be re-imported and click **Next-> Finish**.

**Note:** The library project `libxa_af_hostless`, launch configurations, subsystems and the `xf_shared` project must not be re-imported.

3. In the workspace window, select the following:  
Select core (Example: `hifi4_ss_spfp_u_7`)  
Select test project: (Example: `testxa_af_hostless`)  
Select target: Release
4. In the **System overview** window, expand to see **Subsystems**. Right-click on the named `<subsystem>` (Example: `multicore2c`) and choose **build subsystem** which builds the subsystem into `${workspace_loc}/<subsystem>/bin/sysBuild`
5. Expand the named `<subsystem>` (Example: `multicore2c`) and right-click on **MMap0** and chose **build Memory map** which builds the memory-map and required include header into the mbuild location `${workspace_loc}/<subsystem>/bin/mBuild`

**Note:** MMap0 build can result into error like “Binary map “BMap10\_<unimported project name> of memory map ‘MMap0’ has inaccessible project ‘testxa\_<unimported project name>’”.

Here `<unimported project name>` indicates per-core instances of a `test_xa_*` project. For example: for `NCORES=2`, if `xa_af_hostless2` is not imported or missing for `xa_af_hostless` project, the above error is displayed. Similar `test_xa_*` projects that are part of the same MMap can be available and all these projects need to be resolved by importing necessary project instances.

If there are extra projects that are part of the MMap, then instead of trying to add instances to avoid the error, the projects can be removed from the memory map.

To remove projects, Double click on MMap0 → In the window “multicore2c” → Memory Maps → Memory and Binary maps → drop-down arrow of MMap0, select a project with X-mark in red which indicates necessary instances of that project is not imported, and click ‘**Remove**’ button on the right side of the window.

Do this for all extra projects.

**Ctrl+S** to save the state.

Re-attempt building MMap0 as mentioned at the start of this step.

6. Set required include paths.  
**Note:** These are additional include paths required for multicore build).  
For `libxa_af_hostless` project:

- a. `${workspace_loc}/<subsystem>/bin/sysBuild/include`
- b. `${workspace_loc}/<subsystem>/bin/mBuild/MMap0/package/xtensa-elf/include`  
where `<subsystem>` names in the package are among: `multicore2c`, `multicore3c`, `multicore4c`

---

Example include path if <subsystem> is multicore2c:

```
{workspace_loc}/multicore2c/bin/sysBuild/include  
{workspace_loc}/multicore2c/bin/mBuild/MMap0/package/xtensa-elf/include
```

- c. `{workspace_loc:libxa_af_hostless/include/sysdeps/mc_ipc}`

Include path required for all the projects:

- d. `{workspace_loc:xf_shared/include}`

7. Add/Edit symbols:

For all projects:

- a. To enable cache, set symbol `XF_LOCAL_IPC_NON_COHERENT = 1`.
- b. Set the symbol `XF_CFG_CORES_NUM` to appropriate number.  
**Note:** The value of `XF_CFG_CORES_NUM` is number-of-cores/NCORES in the subsystem. (Example: `XF_CFG_CORES_NUM=2` for 2-core subsystem)

Symbols for test projects:

- a. For `testxa_*`, each `testxa_*` project must have unique `XF_CORE_ID`.  
`XF_CORE_ID` varies from 0 to `NCORES-1`  
Example: for a two core subsystem, `XF_CFG_CORES_NUM=2`  
`testxa_af_hostless->build-properties->common->symbols->XF_CORE_ID = 0`  
`testxa_af_hostless2->build-properties->common->symbols->XF_CORE_ID= 1`

- 8. Link `xf_shared` (the shared library) project as library dependencies to all `testxa_*` projects using **Library dependencies** option.  
(Right-click on all `testxa_*` the project->select **Library dependencies** option then, double click on `xf_shared` which must appear in lower-box.)
- 9. In **System Overview** window: subsystem->MMap0->BMAP0 (Ex: BMap0\_af\_hostless), attach binaries to cores under **core/project mappings window** double click,  
**Select project** → Select correct project from the dropdown list. The association must be unique. For example, it is recommended suggested to associate `testxa_af_hostless` to core0, `testxa_af_hostless2` to core1-etc. Do this for all cores under that BMap0.  
**Select Build Target** → <Active Set> (inherits the Active Build Target of the Active Project).  
**Select LSP** → sim.  
**Arguments for the Xtensa Program** → provide the necessary command argument. The `test_inp` directory can be referenced with `testxa_af_hostless/test/test_inp` for an input file, similarly `testxa_af_hostless/test/test_out` for `test_out` directory. This is necessary for only the master core or core0 in this package.  
**Note:** By default, the example testbench projects have the necessary mappings in place. But it is suggested to verify that the mappings are correct. Do all of the above

---

Selects, except 'Arguments for the Xtensa Program' for all the other worker cores under this BMapX.

10. Build the test-project: Right-click on BMap0 (Ex: BMap0\_af\_hostless) and chose 'build all projects' to build the corresponding test-project. Do the same for all BMap1, BMap2.. BMapN test projects.

11. To run a test project after build, go to **Run Configurations** > Select **MP Launch** and select one of the launch targets in cycle accurate mode.

**Note:** Although the default settings work, it is suggested to check the following are selected:

- Select MP Simulator Launch Type → 'Managed Subsystem'
- Subsystem Launch Options→ Subsystem → Select the project's BMap in the dropdown
- Working Directory → \${workspace\_loc}
- Debug Options → sync
- Debugger Attach Options → Stop All Cores

---

<b>Note</b>	The project <code>testxa_af_hostless</code> has a common <code>test_inp</code> directory that contains the test input files required for all the test projects in the package and a common <code>test_out</code> directory containing any output files generated for all the test projects. Hence one must also import this project into the workspace.
<b>Note</b>	<code>\${workspace_loc}</code> directory is parent directory to all the projects, and can be accessed from command line
<b>Note</b>	<code>test_inp</code> : All test inputs are available in <code>\${workspace_loc}/testxa_af_hostless/test/test_inp</code> .
<b>Note</b>	<code>test_out</code> : All test outputs are to be written to <code>\${workspace_loc}/testxa_af_hostless/test/test_out</code> .
<b>Note</b>	The capturer input file 'capturer_in.pcm' is to be copied to the directory <code>\${workspace_loc}</code> .
<b>Note</b>	The renderer output file 'renderer_out.pcm' is generated in the directory <code>\${workspace_loc}</code> .
<b>Note</b>	To copy <code>capturer_in.pcm</code> to the set location in xws which is <code>\${workspace_loc}</code> , either use command line OR change the "Working-Directory" in the 'Run-Config' or launch followed by modifying the input/output file paths of the "Argument for the Xtensa Program" associated with the binary of the BMap.

---

## 4.4.2 Switching to FreeRTOS with XAF .xws Package

Following are the steps to use FreeRTOS with XAF .xws package.

1. Build FreeRTOS library using steps mentioned in section 4.6. `<BASE_DIR/FreeRTOS>` path is defined as per this step.

- 
2. For 'libxa\_af\_hostless' project, modify include paths for common target as below.

(Go to **T:Debug**, select **Modify**, select Target as “Common Target” in the new window that opens, and select 'Include Paths' tab).

Replace

```
'${workspace_loc}/libxa_af_hostless/build/./include/sysdeps/xos/include'
```

With

```
'${workspace_loc}/libxa_af_hostless/build/./include/sysdeps/freertos/include'
```

3. For 'libxa\_af\_hostless' project, add the following include paths for common target.  
(Go to **T:Debug**, select **Modify**, select Target as “Common Target” in the new window that opens, and select 'Include Paths' tab).

```
<BASE_DIR>/FreeRTOS/include
```

```
<BASE_DIR>/FreeRTOS/portable/XCC/Xtensa
```

```
<BASE_DIR>/FreeRTOS/demos/cadence/sim/common/config_files
```

4. For 'libxa\_af\_hostless' project, update Symbols as below.  
(Go to **T:Debug**, select **Modify**, select Target as “Common Target” in the new window that opens, and select 'Symbols' tab)

Replace 'HAVE\_XOS' with 'HAVE\_FREERTOS' in Defined Symbols list.

5. For 'testxa\_af\_hostless' project, modify include path for common target as below.

(Go to **T:Debug**, select **Modify**, select Target as “Common Target” in the new window that opens, and select 'Include Paths' tab)

Replace

```
'${workspace_loc}/libxa_af_hostless/include/sysdeps/xos/include'
```

With

```
'${workspace_loc}/libxa_af_hostless/include/sysdeps/freertos/include'
```

6. For 'testxa\_af\_hostless' project, add the following include path for common target.

(Go to **T:Debug**, select **Modify**, select Target as “Common Target” in the new window that opens, and select 'Include Paths' tab).

```
<BASE_DIR>/FreeRTOS/include
```

```
<BASE_DIR>/FreeRTOS/portable/XCC/Xtensa
```

```
<BASE_DIR>/FreeRTOS/demos/cadence/sim/common/config_files
```

7. For 'testxa\_af\_hostless' project, update Symbols as below.  
(Go to **T:Debug**, select **Modify**, select Target as “Common Target” in the new window that opens, and select 'Symbols' tab)

Replace 'HAVE\_XOS' with 'HAVE\_FREERTOS' in Defined Symbols list.

8. For 'testxa\_af\_hostless' project, update additional linker options as below.  
(Go to **T:Debug**, select **Modify**, select Target as “Common Target” in the new window that opens, and select 'Addl linker' tab)

Replace '-lxos' in Additional linker options with

```
'-L<BASE_DIR>/FreeRTOS/demos/cadence/sim/build/<your_hifi_core> -lfreertos'
```

- 
9. Clean and Build 'testxa\_af\_hostless' project.  
It must now run with FreeRTOS.

To switch back to XOS, revert steps 2 to 8 and Clean and Build 'testxa\_af\_hostless' project.

## 4.5 Special Build Options

- To build in the debug mode, add "DEBUG=1" to the XAF library and testbench compilation command lines described in section 4.3 and 4.4.
- To build with trace prints, add "XF\_TRACE=<TRACE\_LEVEL>" to the XAF library and testbench compilation command lines described section 4.3 and 4.4. For all trace prints, set TRACE\_LEVEL to 1. For command-related trace prints and response transactions, set TRACE\_LEVEL to 2. Any trace tag can be enabled or disabled by setting or resetting TRACE\_TAG listed in include/xf-debug.h. For example,

```
TRACE_TAG (PROCESS, 1); /*... PROCESS trace tag is enabled */
```

```
TRACE_TAG (PROCESS, 0); /*... PROCESS trace tag is disabled */
```

### Notes:

- With more trace tags enabled, the size of the executable is increased. A "CRITICAL" trace tag is provided to print only minimal and important trace logs of errors/warnings during component execution and configuration without significantly increasing the executable size. For only critical error/warnings trace prints, disable all other tags except the CRITICAL tag.
- If both DEBUG=1 and XF\_TRACE=1 are enabled during compilation, the "BUG" macros are activated in the code and print useful debug information that is largely used to validate NULL pointers and parameter ranges.
- To build without event communication support, add "XA\_DISABLE\_EVENT=1" to both the XAF library and testbench compilation command lines described section 4.3 and 4.4, which can save the corresponding code memory. Event communication support is enabled by default.
- To enable the zero-copy mode of the xaf\_comp\_set\_config\_ext and xaf\_comp\_get\_config\_ext APIs, add "XA\_ZERO\_COPY=1" (enabled by default).

The following flags can be used to disable support of specific classes of components from the XAF library.

Table 4-3 Disable class code build flags

Sr No .	Class	Flag
1	Audio-codec class	XA_DISABLE_CLASS_AUDIO_CODEC = 1
3	MIMO proc class	XA_DISABLE_CLASS_MIMO_PROC = 1
4	Capturer class	XA_DISABLE_CLASS_CAPTURER = 1
5	Renderer class	XA_DISABLE_CLASS_RENDERER = 1

**Note** If a component of a particular class is not required in the pipeline, the corresponding flag can be defined while building the XAF library to disable that class and save corresponding code memory.

## 4.6 Building FreeRTOS for XAF

This section describes how to build the required version of FreeRTOS library to be used with XAF.

**Note** The FreeRTOS compilation is only supported under Linux environment.

1. Copy `libxa_af_hostless/build/getFreeRTOS.sh` from XAF Package to the directory of choice outside XAF Package under Linux environment. This directory is referred to as `<BASE_DIR>` in the following steps.
2. Set up environment variables to have Xtensa Tools in `$PATH` and `$XTENSA_CORE` defined to your HiFi core.
3. Execute `getFreeRTOS.sh`. This downloads and builds FreeRTOS library in `<BASE_DIR/FreeRTOS>`. The FreeRTOS library is created in `<BASE_DIR>/FreeRTOS/demos/cadence/sim/build/<your_hifi_core>` directory.  

```
$ ./getFreeRTOS.sh
```
4. You can copy `<FreeRTOS>` directory from Linux to Windows for building XAF Library and testbenches. In that case, the destination directory on Windows is your new `<BASE_DIR>`.

## 4.7 Building TFLM for XAF

This section describes how to build the required version of TFLM [\[13\]](#) library to be used with XAF.

**Note** This TFLM compilation method is only supported under Linux environment.

1. Copy `libxa_af_hostless/build/getTFLM.sh` from XAF Package to the directory of choice outside XAF Package under Linux environment. This directory is referred to as `<BASE_DIR>` in the following steps.

- 
2. Set up environment variables to have Xtensa Tools in \$PATH and \$XTENSA\_CORE defined to your HiFi core.
  3. Execute `getTFLM.sh <target>` as below. This downloads and builds the tensorflow TFLM libraries in the directory `<BASE_DIR>/tflite-micro`  

```
$ ./getTFLM.sh hifi3/hifi4/hifi5
```
  4. The following libraries are created:
    - `libtensorflow-microlite.a` - TFLM Library
    - `libmicro_speech_frontend.a` - Frontend lib for Microspeech Application

Library path for HiFi 5 core: `<BASE_DIR>/tflite-micro/gen/xtensa_hifi5_default/lib`

Library path for other cores: `<BASE_DIR>/tflite-micro/gen/xtensa_hifi4_default/lib`

You can copy `<tensorflow>` directory from Linux to Windows for building XAF Library and testbenches. In that case, the destination directory on Windows is your new `<BASE_DIR>`.

## 4.8 Building Multicore Subsystem

Multicore XAF tests require a multicore-subsystem to compile and run, so they do not compile and run OOB. A subsystem is required to build and execute the software.

1. In the file `include/xaf-config-user.h`, `XF_EXTERNAL_INTERRUPT_NUMBER` is the BInterrupt number or external interrupt number, which is internally mapped to the Processor interrupt number in the file `include/sysdeps/mc_ipc/xf-mc-ipc.h`
2. The interrupt can be EDGE or LEVEL triggered.
3. For configurations with `XCHAL_HAVE_EXCLUSIVE`, the memory region used for global mutex lock object is required to be in the shared memory region of `NON_CACHEABLE` attributes.

The attributes can be set using `xthal_mpu_set_region_attribute()` with the following flags for all the DSPs in the subsystem before calling the APIs `xaf_adev_open` or `xaf_dsp_open`:

```
XTHAL_MEM_NON_CACHEABLE,  
XTHAL_MEM_SYSTEM_SHAREABLE,  
XTHAL_MEM_BUFFERABLE.
```

Example:

```
err = xthal_mpu_set_region_attribute (addr_pointer, size_in_bytes,  
                                     XTHAL_MPU_USE_EXISTING_ACCESS_RIGHTS,  
                                     (XTHAL_MEM_NON_CACHEABLE |  
                                      XTHAL_MEM_SYSTEM_SHAREABLE |  
                                      XTHAL_MEM_BUFFERABLE),  
                                     0);
```

- 
4. Multicore subsystem consists of the following sections with directory structure:

Shared library: xf\_shared

xf\_shared/include/xf-shared.h

xf\_shared/src/xf-shared.c

Subsystem: example for 2 core 'multicore2c'

multicore2c/spec.yml

multicore2c/cluster.yml

multicore2c/MMap0/MMap0.xld

multicore2c/MMap0/BMap....yml

multicore2c/bin (empty)

multicore2c/params (empty)

The following are populated when 'subsystem' is built

multicore2c/params

multicore2c/bin/sysBuild

The following are populated when 'memory map (MMap)' is built

multicore2c/bin/mBuild

## 4.8.1 Core Configuration Requirements

This section describes the core-configuration requirements for using cores to build multicore subsystem for multicore-XAF. The system files are available under \$(ROOTDIR)/xtsc folder as described in the package directory structure (ROOTDIR is the base directory of the package).

- HiFi DSP cores need the following enabled in the configuration:
- Select “PIF Write Responses” (sets HAL macro XCHAL\_HAVE\_PIF\_WR\_RESP to 1) and add “Write Error Interrupt”
- Select “Inbound PIF” option for Local Instruction RAM(s) and Data RAM(s)
- Select “Synchronize Instruction”. All the DSPs in the multi-core subsystem must have identical multi-core synchronization mechanism:
  - Either “Conditional store sync” (sets HAL macro XCHAL\_HAVE\_S32C1I to 1)
  - Or “Exclusive Access” (also known as, Master Excl. Access) and “Subordinate Exclusive Access” (also known as, Slave Excl. Access) (sets HAL macro XCHAL\_HAVE\_EXCLUSIVE = 1)
- Add at least one edge or level triggered interrupt (<= EXCM Level)
- Add one timer interrupt (<=EXCM level) – optional.

The system definition is provided in .yml and .xtsys file pairs in \$(ROOTDIR)/xtsc folder.

xtsc/xaf\_xtsc\_sys\_2[3,4]c.yml

xtsc/xaf\_xtsc\_sys\_2[3,4]c.xtsys

**Note:** The above files are for example usage and you must review and update these for their multicore subsystem.



---

**Note** In the `.yaml` and `.xtsys` files, update the core name to <your HiFi core config name>.

---

You must update `.yaml` file for parameters like PIF width, local memory access widths, cache access widths, memory configurations etc. to exactly match their core configuration (see section Custom Core-Configuration).

For memory size and partition updates, you must update respective details in `.xtsys` file (see section Custom Core-Configuration).

## 4.8.2 Updating the Shared Memory

The shared memory buffer and the buffer size are defined in `xf_shared/src/xf-shared.c` and `xf_shared/include/xf-shared.h`, respectively. One must update the size of the shared buffer as required. The size must be within the allocated memory partitions specified in the `.xtsys` file.

The buffers required for global lock-objects of IPC and shared-memory management must also be allocated in the global shared memory with additional attributes set using `xthal_mpu_set_region_attribute` as mentioned before.

---

**Note** For cores with `XCHAL_HAVE_EXCLUSIVE` option enabled, the locks are required to be placed in a non-cached, shared memory segment. Such a memory segment can be created by appropriate modifications in the `.xtsys` file.

---

For example, we create `section(".sysram_uncached.data")` in our subsystems for which the following entries are required in the `.xtsys` file, when creating a subsystem on the command-line.

```
<hash n="memories">
<hash      n="sysram_uncached"      paddr="0x24fd8000"      size="0x20000"
writable="1"/>
<array n="partitions">
<hash      corename="*"      memname="sysram_uncached"
name="shared_uncached_sram" offset="0x0" size="0x20000"/>
```

## 4.8.3 Custom Core-Configuration

The necessary sub system parameters definitions are provided in the file with `.yaml` and `.xtsys` extensions.

For a custom HiFi core, update the subsystem parameters to meet the requirements of Multicore XAF, viz. core config name, PIF width, local memory access widths, cache access widths, memory configurations, and so on in the `.yaml` and `.xtsys` files.

yml:

- The file is used to build XTSC execution environment for simulation using `$XTENSA_TOOLS/libexec/xt-sysbuilder` which generates the subsystem files into `sysbuilder` directory.
- **SubSystemName:** The subsystem name must match that in the `.xtsys` file.
- **Interrupt number:** `XF_EXTERNAL_INTERRUPT_NUMBER` in `xaf-config-user.h` must match the `BInterrupt` number in the `.yml` file and must be same for all the cores.
- It is required to setup correct environment variables required for building the subsystem: viz. system paths (`XTENSA_SYSTEM`), tools paths (`XTTOOLS`, `XTENSA_TOOLS`), core-config (`XTENSA_CORE`).

A sample `.yml` file which is available with the release package, is shown in the below table, along with the required parameters settings.

Table-1 Custom Core-Config Parameter List

<b>.yml sample file parameters</b>	<b>Parameters to update (also available in config-params file)</b>
<code>SubSystemName: multicore2c</code>	SubSystemName must match with the one in <code>xtsys</code> file.
<code>Processors:</code>	
<code>- Name: core0</code>	Name of the core must match with the one in <code>xtsys</code> file. (for example, "core0").
<code>Config: &lt;Your HiFi core config name&gt;</code>	Configuration of reference core used to build core ( <code>core0</code> )
<code>ProcId: 0</code>	Processor ID is a numeric constant between <code>0..NCORES-1</code>
<code>Master: true</code>	Master <code>True</code> for Master core (1 per subsystem), <code>False</code> for worker cores and each independent core is a master-core.
<code>Pipeline: LX</code>	
<code>StaticVectorSel: 0</code>	
<code>PifWidth: 8b</code>	PIF width in bytes
<code>DataRamFetchWidth: 8b</code>	DRAM width in bytes
<code>InstRamFetchWidth: 16b</code>	IRAM width in bytes
<code>InstRam0:</code>	
<code>LocalAddr: '0x58000000'</code>	IRAM address
<code>GlobalAddr: '0x88000000'</code>	
<code>Size: 128Mb</code>	IRAM size in Kb or Mb

DataRam0:	
LocalAddr: '0x70000000'	DRAM address
GlobalAddr: '0x98000000'	
Size: 128Mb	DRAM size in Kb or Mb
NumBanks: 4	Number of memory banks
LocalMMIO:	
GlobalAddr: '0x80010000'	
Size: 4b	
InterruptRegister:	
GlobalAddr: '0x80010000'	
InterruptMap:	
- BInterrupt: 7	External interrupt number
ProcInterrupt: 7	Processor interrupt number
BitOffset: 0	External Interrupt bit offset in the interrupt mask
Type: Edge	Interrupt type: Level or Edge
Dcache:	
LineSize: 128	DCACHE line size in bytes
SystemRAM:	
GlobalAddr: '0x20000000'	Update SRAM address
Size: 80Mb	SRAM size in Kb or Mb
ReadDelay: 1	SRAM read memory latency in cycles
ReadRepeat: 1	
WriteDelay: 1	SRAM write memory latency in cycles
WriteRepeat: 1	
RequestFIFODepth: 255	
SystemROM:	
GlobalAddr: '0x50000000'	SRAM address
Size: 12Mb	SRAM size in Kb or Mb
SubSystemInterconnect:	
- Src: CommonBus	
Dests:	
- core0	
- core1	
DeviceMemories:	
- Name: DeviceMemory0	
GlobalAddr: '0x80000000'	
Size: 64Kb	

xtsys:

- The file is used to build the memory maps (`mmmap.xml`) and `ldscripts` for each core and global shared memory using `$XTENSA_TOOLS/libexec/xt-mbuild` which generates the subsystem files in the directory name specified with options `-syspkg` and `-sysbuild` (the name in this PG is `mbuild`)

- The names in both the files `.yaml` and `.xtsys` must match.

```
<hash n="system" name="multicore2c" t="MultiCoreSystem">.
```

- Update the name of the core with name and the reference configuration

```
<hash config="AE_HiFi4_LE5_XC_MOD_XTSC" name="core0"
vecselect="0"/>
```

- The shared memory buffer and buffer size are defined in a separate `xf-shared.c` and `xf-shared.h` files. You must update the size of the shared buffer as required. The size must be within the allocated partition of system-RAM as specified in the `.xtsys` file as follows:

```
<hash      n="sysram"      paddr="0x20000000"      size="0x4fd8000"
writable="1"/>
<array n="partitions">
<hash corename="*" memname="sysram" name="shared_sram"
offset="0x1800000" size="0x37d8000"/>
```

## Memory changes in testbench and subsystem for Custom configuration

With `xaf-playback-usecase-test.c` as an example and a subsystem with 4-DSPs, following is the memory usage logged at the end of execution with `-core-cfg` options `-core-cfg:1,4,5 -core-cfg:2,0,6 -core-cfg:3,7` (that is, component with ID 4,5 is created on DSP-1, component with ID 0,6 is created on DSP-2, and component with ID 7 is created on DSP-3). The example config used is a HiFi4 DSP variant with 4 MB DRAM, 4 MB IRAM, 64 MB SYSRAM and 16 MB SYSROM.

```
Local Memory used by DSP Components, in bytes: 88576 of 89088

Shared Memory used by Components and Framework, in bytes: 47360 of
48128

Local Memory used by Framework, in bytes: 34592

Shared Memory used by Components and Framework, in bytes (type [1]):
16384 of 48128

DSP[1] Local Memory type[2] used by DSP Components, in bytes: 4928
```

---

```

DSP[1] Local Memory type[3] used by DSP Components, in bytes: 79488
DSP[1] Shared Memory type[4] used by DSPs, in bytes: 128640
DSP[1] Local Memory used by Framework, in bytes: 9136

DSP[2] Local Memory type[2] used by DSP Components, in bytes: 80576
DSP[2] Local Memory type[3] used by DSP Components, in bytes: 4224
DSP[2] Shared Memory type[4] used by DSPs, in bytes: 128640
DSP[2] Local Memory used by Framework, in bytes: 9136

DSP[3] Local Memory type[2] used by DSP Components, in bytes: 66048
DSP[3] Local Memory type[3] used by DSP Components, in bytes: 64
DSP[3] Shared Memory type[4] used by DSPs, in bytes: 128640
DSP[3] Local Memory used by Framework, in bytes: 9136

```

If the custom core has limited memory, to optimize the memory usage in this example testcase, make the following changes:

- `include/xaf-config-user.h` file:
  - `XAF_MAX_INBUFS`: can be updated.
  - `XAF_INBUF_SIZE`: can be updated according to components requirement.
  - `XAF_MAX_WORKER_THREADS`: can be updated as per the priorities.
  - `XF_CFG_MAX_COMPS`: can be updated to maximum number simultaneous components used in the processing chain (for playback-usecase the value is 8).
- `test/src/xaf-playback-usecase-test.c` file:
  - `AUDIO_FRMWK_BUF_SIZE` (for playback-usecase, optimum value is 47 KB)
  - `AUDIO_COMP_BUF_SIZE` (for playback-usecase, optimum value is 87 KB)
- `test/src/xaf-utils-test.c` file:
  - `AUDIO_COMP_BUF_SIZE` (for playback-usecase, optimum value is 79 KB)

- 
- `test/include/xaf-mem.h` file:  
`AUDIO_COMP_FAST_BUF_SIZE` (for playback-usecase, optimum value is 79 KB)  
`FRMWK_APP_IF_BUF_SIZE`: (for playback-usecase, optimum value is 45 KB)
  - `test/include/xaf-utils-test.h` file:  
`AUDIO_COMP_FAST_BUF_SIZE` for memory pool `XAF_MEM_ID_COMP+1` (for playback-usecase, optimum value is 5 KB)
  - `xf_shared/include/xf_shared.h` file:  
`AUDIO_FRMWK_BUF_SIZE_MAX` (for playback-usecase, optimum value is 16 KB)  
`AUDIO_DSP_BUF_SIZE_MAX` (for playback-usecase, optimum value is 126 KB)

For subsystem changes, edit the Memory Maps section in the `.xws` package or `.xtsys` file in the `.tgz` package to make sure the memory segment allocation for all DSPs in the subsystem is adequate. Follow the below steps:

For `.xws` package:

1. In Xtensa Explorer, in the **System Overview** window, expand **Subsystems** → **multicore4c**, and double-click **multicore4c**.
2. In the **Components** tab, select **Group0**.
3. In the **Component Details** section, select the **Local MMIO** check box.  
**Note:** After Local MMIO is enabled, remove SubSystemMMIO, if present.
4. Specify the values for global address to 0x80010000, size as 4, interrupt numbers, bit offsets, and edge or level.
5. Click **Apply to all cores**.

For `.tgz` package:

- Edit the `.xtsys` file for size and offset adjustments in the “memories” and “partitions” sections.
- Edit `.yaml` file to set the Local MMIO address to 0x80010000, size as 4, set interrupt numbers, bit offsets, edge or level.

After making the above changes, the playback-usecase-test in the XAF package can execute for custom configurations with limited memory.

---

## 5. Integration of New Audio Components with XAF

---

This section describes how to create an application with a new audio component in addition to the existing example audio components.

### 5.1 Component Modification

The new component must be modified as follows:

1. Change the component interface to conform to the HiFi Audio Codec Application Programming Interface [2]. The interface (API) is a C-callable API that is exposed by all the HiFi based Audio Codecs developed by Cadence. An “audio codec” is a generic term for any audio processing component and is not restricted to encoders and decoders.

2. XAF requires all components to support `get_config` for the following configuration parameters for the PCM data ports.

`XA_CODEC_CONFIG_PARAM_CHANNELS`: Number of channels.

`XA_CODEC_CONFIG_PARAM_SAMPLE_RATE`: Sampling rate.

`XA_CODEC_CONFIG_PARAM_PCM_WIDTH`: PCM width.

3. XAF requires all MIMO class components to support `set_config` for the following configuration parameters to share port pause, resume, connect, and disconnect information with component.

`XA_MIMO_PROC_CONFIG_PARAM_PORT_PAUSE`: specified port is paused

`XA_MIMO_PROC_CONFIG_PARAM_PORT_RESUME`: specified port is resumed

`XA_MIMO_PROC_CONFIG_PARAM_PORT_CONNECT`: specified port is connected

`XA_MIMO_PROC_CONFIG_PARAM_PORT_DISCONNECT`: specified port is disconnected

4. Build the audio component using the Xtensa tools to create a library targeted at the appropriate HiFi core.

### 5.2 Component Integration

The following steps must be followed to integrate the component library into XAF. For each step, the corresponding step for the MP3 decoder library is also provided as an example, marked by **MP3\_DEC\_EG**.

---

## Integration Step 1: Add component files

Three files have to be added to the XAF library to enable support for a new component:

- Header file containing the library API definition.
- Library file implementing the library.
- Wrapper file that “glues” the library to the XAF.

The detailed steps are as follows. These steps are common for .tgz and .xws packages.

1. Create a separate folder under `/test/plugins/` for the new component.  
**MP3\_DEC\_EG:** `test/plugins/cadence/mp3_dec`
2. Copy the component library for the appropriate core(s) to that folder  
**MP3\_DEC\_EG:** `test/plugins/cadence/mp3_dec/lib/xa_mp3_dec.a`
3. Copy the API header file for the audio component to the `test/include/audio` folder. This header file must contain the library entry point declaration and all associated structures and constants.  
**MP3\_DEC\_EG:** `test/include/audio/xa_mp3_dec_api.h`
4. Create a wrapper file for the new component in the `/test/plugins/` folder. The wrapper file connects the library to XAF.  
**MP3\_DEC\_EG:** `test/plugins/cadence/mp3_dec/xa-mp3-decoder.c`

## Integration Step 2: Update the application to include the component

The application must be updated to include references to the new component. The detailed steps are as follows. These steps are common for .tgz and .xws package.

5. In the `test/plugins/xa-factory.c` file, add the audio component entry point API function extern declaration.  
**MP3\_DEC\_EG:** The line below in `xa_factory.c`  

```
extern XA_ERRORCODE xa_mp3_decoder(xa_codec_handle_t, WORD32, WORD32, pVOID);
```
6. In the constant definition of `xf_component_id` (in `xa_factory.c`), add the registration information for the new audio component.  
**MP3\_DEC\_EG:** The line below in `xa_factory.c`  

```
{"audio-decoder/mp3", xa_audio_codec_factory, xa_mp3_decoder},
```

The required fields are:

`class_id` (string identifier): This defines the class name and the component name. The different class names are defined in the `comp_id` array.

**MP3\_DEC\_EG:** "audio-decoder/mp3"



- a. `class_constructor`: Predefined by XAF and can be from:
  - `xa_audio_codec_factory` (for components with a single input port and a single output port and using audio codec as parent class)
  - `xa_renderer_factory` (for components with a single input port and zero or one optional output port and using renderer as parent class)
  - `xa_capturer_factory` (for components with zero input port and single output port and using capturer as parent class)
  - `xa_mimo_proc_factory` (for components with multiple input ports and multiple output ports and using MIMO as parent class)

**MP3\_DEC\_EG:** `xa_audio_codec_factory`

- b. The function name for the audio component entry point, as defined in the component wrapper file created in Integration Step 1.

**MP3\_DEC\_EG:** `xa_mp3_decoder`

7. In the constant definition of `xf_io_ports` (in `xa_factory.c`), add the port information based on `xaf_comp_type` for the new audio component. This step is not needed if `xaf_comp_type` for the new audio component already exists in the `xf_io_ports` definition.

**MP3\_DEC\_EG:** The line below in `xa_factory.c`

```
{1, 1},      /* XAF_DECODER */
```

8. Create a new audio application source file in the `test/src/` folder. The audio application uses the XAF calls to create and run an audio processing chain with the new component.

**MP3\_DEC\_EG:** `test/src/xf-dec-test.c`. In this file, the audio processing chain consists of the MP3 decoder alone. Data is read from a file and provided to the MP3 decoder. The output from the MP3 decoder is written to a file. For more complicated processing chains involving the MP3 decoder, refer to `test/src/xf-dec-mix-test.c` (MP3 decoder and MIMO mixer) and `xf-mp3-dec-render-test.c` (MP3 decoder and renderer).

### Integration Step 3: Compile the application to use the component

The following steps are listed for .tgz package (makefile based usage). For .xws package, refer to section 4.4.1 for additional steps on how to include new application and component in xws project, and how to build and run it.

9. Update the `build/makefile_testbench` file appropriately to include component wrapper file and library into compilation.

**MP3\_DEC\_EG:**

```
XA_MP3_DECODER = 1
ifeq ($(XA_MP3_DECODER), 1)
  PLUGINLIBS_MP3_DEC =
  $(ROOTDIR)/test/plugins/cadence/mp3_dec/lib/xa_mp3_dec.a
  PLUGINOBJS_MP3_DEC += xa-mp3-decoder.o
  INCLUDES += -I$(ROOTDIR)/test/plugins/cadence/mp3_dec
  CFLAGS += -DXA_MP3_DECODER=1
```

---

```
vpath %.c $(ROOTDIR)/test/plugins/cadence/mp3_dec
endif
```

10. Update the `build/makefile_testbench` file appropriately to include the application source file into compilation and create executable binary.

**MP3\_DEC\_EG:**

```
APP2OBS = xaf-dec-test.o.
BIN2 = xa_af_dec_test
```

Refer to BIN2 compilation rules and dependencies in `build/makefile_testbench` file. Create similar rules and resolve the dependencies for new application.

11. Update the `build/makefile_testbench` file to add new application in the create (`all` or `all-dec`) and run (`run` or `run-dec`) targets

**MP3\_DEC\_EG:**

```
all: $(BIN2)
run:
    $(RUN) ./$(BIN2) -infile:$(TEST_INP)/hihat.mp3 -
outfile:$(TEST_OUT)/hihat_dec_out.pcm
```

12. Build and test the application. Refer to the procedure in section 4.3.

---

**Note** If more than required components are enabled in `test/plugins/xa-factory.c` (for example, due to default enabled switches in `build/makefile_testbench`) and respective component wrappers and libraries are not included in compilation, a dummy wrapper function can be defined in testbenches to avoid compilation errors.

**MP3\_DEC\_EG:**

```
/* Dummy unused functions */
XA_ERRORCODE xa_mp3_decoder(xa_codec_handle_t var1, WORD32 var2,
WORD32 var3, pVOID var4) {return 0;}
```

---

## 5.3 Component Integration – Examples

Several example components are provided that can be used as starting points for the development of new components. These are described in Table 5-1. The table does not include the mixer, renderer, and capturer components as they are already part of XAF package. The component folders are under `test/plugins/cadence` and the applications are in the `test/src` folder.

Table 5-1 Example Components

Component Name	API	Description	References
Cadence MP3 decoder <sup>[4]</sup>	Audio <sup>[2]</sup>	Decodes MP3 data	Folder: mp3_dec Application: xaf-dec-test.c, xaf-dec-mix-test.c, xaf-mp3-dec-rend-test.c, xaf-playback-usecase-test.c
Cadence MP3 encoder <sup>[5]</sup>	Audio <sup>[2]</sup>	Encodes MP3 data	Folder: mp3_enc Application: xaf-capturer-mp3-enc-test.c
Cadence AMR-WB decoder <sup>[6]</sup>	Speech <sup>[3]</sup>	Decodes AMR-WB data	Folder: amr_wb Application: xaf-amr-wb-dec-test.c
Cadence Sample rate converter <sup>[8]</sup>	Audio <sup>[2]</sup>	Converts sampling rate	Folder: src-pp Application: xaf-playback-usecase-test.c
Cadence AAC decoder <sup>[9]</sup>	Audio <sup>[2]</sup>	Decodes AAC data	Folder: aac_dec Application: xaf-playback-usecase-test.c
Cadence Opus encoder <sup>[11]</sup>	Speech <sup>[3]</sup>	Encodes Opus data	Folder: opus_enc Application: xaf-full-duplex-opus-test.c
Cadence Opus decoder <sup>[11]</sup>	Speech <sup>[3]</sup>	Decodes Opus data	Folder: opus_dec Application: xaf-full-duplex-opus-test.c

---

## 6. Known Limitations

---

- Only one instance of XAF can run at a time.
- In current version of XAF, only one (first) input port can receive input data from application and only one (first) output port can send output data to application; that is, edge components cannot have multiple input ports or output ports connected to application.
- The current version of XAF has been tested with Version RI-2023.11 of the Xtensa tool chain with XT-CLANG compiler.
- The Instruction Set Simulator (ISS) and Xtensa System C (XTSC) is used in the cycle-accurate simulation mode.
- XTSC supports up to a maximum number of 16 cores (NCORES>1)
- XAF does not support the fast functional “TurboXim” mode of Instruction Set Simulator (ISS).

---

## 7. Appendix: Memory Guidelines

---

### 7.1 Memory Usage and Calculation

XAF manages the memory for all the created components and buffers. The memory type, pointer, and size information is made available by the test application and is passed to the `xaf_adev_open` and `xaf_dsp_open` APIs using `mem_pool[XAF_MEM_ID_MAX]` array parameter of type `xaf_mem_pool_type_t` in the `xaf_adev_config_t` structure.

```
typedef struct xaf_mem_pool_type_s {  
  
    pVOID pmem;                /* ...memory pool pointer. */  
  
    UWORD32 size;              /* ...memory pool size.    */  
  
    XAF_MEM_ID mem_id;         /* ...memory pool id.      */  
  
}xaf_mem_pool_type_t;
```

The memory pool types are enumerated with `XAF_MEM_ID` that is user-extensible.

The default and necessary memory pool types are `XAF_MEM_ID_DEV`, `XA_MEM_ID_COMP`, and `XAF_MEM_ID_DSP`. The application can extend these by systematically adding the required types between the default and the terminating enumerator of each set `XAF_MEM_ID_<[DEV|COMP|DSP]>_MAX`, which should be equal to the last enumeration in the set (For example, `XAF_MEM_ID_DEV_MAX = XAF_MEM_ID_DEV_FAST`).

1. `XAF_MEM_ID_COMP` to `XAF_MEM_ID_COMP_MAX`: This type of memory pool is allocated for usage by audio components. Local buffers required by audio components, such as connect buffers between components, persistent buffers, or scratch buffers are allocated from this memory. Also, if pre-emptive scheduling is enabled, the memory required for the worker threads is allocated from this memory. Buffers required for event communication are also allocated from this memory.  
**Note:** If the error channel is enabled, additional memory of 96 bytes per component is required.
2. `XAF_MEM_ID_DEV` to `XAF_MEM_ID_DEV_MAX`: This type of memory pool is allocated for communication between the application and audio components. Shared buffers required to transfer data and messages between application and audio components are allocated from this memory.  
**Note:** If the error channel is enabled, then `num_err_msg_buf` of size 4 bytes each, aligned to 64 bytes, are created. This requires additional memory of 64 bytes per error message buffer.

**Note:** For NCORES>1 framework, the application allocates the buffer from global shared memory.

In “non zero-copy mode” of `xaf_get_config_ext` and `xaf_set_config_ext` APIs, the required buffers (whose size is determined by the `cfg_param_ext_buf_size_max` variable of `xaf_comp_config_t` structure and an additional 256 bytes) are allocated from this memory.

**Note:** This buffer is only allocated by the master core. Thus, all memory sizes of types `XAF_MEM_ID_DEV` to `XAF_MEM_ID_DEV_MAX` must be zero for the worker core application that calls `xaf_dsp_open`.

3. `XAF_MEM_ID_DSP` to `XAF_MEM_ID_DSP_MAX`: This is the global shared memory required only when the framework is built with NCORES>1. It is used for allocating connect buffers and event buffers between components from two different DSPs.
4. `framework_local_buffer_size`: This is the local memory required by the Application Interface Layer for the internal data structures like device and component objects, state variables -etc. The corresponding memory pointer is `pframework_local_buffer`. This memory is pre-allocated in the `xaf_adev_open` call and can be controlled by `XF_CFG_MAX_COMPS` (in `xaf-config-user.h` default 16). The framework local memory required on the master core for 1-component is ~26 KB for XOS and ~5 KB for FreeRTOS. Each additional component needs ~1.5 KB (1420 bytes) for XOS and ~1.0 KB (892 bytes) for FreeRTOS. For worker-cores, it is a constant memory of size 9 KB for XOS and 0.5 KB for FreeRTOS.

Table 7-1 List of Buffers

Sr No.	Type of Buffer	Type of Memory	
		NCORES = 1	NCORES > 1
1.	Connect buffers	Local Memory ( <code>XAF_MEM_ID_COMP</code> )	Local Memory ( <code>XAF_MEM_ID_COMP</code> ) Global shared Memory ( <code>XAF_MEM_ID_DSP</code> )
2.	Input buffer	Local Memory ( <code>XAF_MEM_ID_COMP</code> )	Local Memory ( <code>XAF_MEM_ID_COMP</code> )
3.	Output buffer	Local Memory ( <code>XAF_MEM_ID_COMP</code> )	Local Memory ( <code>XAF_MEM_ID_COMP</code> )
4.	Persist buffers	Local Memory ( <code>XAF_MEM_ID_COMP</code> )	Local Memory ( <code>XAF_MEM_ID_COMP</code> )
5.	Scratch buffer	Local Memory ( <code>XAF_MEM_ID_COMP</code> )	Local Memory ( <code>XAF_MEM_ID_COMP</code> )

Sr No.	Type of Buffer	Type of Memory	
6.	Stack for worker threads	Local Memory (XAF_MEM_ID_COMP)	Local Memory (XAF_MEM_ID_COMP)
7.	Buffers for xaf_get_config_ext and xaf_set_config_ext	Local Memory (XAF_MEM_ID_DEV)	Global shared Memory (XAF_MEM_ID_DEV)
8.	Event buffers (Events between Application and Component, Framework. For example, Error channel buffers)	Local Memory (XAF_MEM_ID_DEV)	Global shared Memory (XAF_MEM_ID_DEV)
9	Event buffers (Events between Components)	Local Memory (XAF_MEM_ID_COMP)	Local Memory (XAF_MEM_ID_COMP) Global shared Memory (XAF_MEM_ID_DSP)
10.	Message buffers for communication between application and audio components	Local Memory (XAF_MEM_ID_DEV)	Global shared Memory (XAF_MEM_ID_DEV)
11.	Message pool on DSP	Local Memory (XAF_MEM_ID_COMP)	Global shared Memory (XAF_MEM_ID_DSP)

This section provides guidelines to the application developer to compute these parameters.

**Notation:** Consider a chain of N components, where the  $n^{\text{th}}$  component has  $A_n$  input ports and  $B_n$  output ports and requires  $P_n$ ,  $S_n$ ,  $I_n$ , and  $O_n$  KB for persistent, scratch, input, and output buffers, respectively. Assume that the  $n^{\text{th}}$  component is created (xaf\_comp\_create) with  $X_n$  input buffers and  $Y_n$  output buffers.

**Note**  $X_n$  would be zero except for the components that need to receive data from the application, and  $Y_n$  would be zero except for the components that need to send data to the application. Furthermore, assume that the  $n^{\text{th}}$  component is connected (xaf\_comp\_connect) to another component with  $Z_n$  buffers (to be counted only if the  $n^{\text{th}}$  component is connected to another component).

D is the size of the message pool that needs to be allocated on the main DSP. The size of this pool is  $256 \text{ (XF_PROXY_MESSAGE_QUEUE_LENGTH in Table 7-2)} * \text{cache line size bytes}$ . An additional 1KB per core and 2 KB independent of several is required.

$$D = D_1 + D_2,$$

$$D_1 = \begin{cases} 256 * \text{MAX}(\text{cache line size}, 64B) & \text{if } \text{NCORES} > 1 \\ 16 \text{ KB} + 128 B & \text{if } \text{NCORES} = 1 \end{cases}$$

$$D_2 = \begin{cases} 1 \text{ KB} * (\text{Number of cores}) + 2 \text{ KB} & \text{if } \text{NCORES} > 1 \\ 0 & \text{if } \text{NCORES} = 1 \end{cases}$$

For  $\text{NCORES} > 1$ ,  $D_1$  is allocated from `XAF_MEM_ID_DSP` ( $256 * \text{XCHAL\_DCACHE\_LINE\_SIZE}$ ), otherwise from `XAF_MEM_ID_COMP` ( $256 * 64$ ).

XAF allocates two memory buffers within the `xaf_adev_open()` function.

- Memory of type `XAF_MEM_ID_COMP` or component memory:
- All memory required by the components is allocated from this buffer – this includes persistent, scratch, input, and output buffers required by the component. The persistent, scratch, input, and output buffer sizes for a component are typically mentioned in the programmer's guide for that component.

Then, the total memory required by all components in the chain would be given by the formula:

$$T = T_1 + T_2 + T_3, \quad T_1 = \sum_{n=1}^N (P_n + A_n I_n + B_n O_n Z_n + 0.25 * Z_n), \quad T_2 = \max_n S_n$$

$$T_3 = \sum_{n=1}^N \begin{cases} B_n O_n Y_n & \text{for audio-codec-class} \\ 0 & \text{otherwise} \end{cases}$$

$T_1$  is the sum of the persistent, input, output sizes, and overhead memory required for the connect buffer by the components.  $T_2$  is the maximum scratch memory required by the components, as the scratch memory is shared across components. In this version of XAF,  $T_2$  is fixed at 56 KB in `xaf_adev_config_default_init` via the compile time constant `XF_CFG_CODEC_SCRATCHMEM_SIZE`, and  $T_2$  is user-configurable.  $T_3$  is the additional memory required by audio-codec-class components for initialization. Furthermore, some memory is required by XAF itself. For internal use, the allocation for `xf_dsp_t` structure requires 3 KB per DSP and is cache-line aligned. The size of the memory required by XAF is  $(2N + D + 3)$  KB, where  $N$  is the number of components.

---

**Note** This 2 KB per component includes each component's API structure, memory table, and miscellaneous audio-framework data structures for the component.

---

Thus, the size for the memory type `XAF_MEM_ID_COMP` must be set to a value greater than  $(T + 2N + D + 3)$  KB for usage with  $\text{NCORES} = 1$ .

Notes on `XAF_MEM_ID_COMP`:

- Each memory allocation for a component requires an additional 32 bytes to make sure the component gets the pointer of the required alignment. This is absorbed in 2 KB of extra memory per component, as mentioned in the above paragraph. Thus, for every additional 32 memory allocation, 1 KB of extra memory is required (for example,  $2N$  KB in the above formula would become  $3N$  KB).



---

ii. Additional memory is required when pre-emption is enabled:

- (1) XOS:  $88 + 408$  ( $=\text{sizeof}(\text{xf\_thread\_t})$ ) bytes for thread-structure ( $\text{sizeof}(\text{xf\_worker}) = 496$ ), 916 bytes for RTOS message-queue and 8192 bytes for thread-stack for each of the priority ( $n_{\text{rt\_priorities}}$ ) and non-priority ( $bg\_priority$ ) threads.

Example: `xaf_adev_set_priorities` (`p_adev`, 2, 3, 2) requires  $3 \times (88 + 408 + 916) + 3 \times 8192$  bytes, with additional 32 bytes per allocation as mentioned above.

- (2) FreeRTOS:  $64 + 16$  ( $=\text{sizeof}(\text{xf\_thread\_t})$ ) bytes each for thread-structure for all priority ( $n_{\text{rt\_priorities}}$ ) and non-priority ( $bg\_priority$ ) threads.

Example: `xaf_adev_set_priorities` (`p_adev`, 2, 3, 2) requires  $3 \times 80$  bytes.

- (3)  $T_2$  bytes of scratch memory (of size `XF_CFG_CODEC_SCRATCHMEM_SIZE`) per priority thread.

---

**Note** `xf_thread_t` is defined in `include/sysdeps/<RTOS>/include/osal-thread.h`, which can vary between core configurations for XOS. For FreeRTOS, it is of a constant size of 16 bytes across core configurations.

---

Memory of type `XAF_MEM_ID_DEV` or device memory:

All buffers exchanged between components and the application are allocated from this buffer. The number of buffers exchanged is defined in the `xaf_comp_create` call.

---

**Note** All buffer allocations have a cache line size overhead, the minimum alignment value is 1 (for `NCORES=1`), and the maximum supported alignment value is 4096.

---

Then, the total memory required by all components in the chain would be given by the formula:

$$S = \sum_{n=1}^N (4A_n X_n + O_n B_n Y_n),$$

In this version of XAF, the size of input buffer from the application to the audio component is fixed at 4 KB, via the `XAF_INBUF_SIZE` compile time constant. Furthermore, some memory is also required by XAF itself. The size of the memory required by XAF is 24 KB, independent of the number of components. Thus, `XAF_MEM_ID_DEV` must be set to a value greater than  $(S + 24)$  KB. The 24 KB is calculated as follows:

8 KB =  $32$  (value of `XAF_AUX_POOL_SIZE` in `algo/host-apf/include/xaf-structs.h`)  $\times 256$  (value of `XAF_AUX_POOL_MSG_LENGTH` in `algo/host-apf/include/xaf-structs.h`)

16 KB =  $256$  (value of `XF_PROXY_MESSAGE_QUEUE_LENGTH` in `algo/hifi-dpf/include/xf-dp_proxy.h`)  $\times \text{sizeof}(\text{xf\_proxy\_message\_t})$  (defined in `algo/hifi-dpf/include/xf-dp_proxy.h`) command queue + response queue.

The memory pointer passed to the XAF library must be aligned to 4 KB; otherwise, the library itself will try to align the pointer before use, but an additional size of 4 KB per memory pool needs to be provided (using `mem_pool[XAF_MEM_ID_DEV].pmem`, `mem_pool[XAF_MEM_ID_DEV].size` parameters of `xaf_adev_config_t` structure).

Memory of type `XAF_MEM_ID_DSP` or DSP-DSP shared memory (NCORES>1):

If the source and destination components of the connect buffer are on different cores, then the connect buffer is allocated from this buffer pool. An additional 0.25 KB overhead is required per connect buffer, which is the memory required for maintaining pool and message structure. It can vary depending on cache line size.

$$U = U_1, \quad U_1 = \sum_{n=1}^N (B_n O_n Z_n + 0.25 * Z_n),$$

A message pool of size D is also allocated from this buffer.

Thus, the size of the memory type `XAF_MEM_ID_DSP` must be set to a value greater than (U + D) KB.

---

**Note** The Scratch memory alignment is fixed at 16 bytes to support efficient load-store instructions for higher register widths.

---

The following examples illustrate the memory size computations described above for two example testbenches.


---

**Note** The memory numbers provided in these examples are for the 5-stage HiFi4 DSP core.

---

- **Example 1:** "PCM\_Gain" (`xa_af_hostless_test`) with NCORES= 1

Number of components, N =1 (PCM Gain)



n = 1 (PCM-gain):

$A_1 = 1$ ,  $B_1 = 1$ ,  $X_1 = 2$ ,  $Y_1 = 1$ ,  $Z_1 = 0$ ,  $S_1$  (Scratch Memory) = 4 KB,  $P_1$  (Persistent Memory) = 0,  $I_1$  (Input buffer) = 4 KB,  $O_1$  (Output buffer) = 4 KB

- Computation of size for the type `XAF_MEM_ID_COMP`:

$$T_1 = 0(P_1) + 1(A_1) * 4(I_1) + 1(B_1) * 4(O_1) * 0(Z_1) = 4 \text{ KB}$$

$$T_2 = 56 \text{ KB}$$

$$T_3 = 1(B_1) * 4(O_1) = 4 \text{ KB}$$

$$D = 16(D_1) + 0(D_2) = 16 \text{ KB}$$

$$T = 4(T_1) + 56(T_2) + 2 * 1(N) + 16(D) + 3 + 4(T_3) = 85 \text{ KB is the required size .}$$


- Computation of size for the type `XAF_MEM_ID_DEV`:

$$S = 4 * 1(A_1) * 2(X_1) + 4(O_1) * 1(B_1) * 1(Y_1) = 12 \text{ KB}$$

$$S + 24 = 12 + 24 = 36 \text{ KB is the required size.}$$

- Example 2:** “2 MP3 Decoder + Mixer” (`xaf-dec-mix-test`) with `NCORES = 1`

Number of components,  $N = 3$  (MP3 Decoder1, MP3 Decoder2, Mixer)



$n = 1$  (MP3 Decoder1):

$A_1 = 1, B_1 = 1, X_1 = 2, Y_1 = 0, Z_1 = 4, S_1$  (Scratch Memory) = 7 KB,  $P_1$  (Persistent Memory) = 12.125 KB,  $I_1$  (Input buffer) = 2 KB,  $O_1$  (Output buffer) = 4.5 KB

$n = 2$  (MP3 Decoder2):

$A_2 = 1, B_2 = 1, X_2 = 2, Y_2 = 0, Z_2 = 4, S_2$  (Scratch Memory) = 7 KB,  $P_2$  (Persistent Memory) = 12.125 KB,  $I_2$  (Input buffer) = 2 KB,  $O_2$  (Output buffer) = 4.5 KB

$n = 3$  (Mixer):

$A_3 = 4, B_1 = 1, X_3 = 0, Y_3 = 1, Z_3 = 0, S_3$  (Scratch Memory) = 2 KB,  $P_3$  (Persistent Memory) = 0,  $I_3$  (Input buffer) = 2 KB,  $O_3$  (Output buffer) = 2 KB.

- Computation of size for the type `XAF_MEM_ID_COMP`:

$$\text{sum1} = 12.125 (P_1) + 1 (A_1) * 2 (I_1) + 1 (B_1) * 4.5 (O_1) * 4 (Z_1) + 0.25 * 4(Z_1) = 33.125 \text{ KB}$$

---


$$\text{sum2} = 12.125 (P_2) + 1 (A_2) * 2 (I_2) + 1 (B_2) * 4.5 (O_2) * 4 (Z_2) + 0.25 * 4(Z_2) = 33.125 \text{ KB}$$

$$\text{sum3} = 0 (P_3) + 4 (A_3) * 2 (I_3) + 1 (B_3) * 2 (O_3) * 0 (Z_3) = 8 \text{ KB}$$

$$T_1 = 33.125 + 33.125 + 8 = 74.25 \text{ KB}$$

$$T_3 = 1 (B_1) * 4.5 (O_1) = 4.5 \text{ KB}$$

$$D = 16 (D_1) + 0 (D_2) = 16 \text{ KB}$$

$$T = 74.25 (T_1) + 56 (T_2) + 2*3(N) + 3 + 4.5 (T_3) + 16 (D) = 159.75 \text{ KB is the required size.}$$

- With multiple component memory pools, namely, `XF_MEM_ID_COMP_FAST` to `XF_MEM_ID_COMP_MAX`, a part of the memory that gets allocated in the default pool `XF_MEM_ID_COMP` is allocated in another pool according to your configuration. The total memory used by components remains the same as calculated for a single memory pool.
- Example: If the input memory type of the Mixer component is set as:

```
comp_config.mem_pool_type[XAF_MEM_POOL_TYPE_COMP_INPUT] =
XAF_MEM_ID_COMP_FAST;
```

The calculations become:

$$\text{sum3} = 0 (P_3) + 4 (A_3) * 2 (I_3) * 0 (\text{MEM\_ID\_COMP}) + 1 (B_3) * 2 (O_3) * 0 (Z_3) = 0 \text{ KB}$$

$$\text{sum3}_{\text{ID\_COMP\_FAST}} = 0 (P_3) + 4 (A_3) * 2 (I_3) * 1 (\text{MEM\_ID\_COMP\_FAST}) + 1 (B_3) * 2 (O_3) * 0 (Z_3) = 8 \text{ KB}$$

$$T = 66.25 (T_1) + 56 (T_2) + 2*3(N) + 4.5 (T_3) + 16 (D) = 148.75 \text{ KB is the required size.}$$

$T_{\text{ID\_COMP\_FAST}} = 8 (T_1) + 0 (T_2) + 2*1(N) + 0 (T_3) + 0 = 10 \text{ KB}$  is the required size for type `XAF_MEM_ID_COMP_FAST` (If additional memory of 32 bytes per allocation is absorbed in 2 KB per component, then assuming 1 component and an overhead of 2 KB for that component).

- Computation of size for type `XAF_MEM_ID_DEV`:

$$\text{sum1} = 4 * 1 (A_1) * 2 (X_1) + 4.5 (O_1) * 1 (B_1) * 0 (Y_1) = 8 \text{ KB}$$

$$\text{sum2} = 4 * 1 (A_2) * 2 (X_2) + 4.5 (O_2) * 1 (B_2) * 0 (Y_2) = 8 \text{ KB}$$

$$\text{sum3} = 4 * 4 (A_3) * 0 (X_3) + 2 (O_3) * 1 (B_3) * 1 (Y_3) = 2 \text{ KB}$$

$$S = 8 + 8 + 2 = 18 \text{ KB}$$

- $S + 24 \text{ KB} = 18 \text{ KB} + 24 \text{ KB} = 42 \text{ KB}$  is the required size.

- **Note:** If the pointer `mem_pool[XAF_MEM_ID_DEV].pmem` is not aligned, the size needs to be the next multiple of 4 KB. (In this example,  $42 + 4 = 46$  KB if the `pmem` pointer is unaligned to 4 KB).
- With multiple framework memory pools, namely, `XF_MEM_ID_DEV_FAST` to `XF_MEM_ID_DEV_MAX`, a part of the memory that gets allocated in the default pool `XF_MEM_ID_DEV` is allocated in another pool according to user-configuration. The total memory used by the framework remains the same as calculated for a single memory pool.

- Example: If the output memory type of the Mixer component is set as:

```
comp_config.mem_pool_type[XAF_MEM_POOL_TYPE_COMP_APP_OUTPUT] =
XAF_MEM_ID_DEV_FAST;
```

The above calculations become:

$$\text{sum3} = 4 * 4 (A_3) * 0 (X_3) + 2 (O_3) * 1 (B_3) * 1 (Y_3) * 0 (\text{MEM\_ID\_DEV}) = 0 \text{ KB}$$


$$\text{sum3}_{\text{ID\_DEV\_FAST}} = 4 * 4 (A_3) * 0 (X_3) + 2 (O_3) * 1 (B_3) * 1 (Y_3) * 1 (\text{MEM\_ID\_DEV\_FAST}) = 2 \text{ KB}$$

$$S = 8 + 8 + 0 + 24 = 40 \text{ KB is the required size.}$$

$$S_{\text{ID\_DEV\_FAST}} = 0 + 0 + 2 + 0 = 2 \text{ KB is the required size.}$$

- **Example 3:** "PCM\_Gain" (`xa_af_hostless_test`) with `NCORES = 2`

In this example, PCM Gain is on core-1 ( $N_{c0} = 0$   $N_{c1} = 1$ , where  $N_{c0}$  is the number of components on core-0)



$n = 1$  (PCM-gain):

$A_1 = 1$ ,  $B_1 = 1$ ,  $X_1 = 2$ ,  $Y_1 = 1$ ,  $Z_1 = 0$ ,  $S_1$  (Scratch Memory) = 4 KB,  $P_1$  (Persistent Memory) = 0,  $I_1$  (Input buffer) = 4 KB,  $O_1$  (Output buffer) = 4 KB

- Computation of size for the type `XAF_MEM_ID_COMP`:

Core-0 (Master core):

$$N_{c0} = 0 \text{ (Number of components)}$$

---

$T = 0 (T_1) + 0 (T_2) + 2 * 0 (N_{c1}) + 3 + 0 (T_3) + 0 (D) = 3 \text{ KB}$  is the required size  
( $D = 0$  for  $NCORES > 1$ , for `XAF_MEM_ID_COMP`).

Core-1(Worker core):

$N_{c1} = 1$  (Number of components)

$T_1 = 0(P_1) + 1(A_1) * 4(I_1) + 1(B_1) * 4(O_1) * 0 (Z_1) = 4 \text{ KB}$

$T_2 = 56 \text{ KB}$

$T_3 = 1(B_1) * 4(O_1) = 4 \text{ KB}$

$T = 4 (T_1) + 56(T_2) + 2 * 1(N_{c1}) + 3 + 4 (T_3) + 0 (D) = 69 \text{ KB}$  is the required size  
( $D = 0$  for  $NCORES > 1$ , for `XAF_MEM_ID_COMP`).

- Computation of size for the type `XAF_MEM_ID_DEV`:

Core-0 (Master core):

$S = 4 * 1(A_1) * 2(X_1) + 4(O_1) * 1(B_1) * 1(Y_1) = 12 \text{ KB}$

$S + 24 = 12 + 24 = 36 \text{ KB}$  is the required size.

Core-1 (Worker core):

0 KB is the required size.

- Computation of size for the type `XAF_MEM_ID_DSP`:


$D = 256$  (Number of messages) \* 0.125 KB (Size of 128 bytes cache aligned message) + 1 KB \* 2 (Number of cores) + 2 KB = 36 KB

$U = 0$  (no connect buffers for the only component)

$D + U = 36 + 0 = 36 \text{ KB}$  is the required size.

- **Example 4:** “2 MP3 Decoder + Mixer” (`xaf-dec-mix-test`) with  $NCORES = 2$

Number of components,  $N = 3$  (MP3 Decoder1, MP3 Decoder2, Mixer). In this example, MP3 Decoder1 and MP3 Decoder2 are on Core-0 while Mixer is on Core-1 ( $N_{c0} = 2$ ,  $N_{c1} = 1$ ).



n = 1 (MP3 Decoder1):

$A_1 = 1$ ,  $B_1 = 1$ ,  $X_1 = 2$ ,  $Y_1 = 0$ ,  $Z_1 = 4$ ,  $S_1$  (Scratch Memory) = 7 KB,  $P_1$  (Persistent Memory) = 12.125 KB,  $I_1$  (Input buffer) = 2 KB,  $O_1^{\#}$  (Output buffer) = 4.5 KB

n = 2 (MP3 Decoder2):

$A_2 = 1$ ,  $B_2 = 1$ ,  $X_2 = 2$ ,  $Y_2 = 0$ ,  $Z_2 = 4$ ,  $S_2$  (Scratch Memory) = 7 KB,  $P_2$  (Persistent Memory) = 12.125 KB,  $I_2$  (Input buffer) = 2 KB,  $O_2^{\#}$  (Output buffer) = 4.5 KB

n = 3 (Mixer):

$A_3 = 4$ ,  $B_1 = 1$ ,  $X_3 = 0$ ,  $Y_3 = 1$ ,  $Z_3 = 0$ ,  $S_3$  (Scratch Memory) = 2 KB,  $P_3$  (Persistent Memory) = 0,  $I_3$  (Input buffer) = 2 KB,  $O_3$  (Output buffer) = 2 KB.

**Note:** If both source and destination components are on different cores, connect buffers are allocated from memory pool type `XAF_MEM_ID_DSP`; else, they are allocated from the memory pool type `XAF_MEM_ID_COMP`

- Computation of size for the type `XAF_MEM_ID_COMP`:

Computation for core-0 (Master DSP):

$$\text{sum1} = 12.125 (P_1) + 1 (A_1) * 2 (I_1) + 1 (B_1) * 4.5 (O_1) * 0 (Z_1) = 14.125 \text{ KB}$$

$$\text{sum2} = 12.125 (P_2) + 1 (A_2) * 2 (I_2) + 1 (B_2) * 4.5 (O_2) * 0 (Z_2) = 14.125 \text{ KB}$$

$$T_1 = 14.125 + 14.125 = 28.25 \text{ KB}$$

$$T_2 = 56 \text{ KB}$$

$$T_3 = 1 (B_1) * 4.5 (O_1) = 4.5 \text{ KB}$$

$$T = 28.25 (T_1) + 56 (T_2) + 2 * 2 (N_{c0}) + 3 + 4.5 (T_3) + 0 (D) = 95.5 \text{ KB is the required size (D = 0 for NCORES > 1, for XAF_MEM_ID_COMP).}$$

Computation for core-1 (Worker DSP):

---


$$\text{Sum1} = 0 (P_3) + 4 (A_3) * 2 (I_3) + 1 (B_3) * 2 (O_3) * 0 (Z_3) = 8 \text{ KB}$$

$$T_1 = 8 \text{ KB}$$

$T = 8 (T_1) + 56 (T_2) + 2 * 1 (N_{c1}) + 3 + 0 (T_3) + 0 (D) = 69 \text{ KB}$  is the required size  
( $D = 0$  for  $\text{NCORES} > 1$ , for `XAF_MEM_ID_COMP`).

- Computation of size for the type `XAF_MEM_ID_DEV`:

Core-0(Master DSP):

$$\text{sum1} = 4 * 1 (A_1) * 2 (X_1) + 4.5 (O_1) * 1 (B_1) * 0 (Y_1) = 8 \text{ KB}$$

$$\text{sum2} = 4 * 1 (A_2) * 2 (X_2) + 4.5 (O_2) * 1 (B_2) * 0 (Y_2) = 8 \text{ KB}$$

$$\text{sum3} = 4 * 4 (A_3) * 0 (X_3) + 2 (O_3) * 1 (B_3) * 1 (Y_3) = 2 \text{ KB}$$

$$S = 8 + 8 + 2 = 18 \text{ KB}$$

$$S + 24 = 18 + 24 = 42 \text{ KB is the required size.}$$

**Note:** If the pointer `mem_pool[XAF_MEM_ID_DEV].pmem` is not aligned, the size needs to be the next multiple of 4 KB. (In this example,  $42 + 4 = 46 \text{ KB}$  if the `pmem` pointer is unaligned to 4 KB).

- Core-1 (Worker DSP):

0 KB is the required size.

- Computation of size for the type `XAF_MEM_ID_DSP`:

$$D = 256(\text{Number of messages}) * 0.125 (\text{Size of 128 bytes cache aligned message}) + 1 * 2 (\text{Number of cores}) + 2 = 36 \text{ KB}$$

$$U = 1 (B_1) * 4.5 (O_1) * 4 (Z_1) + 1 (B_1) * 4.5 (O_1) * 4 (Z_2) + 0.25 * 4 (Z_1) + 0.25 * 4 (Z_2) = 38 \text{ KB}$$

$$D + U = 36 + 38 = 74 \text{ KB is the required size.}$$



## 7.2 Memory-related Constants

Table 7-2 Memory-related Constants

Constant Name	Value	Description	File Name
XAF_AUX_POOL_SIZE	32	<p>Number of auxiliary buffers used for each component's command response with the DSP interface layer. Each component requires at least two auxiliary buffers. Hence, a value of 32 can support creating 30 components simultaneously (Case 1 below) and needs to be updated to support more as required.</p> <p><b>Notes:</b> For efficient use of buffers, <code>xaf_comp_process(XAF_START_F LAG)</code> and <code>xaf_comp_get_status()</code> APIs must be called as a set during init.</p> <p>Case 1: Processing chain with N components running on a single RTOS app-thread, number of aux buffers = <math>N + 2</math>.</p> <p>Case 2: Processing chain with N components, running on T RTOS app-threads, each app thread trying a synchronous API call, number of aux buffers = <math>N + 2 * T</math> (for Case 1, <math>T=1</math>)</p>	algo/host-apf/include/xaf-structs.h
XAF_AUX_POOL_MSG_LENGTH	256	Size of each auxiliary buffer, totaling XAF_AUX_POOL_SIZE	algo/host-apf/include/xaf-structs.h
XAF_EXT_CFG_POOL_SIZE	1	Number of extended config buffers used for component's command and response with the DSP interface layer for <code>xaf_comp_set_config_ext</code> and <code>xaf_comp_get_config_ext</code> APIs.	algo/host-apf/include/xaf-structs.h
XAF_MAX_EXT_CFG_BUFFER_LEN	8192	Size of each extended config buffer for <code>xaf_comp_set_config_ext</code> and <code>xaf_comp_get_config_ext</code> APIs, totaling to XAF_EXT_CFG_POOL_SIZE	algo/host-apf/include/xaf-structs.h
XAF_EXT_CFG_OVERHEAD	32	Overhead, in bytes, for extended config per param containing pointers, offsets for variable-sized parameters. The worst-case length is required for the non-zero copy option.	algo/host-apf/include/xaf-structs.h

XF_CFG_MAX_CLIENTS	64	Maximum number of components supported in the DSP interface layer. [This is not tested for other values]	algo/hifi-dpf/include/xf-dp.h
XF_CFG_CODEC_SCRATCHMEM_ALIGN	16	Scratch memory alignment in bytes. As the scratch buffer is shared across components, the maximum of all alignments is considered. For audio codec libraries, a 16-byte alignment is sufficient, and this value is fixed.	algo/hifi-dpf/include/sys/xos-msgq/xf-dp_config.h
XF_PROXY_MESSAGE_QUEUE_LENGTH	256	Command and response message queue length for RTOS-based IPC between App interface layer and DSP interface layer	algo/hifi-dpf/include/xf-dp_proxy.h
XF_MIN_ALIGNMENT	1	Minimum alignment requested for memory allocation in the DSP interface layer	algo/hifi-dpf/include/sys/xos-msgq/xf-mem.h
XF_MAX_ALIGNMENT	4096	Maximum alignment requested for memory allocation in the DSP interface layer	algo/hifi-dpf/include/sys/xos-msgq/xf-mem.h
XF_CFG_MESSAGE_POOL_SIZE	256	Number of messages in common message pool for command and response at the DSP interface layer	algo/hifi-dpf/include/sys/xos-msgq/xf-dp_config.h
XF_CFG_REMOTE_IPC_POOL_SIZE	0x40000	Maximum length, in bytes, of the RTOS IPC buffer (or framework buffer of type XAF_MEM_ID_DEV pool)	algo/hifi-dpf/include/sys/xos-msgq/xf-shmem.h
XF_SHMEM_DATA_ALIGNMENT	4096	Alignment required for the framework memory (type XAF_MEM_ID_DEV)	algo/hifi-dpf/include/sys/xos-msgq/xf-shmem.h
XA_AUDIO_FRMWK_BUFFER_SIZE_MIN	16384	Minimum length, in bytes, of the framework buffer (type XAF_MEM_ID_DEV)	algo/host-apf/src/xf-api.c
XA_AUDIO_FRMWK_BUFFER_SIZE_FAST_MIN	128	Minimum length, in bytes, of the framework buffer (type XAF_MEM_ID_DEV+1 to XAF_MEM_ID_DEV_MAX)	algo/host-apf/src/xf-api.c
XA_AUDIO_COMP_BUFFER_SIZE_MIN	0x12400	Minimum length, in bytes, of component buffer (type XAF_MEM_ID_COMP)	algo/host-apf/src/xf-api.c

		(3072 bytes for NCORES > 1, to allow for the component to be created only on worker-DSPs)	
XA_AUDIO_COMP_BUF_SIZE_FAST_MIN	64	Minimum length, in bytes, of the component buffer (type XAF_MEM_ID_COMP+1 to XAF_MEM_ID_COMP_MAX)	algo/host-apf/src/xaf-api.c
IRQ_THREAD_STACK_SIZE	1024	IRQ offload processing thread stack size	algo/hifi-dpf/src/xf-core.c
XF_EVENT_CHANNEL_INFO_ALIGNMENT	32	Alignment, in bytes, for event channel info structure.	algo/hifi-dpf/src/xaf-class-base.c
XF_CFG_MAX_COMPS	16	Default value of number of the active components at any point during execution (provided the same in include/xaf-config-user.h; this will be effective for optimal usage of framework-local memory)	algo/host-apf/src/xaf-api.c
XF_EVENT_BUFFER_ALIGNMENT	8	Alignment, in bytes, required for event channel to application.	algo/host-apf/src/xaf-api.c
XF_COMP_ERROR_CHANNEL_BUF_SIZE	4	Buffer size, in bytes, of error events to the application.	algo/host-apf/src/xaf-api.c
XF_MAX_EVENT_BUFS_PER_COMP	16	Maximum number of event buffers per component.	algo/host-apf/src/xaf-api.c
XF_MAX_ERROR_EVENT_BUFS_PER_COMP	4	Maximum number of error buffers (as events) per component.	algo/host-apf/src/xaf-api.c
XAF_COMMON_RTOS_IPC_MSGQ_NUM	5	Maximum number of RTOS IPC message queues active at any time, considered to calculate internal memory XA_FRMWK_LOCAL_BUF_SIZE_MIN	algo/host-apf/src/xaf-api.c
XAF_MAX_OUTBUFS	1	Number of output buffers per component, considered to calculate internal memory XA_FRMWK_LOCAL_BUF_SIZE_MIN	algo/host-apf/src/xaf-api.c
XAF_MAX_PROBE_BUFS	1	Number of probe buffers per component, considered to calculate internal memory XA_FRMWK_LOCAL_BUF_SIZE_MIN	algo/host-apf/src/xaf-api.c
MAX_EVENTS_PER_COMPONENT	4	Number of events per component, considered to calculate internal memory XA_FRMWK_LOCAL_BUF_SIZE_MIN	algo/host-apf/src/xaf-api.c

---

MAX_EVENT_CHANNELS_TO_APP	4* XF_CFG_MAX_COMPS	Number of event channels per component, considered to calculate internal memory XA_FRMWK_LOCAL_BUF_SIZE_MIN	algo/host-apf/src/xaf-api.c
XA_FRMWK_LOCAL_BUF_SIZE_MIN	5120 (Free RTOS) 26624 (XOS)	Minimum bytes for App interface layer internal structures (not from any of the types XAF_MEM_ID_DEV, ID_COMP or ID_DSP)	algo/host-apf/src/xaf-api.c
XAF_MEM_ID_DEV_MAX_POOLS	8	Maximum number of memory pools of type XAF_MEM_ID_DEV to XAF_MEM_ID_DEV_MAX	algo/host-apf/src/xaf-api.c
XAF_MEM_ID_COMP_MAX_POOLS	8	Maximum number of memory pools of type XAF_MEM_ID_COMP to XAF_MEM_ID_COMP_MAX	algo/host-apf/src/xaf-api.c

---

## 8. Appendix: OSAL APIs

---

Operating System Abstraction Layer (OSAL) is defined for all RTOS functionality requirements in XAF. Table 8-1 lists all OSAL APIs that are defined and used in XAF. Cadence XOS and FreeRTOS are supported with XAF. Porting XAF to a new RTOS would require implementation of these OSAL APIs with that new RTOS.

---

**Note** The Timer APIs listed in Table 8-1 are only used by capturer and renderer components to mimic real time interrupts and by testbenches for MCPS measurement. The timer APIs are not required by XAF internal implementation.

---

### OSAL APIs List

Table 8-1 OSAL APIs

API Class	OSAL API Defined in XAF
Message Queue APIs	<code>xf_msgq_t __xf_msgq_create (size_t n_items, size_t item_size);</code> <code>void __xf_msgq_destroy (xf_msgq_t q);</code> <code>int __xf_msgq_send (xf_msgq_t q, const void *data, size_t sz);</code> <code>int __xf_msgq_rcv (xf_msgq_t q, void *data, size_t sz);</code> <code>int __xf_msgq_rcv_blocking(xf_msgq_t q, void *data, size_t sz);</code> <code>int __xf_msgq_empty (xf_msgq_t q);</code> <code>int __xf_msgq_full (xf_msgq_t q);</code>
Thread APIs	<code>int __xf_thread_init (xf_thread_t *thread);</code> <code>int __xf_thread_create (xf_thread_t *thread, xf_entry_t *f, void *arg, const char *name, void *stack, unsigned int stack_size, int priority);</code> <code>void __xf_thread_yield (void);</code> <code>int __xf_thread_cancel (xf_thread_t *thread);</code> <code>int __xf_thread_join (xf_thread_t *thread, int32_t *p_exitcode);</code> <code>int __xf_thread_destroy (xf_thread_t *thread);</code> <code>const char * __xf_thread_name (xf_thread_t *thread);</code> <code>int __xf_thread_sleep_msec (uint64_t msecs);</code> <code>int __xf_thread_get_state (xf_thread_t *thread);</code>
Mutex APIs	<code>void __xf_lock_init (xf_lock_t *lock);</code> <code>void __xf_lock_destroy (xf_lock_t *lock);</code> <code>void __xf_lock (xf_lock_t *lock);</code> <code>void __xf_unlock (xf_lock_t *lock);</code>
Event APIs	<code>void __xf_event_init (xf_event_t *event, uint32_t mask);</code> <code>void __xf_event_destroy (xf_event_t *event);</code>

API Class	OSAL API Defined in XAF
	unsigned int <b>__xf_event_get</b> (xf_event_t *event); void <b>__xf_event_set</b> (xf_event_t *event, uint32_t mask); void <b>__xf_event_set_isr</b> (xf_event_t *event, uint32_t mask); void <b>__xf_event_clear</b> (xf_event_t *event, uint32_t mask); void <b>__xf_event_wait_any</b> (xf_event_t *event, uint32_t mask); void <b>__xf_event_wait_all</b> (xf_event_t *event, uint32_t mask);
Interrupt APIs	int <b>__xf_set_threaded_irq_handler</b> (int irq, xf_isr *irq_handler, xf_isr *threaded_handler, void *arg); int <b>__xf_unset_threaded_irq_handler</b> (int irq); unsigned long <b>__xf_disable_interrupts</b> (void); void <b>__xf_restore_interrupts</b> (unsigned long prev); void <b>__xf_enable_interrupt</b> (int irq); void <b>__xf_disable_interrupt</b> (int irq);
Timer APIs	int <b>__xf_timer_init</b> (xf_timer_t *timer, xf_timer_fn_t *fn, void *arg, int autoreload); unsigned long <b>__xf_timer_ratio_to_period</b> (unsigned long numerator, unsigned long denominator); int <b>__xf_timer_start</b> (xf_timer_t *timer, unsigned long period); int <b>__xf_timer_stop</b> (xf_timer_t *timer); int <b>__xf_timer_destroy</b> (xf_timer_t *timer);

OSAL APIs are declared in the following header files for XOS:

```

/include/sysdeps/xos/include/osal-msgq.h
/include/sysdeps/xos/include/osal-thread.h
/include/sysdeps/xos/include/osal-timer.h
/include/sysdeps/xos/include/osal-isr.h

```

OSAL APIs are declared in the following header files for FreeRTOS:

```

/include/sysdeps/freertos/include/osal-msgq.h
/include/sysdeps/freertos/include/osal-thread.h
/include/sysdeps/freertos/include/osal-timer.h
/include/sysdeps/freertos/include/osal-isr.h

```

---

**Note**      While building your test bench example for a particular HiFi DSP configuration, make sure to link the FreeRTOS library that is built for the same HiFi DSP configuration.

---

---

## Multicore IPC Abstraction API List

Table 8-2 Multicore IPC APIs

API Class	Multicore-IPC abstraction API Defined in XAF
Mutex APIs	<code>uint32_t __xf_ipc_lock(xf_ipc_lock_t *lock)</code> <code>uint32_t __xf_ipc_unlock(xf_ipc_lock_t *lock)</code>
Interrupt APIs	<code>void __xf_ipc_interrupt_notify(uint32_t core)</code> <code>void __xf_ipc_interrupt_clear(uint32_t core)</code>
Reset Sync API	<code>int __xf_ipc_reset_sync(void);</code>

Multicore-IPC APIs are declared in the following header files:

```
/include/sysdeps/mc_ipc/xf-mc-ipc.h
```

### Selection of the System Timer in Timer APIs

The system timer selected to generate interrupts for capturer and renderer is, by default, such that the timer has the highest interrupt-priority not exceeding EXCMLEVEL priority.

For XOS, passing argument -1 would select such a timer at the time of execution (`xos_start_system_timer(-1, TICK_CYCLES)`) or by directly specifying a timer number with appropriate priority (`xos_start_system_timer(0, TICK_CYCLES)`).

For FreeRTOS, preprocessor logic selects such a timer during compilations of FreeRTOS library.

### Interrupt Handler Implementation with XAF

The interrupt handler for capturer and renderer components must be implemented using the `__xf_set_threaded_irq_handler` API. This threaded interrupt handler splits interrupt processing into two parts. The first part (`irq_handler`) runs in interrupt context and must do minimal, critical work (acknowledge, clear the interrupt etc.). The second part (`threaded_handler`) runs in a high priority background thread, can be context switched, and does the rest of the interrupt processing.

---

**Note** The high priority background thread mentioned above is created by XAF during DSP Interface Layer initialization at highest priority available with RTOS only for interrupt processing.

---

The XAF schedules capturer and renderer processing through callback function upon receiving respective interrupt. This must be implemented in `threaded_handler` as it requires to acquire RTOS lock to access XAF scheduler.

---

**Note** The capturer and renderer in XAF package mimic real time interrupts using the timer interrupts and therefore do not use `__xf_set_threaded_irq_handler` API.

---

---

## 9. References

---

- [1] *Xtensa XOS Reference Manual* – For Version RI-2023.11 of the Xtensa tool chain, this is provided as part of the Xtensa tool chain, <TOOLS\_INSTALL\_PATH>/XtDevTools/downloads/RI-2023.11/docs/xos\_rm.pdf.
- [2] *HiFi Audio Codec Application Programming Interface (API) Definition*, Ver 1.0. This document is provided as part of this package.
- [3] *HiFi Speech Codec Application Programming Interface (API) Definition*, Ver 1.0. This document is provided as part of this package.
- [4] *Cadence MP3 Decoder* – Library version 3.18 for Tensilica HiFi DSPs.
- [5] *Cadence MP3 Encoder* – Library version 1.6 for Tensilica HiFi DSPs. The library must be rebuilt from sources for HiFi 4.
- [6] *Cadence AMR-WB Decoder* – Library version 2.7 for Tensilica HiFi DSPs.
- [7] *Cadence AMR-WB Decoder* – Library version 2.3 for Tensilica HiFi DSPs.
- [8] *Cadence Sample Rate Converter* – Library version 1.9 for Tensilica HiFi DSPs.
- [9] *Cadence AAC Decoder* – Library version 3.7 for Tensilica HiFi DSPs.
- [10] *Cadence Ogg-Vorbis Decoder* – Library version 1.12 for Tensilica HiFi DSPs.
- [11] *Cadence Opus Codec* – Library version 1.8 for Tensilica HiFi DSPs.
- [12] *Xtensa port of FreeRTOS* – <https://github.com/foss-xtensa/amazon-freertos/tree/xtensa-v10.4.4-stable>
- [13] *TensorFlow* – <https://github.com/tensorflow/tensorflow>