

# **Vantage Pro™, Vantage Pro2™ and Vantage Vue™ Serial Communication Reference Manual**

**For Vantage Pro™, Vantage Pro2™, Vantage Pro Plus™ Vantage Pro2 Plus™ and  
Vantage Vue™ Weather Stations**



**Vantage Pro, Vantage Pro2, and Vantage Vue Serial Communication Reference Manual  
Rev 2.6.1 (03/29/2013)**

**Davis Instruments Part Number: 07395.801**

**© Davis Instruments Corp. 2013. All rights reserved.**

**Note:** This document will be periodically updated along with our product development. Please check Davis Instruments' website ([www.davisnet.com](http://www.davisnet.com)) for the latest version.

**Vantage Pro is a registered trademark of Davis Instruments Corp. Vantage Pro2 is a registered trademark of Davis Instruments Corp. Vantage Vue is a registered trademark of Davis Instruments Corp.**



**Davis Instruments Corp.**  
3465 Diablo Avenue, Hayward, CA 94545-2778 U.S.A.  
510-732-9229 • Fax: 510-732-9188  
E-mail: [info@davisnet.com](mailto:info@davisnet.com) • [www.davisnet.com](http://www.davisnet.com)

## Revision History

<b>Revision</b>	<b>Date</b>	<b>Changes</b>
<b>2.3.0</b>	<b>February 9, 2009</b>	<b>1. Fix default value errors in the document</b>
<b>2.5.0</b>	<b>July 30, 2012</b>	<b>1. Add section for new command “LPS” to support new loop packet type</b> <b>2. Added section to document Vue EEPOM layout.</b> <b>3. Added references to the Vantage Vue product as appropriate.</b>
<b>2.6.0</b>	<b>November 30, 2012</b>	<b>1. Removed unused STRMON and STRMOFF commands</b> <b>2. Added RXTEST command to get console out of “Receiving from” screen</b> <b>3. Add section for web download protocol</b> <b>4. Added Wind Cup Size EEPROM location for Vantage Vue &amp; VP2 station.</b> <b>5. Corrected data formats in LOOP2 packet definition</b> <b>6. Corrected unit description of rain alarm and high/low values (i.e. rain clicks, not 1/100 inch) and Daily ET (1/1000 in)</b>
<b>2.6.1</b>	<b>March 29, 2013</b>	<b>1. Documented how to configure reception through repeaters.</b> <b>2. Added Document revision and date to footers on all pages.</b> <b>3. Corrected the response of the BAR= command from &lt;ACK&gt; to "OK"</b> <b>4. Fixed offset of Leaf data in HILOW format table.</b> <b>5. Corrected descriptions of dew point, wind chill, heat index, and THSW index in LOOP 2 format table.</b>

## Table of Contents

I. Introduction .....	5
II. Additional Commands Not in Monitor II.....	5
III. Differences between Vantage Pro and Vantage Pro 2 .....	6
IV. Differences between Vantage Pro 2 and Vantage Vue.....	6
V. Waking up the Console .....	6
VI. Blackout Periods.....	7
VII. Command Formats .....	7
VIII. Command Summary .....	8
1. Testing commands .....	8
2. Current Data commands .....	8
3. Download Commands.....	8
4. EEPROM Commands .....	8
5. Calibration Commands .....	9
6. Clearing Commands.....	9
7. Configuration Commands.....	9
IX. Command Details .....	10
1. Testing commands .....	10
2. Current Data commands .....	12
3. Download Commands.....	14
4. EEPROM Commands .....	14
5. Calibration Commands .....	15
6. Clearing Commands.....	17
7. Configuration Commands.....	19
X. Data Formats .....	21
1. LOOP data format.....	21
2. LOOP2 Packet Format.....	25
3. HILOW data format.....	27
4. DMP and DMPAFT data format.....	30
5. Alarm thresholds data format.....	33
6. CALED and CALFIX data format.....	34
XI. Download Protocol .....	34
1. Serial Download Protocol .....	34
2. Web Download protocol .....	36
XII. CRC calculation .....	37
XIII. EEPROM configuration settings.....	39
XIV. Common Tasks .....	43
1. Setting Temperature and Humidity Calibration Values.....	43
2. Setting the Time, Time Zone, and Daylight savings .....	43
3. Setting the Rain Collector type .....	45
4. Setting up transmitter station ID's and retransmit function. ....	45
5. Setting Alarm Thresholds .....	48
6. Calculating ISS reception .....	51
XV. EEPROM Graph data locations for Vantage Pro .....	52
XVI. EEPROM Graph data locations for VP2 .....	55
XVII. EEPROM Graph data locations for Vue .....	58

### Important Note:

Please note, this information is provided as is, and we do not provide application engineering or comprehensive technical support. Also, we do not guarantee our station will meet the needs of your specific application. If you have questions, they should be submitted through email and they will be answered when resources are available. Also, although we would not do so without good reason, we reserve the right to modify our weather station design without warning at any time.

## I. Introduction

Thank you for choosing Davis Instruments for your weather application. This document explains the serial data protocol between the Vantage Pro, Vantage Pro2, Vantage Vue consoles (or Envoys) and a PC. This requires a WeatherLink with Standard Data Logger

Note, the serial communication between Vantage Pro and Vantage Pro2 are very similar except in a few places noted in this document. Important differences are described in section III.

Serial communication parameters are:

8 data bits, 1 start bit, 1 stop bit, and no parity.

Default baud rate is 19200. User selectable between 1200, 2400, 4800, 9600, 14400, and 19200 baud.

The console with a WeatherLink data logger has 3 types of memory:

- 132 KB archive memory, which stores up to 2560 archive records
- 4 KB EEPROM memory, which is used for calibration numbers, station latitude/longitude/elevation/timezone values, transmitter configuration, and Console graph points
- 4 KB of processor memory, which is used to store the current sensor data, today's high/low values, and other real-time values. **This memory is not directly available to the PC!** Commands such as LOOP and LPS, provide access to the most useful and important of these data values.

Commands are primarily ASCII strings. Letters should be in ALL CAPS. Please note that in some strings numeric values are in decimal, while in others are in hexadecimal.

Multi-byte binary values are generally stored and sent least significant byte first. Negative numbers use 2's complement notation. CRC values are sent and received most significant byte first.

## II. Additional Commands Not in Monitor II

1. An expanded LOOP packet is the only way to receive the current weather data. There is no command to get a single parameter (such as outside temperature).
2. Similarly there is a HILOWS command to receive all of the current daily, monthly, and yearly high/low values with corresponding dates and times.
3. A special DMPAFT command allows you to specify the last record you have previously downloaded so that only the records after that one are downloaded. There is no need to

clear the archive memory to keep download times short. The downloaded records are pre-sorted, so you do not have to determine where the first record is.

4. You can not reset individual high or low values. Instead there are commands to clear all the high values or all the low values.
5. You must make sure that the console is awake before sending commands to it.

### **III. Differences between Vantage Pro and Vantage Pro 2**

The Vantage Pro2 serial support is almost the same as the Vantage Pro, but there are some important differences listed below.

1. Serial commands for Vantage Pro2 must be terminated by a single line feed or a single carriage return character, but not both. Older code that terminates commands with both a line feed and a carriage return will not work or will work intermittently. *Beware that some communication programs translate a line feed to both a line feed and a carriage return.*
2. The locations of the graph data has changed in Vantage Pro2.
3. The transmission packet interval of the Vantage Pro2 ISS is 1/16 of a second longer for every station ID number. For example, ID 1 transmits at an interval of every 2.5625 seconds rather than 2.5 seconds.
4. "GAIN" command is supported in Vantage Pro but not in Vantage Pro2.
5. Vantage Pro2 does not support different transmitting period. It only supports the normal ISS transmit period.
6. Vantage Pro2 does not support SensorLink station type.
7. Vantage Pro2 with firmware 1.90 or later supports "LPS" command, but Vantage Pro does not.

### **IV. Differences between Vantage Pro 2 and Vantage Vue**

The Vantage Vue command protocol is substantially the same as the Vantage Pro 2. The primary differences are: the "console type" value returned by the "WRD"... command is 17 instead of 16 for the Vantage Pro, the list of supported sensors and transmitter types is smaller, and the EEPROM graph memory layout is different.

### **V. Waking up the Console**

In order to conserve battery power, the console spends as much time "asleep" as possible, waking up only when required. Receiving a character on the serial port will cause the console to wake up, but it might not wake up fast enough to read the first character correctly. Because of this, you should always perform a wakeup procedure before sending commands to the console:

Console Wakeup procedure:

1. Send a Line Feed character, '\n' (decimal 10, hex 0x0A).
2. Listen for a returned response of Line Feed and Carriage Return characters, ('\n\r').
3. If there is no response within a reasonable interval (say 1.2 seconds), then try steps 1 and 2 again up to a total of 3 attempts.
4. If the console has not woken up after 3 attempts, then signal a connection error

After the console has woken up, it will remain awake for 2 minutes. Every time the Vantage receives another character, the 2 minute timer will be reset.

Please note that this is **NOT TRUE** for the LOOP command. In the LOOP mode, we expect that the Vantage will be sending LOOP packets over time, so it will go to sleep immediately between each packet.

## **VI. Blackout Periods**

The console will not process commands when it is in any of the Setup screens (except the first: "Receiving From..."). It will also not process commands when the console is in a number entry mode (e.g. setting an alarm value).

Similarly, when a Download is in progress, the console will not respond to key presses and will not receive data packets from remote sensors.

## **VII. Command Formats**

The command strings given in the following sections must be followed by a Line Feed characters ('\n' or 0x0A or decimal 10) before the console will execute the command.

There are 3 different types of numbers that can be used as command parameters: decimal, hexadecimal and binary. Command parameters are shown with "<parameter name-decimal>", "<parameter name-hex>", or "<parameter name-binary>" to indicate which format should be used in each case.

Please note that using the correct number of spaces is very important. For example the command "LOOP <number of LOOP packets to send-decimal>" should be realized with the string "LOOP 4" (i.e. a single space between the "P" and the "4").

There are several different types of command responses. These responses come before any other returned data values.

1. ACK response: when this command is recognized, the console responds with an ASCII ACK (0x06) character. If the command parameters are invalid, a Not Acknowledge response of (0x21) is used. If a block of data is sent with a CRC code, the response CANCEL (0x18) means that the data did not pass the CRC check.

Note: The DMP and DMPAFT commands can use the character <0x15> for negative acknowledgements. See the detailed documentation of these commands in Section XI Download Protocol below for more details.

2. "OK" response: when this command is recognized, the console responds with the character string "\n\rOK\n\r".
3. "DONE" response: Some commands take some time to complete their operation. For example the command "CLRGRA" will clear all the console graph points. The Vantage will respond with an "OK" when it receives the command, and "DONE" when it is finished. Do not attempt to send any commands to the console until the "DONE\n\r" response has been received.

## VIII. Command Summary

### 1. Testing commands

"TEST"

Sends the string "TEST\n" back.

"WRD"<0x12><0x4d>, ACK

Responds with a weather station type that is backward compatible with earlier Davis weather products.

"RXCHECK"

Sends the Console Diagnostics report.

"RXTEST"

Moves the console from the "Receiving from" screen to the main current conditions screen.

"VER"

Sends the firmware date code as a text string.

"RECEIVERS"

Sends the bit map of station IDs that the console can hear, This is not the byte for indicating what the console selects to listen from.

"NVER"

Sends the firmware version number as a text string. This command is only supported by Vantage Pro2 (Firmware 1.90 or later) and Vantage Vue.

### 2. Current Data commands

"LOOP <number of LOOP packets to send-decimal>"

Sends the specified number of LOOP packets, 1 every 2 seconds. Console sleeps between packets.

"LPS <loop packet type bit mask-hex> <number of packets to send-decimal>"

Sends the specified number of the different loop packet(s), 1 every 2 seconds. Console sleeps between packets.

"HILOWS"

Sends all the current high/low data in a single 436 byte data block, plus 2 CRC bytes.

"PUTRAIN <Yearly Rain in rain clicks-decimal>"

Set the Yearly rainfall amount on the Vantage Console.

"PUTET <Yearly ET in 100th inch-decimal>"

Set the Yearly ET amount on the Vantage Console.

### 3. Download Commands

"DMP"

Downloads the entire archive memory. See the sections X.6 and X.4 for more details.

"DMPAFT"

Downloads the records after a specified date and time. See the sections X.6 and X.4 for more details.

### 4. EEPROM Commands

"GETEE"

Reads the full 4K EEPROM in one data block.

"EEWR <EE address-hex> <EE data-hex>"

Writes one byte of data to the specified address in the EEPROM.

"EERD <EE address-hex> <number of bytes to read-hex>"

Reads the specified number of bytes starting at the specified address. Results are given as hex strings, one byte per line.



"EEBWR <EE address-hex> <number of bytes to write-hex>"

Writes data to the EEPROM. The data and CRC are given in binary format following an ACK response.

"EEBRD <EE address-hex> <number of bytes to read-hex>"

Reads data from the EEPROM. The data and CRC are given in binary format following an ACK response.

## 5. Calibration Commands

"CALED"

Sends a block of data with the current temperature and humidity values for setting calibration values.

"CALFIX"

Updates the display when calibration numbers have been changed.

"BAR=<bar value to display (in Hg \* 1000)-decimal> <elevation (ft)-decimal>"

Sets the elevation and barometer offset values when setting the barometer for a new location.

"BARDATA"

Displays of the current barometer calibration parameters in text.

## 6. Clearing Commands

"CLRLOG"

Clears the archive data.

"CLRALM"

Clears all the alarm thresholds.

"CLRCAL"

Clears all the Temperature and Humidity calibration offsets.

"CLRGRA"

Clears all of the graph points on the Vantage console.

"CLRVAR <Data variable-decimal>"

Clears a rain or ET data value.

"CLRHIGHS <0, 1, or 2>"

Clears all of the daily (0), monthly (1), or yearly (2) high values.

"CLRLOWS <0, 1, or 2>"

Clears all of the daily (0), monthly (1), or yearly (2) low values.

"CLRBITS"

Clears the active alarm bits. Alarms will be reactivated if the alarm condition is still present.

"CLRDATA"

Clears all current data values to dashes.

## 7. Configuration Commands

"BAUD <New baud rate-decimal>"

Sets the console to a new baud rate. Valid values are 1200, 2400, 4800, 9600, 14400, and 19200.

"SETTIME"

Sets the time and date on the Vantage console. Data in a binary format is sent after ACK.

"GAIN <Gain State: '0' (off) or '1' (on)>"

Sets the gain of the radio receiver. This command is currently not supported in Vantage Pro2.

"GETTIME"

Retrieves the current time and date on the Vantage console. Data is sent in a binary format.

"SETPER <Archive interval in minutes-decimal>"

Sets the Vantage archive interval. Valid values are (1, 5, 10, 15, 30, 60, and 120).

"STOP"

Disables the creation of archive records.

"START"

Enables the creation of archive records, if they have been halted with the STOP command.

"NEWSETUP"

Re-initialize the Vantage console after making certain configuration changes.

"LAMPS <Lamp state: '0' (off) or '1' (on)>"

Turns the lamps on the Vantage console on or off.

## IX. Command Details

All commands must be terminated by a single line feed character ('\n') or a single carriage return character ('\r'). These are not shown in the command syntax, but are shown in the examples.

Beware that some systems may translate a new line character into both a new line and a carriage return which will cause intermittent operation when using a Vantage Pro2 console.

In the following command examples, lines starting with ">" are set to the console, and lines starting with "<" are received from the console.

### Character symbols

Symbol	Value	Name
<CR>	0x0D	Carriage return, "\r"
<LF>	0x0A	Line Feed, "\n"
<ACK>	0x06	Acknowledge
<NAK>	0x21	Not Acknowledge
<CANCEL>	0x18	Bad CRC code
<0xdd>	0xdd	Character code specified in hex.

### 1. Testing commands

"TEST"

It sends the string "TEST\n" back. Mostly useful when using HyperTerminal for testing a connection to the console.

Example:

>"TEST"<LF>

<"TEST"<LF><CR>

"WRD"<0x12><0x4d>

This is the same command sequence used by earlier Davis weather stations to read the Station Type value. The station will respond with an <ACK> and then a one byte identifier, which can be one of these values:

Value	Station	Value	Station
0	Wizard III	5	Energy Enviromontor
1	Wizard II	6	Health Enviromonitor
2	Monitor		
3	Perception	16	Vantage Pro, Vantage Pro 2
4	GroWeather	17	Vantage Vue

Example:

```
>"WRD"<0x12><0x4D><LF>
<<ACK><16>
```

#### **"RXCHECK"**

It sends the Console Diagnostics report. The following values are sent on one line as a text string: total packets received, total packets missed, number of resynchronizations, the largest number of packets received in a row., and the number of CRC errors detected.

All values are recorded since midnight, or since the diagnostics are cleared manually.

Example:

```
>"RXCHECK"<LF>
<<LF><CR>"OK"<LF><CR>" 21629 15 0 3204 128"<LF><CR>
```

It shows we received 21,629 packets, missed 15 packets, there were no resynchronizations, the maximum number of packets received in a row without an error was 3204, and there were 128 CRC errors detected.

#### **"RXTEST"**

It moves the console from the "Receiving from" screen to the main current conditions screen. This command is useful to programmatically recover from a powerloss when the console boots into the "receiving from" screen. RXTEST also clears the count of CRC errors seen in RXCHECK.

#### **"VER"**

It sends the firmware date code as a text string. Some functions on the console are implemented differently in different firmware versions. See the separate file "Vantage Console Firmware Release History.doc" or "Envoy Firmware Release History.doc" to determine which functions are available with each firmware version.

The date code is sent in the following format:

"Mmm dd yyyy"

Mmm is the three-letter English month abbreviation

dd is the day of the month

yyyy is the year.

Example:

```
>"VER"<LF>  
<<LF><CR>"OK"<LF><CR>"Apr 24 2002"<LF><CR>
```

#### **"RECEIVERS"**

It sends a byte that contains the stations received in the "Receiving From ..." setup screen. The station responds with "OK" followed by the bit map. For each bit position, a value of 1 indicates that that transmitter was received. Bit position 0 (least significant bit) corresponds with Tx ID 1 in the Davis Talk protocol.

Example:

```
>"RECEIVERS"<LF>  
<<LF><CR>"OK"<LF><CR><0x01>
```

#### **"NVER"**

It sends the firmware version as a text string. Some functions on the console are implemented differently in different firmware versions. See the separate file "Vantage Console Firmware Release History.doc" or "Envoy Firmware Release History.doc" to determine which functions are available with each firmware version.

The version sent in the following format:

x.xx

Example:

```
>"NVER"<LF>  
<<LF><CR>"OK"<LF><CR>"1.73"<LF><CR>
```

## **2. Current Data commands**

#### **"LOOP <number of LOOP packets to send-decimal>"**

It sends the specified number of LOOP packets, 1 every 2 seconds. Console sleeps between each packet sent. The station responds with an <ACK> then with binary data packet every 2 seconds.

To halt the sending of LOOP packets before receiving all of the requested packets, send a <CR> by itself. Note that this is the same as the Wakeup sequence.

Each data packet is 99 bytes long and contains most of the current data values shown on the vantage console. In addition, the state of alarms, the battery status of the console and the transmitters, the weather forecast icon, and the sunrise and sunset times are included. Rev B and Vantage Pro2 firmware also have the 3 hour barometer trend value. A CRC value is calculated and transmitted so that the PC can validate the transmission accuracy of the data. The data format is described in detail in section X.1

Example (request 4 LOOP packets):

```
>"LOOP 4"<LF>
<<ACK>
<<99 byte LOOP packet> . . .
```

**"LPS <loop packet type bit mask-decimal><number of packets to send-decimal>"**

It sends the specified number of the different type LOOP packets, 1 every 2.5 seconds. It supports up to 8 different types of loop packets, with each bit maps to one type. So far only two types are supported, bit 0 for LOOP packet, bit 1 for LOOP2 packet. If both bits are set to 1s, the LOOP and the LOOP2 packet will be sent one after another. If more than one type of loop packet is selected, the number of packets to send is the total number of all the different type of loop packets. Console sleeps between each packet sent. The station responds with an <ACK> then with binary data packet every 2.5 seconds.

To halt the sending of LOOP packets before receiving all of the requested packets, send a <CR> by itself. Note that this is the same as the Wakeup sequence.

All the loop packets are 99 bytes long and contain most of the current data values shown on the Vantage Pro, Vantage Pro2 and Vantage Vue consoles. See the previous section for LOOP packet details.

Example (request 2 LOOP and 2 LOOP2 packets):

```
>"LPS 3 4"<LF>
<<ACK>
<<99 byte LOOP packet>...
Wait 2.0 seconds
<<99 byte LOOP2 packet>...
Wait 2.0 seconds
<<99 byte LOOP packet>...
Wait 2.0 seconds
<<99 byte LOOP2 packet>...
```

Example (request 1 LOOP2 packets):

```
>"LPS 2 1"<LF>
<<ACK>
<<99 byte LOOP2 packet>...
```

#### **"HILOWS"**

It sends all the current high/low data in a single data block. The station responds with an <ACK> then a 436 byte data block that includes all the daily, monthly, and yearly high and low values on the Vantage console, and then a 2 byte CRC value. This is so that the PC can validate the transmission accuracy of the data. The data format is described in detail in section X.2 .

Example:

```
>"HILOWS"<LF>  
<<ACK>  
<<436 byte hi/low packet><2-Byte CRC>
```

**"PUTRAIN <Yearly Rain in rain clicks-decimal>"**

It sets the Yearly rainfall amount on the console.

Example (set the Yearly rain to 24.83 inches):

```
>"PUTRAIN 2483"<LF>  
<<ACK>
```

The console shows yearly rain of 24.83 inches (assuming that the rain collector is configured for a 0.01" collector).

**"PUTET <Yearly ET in 100th inch-decimal>"**

It sets the Yearly ET amount on the console

Example (set the Yearly ET to 24.83 inches):

```
>"PUTET 2483"<LF>  
<<ACK>
```

The console display shows yearly ET 24.83 inches.

### 3. Download Commands

**"DMP"**

It downloads the entire archive memory. See the sections X.6 and X.4 for more details on downloading data.

**"DMPAFT"**

It downloads the records after a specified date and time. See the sections X.6 and X.4 for more details on downloading data.

### 4. EEPROM Commands

**"GETEE"**

It reads the full 4K EEPROM in one data block. There is also a 2 byte CRC.

Example:

```
>"GETEE"<LF>  
<<ACK>  
<<4096 byte block of EEPROM data>  
<<2-Byte CRC>
```

**"EERD <EE address-hex> <number of bytes to read-hex>"**

It reads the specified number of bytes starting at the specified address. Results are given as hex strings, one byte per line. See section XIII for more details on accessing EEPROM data.

Example (Read the station Longitude [-122.1]):

```
>"EERD 0D 02"<LF>
<"OK"<LF><CR>
<"3B"<LF><CR>
<"FB"<LF><CR>
-- 0xFB3B = -1221
```

**"EEWR <EE address-hex> <EE data-hex>"**

It writes one byte of data to the specified address in the EEPROM. See section XIII for more details on accessing EEPROM data.

Example (It writes 0x87 to EEPROM address 0x58.):

```
>"EEWR 58 87"<LF>
<<LF><CR>"OK"<LF><CR>
```

**"EEBRD <EE address-hex> < number of bytes to read-hex>"**

Reads data in binary format from the EEPROM. The data and CRC is given in binary format following an ACK response. See section XIII for more details on accessing EEPROM data.

Example (It reads three bytes from the EEPROM at location 0x32.)

```
>"EEBRD 32 03"<LF>
<<ACK>
<<0x05><0xFA><0x0E><2-Byte CRC>
```

**"EEBWR <EE address-hex> <number of bytes to write-hex>"**

It writes data to the EEPROM. The data and CRC is given in binary format following an ACK response. See section XIII for more details on accessing EEPROM data.

Example (Set the time alarm to 7:15 am, the TIME\_COMP field must also be set):

```
>"EEBWR 54 04"<LF>
<<ACK>
><0xCB><0x02><0x34><0xFD><2-Byte CRC>
```

## 5. Calibration Commands

**"CALED"**

It sends a block of data with the current temperature and humidity values for setting calibration values. These values are the current CALIBRATED sensor values. The data format is the same that is used in the "CALFIX" command.

Example:

```
>"CALED"<LF>
```

```
<<ACK>
```

```
<<43 bytes of data block with current data values><2-Byte CRC>
```

#### **"CALFIX"**

It updates the display when temperature and humidity calibration numbers have been changed. The values sent should be UN-CALIBRATED sensor values.

Example:

```
>"CALFIX"<LF>
```

```
<<ACK>
```

```
><43 bytes of data block with raw sensor values><2-Byte CRC>
```

```
<<ACK>
```

#### **"BAR=<bar value to display (in Hg \* 1000)-decimal> <elevation (ft)-decimal>"**

It sets the elevation and barometer offset values when setting the barometer for a new location.

##### **<bar value to display (in Hg \* 1000)-decimal>**

If you have a current barometer reading from a very reliable nearby reference, you can use this parameter to force the display to an exact setting. The console uses this value to fine-tune its own adjusted barometric pressure calculations. Do not use this setting alone to correct your barometer to sea-level.

Use a value of zero when you do not have an exact barometer value that you want the Vantage console to display. This also clears out any existing offset value previously set.

This value should either be zero or between 20.000" Hg and 32500" Hg.

##### **<elevation (ft)-decimal>**

This is the primary means to correct the barometer measurement. Negative values for elevation can be used.

This value should be between -2000 ft and 15000 ft.

If accepted, the console will respond with an "OK", otherwise it will respond with a Not Acknowledged (0x21 = "!") character.

Example (No local Barometer value, elevation 132 ft):

```
>"BAR=0 132"<LF>
```

```
<<LF><CR>"OK"<LF><CR>
```

Example (Barometer value = 29.491 in Hg, elevation 0 ft):

```
>"BAR=29491 0"<LF>
```

```
<<LF><CR>"OK"<LF><CR>
```



Example (Barometer value = 29.991 in Hg, elevation -75 ft):

```
>"BAR=29991 -75"<LF>
<<LF><CR>"OK"<LF><CR>
```

#### "BARDATA"

It retrieves the current barometer calibration parameters in text. These tell you what the current elevation setting and barometer offset values are, plus some details on the barometer correction factor being used.

Example:

```
>"BARDATA"<LF>
<<LF><CR>"OK"<LF><CR>
<"BAR 29775"<LF><CR>
<"ELEVATION 27"<LF><CR>
<"DEW POINT 56"<LF><CR>
<"VIRTUAL TEMP 63"<LF><CR>
<"C 29"<LF><CR>
<"R 1001"<LF><CR>
<"BARCAL 0"<LF><CR>
<"GAIN 1533"<LF><CR>
<"OFFSET 18110"<LF><CR>
```

Name	Value in example	Explanation
BAR	29.775 in Hg	The most recent barometer measurement.
ELEVATION	27 ft	Elevation in feet
DEW POINT	56 °F	Dew point when the barometer measurement was taken
VIRTUAL TEMP	63 °F	Temperature used in correction formula (12 hour average)
C	29	Humidity correction factor used in the formula
R	1.001	Correction ratio. Multiply the raw sensor value by this to get the corrected measurement.
BARCAL	0.000 in Hg	Constant offset correction factor. See " <b>BAR=</b> " command.
GAIN		These are the factory set values to calibrate the barometer sensor on this console.
OFFSET		

## 6. Clearing Commands

#### "CLRLOG"

It clears the archived data.

Example:

```
>"CLRLOG"<LF>
<<ACK>
```

#### **"CLRALM"**

It clears all the alarm thresholds. Use **"CLRBITS"** to clear any active alarms.

This command takes time to perform, so you must wait for the console to send "DONE" before sending any further commands

Example:

```
>"CLRALM"<LF>
<<LF><CR>"OK"<LF><CR>
-- After some time passes --
<"DONE"<LF><CR>
```

#### **"CLRCAL"**

Clears all the Temperature and Humidity calibration offsets to zero.

Note that the values displayed on the console do not use the new calibration values until a new data packet arrives for that sensor. You must use the procedure from section XIV.1 to force the current display to use the new cal numbers

Example:

```
>"CLRCAL"<LF>
<"OK"<LF><CR>
-- After some time passes --
<"DONE"<LF><CR>
```

#### **"CLRGRA"**

It clears all of the graph points on the Vantage console.

Example:

```
>"CLRGRA"<LF>
<"OK"<LF><CR>
-- After some time passes --
<"DONE"<LF><CR>
```

#### **"CLRVAR <Data variable-decimal>"**

It clears a rain or ET data value from the following table:

Rain Variable Name	Number	ET Variable Name	Number
Daily Rain	13	Day ET	26
Storm Rain	14	Month ET	25
Month Rain	16	Year ET	27
Year Rain	17		

Results are undefined if you use a number not on this list

Example (Clear Month Rain value):

```
>"CLRVAR 16"<LF>  
<<ACK>
```

**"CLRHHIGHS <0, 1, or 2>"**

It clears all of the daily (0), monthly (1), or yearly (2) high values

Example (Clear Monthly High values):

```
>"CLRHHIGHS 1"<LF>  
<<ACK>
```

**"CLRLOWES <0, 1, or 2>"**

It clears all of the daily (0), monthly (1), or yearly (2) low values

Example (Clear Yearly Low values):

```
>"CLRLOWES 2"<LF>  
<<ACK>
```

**"CLRBITS"**

It clears the active alarm bits. They will reactivate if the alarm condition is still present.

Example:

```
>"CLRBITS"<LF>  
<<ACK>
```

**"CLRDATA"**

It clears all current data values to dashes.

Example:

```
>"CLRDATA"<LF>  
<<ACK>
```

## 7. Configuration Commands

**"BAUD <New baud rate-decimal>"**

It sets the console to a new baud rate. Valid values are 1200, 2400, 4800, 9600, 14400, and 19200. If the new baud rate is accepted, an "OK" will be returned at the new baud rate. If it is not, a "NO" will be returned and the baud rate will not be changed.

Example (to set 9600 baud):

```
>"BAUD 9600"<LF>  
<<LF><CR>"OK"<LF><CR>
```

#### **"SETTIME"**

It sets the time and date on the console. Data in a binary format is sent after ACK.

The data is 6 bytes plus a 2 bytes of CRC. The each field is one byte. The fields, in order, are: seconds, minutes, hour (24 hour format), day, month, year – 1900. See section XII for more information on calculating CRC values.

Example (to set 3:27:00 pm, June 4, 2003):

```
>"SETTIME"<LF>
<<ACK>
><0><27><15><4><6><103><2 Bytes of CRC>
<<ACK>
```

#### **"GETTIME"**

It retrieves the current time and date on the console. Data is sent in a binary format. The format is the same as the SETTIME command.

Example (Vantage responds with 5:17:42 am, January 28, 1998):

```
>"GETTIME"<LF>
<<ACK>
><42><17><5><28><1><98><2 Bytes of CRC>
```

#### **"GAIN <Gain State: '0' (off) or '1' (on)>"**

**This command only works with the VantagePro station and is not currently implemented on the VantagePro 2 or Vue stations.**

It sets the gain of the radio receiver, same as pressing the HI/LOW key on the console diagnostics screen. "GAIN 1" turns the gain on. "GAIN <Anything else>" turns the gain off:

Example (Turn on the Radio Gain):

```
>"GAIN 1"<LF>
<<LF><CR>"OK"<LF><CR>
```

Example (Turn off the Radio Gain):

```
>"GAIN 0"<LF>
<<LF><CR>"OK"<LF><CR>
```

#### **"SETPER <Archive interval in minutes-decimal>"**

It sets the console archive interval. This is the interval that archive data records are recorded into the archive memory. The smaller this value is, the faster the archive memory will fill up.

Valid values are (1, 5, 10, 15, 30, 60, and 120). Results are undefined if you try to select an archive period not on the list.

This command automatically clears the archive memory. Use the "CLRLOG" command to clear the archive memory. WeatherLink clears the archive memory so that all archived records in the archive memory use the same archive interval.

Example (set a 10 minute archive interval):

```
>"SETPER 10"<LF>
<<ACK>
```

#### "STOP"

It disables the creation of archive records.

#### "START"

It enables the creation of archive records, if they have been halted with the STOP command.

These two commands are not needed for normal operation.

#### "NEWSETUP"

It re-initializes the console after making certain configuration changes.

**Make sure to issue this command after you set the Latitude or Longitude, and after you change any of the Setup bits in the EEPROM (address 43 = 0x2B) especially the Rain collector type,**

Example (set a 10 minute archive interval):

```
>"NEWSETUP"<LF>
<<ACK>
```

#### "LAMPS <Lamp state: '0' (off) or '1' (on)>"

It turns the lamps on the Vantage console on or off.

Example (turn the lamps off):

```
>"LAMPS 0"<LF>
<<LF><CR>"OK"<LF><CR>
```

## X. Data Formats

### 1. LOOP data format

There are two different LOOP data formats. Rev "A" firmware, dated before April 24, 2002 uses the old format. Rev "B" firmware, dated on or after April 24, 2002 uses the new format. The only difference between these formats is the inclusion of the current 3 hour barometer trend in place of the fixed value "P" in the fourth byte of the data packet.

Only values read directly from sensors are included in the LOOP packet. Desired values (i.e., Dew Point or Wind Chill) must be calculated on the PC. The LOOP packet also contains

information on the current status of all Vantage Alarm conditions, battery status, weather forecasts, and sunrise and sunset times.

#### Contents of the LOOP packet.

Field	Offset	Size	Explanation
"L"	0	1	Spells out "LOO" for Rev B packets and "LOOP" for Rev A packets. Identifies a LOOP packet
"O"	1	1	
"O"	2	1	
"P" (Rev A) Bar Trend (Rev B)	3	1	Signed byte that indicates the current 3-hour barometer trend. It is one of these values: -60 = Falling Rapidly = 196 (as an unsigned byte) -20 = Falling Slowly = 236 (as an unsigned byte) 0 = Steady 20 = Rising Slowly 60 = Rising Rapidly 80 = ASCII "P" = Rev A firmware, no trend info is available Any other value means that the Vantage does not have the 3 hours of bar data needed to determine the bar trend.
Packet Type	4	1	0 for LOOP and 1 for LOOP2 packet
Next Record	5	2	Location in the archive memory where the next data packet will be written. This can be monitored to detect when a new record is created.
Barometer	7	2	Current Barometer. Units are (in Hg / 1000). The barometric value should be between 20 inches and 32.5 inches in Vantage Pro and between 20 inches and 32.5 inches in both Vantage Pro2. Values outside these ranges will not be logged.
Inside Temperature	9	2	The value is sent as 10 <sup>th</sup> of a degree in F. For example, 795 is returned for 79.5°F.
Inside Humidity	11	1	This is the relative humidity in %, such as 50 is returned for 50%.
Outside Temperature	12	2	The value is sent as 10 <sup>th</sup> of a degree in F. For example, 795 is returned for 79.5°F.
Wind Speed	14	1	It is a byte unsigned value in mph. If the wind speed is dashed because it lost synchronization with the radio or due to some other reason, the wind speed is forced to be 0.
10 Min Avg Wind Speed	15	1	It is a byte unsigned value in mph.
Wind Direction	16	2	It is a two byte unsigned value from 1 to 360 degrees. (0° is no wind data, 90° is East, 180° is South, 270° is West and 360° is north)
Extra Temperatures	18	7	This field supports seven extra temperature stations. Each byte is one extra temperature value in whole degrees F with an offset of 90 degrees. For example, a value of 0 = -90°F ; a value of 100 = 10°F ; and a value of 169 = 79°F.
Soil Temperatures	25	4	This field supports four soil temperature sensors, in the same format as the Extra Temperature field above
Leaf Temperatures	29	4	This field supports four leaf temperature sensors, in the same format as the Extra Temperature field above
Outside Humidity	33	1	This is the relative humidity in %.
Extra Humidities	34	7	Relative humidity in % for extra seven humidity stations.
Rain Rate	41	2	This value is sent as number of rain clicks (0.2mm or 0.01in). For example, 256 can represent 2.56 inches/hour.
UV	43	1	The unit is in UV index.
Solar Radiation	44	2	The unit is in watt/meter <sup>2</sup> .
Storm Rain	46	2	The storm is stored as 100 <sup>th</sup> of an inch.

Field	Offset	Size	Explanation
Start Date of current Storm	48	2	Bit 15 to bit 12 is the month, bit 11 to bit 7 is the day and bit 6 to bit 0 is the year offsetted by 2000.
Day Rain	50	2	This value is sent as number of rain clicks. (0.2mm or 0.01in)
Month Rain	52	2	This value is sent as number of rain clicks. (0.2mm or 0.01in)
Year Rain	54	2	This value is sent as number of rain clicks. (0.2mm or 0.01in)
Day ET	56	2	This value is sent as the 1000 <sup>th</sup> of an inch.
Month ET	58	2	This value is sent as the 100 <sup>th</sup> of an inch.
Year ET	60	2	This value is setnt as the 100 <sup>th</sup> of an inch.
Soil Moistures	62	4	The unit is in centibar. It supports four soil sensors.
Leaf Wetnesses	66	4	This is a scale number from 0 to 15 with 0 meaning very dry and 15 meaning very wet. It supports four leaf sensors.
Inside Alarms	70	1	Currently active inside alarms. See the table below
Rain Alarms	71	1	Currently active rain alarms. See the table below
Outside Alarms	72	2	Currently active outside alarms. See the table below
Extra Temp/Hum Alarms	74	8	Currently active extra temp/hum alarms. See the table below
Soil & Leaf Alarms	82	4	Currently active soil/leaf alarms. See the table below
Transmitter Battery Status	86	1	
Console Battery Voltage	87	2	Voltage = ((Data * 300)/512)/100.0
Forecast Icons	89	1	
Forecast Rule number	90	1	
Time of Sunrise	91	2	The time is stored as hour * 100 + min.
Time of Sunset	93	2	The time is stored as hour * 100 + min.
"\n" <LF> = 0x0A	95	1	
"\r" <CR> = 0x0D	96	1	
CRC	97	2	
Total Length	99		

#### Forecast Icons in LOOP packet

Field	Byte	Bit #	
Forecast Icons	89		Bit maps for forecast icons on the console screen.
Rain		0	
Cloud		1	
Partly Cloudy		2	
Sun		3	
Snow		4	

#### Forecast Icon Values

Value Decimal	Value Hex	Segments Shown	Forecast
8	0x08	Sun	Mostly Clear
6	0x06	Partial Sun + Cloud	Partly Cloudy
2	0x02	Cloud	Mostly Cloudy
3	0x03	Cloud + Rain	Mostly Cloudy, Rain within 12 hours
18	0x12	Cloud + Snow	Mostly Cloudy, Snow within 12 hours
19	0x13	Cloud + Rain + Snow	Mostly Cloudy, Rain or Snow within 12 hours
7	0x07	Partial Sun + Cloud + Rain	Partly Cloudy, Rain within 12 hours

Value Decimal	Value Hex	Segments Shown	Forecast
22	0x16	Partial Sun + Cloud + Snow	Partly Cloudy, Snow within 12 hours
23	0x17	Partial Sun + Cloud + Rain + Snow	Partly Cloudy, Rain or Snow within 12 hours

Currently active alarms in the LOOP packet

This table shows which alarms correspond to each bit in the LOOP alarm fields. Not all bits in each field are used. The Outside Alarms field has been split into 2 1-byte sections.

Field	Byte	Bit #	
<b>Inside Alarms</b>	<b>70</b>		Currently active inside alarms.
Falling bar trend alarm		0	
Rising bar trend alarm		1	
Low inside temp alarm		2	
High inside temp alarm		3	
Low inside hum alarm		4	
High inside hum alarm		5	
Time alarm		6	
<b>Rain Alarms</b>	<b>71</b>		Currently active rain alarms.
High rain rate alarm		0	
15 min rain alarm		1	Flash Flood alarm
24 hour rain alarm		2	
Storm total rain alarm		3	
Daily ET alarm		4	
<b>Outside Alarms</b>	<b>72</b>		Currently active outside alarms.
Low outside temp alarm		0	
High outside temp alarm		1	
Wind speed alarm		2	
10 min avg speed alarm		3	
Low dewpoint alarm		4	
High dewpoint alarm		5	
High heat alarm		6	
Low wind chill alarm		7	
<b>Outside Alarms, byte 2</b>	<b>73</b>		
High THSW alarm		0	
High solar rad alarm		1	
High UV alarm		2	
UV Dose alarm		3	
UV Dose alarm Enabled		4	It is set to 1 when a UV dose alarm threshold has been entered AND the daily UV dose has been manually cleared.
<b>Outside Humidity Alarms</b>	<b>74</b>	1	Currently active outside humidity alarms.
Low Humidity alarm		2	
High Humidity alarm		3	



Field	Byte	Bit #	
Extra Temp/Hum Alarms	75 - 81	7	Each byte contains four alarm bits (0 – 3) for a single extra Temp/Hum station. Bits (4 – 7) are not used and reserved for future use. Use the temperature and humidity sensor numbers, as described in Section XIV.4 to locate which byte contains the appropriate alarm bits. In particular, the humidity and temperature alarms for a single station will be found in different bytes.
Low temp X alarm		0	
High temp X alarm		1	
Low hum X alarm		2	
High hum X alarm		3	
Soil & Leaf Alarms	82 - 85	4	Currently active soil/leaf alarms.
Low leaf wetness X alarm		0	
High leaf wetness X alarm		1	
Low soil moisture X alarm		2	
High soil moisture X alarm		3	
Low leaf temp X alarm		4	
High leaf temp X alarm		5	
Low soil temp X alarm		6	
High soil temp X alarm		7	

## 2. LOOP2 Packet Format

The “LPS” command sends the different types of LOOP packet including the newer LOOP2 packet. The LOOP2 packet is NOT supported in Vantage Pro and only supported in Vantage Pro2 (Firmware 1.90 or later) and Vantage Vue.

Note: Some of the fields are included in both LOOP and LOOP2 packets.

Field	Offset	Size	Explanation
"L"	0	1	Spells out "LOO", identifies a LOOP packet
"O"	1	1	
"O"	2	1	
Bar Trend	3	1	Signed byte that indicates the current 3-hour barometer trend. It is one of these values: -60 = Falling Rapidly = 196 (as an unsigned byte) -20 = Falling Slowly = 236 (as an unsigned byte) 0 = Steady 20 = Rising Slowly 60 = Rising Rapidly 80 = ASCII "P" = Rev A firmware, no trend info is available Any other value means that the Vantage does not have the 3 hours of bar data needed to determine the bar trend.
Packet Type	4	1	0 for LOOP and 1 for LOOP2 packet
Unused	5	2	Unused field, filled with 0x7FFF
Barometer	7	2	Current Barometer. Units are (in Hg / 1000). The barometric value should be between 20 inches and 32.5 inches. Values outside these ranges will not be logged.
Inside Temperature	9	2	The value is sent as 10 <sup>th</sup> of a degree in F. For example, 795 is returned for 79.5°F.

Field	Offset	Size	Explanation
Inside Humidity	11	1	This is the relative humidity in %, such as 50 is returned for 50%.
Outside Temperature	12	2	The value is sent as 10 <sup>th</sup> of a degree in F. For example, 795 is returned for 79.5°F.
Wind Speed	14	1	It is a byte unsigned value in mph. If the wind speed is dashed because it lost synchronization with the radio or due to some other reason, the wind speed is forced to be 0.
Unused	15	1	Unused field, filled with 0xFF
Wind Direction	16	2	It is a two-byte unsigned value from 1 to 360 degrees. (0° is no wind data, 90° is East, 180° is South, 270° is West and 360° is north)
10-Min Avg Wind Speed	18	2	It is a two-byte unsigned value in 0.1mph resolution.
2-Min Avg Wind Speed	20	2	It is a two-byte unsigned value in 0.1mph resolution.
10-Min Wind Gust	22	2	It is a two-byte unsigned value in 0.1mph resolution.
Wind Direction for the 10-Min Wind Guest	24	2	It is a two-byte unsigned value from 1 to 360 degrees. (0° is no wind data, 90° is East, 180° is South, 270° is West and 360° is north)
Unused	26	2	Unused field, filled with 0xFFFF
Unused	28	2	Unused field, filled with 0xFFFF
Dew Point	30	2	The value is a signed two byte value in whole degrees F. 255 = dashed data
Unused	32	1	Unused field, filled with 0xFF
Outside Humidity	33	1	This is the relative humidity in %, such as 50 is returned for 50%.
Unused	34	1	Unused field, filled with 0xFF
Heat Index	35	2	The value is a signed two byte value in whole degrees F. 255 = dashed data
Wind Chill	37	2	The value is a signed two byte value in whole degrees F. 255 = dashed data
THSW Index	39	2	The value is a signed two byte value in whole degrees F. 255 = dashed data
Rain Rate	41	2	In rain clicks per hour.
UV	43	1	Unit is in UV Index
Solar Radiation	44	2	The unit is in watt/meter <sup>2</sup> .
Storm Rain	46	2	The storm is stored as number of rain clicks. (0.2mm or 0.01in)
Start Date of current Storm	48	2	Bit 15 to bit 12 is the month, bit 11 to bit 7 is the day and bit 6 to bit 0 is the year offsetted by 2000.
Daily Rain	50	2	This value is sent as number of rain clicks. (0.2mm or 0.01in)
Last 15-min Rain	52	2	This value is sent as number of rain clicks. (0.2mm or 0.01in)
Last Hour Rain	54	2	This value is sent as number of rain clicks. (0.2mm or 0.01in)
Daily ET	56	2	This value is sent as the 1000 <sup>th</sup> of an inch.
Last 24-Hour Rain	58	2	This value is sent as number of rain clicks. (0.2mm or 0.01in)
Barometric Reduction Method	60	1	Bar reduction method: 0 - user offset 1- Altimeter Setting 2- NOAA Bar Reduction. For VP2, this will always be 2.
User-entered Barometric Offset	61	2	Barometer calibration number in 1000 <sup>th</sup> of an inch
Barometric calibration number	63	2	Calibration offset in 1000 <sup>th</sup> of an inch
Barometric Sensor Raw Reading	65	2	In 1000 <sup>th</sup> of an inch
Absolute Barometric Pressure	67	2	In 1000 <sup>th</sup> of an inch, equals to the raw sensor reading plus user entered offset
Altimeter Setting	69	2	In 1000 <sup>th</sup> of an inch
Unused	71	1	Unused field, filled with 0xFF
Unused	72	1	Undefined

Field	Offset	Size	Explanation
Next 10-min Wind Speed Graph Pointer	73	1	Points to the next 10-minute wind speed graph point. For current graph point, just subtract 1 (range from 0 to 23 on VP/VP2 console and 0 to 24 on Vantage Vue console)
Next 15-min Wind Speed Graph Pointer	74	1	Points to the next 15-minute wind speed graph point. For current graph point, just subtract 1 (range from 0 to 23 on VP/VP2 console and 0 to 24 on Vantage Vue console)
Next Hourly Wind Speed Graph Pointer	75	1	Points to the next hour wind speed graph point. For current graph point, just subtract 1 (range from 0 to 23 on VP/VP2 console and 0 to 24 on Vantage Vue console)
Next Daily Wind Speed Graph Pointer	76	1	Points to the next daily wind speed graph point. For current graph point, just subtract 1 (range from 0 to 23 on VP/VP2 console and 0 to 24 on Vantage Vue console)
Next Minute Rain Graph Pointer	77	1	Points to the next minute rain graph point. For current graph point, just subtract 1 (range from 0 to 23 on VP/VP2 console and 0 to 24 on Vantage Vue console)
Next Rain Storm Graph Pointer	78	1	Points to the next rain storm graph point. For current graph point, just subtract 1 (range from 0 to 23 on VP/VP2 console and 0 to 254on Vantage Vue console)
Index to the Minute within an Hour	79	1	It keeps track of the minute within an hour for the rain calculation. (range from 0 to 59)
Next Monthly Rain	80	1	Points to the next monthly rain graph point. For current graph point, just subtract 1 (range from 0 to 23 on VP/VP2 console and 0 to 24 on Vantage Vue console)
Next Yearly Rain	81	1	Points to the next yearly rain graph point. For current graph point, just subtract 1 (range from 0 to 23 on VP/VP2 console and 0 to 24 on Vantage Vue console)
Next Seasonal Rain	82	1	Points to the next seasonal rain graph point. Yearly rain always resets at the beginning of the calendar, but seasonal rain resets when rain season begins. For current graph point, just subtract 1 (range from 0 to 23 on VP/VP2 console and 0 to 24 on Vantage Vue console)
Unused	83	2	Unused field, filled with 0x7FFF
Unused	85	2	Unused field, filled with 0x7FFF
Unused	87	2	Unused field, filled with 0x7FFF
Unused	89	2	Unused field, filled with 0x7FFF
Unused	91	2	Unused field, filled with 0x7FFF
Unused	93	2	Unused field, filled with 0x7FFF
"\n" <LF> = 0x0A	95	1	
"\r" <CR> = 0x0D	96	1	
CRC	97	2	
Total Length	99		

### 3. HILOW data format

The "**HILOWS**" command sends a 436 byte data packet and a 2 byte CRC value. The data packet is broken up into sections of related data values.

Contents of the HILOW packet.

Field	Offset	Size	Explanation
Barometer Section	0	16	
Daily Low Barometer	0	2	
Daily High Barometer	2	2	
Month Low Bar	4	2	

Field	Offset	Size	Explanation
Month High Bar	6	2	
Year Low Barometer	8	2	
Year High Barometer	10	2	
Time of Day Low Bar	12	2	
Time of Day High Bar	14	2	
Wind Speed Section	16	5	
Daily Hi Wind Speed	16	1	
Time of Hi Speed	17	2	
Month Hi Wind Speed	19	1	
Year Hi Wind Speed	20	1	
Inside Temp Section	21	16	
Day Hi Inside Temp	21	2	
Day Low Inside Temp	23	2	
Time Day Hi In Temp	25	2	
Time Day Low In Temp	27	2	
Month Low In Temp	29	2	
Month Hi In Temp	31	2	
Year Low In Temp	33	2	
Year Hi In Temp	35	2	
Inside Humidity Section	37	10	
Day Hi In Hum	37	1	
Day Low In Hum	38	1	
Time Day Hi In Hum	39	2	
Time Day Low In Hum	41	2	
Month Hi In Hum	43	1	
Month Low In Hum	44	1	
Year Hi In Hum	45	1	
Year Low In Hum	46	1	
Outside Temp Section	47	16	
Day Low Out Temp	47	2	
Day Hi Out Temp	49	2	
Time Day Low Out Temp	51	2	
Time Day Hi Out Temp	53	2	
Month Hi Out Temp	55	2	
Month Low Out Temp	57	2	
Year Hi Out Temp	59	2	
Year Low Out Temp	61	2	
Dew Point Section	63	16	
Day Low Dew Point	63	2	
Day Hi Dew Point	65	2	
Time Day Low Dew Point	67	2	
Time Day Hi Dew Point	69	2	
Month Hi Dew Point	71	2	
Month Low Dew Point	73	2	
Year Hi Dew Point	75	2	
Year Low Dew Point	77	2	

Field	Offset	Size	Explanation
Wind Chill Section	79	8	
Day Low Wind Chill	79	2	
Time Day Low Chill	81	2	
Month Low Wind Chill	83	2	
Year Low Wind Chill	85	2	
Heat Index Section	87	8	
Day High Heat	87	2	
Time of Day High Heat	89	2	
Month High Heat	91	2	
Year High Heat	93	2	
THSW Index Section	95	8	
Day High THSW	95	2	
Time of Day High THSW	97	2	
Month High THSW	99	2	
Year High THSW	101	2	
Solar Radiation Section	103	8	
Day High Solar Rad	103	2	
Time of Day High Solar	105	2	
Month High Solar Rad	107	2	
Year High Solar Rad	109	2	
UV Section	111	5	
Day High UV	111	1	
Time of Day High UV	112	2	
Month High UV	114	1	
Year High UV	115	1	
Rain Rate Section	116	10	
Day High Rain Rate	116	2	
Time of Day High Rain Rate	118	2	
Hour High Rain Rate	120	2	
Month High Rain Rate	122	2	
Year High Rain Rate	124	2	
Extra/Leaf/Soil Temps	126	150	Each field has 15 entries. Indexes 0 – 6 = Extra Temperatures 2 – 8 Indexes 7 – 10 = SoilTemperatures 1 – 4 Indexes 11 – 14 = Leaf Temperatures 1 – 4
Day Low Temperature	126	15	(15 * 1)
Day Hi Temperature	141	15	(15 * 1)
Time Day Low Temperature	156	30	(15 * 2)
Time Day Hi Temperature	186	30	(15 * 2)
Month Hi Temperature	216	15	(15 * 1)
Month Low Temperature	231	15	(15 * 1)
Year Hi Temperature	246	15	(15 * 1)
Year Low Temperature	261	15	(15 * 1)

Field	Offset	Size	Explanation
Outside/Extra Hums	276	80	Each field has 8 entries Index 0 = Outside Humidity Index 1 – 7 = Extra Humidities 2 – 8
Day Low Humidity	276	8	(8 * 1)
Day Hi Humidity	284	8	(8 * 1)
Time Day Low Humidity		16	(8 * 2)
Time Day Hi Humidity		16	(8 * 2)
Month Hi Humidity		8	(8 * 1)
Month Low Humidity		8	(8 * 1)
Year Hi Humidity		8	(8 * 1)
Year Low Humidity		8	(8 * 1)
Soil Moisture Section	356	40	Each field has 4 entries. Indexes 0 – 3 = Soil Moistures 1 – 4
Day Hi Soil Moisture		4	(4 * 1)
Time Day Hi Soil Moisture		8	(4 * 2)
Day Low Soil Moisture		4	(4 * 1)
Time Day Low Soil Moisture		8	(4 * 2)
Month Low Soil Moisture		4	(4 * 1)
Month Hi Soil Moisture		4	(4 * 1)
Year Low Soil Moisture		4	(4 * 1)
Year Hi Soil Moisture		4	(4 * 1)
Leaf Wetness Section	396	40	Each field has 4 entries. Indexes 0 – 3 = Leaf Wetness 1 – 4
Day Hi Leaf Wetness		4	(4 * 1)
Time Day Hi Leaf Wetness		8	(4 * 2)
Day Low Leaf Wetness		4	(4 * 1)
Time Day Low Leaf Wetness		8	(4 * 2)
Month Low Leaf Wetness		4	(4 * 1)
Month Hi Leaf Wetness		4	(4 * 1)
Year Low Leaf Wetness		4	(4 * 1)
Year Hi Leaf Wetness		4	(4 * 1)
CRC	436	2	

#### 4. DMP and DMPAFT data format

There are two different archived data formats. Rev "A" firmware, dated before April 24, 2002 uses the old format. Rev "B" firmware dated on or after April 24, 2002 uses the new format. The fields up to ET are identical for both formats. The only differences are in the Soil, Leaf, Extra Temperature, Extra Humidity, High Solar, High UV, and forecast fields (reedOpen and reedClosed fields are removed).

You can use the VER command and parse the date returned to determine the archive data format, or you can examine byte 42 in the archive record. In a Rev B record, it will have the value 0x00. In a Rev A record, this byte is used for "Leaf Wetness 4" which is never assigned a real data value, so it will always contain 0xFF. Future record formats may assign different values for this field.

Each archive record is 52 bytes. Records are sent to the PC in 264 byte pages. Each page contains 5 archive records and 4 unused bytes. See section 6 for more details on performing download operations.

The value in the “Dash Value” column is what you will see if that field is not updated at all during the archive interval. A dash value can appear for several reasons, and different weather variables are treated differently. For example, if you see 32767 for Outside Temperature that could be because of a communication problem, the sensor was unplugged, or the sensor has failed. Note, a dashed value is not always the sign of a problem. For example, the rainfall reading could be 0 if no rain fell in that interval. To determine if a problem exists, often times you will need to look at more than one weather variable.

Contents of the Rev "A" archive record.

Field	Offset	Size	Dash Value	Explanation
Date Stamp	0	2	Not applicable	These 16 bits hold the date that the archive was written in the following format: Year (7 bits)   Month (4 bits)   Day (5 bits) or: day + month*32 + (year-2000)*512)
Time Stamp	2	2	Not applicable	Time on the Vantage that the archive record was written: (Hour * 100) + minute.
Outside Temperature	4	2	32767	Either the Average Outside Temperature, or the Final Outside Temperature over the archive period. Units are (°F / 10)
High Out Temperature	6	2	-32768	Highest Outside Temp over the archive period.
Low Out Temperature	8	2	32767	Lowest Outside Temp over the archive period.
Rainfall	10	2	0	Number of rain clicks over the archive period
High Rain Rate	12	2	0	Highest rain rate over the archive period, or the rate shown on the console at the end of the period if there was no rain. Units are (rain clicks / hour)
Barometer	14	2	0	Barometer reading at the end of the archive period. Units are (in Hg / 1000)
Solar Radiation	16	2	32767	Average Solar Rad over the archive period. Units are (Watts / m <sup>2</sup> )
Number of Wind Samples	18	2	0	Number of packets containing wind speed data received from the ISS or wireless anemometer.
Inside Temperature	20	2	32767	Either the Average Inside Temperature, or the Final Inside Temperature over the archive period. Units are (°F / 10)
Inside Humidity	22	1	255	Inside Humidity at the end of the archive period
Outside Humidity	23	1	255	Outside Humidity at the end of the archive period
Average Wind Speed	24	1	255	Average Wind Speed over the archive interval. Units are (MPH)
High Wind Speed	25	1	0	Highest Wind Speed over the archive interval. Units are (MPH)
Direction of Hi Wind Speed	26	1	32767	Direction code of the High Wind speed. 0 = N, 1 = NNE, 2 = NE, ... 14 = NW, 15 = NNW, 255 = Dashed

Field	Offset	Size	Dash Value	Explanation
Prevailing Wind Direction	27	1	32767	Prevailing or Dominant Wind Direction code. 0 = N, 1 = NNE, 2 = NE, ... 14 = NW, 15 = NNW, 255 = Dashed Firmware before July 8, 2001 does not report direction codes of 255. Software should substitute the dash value whenever the High Wind Speed is zero.
Average UV	28	1	255	Average UV Index. Units are (UV Index / 10)
ET	29	1	0	ET accumulated over the last hour. Only records "on the hour" will have a non-zero value. Units are (in / 1000)
Invalid data	30	1		This byte is contains invalid data in Rev A data records
Soil Moistures	31	4	255	4 Soil Moisture values. Units are (cb)
Soil Temperatures	35	4	255	4 Soil Temperatures. Units are (°F + 90)
Leaf Wetnesses	39	4	255	4 Leaf Wetness values. Range is 0 – 15
Extra Temperatures	43	2	32767	2 Extra Temperature values. Units are (°F + 90)
Extra Humidities	45	2	255	2 Extra Humidity values
Reed Closed	47	2	0	Count of the number of time the anemometer reed switch was closed
Reed Opened	49	2	0	Count of the number of time the anemometer reed switch was opened
Unused Byte	51	1		

#### Contents of the Rev "B" archive record.

Field	Offset	Size	Dash Value	Explanation
Date Stamp	0	2	Not applicable	These 16 bits hold the date that the archive was written in the following format: Year (7 bits)   Month (4 bits)   Day (5 bits) or: day + month*32 + (year-2000)*512
Time Stamp	2	2	Not applicable	Time on the Vantage that the archive record was written: (Hour * 100) + minute.
Outside Temperature	4	2	32767	Either the Average Outside Temperature, or the Final Outside Temperature over the archive period. Units are (°F / 10)
High Out Temperature	6	2	-32768	Highest Outside Temp over the archive period.
Low Out Temperature	8	2	32767	Lowest Outside Temp over the archive period.
Rainfall	10	2	0	Number of rain clicks over the archive period
High Rain Rate	12	2	0	Highest rain rate over the archive period, or the rate shown on the console at the end of the period if there was no rain. Units are (rain clicks / hour)
Barometer	14	2	0	Barometer reading at the end of the archive period. Units are (in Hg / 1000).
Solar Radiation	16	2	32767	Average Solar Rad over the archive period. Units are (Watts / m <sup>2</sup> )
Number of Wind Samples	18	2	0	Number of packets containing wind speed data received from the ISS or wireless anemometer.
Inside Temperature	20	2	32767	Either the Average Inside Temperature, or the Final Inside Temperature over the archive period. Units are (°F / 10)
Inside Humidity	22	1	255	Inside Humidity at the end of the archive period
Outside Humidity	23	1	255	Outside Humidity at the end of the archive period



Field	Offset	Size	Dash Value	Explanation
Average Wind Speed	24	1	255	Average Wind Speed over the archive interval. Units are (MPH)
High Wind Speed	25	1	0	Highest Wind Speed over the archive interval. Units are (MPH)
Direction of Hi Wind Speed	26	1	32767	Direction code of the High Wind speed. 0 = N, 1 = NNE, 2 = NE, ... 14 = NW, 15 = NNW, 255 = Dashed
Prevailing Wind Direction	27	1	32767	Prevailing or Dominant Wind Direction code. 0 = N, 1 = NNE, 2 = NE, ... 14 = NW, 15 = NNW, 255 = Dashed Firmware before July 8, 2001 does not report direction code 255
Average UV Index	28	1	255	Average UV Index. Units are (UV Index / 10)
ET	29	1	0	ET accumulated over the last hour. Only records "on the hour" will have a non-zero value. Units are (in / 1000)
High Solar Radiation	30	2	0	Highest Solar Rad value over the archive period. Units are (Watts / m <sup>2</sup> )
High UV Index	32	1	0	Highest UV Index value over the archive period. Units are (Watts / m <sup>2</sup> )
Forecast Rule	33	1	193	Weather forecast rule at the end of the archive period.
Leaf Temperature	34	2	255	2 Leaf Temperature values. Units are (°F + 90)
Leaf Wetnesses	36	2	255	2 Leaf Wetness values. Range is 0 – 15
Soil Temperatures	38	4	255	4 Soil Temperatures. Units are (°F + 90)
Download Record Type	42	1		0xFF = Rev A, 0x00 = Rev B archive record
Extra Humidities	43	2	255	2 Extra Humidity values
Extra Temperatures	45	3	32767	3 Extra Temperature values. Units are (°F + 90)
Soil Moistures	48	4	255	4 Soil Moisture values. Units are (cb)

## 5. Alarm thresholds data format

The alarm thresholds data does not have a dedicated command to set or retrieve the values. Instead see section XIII for more information on reading and writing EEPROM data.

Field	Offset	Size	Explanation
ALARM_START	82=0x52	94	Starting location for the Alarm threshold data. See section 0 for more details on setting alarm thresholds
BAR_RISE_ALARM	0	1	3 hour rising bar trend alarm. Units are in Hg * 1000
BAR_FALL_ALARM	1	1	3 hour falling bar trend alarm. Units are in Hg * 1000
TIME_ALARM	2	2	Time alarm. Hours * 100 + minutes
TIME_COMP_ALARM	4	2	1's compliment of TIME_ALARM to validate alarm entries
LOW_TEMP_IN_ALARM	6	1	Threshold is (data value – 90) °F
HIGH_TEMP_IN_ALARM	7	1	Threshold is (data value – 90) °F
LOW_TEMP_OUT_ALARM	8	1	Threshold is (data value – 90) °F
HIGH_TEMP_OUT_ALARM	9	1	Threshold is (data value – 90) °F
LOW_TEMP_ALARM	10	15	7 extra temps, 4 soil temps, 4 leaf temps
HIGH_TEMP_ALARM	25	15	7 extra temps, 4 soil temps, 4 leaf temps
LOW_HUM_IN_ALARM	40	1	Inside humidity is one byte unsigned number in decimal, such as 100 represent 100%.
HIGH_HUM_IN_ALARM	41	1	Inside humidity is one byte unsigned number in decimal, such

Field	Offset	Size	Explanation
			as 100 represent 100%.
LOW_HUM_ALARM	42	8	First entry is the current Outside Humidity setting
HIGH_HUM_ALARM	50	8	First entry is the current Outside Humidity setting
LOW_DEW_ALARM	58	1	Threshold is (data value – 120) °F
HIGH_DEW_ALARM	59	1	Threshold is (data value – 120) °F
CHILL_ALARM	60	1	Threshold is (data value – 120) °F
HEAT_ALARM	61	1	Threshold is (data value – 90) °F
THSW_ALARM	62	1	Threshold is (data value – 90) °F
SPEED_ALARM	63	1	Current Wind Speed alarm. Units are MPH
SPEED_10MIN_ALARM	64	1	10 minute average Wind Speed alarm. Units are MPH
UV_ALARM	65	1	Current UV index alarm. Units are (UV Index * 10)
UV_DOSE_ALARM	66	1	Daily UV Dose alarm. Units are MEDS * 10
LOW_SOIL_ALARM	67	4	Low soil moisture alarm with unit in centibar.
HIGH_SOIL_ALARM	71	4	High soil moisture alarm with unit in centibar.
LOW_LEAF_ALARM	75	4	Low leaf wetness alarm with index 0 to 15. 0 is very dry and 15 is very wet.
HIGH_LEAF_ALARM	79	4	High leaf wetness alarm with index 0 to 15. 0 is very dry and 15 is very wet.
SOLAR_ALARM	83	2	Solar energy alarm with unit in watt/meter <sup>2</sup> .
RAIN_RATE_ALARM	85	2	Rain rate alarm is set with rain clicks per hour.
RAIN_15MIN_ALARM	87	2	15-minute rain alarm is set with rain clicks. (0.2mm or 0.01in)
RAIN_24HR_ALARM	89	2	24-hour rain alarm is set with rain clicks. (0.2mm or 0.01in)
RAIN_STORM_ALARM	91	2	Rain storm alarm is set with rain clicks. (0.2mm or 0.01in)
ET_DAY_ALARM	93	1	Units are (0.001 inches)

## 6. CALED and CALFIX data format

The "**CALED**" and "**CALFIX**" commands send and receive a block of temperature and humidity data used to update the current display whenever the calibration offsets are changed. The format of this data block is:

Field	Offset	Size	Explanation
Inside Temperature	0	2	
Outside Temperature	2	2	
Extra Temperature	4	14	(7 * 2)
Soil Temperatures	18	8	(4 * 2)
Leaf Temperatures	26	8	(4 * 2)
Inside Humidity	34	1	
Outside Humidity	35	1	
Extra Humidities	36	7	

## XI. Download Protocol

### 1. Serial Download Protocol

There are two commands you can use to get archived data records from the console. "**DMP**" downloads all data records, while "**DMPAFT**" only downloads the records archived "after" a selected time and date. The other advantage of the "**DMPAFT**" command is that the data blocks are sorted so that the oldest data downloaded is in the first page sent. The "**DMP**" command on the

other hand always starts with "page zero" which may not be the oldest data if the archive memory has filled up.

This section will concentrate on the operation of the "**DMPAFT**" command. The "**DMP**" command is identical in operation except that you do not send or receive any additional data between sending the command and receiving archive records.

In order to use the "**DMPAFT**" command you need to determine the time and date-stamp of the last record that you already have, AND this record should match one of the records already archived in the WeatherLink data logger. (if the data is not found, then the entire contents of the data archive will be downloaded.)

To calculate the time and date-stamps, use these formulas: (hour is in 24 hour format, both of these values are 2-byte values)

$\text{vantageDateStamp} = \text{day} + \text{month} * 32 + (\text{year} - 2000) * 512;$

$\text{vantageTimeStamp} = (100 * \text{hour} + \text{minute});$

Use zero for both of these values (and the CRC) to force a full download.

Send the command "**DMPAFT**" to the Vantage Pro

When you get an <ACK> back, send the 2 byte  $\text{vantageDateStamp}$ , the 2 byte  $\text{vantageTimeStamp}$ , and a 2 byte CRC value calculated from them. See section XII for more information on calculating CRC values. Send the MSB of the CRC first, then the LSB.

If the CRC is correct, the console will send back another <ACK> the number of "pages" that will be send (2 bytes), the location within the first page of the first record, and 2 Byte CRC.

If the CRC is not correct, the vantage will respond with 0x18. If you do not sent 6 bytes, it will respond with 0x21.

Note that while the console tells you which record in the first page it sends contains the first new data record, it does not tell you which record in the last page it sends is the last new data record. Records after the most recent will either contain all 0xFF bytes (if the archive has never been completely filled), or will contain old data records.

At this point you can either send an <ESC> = 0x1B to cancel the download, or an <ACK> to start the download.

After receiving each page of data, calculate the CRC value. If the CRC was incorrect, send 0x21 (really "!" but used as <NAK>) to have the Vantage send the page again.

Otherwise, send <ACK> to receive the next page (if there is one), or <ESC> to cancel the download early.

Each "Page" is 267 bytes and contains 5 records of data. There are a total of 512 pages of archive memory for a total of 2560 records. If a "**DMPAFT**" command results in downloading the entire archive, 513 pages will be downloaded. The first and last pages in this case are identical.

The format of each page is:

- 1 Byte sequence number (starts at 0 and wraps from 255 back to 0)
- 52 Byte Data record
- 52 Byte Data record
- 52 Byte Data record
- 52 Byte Data record
- 52 Byte Data record
- 4 Byte unused bytes
- 2 Byte CRC

See section X.4 for details on the format of the archive data record.

Example (download records after June 6, 2003 9:30am [270 pages, the first valid record is 2]):

```
>"DMPAFT"<LF>
<<ACK>
-- Send the Date and Time stamp --
><0xC6><0xCE><0xA2><0x03>
-- Send the calculated CRC 0xE2B4 --
><0xE2><0xB4>
<<ACK>
-- Vantage responds with the number of pages it will send --
<<0x0E><0x01><0x02><0x00><2 Bytes of CRC Data>
-- Begin the download – Use <ESC> instead to cancel it
><ACK>
-- Block sequence number
<<0x00>
<<52 byte data record 0>
<<52 byte data record 1>
-- The next record is the first record with new data
<<52 byte data record 2>
<<52 byte data record 3>
<<52 byte data record 4>
<<4 unused bytes>
<<2 byte CRC>
-- At this point verify the CRC and send either <ACK>, <0x21>, or <ESC>
```

## 2. Web Download protocol

If the console is reporting to weatherlink.com, it is possible to download the archive records using the HTTP GET request method. There are two requests required, the first returns the number of records available along with some information required to process them and the second returns the actual data records.

Note that the requests should be made to *http://weatherlink.com* and NOT to *http://www.weatherlink.com*. Do not add "www." to the beginning of the URL because there is no "www" subdomain on weatherlink.com.

The initial “headers” request is as follows:

```
http://weatherlink.com/webdl.php?timestamp=TimeStamp&user=username&pass=password&action=headers
```

Where:

*TimeStamp* is the decimal timestamp of the latest record already downloaded. All newer records will be sent. If all records are required, send “0”. This time stamp is in the format defined in XI.1 above. Example: 416351713 is 06/17/2012 15:05

*username* and *password* are the username and password of the weatherlink.com account to download.

The response includes the following fields:

Model=16<CR><LF>	Console model. VP2=16;Vue=17
Records=2315<CR><LF>	Number of records newer than timestamp sent
MaxRecords=10240<CR><LF>	Maximum archive records account will store
ArchiveInt=30<CR><LF>	Console Archive Interval
ConsoleVer=Apr 10 2006<CR><LF>	Version of console firmware
VantageTX=0<CR><LF>	TransmitterID of the anemometer

After the “headers” request is processed, a “data” request is made as follows:

```
http://weatherlink.com/webdl.php?timestamp=TimeStamp&user=username&pass=password&action=data
```

The response is a binary encoded octet stream of the raw 52 byte archive records. These can be decoded per the definition in [X.4](#)

## **XII. CRC calculation**

The console uses the same CRC calculation that was used by earlier Davis Instruments weather stations.

The CRC checking used by the WeatherLink is based on the CRC-CCITT standard. The heart of the method involves a CRC-accumulator that uses the following formula on each successive data byte. After all the data bytes have been "accumulated", there will be a two byte CRC checksum that will get processed in the same manner as the data bytes. If there has been no transmission error, then the final CRC-accumulator value will be 0 (assuming it was set to zero before accumulating data).

In the following code, "crc" is the crc accumulator (16 bits or 2 bytes), "data" is the data or CRC checksum byte to be accumulated, and "crc\_table" is the table of CRC value found in the array below. The operator "^" is an exclusive-or (XOR), ">> 8" shifts the data right by one byte (divides by 256), and "<< 8" shifts the data left by one byte (multiplies by 256).

```

crc = crc_table [(crc >> 8) ^ data] ^ (crc << 8);

unsigned short crc_table [] = {
    0x0, 0x1021, 0x2042, 0x3063, 0x4084, 0x50a5, 0x60c6, 0x70e7,
    0x8108, 0x9129, 0xa14a, 0xb16b, 0xc18c, 0xd1ad, 0xe1ce, 0xf1ef,
    0x1231, 0x210, 0x3273, 0x2252, 0x52b5, 0x4294, 0x72f7, 0x62d6,
    0x9339, 0x8318, 0xb37b, 0xa35a, 0xd3bd, 0xc39c, 0xf3ff, 0xe3de,
    0x2462, 0x3443, 0x420, 0x1401, 0x64e6, 0x74c7, 0x44a4, 0x5485,
    0xa56a, 0xb54b, 0x8528, 0x9509, 0xe5ee, 0xf5cf, 0xc5ac, 0xd58d,
    0x3653, 0x2672, 0x1611, 0x630, 0x76d7, 0x66f6, 0x5695, 0x46b4,
    0xb75b, 0xa77a, 0x9719, 0x8738, 0xf7df, 0xe7fe, 0xd79d, 0xc7bc,
    0x48c4, 0x58e5, 0x6886, 0x78a7, 0x840, 0x1861, 0x2802, 0x3823,
    0xc9cc, 0xd9ed, 0xe98e, 0xf9af, 0x8948, 0x9969, 0xa90a, 0xb92b,
    0x5af5, 0x4ad4, 0x7ab7, 0x6a96, 0x1a71, 0xa50, 0x3a33, 0x2a12,
    0xdbfd, 0xcdbc, 0xfbff, 0xeb9e, 0x9b79, 0x8b58, 0xbb3b, 0xab1a,
    0x6ca6, 0x7c87, 0x4ce4, 0x5cc5, 0x2c22, 0x3c03, 0xc60, 0x1c41,
    0xedae, 0xfd8f, 0xcdec, 0xddcd, 0xad2a, 0xbd0b, 0x8d68, 0x9d49,
    0x7e97, 0x6eb6, 0x5ed5, 0x4ef4, 0x3e13, 0x2e32, 0x1e51, 0xe70,
    0xff9f, 0xefbe, 0xdfdd, 0xcffc, 0xbf1b, 0xaf3a, 0x9f59, 0x8f78,
    0x9188, 0x81a9, 0xb1ca, 0xa1eb, 0xd10c, 0xc12d, 0xf14e, 0xe16f,
    0x1080, 0xa1, 0x30c2, 0x20e3, 0x5004, 0x4025, 0x7046, 0x6067,
    0x83b9, 0x9398, 0xa3fb, 0xb3da, 0xc33d, 0xd31c, 0xe37f, 0xf35e,
    0x2b1, 0x1290, 0x22f3, 0x32d2, 0x4235, 0x5214, 0x6277, 0x7256,
    0xb5ea, 0xa5cb, 0x95a8, 0x8589, 0xf56e, 0xe54f, 0xd52c, 0xc50d,
    0x34e2, 0x24c3, 0x14a0, 0x481, 0x7466, 0x6447, 0x5424, 0x4405,
    0xa7db, 0xb7fa, 0x8799, 0x97b8, 0xe75f, 0xf77e, 0xc71d, 0xd73c,
    0x26d3, 0x36f2, 0x691, 0x16b0, 0x6657, 0x7676, 0x4615, 0x5634,
    0xd94c, 0xc96d, 0xf90e, 0xe92f, 0x99c8, 0x89e9, 0xb98a, 0xa9ab,
    0x5844, 0x4865, 0x7806, 0x6827, 0x18c0, 0x8e1, 0x3882, 0x28a3,
    0xcb7d, 0xdb5c, 0xeb3f, 0xfb1e, 0x8bf9, 0x9bd8, 0xabbb, 0xbb9a,
    0x4a75, 0x5a54, 0x6a37, 0x7a16, 0xaf1, 0x1ad0, 0x2ab3, 0x3a92,
    0xfd2e, 0xed0f, 0xdd6c, 0xcd4d, 0xbdaa, 0xad8b, 0x9de8, 0x8dc9,
    0x7c26, 0x6c07, 0x5c64, 0x4c45, 0x3ca2, 0x2c83, 0x1ce0, 0xcc1,
    0xef1f, 0xff3e, 0xcf5d, 0xdf7c, 0xaf9b, 0xbfba, 0x8fd9, 0x9ff8,
    0x6e17, 0x7e36, 0x4e55, 0x5e74, 0x2e93, 0x3eb2, 0xed1, 0x1ef0,
};

```

When sending a CRC to the console, always send the most significant byte first. This is the opposite of how regular data values are sent where the least significant byte is sent first.

Example, calculating the CRC in the DMPAFT example above:

Old CRC	Data byte	Table index	Table Value	New CRC
0x0000	0xC6	$(0x00 \wedge 0xC6) = 0xC6$	0xB98A	$(0x0000 \wedge 0xB98A) = 0xB98A$
0xB98A	0xCE	$(0xB9 \wedge 0xCE) = 0x77$	0x0E70	$(0x8A00 \wedge 0x0E70) = 0x8470$
0x8470	0xA2	$(0x84 \wedge 0xA2) = 0x26$	0x44A4	$(0x7000 \wedge 0x44A4) = 0x34A4$
0x34A4	0x03	$(0x34 \wedge 0x03) = 0x37$	0x46B4	$(0xA400 \wedge 0x46B4) = \mathbf{0xE2B4}$

If you continue processing the received CRC value of 0xE2B4 it will look like this:

Old CRC	Data byte	Table index	Table Value	New CRC
0xE2B4	0xE2	$(0xE2 \wedge 0xE2) = 0x00$	0x0000	$(0xB400 \wedge 0x0000) = 0xB400$
0xB400	0xB4	$(0xB4 \wedge 0xB4) = 0x00$	0x0000	$(0x0000 \wedge 0x0000) = \mathbf{0x0000}$

The final CRC of zero indicates that the "packet" passed its CRC check.

### XIII. EEPROM configuration settings

There are two different ways to access data from the EEPROM. The commands "**EERD**" and "**EEWR**" provide a text based interface that you can use with a terminal emulation program, such as HyperTerminal. All numerical data is sent and received as ASCII strings that represent hexadecimal numbers. You can read as many values as you want with one "**EERD**" command, but you can only write one byte of data for each "**EEWR**" command.

The commands "**EEBRD**" and "**EEBWR**" use similar hex strings to specify what data you want to read or write, but the actual EEPROM data is send and received as binary bytes. You can read and write as many bytes as you would like to in a single command.

Both read and written data includes a CRC code. A CRC is required for data written with the "**EEBWR**" command.

There are several EEPROM data locations that should not be written with the "**EEWR**" or "**EEBWR**" commands. These are either factory calibration values that should not be changed, or else they are values that can be set from a different command. For example, use the "**SETPER**" command to set the ARCHIVE\_PERIOD value, and the "**BAR=**" command to set the BAR\_CAL and ELEVATION values. It is safe to read these EEPROM values.

The table below gives the addresses and sizes of the most useful EEPROM data values. The address of each field is given both in decimal and in hex. Use the hex value in all "**EE . . .**" commands. There is a supplemental list of the locations where the Vantage graph data is stored in section XV.

EEPROM address table

Name	Hex	Dec	Size	Description
BAR_GAIN	1	1	2	These are the factory barometer calibration values. <b>Do not modify them!</b>
BAR_OFFSET	3	3	2	
BAR_CAL	5	5	2	Barometer Offset calibration. <b>Use the "BAR=" command to set this value!</b>
HUM33	7	7	2	These are the factory inside humidity calibration values. <b>Do not modify them!</b>
HUM80	9	9	2	
LATITUDE	0B	11	2	Station Latitude in tenths of a degree. Negative values = southern hemisphere
LONGITUDE	0D	13	2	Station Longitude in tenths of a degree. Negative values = western hemisphere
ELEVATION	0F	15	2	Station elevation in feet. <b>Use the "BAR=" command to set this value!</b>
TIME_ZONE	11	17	1	String number of the time zone selected on the setup screen.
MANUAL_OR_AUTO	12	18	1	1 = manual daylight savings, 0 = automatic daylight savings

Name	Hex	Dec	Size	Description
DAYLIGHT_SAVINGS	13	19	1	This is the configuration bit for the day light savings mode when it is set in manual mode. 1 = daylight savings is now on, 0 = daylight savings is now off. When automatic daylight savings mode is selected, this bit is ignored and it does not indicate whether the daylight savings is on or not.
GMT_OFFSET	14	20	2	The time difference between GMT and local time (a 2-byte signed number in hundredths of hours. For example, a value of 850 would be +8.50 hours. Negative values in 2's complements, represent western hemisphere.
GMT_OR_ZONE	16	22	1	1 = use the GMT_OFFSET value, 0 = use the TIME_ZONE value
USETX	17	23	1	Bitmapped field that indicates which DavisTalk transmitters to listen to. Bit 0 = ID 1.
RE_TRANSMIT_TX	18	24	1	ID number to use for retransmit. 0 = don't retransmit, 1 = use ID 1, 2 = use ID 2, etc.
STATION_LIST	19	25	16	2 bytes per transmitter ID. First byte is station type, second byte is <temp sensor #   hum sensor #>. See section XIV.4 for more details.
UNIT_BITS	29	41	1	Barometer unit (bit 1:0): 0: 0.01 INCHES 1: 0.1 MM 2: 0.1 HPA 3: 0.1 MB Temperature unit (Bit 3:2): 0: °F (Whole degrees) 1: °F (Tenths of a degree) 2: °C (Whole degrees) 3: °C (Tenths of a degree) Elevation unit (Bit 4): 0: FEET 1: METERS RAIN unit (Bit 5): 0: INCHES 1: MM Wind unit (Bit 7:6): 0: MPH 1: M/S 2: Km/H 3: KNOTS
UNIT_BITS_COMP	2A	42	1	This should be the 1's complement of UNIT_BITS for validation.



Name	Hex	Dec	Size	Description
SETUP_BITS	2B	43	1	AM/PM Time Mode (Bit 0): 0: AM/PM Mode 1: 24-Hour Mode Is AM or PM (Bit 1): 0: PM 1: AM Month/Day Format (Bit 2): 0: Shown as Month/Day 1: Shown as Day/Month Wind Cup Size (Bit 3): <b>(VP and VP2 only)</b> 0: Small Size 1: Large Size Rain Collector Size (Bit 5:4): 0: 0.01 INCHES 1: 0.2 MM 2: 0.1 MM Latitude (Bit 6): 0: South 1: North Longitude (Bit 7): 0: West 1: East
RAIN_SEASON_START	2C	44	1	Month that the Yearly rain total is cleared. 1 = January, etc
ARCHIVE_PERIOD	2D	45	1	Number of minutes in the archive period. <b>Use "SETPER" to set this value.</b>
Calibration values are 1 byte signed numbers that are offsets applied to the corresponding raw sensor value in the native sensor units (either 0.1 °F or 1 %)				
TEMP_IN_CAL	32	50	1	The setting range is from (-12.8 °F to 12.7 °F) with the most significant byte as the sign bit.
TEMP_IN_COMP	33	51	1	1's compliment of TEMP_IN_CAL to validate calibration data
TEMP_OUT_CAL	34	52	1	The setting range is from (-12.8 °F to 12.7 °F) with the most significant byte as the sign bit.
TEMP_CAL	35	53	15	7 "extra" temperatures, 4 soil temperatures, and 4 leaf temperatures
HUM_IN_CAL	44	68	1	The inside humidity calibration value is ranged from 0 to 100%.
HUM_CAL	45	69	8	The first entry is the currently selected outside humidity sensor.
DIR_CAL	4D	77	2	2 byte wind direction calibration allows full 360° calibration in both directions.
DEFAULT_BAR_GRAPH	4F	79	1	These values control which time span to use on the console graph display when Rain, Barometer, or Wind Speed is shown.
DEFAULT_RAIN_GRAPH	50	80	1	
DEFAULT_SPEED_GRAPH	51	81	1	
ALARM_START	52	82	94	Starting location for the Alarm threshold data. See section XIV.5 for more details on setting alarm thresholds
BAR_RISE_ALARM	52	82	1	3 hour rising bar trend alarm. Units are in Hg * 1000
BAR_FALL_ALARM	53	83	1	3 hour falling bar trend alarm. Units are in Hg * 1000
TIME_ALARM	54	84	2	Time alarm. Hours * 100 + minutes
TIME_COMP_ALARM	56	86	2	1's compliment of TIME_ALARM to validate alarm entries
LOW_TEMP_IN_ALARM	58	88	1	Threshold is (data value – 90) °F
HIGH_TEMP_IN_ALARM	59	89	1	Threshold is (data value – 90) °F

Name	Hex	Dec	Size	Description
LOW_TEMP_OUT_ALARM	5A	90	1	Threshold is (data value – 90) °F
HIGH_TEMP_OUT_ALARM	5B	91	1	Threshold is (data value – 90) °F
LOW_TEMP_ALARM	5C	92	15	7 extra temps, 4 soil temps, 4 leaf temps
HIGH_TEMP_ALARM	6B	107	15	7 extra temps, 4 soil temps, 4 leaf temps
LOW_HUM_IN_ALARM	7A	122	1	Low relative humidity alarm in %.
HIGH_HUM_IN_ALARM	7B	123	1	High relative humidity alarm in %.
LOW_HUM_ALARM	7C	124	8	First entry is the current Outside Humidity setting
HIGH_HUM_ALARM	84	132	8	First entry is the current Outside Humidity setting
LOW_DEW_ALARM	8C	140	1	Threshold is (data value – 120) °F
HIGH_DEW_ALARM	8D	141	1	Threshold is (data value – 120) °F
CHILL_ALARM	8E	142	1	Threshold is (data value – 120) °F
HEAT_ALARM	8F	143	1	Threshold is (data value – 90) °F
THSW_ALARM	90	144	1	Threshold is (data value – 90) °F
SPEED_ALARM	91	145	1	Current Wind Speed alarm. Units are MPH
SPEED_10MIN_ALARM	92	146	1	10 minute average Wind Speed alarm. Units are MPH
UV_ALARM	93	147	1	Current UV index alarm. Units are (UV Index * 10)
LOW_SOIL_ALARM	95	149	4	Low soil moisture alarm in centibar. It supports four soil moisture sensors.
HIGH_SOIL_ALARM	99	153	4	High soil moisture alarm in centibar. It supports four soil moisture sensors.
LOW_LEAF_ALARM	9D	157	4	Low leaf wetness alarm with index 0 to 15. 0 is very dry and 15 is very wet.
HIGH_LEAF_ALARM	A1	161	4	High leaf wetness alarm with index 0 to 15. 0 is very dry and 15 is very wet.
SOLAR_ALARM	A5	165	2	Solar energy alarm is set with watts/meter <sup>2</sup> .
RAIN_RATE_ALARM	A7	167	2	Rate rain alarm is set with rain clicks/hour
RAIN_15MIN_ALARM	A9	169	2	15-minute alarm is set with rain clicks.
RAIN_24HR_ALARM	AB	171	2	24-hour alarm is set with rain clicks.
RAIN_STORM_ALARM	AD	173	2	Rain storm alarm is set with rain clicks.
ET_DAY_ALARM	AF	175	1	Evapotranspiration alarm is set with 1000 <sup>th</sup> of an inch.
Graph Pointers		177	8	See section XV
Graph data (VP only)		185		See section XV
Wind Cup Size (VP2 & Vue only)		195		Only 2 least significant bits are used: 0 = undefined 1 = small; 2 = large; 3 = other (no speed correction applied by console);
Graph data (VP2 & Vue only)		325		See section XV
Log Average Temperature	FFC	4092	1	Set this value to zero to enable logging of average temperature values. A non-zero value causes the temperature at the end of the archive period to be logged.
Password CRC	FFE	4094	2	WeatherLink uses these two bytes to hold the CRC of a password in order to provide some protection from unauthorized access. This is only enforced by software implementation. The value 0xFFFF indicates that no password is set.

## XIV. Common Tasks

This section describes how to perform several common tasks, especially ones that need to be done in a particular way.

### 1. Setting Temperature and Humidity Calibration Values

The 28 EEPROM bytes starting at address 50 (0x32) contain the calibration offsets for temperature and humidity values. Unfortunately, if you modify these values in the EEPROM, the new calibration value will not take effect until the next time the Vantage receives a data packet containing that temperature or humidity value. In order to update the Vantage display with the new calibration values, you have to follow this procedure.

Create a data structure to hold all of the calibration values, and one to hold the results of the **"CALED"** command.

1. Use **"EEBRD 32 2B"** to read in the current calibration offset values.
2. Use **"CALED"** to read in the current calibrated sensor values.
3. Determine what the un-calibrated sensor values are by subtracting the calibration offset from the data value. Make sure that you only do this if the sensor has valid data (i.e. not 0x7FFF, or 0xFF).
4. Determine and write the new calibration values into the EEPROM using **"EEBWR 32 2B"**.
5. Use **"CALFIX"** to send the un-calibrated sensor values to the Vantage to have the display update using the new calibration values.

You can use the **"EERD 32 2B"** command if you want to, but it is harder to process.

You do not have to set all of the calibration values, but you do have to send all of the sensor data values in the **"CALFIX"** command.

### 2. Setting the Time, Time Zone, and Daylight savings

The **"GETTIME"** and **"SETTIME"** commands will get and set the time and date on the Vantage console, but you will need to use additional commands to set the time zone and daylight savings settings.

#### Daylight Savings

To set up the automatic daylight savings mode (works for US, Europe, and Australia), use the command **"EEWR 12 00"** (or its **"EEBWR"** equivalent). To use manual daylight savings mode (or if daylight savings is not used at all) use the command **"EEWR 12 01"**.

If you have selected manual daylight savings mode, use the command **"EEWR 13 00"** to set standard time and **"EEWR 13 01"** to set daylight savings time.

## Time Zone

You can either choose a time zone from the list of timezones shown on the console time zone setup screen, or you can set the GMT offset directly.

To use a preset time zone, write the zone index number from the table below into the TIME\_ZONE EEPROM field (i.e. "**EEWR 11 xx**"), and also write a zero into the GMT\_OR\_ZONE field (i.e. "**EEWR 16 00**").

To use a custom time zone, write the GMT offset – in (hours \* 100 + minutes), to a 15 minute resolution, with negative values for time zones west of GMT – to the 2 byte GMT\_OFFSET field. Also write a one to the GMT\_OR\_ZONE field (i.e. "**EEWR 16 01**").

Table of preset time zones on the Vantage and WeatherLink software.

Index	GMT Offset	Name
0	-1200	(GMT-12:00) Eniwetok, Kwajalein
1	-1100	(GMT-11:00) Midway Island, Samoa
2	-1000	(GMT-10:00) Hawaii
3	-900	(GMT-09:00) Alaska
4	-800	(GMT-08:00) Pacific Time, Tijuana
5	-700	(GMT-07:00) Mountain Time
6	-600	(GMT-06:00) Central Time
7	-600	(GMT-06:00) Mexico City
8	-600	(GMT-06:00) Central America
9	-500	(GMT-05:00) Bogota, Lima, Quito
10	-500	(GMT-05:00) Eastern Time
11	-400	(GMT-04:00) Atlantic Time
12	-400	(GMT-04:00) Caracas, La Paz, Santiago
13	-330	(GMT-03:30) Newfoundland
14	-300	(GMT-03:00) Brasilia
15	-300	(GMT-03:00) Buenos Aires, Georgetown, Greenland
16	-200	(GMT-02:00) Mid-Atlantic
17	-100	(GMT-01:00) Azores, Cape Verde Is.
18	0	(GMT) Greenwich Mean Time, Dublin, Edinburgh, Lisbon, London
19	0	(GMT) Monrovia, Casablanca
20	100	(GMT+01:00) Berlin, Rome, Amsterdam, Bern, Stockholm, Vienna
21	100	(GMT+01:00) Paris, Madrid, Brussels, Copenhagen, W Central Africa
22	100	(GMT+01:00) Prague, Belgrade, Bratislava, Budapest, Ljubljana
23	200	(GMT+02:00) Athens, Helsinki, Istanbul, Minsk, Riga, Tallinn
24	200	(GMT+02:00) Cairo
25	200	(GMT+02:00) Eastern Europe, Bucharest
26	200	(GMT+02:00) Harare, Pretoria
27	200	(GMT+02:00) Israel, Jerusalem
28	300	(GMT+03:00) Baghdad, Kuwait, Nairobi, Riyadh
29	300	(GMT+03:00) Moscow, St. Petersburg, Volgograd
30	330	(GMT+03:30) Tehran
31	400	(GMT+04:00) Abu Dhabi, Muscat, Baku, Tblisi, Yerevan, Kazan
32	430	(GMT+04:30) Kabul
33	500	(GMT+05:00) Islamabad, Karachi, Ekaterinburg, Tashkent
34	530	(GMT+05:30) Bombay, Calcutta, Madras, New Delhi, Chennai
35	600	(GMT+06:00) Almaty, Dhaka, Colombo, Novosibirsk, Astana
36	700	(GMT+07:00) Bangkok, Jakarta, Hanoi, Krasnoyarsk

Index	GMT Offset	Name
37	800	(GMT+08:00) Beijing, Chongqing, Urumqi, Irkutsk, Ulaan Bataar
38	800	(GMT+08:00) Hong Kong, Perth, Singapore, Taipei, Kuala Lumpur
39	900	(GMT+09:00) Tokyo, Osaka, Sapporo, Seoul, Yakutsk
40	930	(GMT+09:30) Adelaide
41	930	(GMT+09:30) Darwin
42	1000	(GMT+10:00) Brisbane, Melbourne, Sydney, Canberra
43	1000	(GMT+10:00) Hobart, Guam, Port Moresby, Vladivostok
44	1100	(GMT+11:00) Magadan, Solomon Is, New Caledonia
45	1200	(GMT+12:00) Fiji, Kamchatka, Marshall Is.
46	1200	(GMT+12:00) Wellington, Auckland

### 3. Setting the Rain Collector type

The rain collector type is stored in the SETUP\_BITS EEPROM data byte.

To read what the current rain collector type is:

1. Use "**EEBRD 2B 01**" to read the current setup bits into the variable `setup_bits`.
2. Calculate: `rain_type = setup_bits & 0x30`
3. `rain_type` will have one of the following values: 0x00 = 0.01 in, 0x10 = 0.2 mm, or 0x20 = 0.1 mm

To set a new rain collector type:

1. Use "**EEBRD 2B 01**" to read the current setup bits into the variable `setup_bits`.
2. Mask the rain collector bits to zero with `setup_bits = setup_bits & 0xCF`
3. Set `rain_type` to one of the rain collector values given above.
4. Calculate the new `setup_bits = setup_bits | rain_type`
5. Use "**EEBWR 2B 01**" to set the new rain collector type
6. Use "**NEWSETUP**" to have the Vantage use the new setting.

### 4. Setting up transmitter station ID's and retransmit function.

The 16 bytes of EEPROM data at STATION\_LIST, plus the USETX field, control what transmitters the Vantage will listen to. These can be set for both wireless and cabled consoles, but the cabled ISS will always transmit on ID 1.

**IMPORTANT!!** You must use the "**NEWSETUP**" command after changing the transmitter ID or retransmit settings. This allows the console to use the new settings.

Use "EEBRD 19 10" to read in the 16 bytes of station data. The format will look like this:

Index	Contents	
	Upper nibble	Lower nibble
0	Tx period (VP) / Repeater ID (VP2 & Vue)	ID 1 Transmitter type
1	Humidity Sensor #	Temperature Sensor #
2	Tx period (VP) / Repeater ID (VP2 & Vue)	ID 2 Transmitter type
3	Humidity #	Temperature #
4	Tx period (VP) / Repeater ID (VP2 & Vue)	ID 3 Transmitter type
5	Humidity #	Temperature #
6	Tx period (VP) / Repeater ID (VP2 & Vue)	ID 4 Transmitter type
7	Humidity #	Temperature #
8	Tx period (VP) / Repeater ID (VP2 & Vue)	ID 5 Transmitter type
9	Humidity #	Temperature #
10	Tx period (VP) / Repeater ID (VP2 & Vue)	ID 6 Transmitter type
11	Humidity #	Temperature #
12	Tx period (VP) / Repeater ID (VP2 & Vue)	ID 7 Transmitter type
13	Humidity #	Temperature #
14	Tx period (VP) / Repeater ID (VP2 & Vue)	ID 8 Transmitter type
15	Humidity #	Temperature #

The Transmitter type field is taken from either the Rev A or Rev B station type tables below, depending on the firmware version date (April 24, 2002 and later use Rev B format).

On the Vantage Pro, the Tx period field will have one of these values: 0 = station turned off, 1 = ISS normal or Temp/Hum 4x, 4 = ISS 0.25x or Temp/Hum normal.

On the VantagePro2 wireles or the Vue consoles, the Repeater ID field holds the ID of the repeater to listed to, if one is being used. 0 = No Repeater used, 8 = listen to repeater A, 9 = listen to repeater B, 10 = listen to repeater C, ... , 15 = listen to repeater H.

For example on a VP 2, an ISS without a repeater would have the value  $(0x00 + 0x00) = 0x00$ . A Temperature/Humidity station that is being listened to from repeater A would have the value  $(0x80 + 0x03) = 0x83$ .

The humidity sensor number and temperature sensor number fields are only used if the transmitter type is a Temperature-Humidity station or a Temperature only station. These fields determine how the extra temperature and humidity data values are logged. These fields are ignored for other station types.

Starting with ID 1, the first transmitter with an extra Humidity sensor should be assigned the value 1, the second should have the value 2, etc.

In the same maner, the first extra temperature sensor should be assigned the value **ZERO**, the second should have the value 1, etc.

The USETX field holds bitmapped information on the transmitters that the Vantage will actively listen to. Bit 0 corresponds with ID 1, Bit 1 with ID 2, etc. Set this value after you have made any modifications to the STATION\_LIST field.

**IMPORTANT!!** You must use the "**NEWSETUP**" command after changing the transmitter ID or retransmit settings. This allows the console to use the new settings.

Set Transmitters example (Rev B and VantagePro 2):

Index	Contents		Description
0	1	0	0x10 ID 1 = ISS
1	F	F	0xFF
2	4	3	0x43 ID 2 = Temp/Hum
3	1	0	0x10
4	1	3	0x13 ID 3 = Temp/Hum 4x
5	2	1	0x21
6	1	8	0x18 ID 4 = Leaf/Soil
7	F	F	0xFF
8	1	4	0x14 ID 5 = Wireles anemometer
9	F	F	0xFF
10	0	A	0x0A ID 6 = Not used
11	F	F	0xFF
12	0	A	0x0A ID 6 = Not used
13	F	F	0xFF
14	0	A	0x0A ID 6 = Not used
15	F	F	0xFF
USETX			0x1F

List of Station Types (Rev A):

Station Name	Station Type (hex)	"standard" period
ISS	0	1
Temperature Only Station	1	4
Humidity Only Station	2	4
Temperature/Humidity Station	3	4
Wireless Anemometer Station	4	1
Rain Station	5	1
Leaf Station	6	1
Soil Station	7	1
SensorLink Station	8	1
No station – OFF	9	0

List of Station Types (Rev B and VantagePro 2):

Station Name	Station Type (hex)	"standard" period
ISS	0	1
Temperature Only Station	1	4
Humidity Only Station	2	4
Temperature/Humidity Station	3	4
Wireless Anemometer Station	4	1
Rain Station	5	1
Leaf Station	6	1
Soil Station	7	1
Soil/Leaf Station	8	1
SensorLink Station *	9	1
No station – OFF	A	0

\* Vantage Pro2 and Vantage Vue do not support the SensorLink station type.

List of Station Types (Vantage Vue):

Station Name	Station Type (hex)
ISS – Vantage Vue	0
Temperature Only Station *	1
Humidity Only Station *	2
Temperature/Humidity Station *	3
Wireless Anemometer Station	4
ISS – Vantage Pro 2	5
Leaf Station *	6
Soil Station *	7
Soil/Leaf Station *	8
SensorLink Station *	9
No station – OFF	A

\* The only station types supported by the Vantage Vue are: "ISS – Vantage Vue", "ISS – VP2", "Wireless Anemometer", and "No Station – OFF".

#### Retransmit feature

To activate the retransmit feature of the console, write the ID number (1-8) that you would like the Vantage to transmit on into the RE\_TRANSMIT\_TX field. This ID can not also be used to receive data from a remote sensor. Use the value 0 to turn retransmit off.

**IMPORTANT!!** You must use the "**NEWSETUP**" command after changing the transmitter ID or retransmit settings. This allows the console to use the new settings.

## 5. Setting Alarm Thresholds

The alarm values are stored in the EEPROM. Each alarm is described below along with its EEPROM address.



Field	Offset	Size	Explanation
ALARM_START	82=0x52	94	Starting location for the Alarm threshold data.
BAR_RISE_ALARM	0	1	The BAR_RISE alarms is 1 byte unsigned number. A zero value indicates the alarm is not set. A non-zero value of 1 to 255 represents .001 in to .255 in.
BAR_FALL_ALARM	1	1	The BAR_FALL alarms is 1 byte unsigned number. A zero value indicates the alarm is not set. A non-zero value of 1 to 255 represents .001 in to .255 in.
TIME_ALARM	2	2	The TIME_ALARM is a 2 byte number in the format HOURS * 100 + MINUTES.
TIME_COMP_ALARM	4	2	A value of 0xffff indicates an alarm is not set.
LOW_TEMP_IN_ALARM	6	1	The temperature alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +90°F so every number is positive. For example -32 °F would be stored as 58°F. If the alarm is not set, a 255 is stored.
HIGH_TEMP_IN_ALARM	7	1	The temperature alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +90°F so every number is positive. For example -32 °F would be stored as 58 °F. If the alarm is not set, a 255 is stored.
LOW_TEMP_OUT_ALARM	8	1	The temperature alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +90°F so every number is positive. For example -32°F would be stored as 58°F (-32 + 90). If the alarm is not set, a 255 is stored.
HIGH_TEMP_OUT_ALARM	9	1	The temperature alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +90°F so every number is positive. For example -32°F would be stored as 58°F (-32 + 90). If the alarm is not set, a 255 is stored.
LOW_TEMP_ALARM	10	15	The temperature alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +90°F so every number is positive. For example -32°F would be stored as 58°F (-32 + 90). If the alarm is not set, a 255 is stored. There are 15 bytes for the temperature alarm. Bytes 0 to 6 are for the extra temperature stations, bytes 7 to 10 are for the soil station temperature, and bytes 11 to 14 are for the leaf station temperature.
HIGH_TEMP_ALARM	25	15	The temperature alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +90°F so every number is positive. For example -32°F would be stored as 58°F (-32 + 90). If the alarm is not set, a 255 is stored. Bytes 0 to 6 are for the extra temperature stations, bytes 7 to 10 are for the soil station temperature, and bytes 11 to 14 are for the leaf station temperature.
LOW_HUM_IN_ALARM	40	1	The humidity alarm is stored in 1 unsigned byte in 1% resolution. A value of 255 indicates the alarm is not set.
HIGH_HUM_IN_ALARM	41	1	The humidity alarm is stored in 1 unsigned byte in 1% resolution. A value of 255 indicates the alarm is not set.
LOW_HUM_ALARM	42	8	The humidity alarm is stored in 1 unsigned byte in 1% resolution. A value of 255 indicates the alarm is not set. Note that the first byte is for the ISS outside humidity.
HIGH_HUM_ALARM	50	8	The humidity alarm is stored in 1 unsigned byte in 1% resolution. A value of 255 indicates the alarm is not set. . Note that the first byte is for the ISS outside humidity.
LOW_DEW_ALARM	58	1	The dew alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +120°F so every number is positive. For example -32 °F would be stored as 88 °F. If the alarm is not set, a 255 is stored.

Field	Offset	Size	Explanation
HIGH_DEW_ALARM	59	1	The dew alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +120°F so every number is positive. For example -32 °F would be stored as 88 °F. If the alarm is not set, a 255 is stored.
CHILL_ALARM	60	1	The chill alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +120°F so every number is positive. For example -32 °F would be stored as 88 °F. If the alarm is not set, a 255 is stored.
HEAT_ALARM	61	1	The heat alarm is in 1 unsigned byte in 1 °F resolution. It has an offset of +90°F so every number is positive. For example
THSW_ALARM	62	1	The temperature alarm is in 1 unsigned byte in 1°F resolution. It has an offset of +90°F so every number is positive. For example, -32°F would be stored as -32 plus 90, which is 58°F.
SPEED_ALARM	63	1	Wind speed alarm is stored in 1 unsigned byte in 1 mph resolution. A value of 255 indicates the alarm is not set.
SPEED_10MIN_ALARM	64	1	10 minute average Wind Speed alarm is stored in 1 unsigned byte in 1 mph resolution. A value of 255 indicates the alarm is not set.
UV_ALARM	65	1	The UV alarm is stored in 1 unsigned byte in the units of .1 index. A value of 255 indicats no alarm is set.
UV_DOSE_ALARM	66	1	The UV exposure alarm threshold is stored in the UV_DOSE_A_X location. However, this is an internal alarm that must be set throught he console.
LOW_SOIL_ALARM	67	4	The soil moisture alarm is stored in 1 byte unsigned values with resolution of 1 cb. A value of 255 indicates the alarm is not set. There are four bytes for the soil alarm, one for each of the four sensors.
HIGH_SOIL_ALARM	71	4	The soil moisture alarm is stored in 1 byte unsigned values with resolution of 1 cb. A value of 255 indicates the alarm is not set. There are four bytes for the soil alarm, one for each of the four sensors.
LOW_LEAF_ALARM	75	4	The leaf wetness alarm is stored in 1 byte unsigned value. Leaf wetness ranges from 0 to 15. A value of 255 indicates the alarm is not set. There are four bytes for the leaf alarm, one for each of the four sensors.
HIGH_LEAF_ALARM	79	4	The leaf wetness alarm is stored in 1 byte unsigned value. Leaf wetness ranges from 0 to 15. A value of 255 indicates the alarm is not set. There are four bytes for the leaf alarm, one for each of the four sensors.
SOLAR_ALARM	83	2	The solar radiation alarm is a 2 byte value stored in 1 W/m <sup>2</sup> resolution. Valid range is from 0 to 1800. A value of 0xffff (65535) indicates the alarm is not set.
RAIN_RATE_ALARM	85	2	The rain rate alarm is a 2 byte value stored with a resolution of rain clicks per hour (0.01 in or 0.2 mm). A value of 0xffff (65535) indicates the alarm is not set.
RAIN_15MIN_ALARM	87	2	The rain total alarms are stored in 2 bytes with a resolution of rain clicks (0.01 in or 0.2 mm). A value of 0xffff (65535) means no alarm is set.
RAIN_24HR_ALARM	89	2	
RAIN_STORM_ALARM	91	2	
ET_DAY_ALARM	93	1	The ET day alarm is stored in 1 unsigned byte in the resolution of .001 inches. A value of 255 means no alarm is set.

## 6. Calculating ISS reception

The "Number of Wind Samples" field in the archive record can tell you the quality of radio communication between the ISS (or wireless anemometer) and the console because wind speed data is sent in almost all data packets. In order to use this, you need to know how many packets you could have gotten if you had 100 % reception. This is a function of both the archive interval and the transmitter ID that is sending wind speed. The formula for Vantage Pro2 console is different from the one for Vantage Pro console.

The formulas for determining the expected maximum number of packets containing wind speed are:

$$\frac{\text{archive\_interval\_min} * 60}{2.5 + \frac{ID - 1}{16.0}} - \frac{\text{archive\_interval\_min} * 60}{50.0 + (ID - 1) * 1.25} \quad (\text{for Vantage Pro})$$

or

$$\frac{\text{archive\_interval\_min} * 60}{\frac{41 + ID - 1}{16}} \quad (\text{for Vantage Pro2 and Vantage Vue})$$

Here *archive\_interval\_min* is the archive interval in minutes and *ID* is the transmitter ID number between 1 and 8.

It is possible for the number of wind samples to be larger than the "expected" maximum value. This is because the maximum value is a long term average, rounded to an integer. The WeatherLink program displays 100% in these cases (i.e. not the 105% that the math would suggest).

## XV. EEPROM Graph data locations for Vantage Pro

Please note that some of the pointer values stored in the EEPROM may not be updated immediately, such as NEXT\_10MIN\_PTR and NEXT\_15MIN\_PTR. This is done to save EEPROM write cycles, since the EEPROM is good for 100,000 times of write. Those data will only be saved into the EEPROM at the beginning of each new month or when the console goes into setup mode.

GRAPH_START	176			
NEXT_10MIN_PTR	GRAPH_START+1			
NEXT_15MIN_PTR	GRAPH_START+2			
NEXT_HOUR_PTR	GRAPH_START+3			
NEXT_DAY_PTR	GRAPH_START+4			
NEXT_MONTH_PTR	GRAPH_START+5			
NEXT_YEAR_PTR	GRAPH_START+6			
NEXT_RAIN_STORM_PTR	GRAPH_START+7			
NEXT_RAIN_YEAR_PTR	GRAPH_START+8			
START	GRAPH_START+9 = 185			
//			NUMBER	NUMBER
//			OF	OF
//			ENTRYS	BYTES
//			-----	-----
TEMP_IN_HOUR	START + 0	//	24	1
TEMP_IN_DAY_HIGHS	START + 24	//	24	1
TEMP_IN_DAY_HIGH_TIMES	START + 48	//	24	2
TEMP_IN_DAY_LOWS	START + 96	//	24	1
TEMP_IN_DAY_LOW_TIMES	START + 120	//	24	2
TEMP_IN_MONTH_HIGHS	START + 168	//	25	1
TEMP_IN_MONTH_LOWS	START + 193	//	25	1
TEMP_IN_YEAR_HIGHS	START + 218	//	1	1
TEMP_IN_YEAR_LOWS	START + 219	//	1	1
TEMP_OUT_HOUR	START + 220	//	24	1
TEMP_OUT_DAY_HIGHS	START + 244	//	24	1
TEMP_OUT_DAY_HIGH_TIMES	START + 268	//	24	2
TEMP_OUT_DAY_LOWS	START + 316	//	24	1
TEMP_OUT_DAY_LOW_TIMES	START + 340	//	24	2
TEMP_OUT_MONTH_HIGHS	START + 388	//	25	1
TEMP_OUT_MONTH_LOWS	START + 413	//	25	1
TEMP_OUT_YEAR_HIGHS	START + 438	//	25	1
TEMP_OUT_YEAR_LOWS	START + 463	//	25	1
DEW_HOUR	START + 488	//	24	1
DEW_DAY_HIGHS	START + 512	//	24	1
DEW_DAY_HIGH_TIMES	START + 536	//	24	2
DEW_DAY_LOWS	START + 584	//	24	1
DEW_DAY_LOW_TIMES	START + 608	//	24	2
DEW_MONTH_HIGHS	START + 656	//	25	1
DEW_MONTH_LOWS	START + 681	//	25	1
DEW_YEAR_HIGHS	START + 706	//	1	1
DEW_YEAR_LOWS	START + 707	//	1	1
CHILL_HOUR	START + 708	//	24	1
CHILL_DAY_LOWS	START + 732	//	24	1
CHILL_DAY_LOW_TIMES	START + 756	//	24	2
CHILL_MONTH_LOWS	START + 804	//	25	1
CHILL_YEAR_LOWS	START + 829	//	1	1
THSW_HOUR	START + 830	//	24	1
THSW_DAY_HIGHS	START + 854	//	24	1
THSW_DAY_HIGH_TIMES	START + 878	//	24	2
THSW_MONTH_HIGHS	START + 926	//	25	1
THSW_YEAR_HIGHS	START + 951	//	1	1
HEAT_HOUR	START + 952	//	24	1
HEAT_DAY_HIGHS	START + 976	//	24	1

HEAT_DAY_HIGH_TIMES	START + 1000	// 24	2
HEAT_MONTH_HIGHS	START + 1048	// 25	1
HEAT_YEAR_HIGHS	START + 1073	// 1	1
HUM_IN_HOUR	START + 1074	// 24	1
HUM_IN_DAY_HIGHS	START + 1098	// 24	1
HUM_IN_DAY_HIGH_TIMES	START + 1122	// 24	2
HUM_IN_DAY_LOWS	START + 1170	// 24	1
HUM_IN_DAY_LOW_TIMES	START + 1194	// 24	2
HUM_IN_MONTH_HIGHS	START + 1242	// 25	1
HUM_IN_MONTH_LOWS	START + 1267	// 25	1
HUM_IN_YEAR_HIGHS	START + 1292	// 1	1
HUM_IN_YEAR_LOWS	START + 1293	// 1	1
HUM_OUT_HOUR	START + 1294	// 24	1
HUM_OUT_DAY_HIGHS	START + 1318	// 24	1
HUM_OUT_DAY_HIGH_TIMES	START + 1342	// 24	2
HUM_OUT_DAY_LOWS	START + 1390	// 24	1
HUM_OUT_DAY_LOW_TIMES	START + 1414	// 24	2
HUM_OUT_MONTH_HIGHS	START + 1462	// 25	1
HUM_OUT_MONTH_LOWS	START + 1487	// 25	1
HUM_OUT_YEAR_HIGHS	START + 1512	// 1	1
HUM_OUT_YEAR_LOWS	START + 1513	// 1	1
BAR_15_MIN	START + 1514	// 24	2
BAR_HOUR	START + 1562	// 24	2
BAR_DAY_HIGHS	START + 1610	// 24	2
BAR_DAY_HIGH_TIMES	START + 1658	// 24	2
BAR_DAY_LOWS	START + 1706	// 24	2
BAR_DAY_LOW_TIMES	START + 1754	// 24	2
BAR_MONTH_HIGHS	START + 1802	// 25	2
BAR_MONTH_LOWS	START + 1852	// 25	2
BAR_YEAR_HIGHS	START + 1902	// 1	2
BAR_YEAR_LOWS	START + 1904	// 1	2
WIND_SPEED_10_MIN_AVG	START + 1906	// 24	1
WIND_SPEED_HOUR_AVG	START + 1930	// 24	1
WIND_SPEED_DAY_HIGHS	START + 1954	// 24	1
WIND_SPEED_DAY_HIGH_TIMES	START + 1978	// 24	2
WIND_SPEED_DAY_HIGH_DIR	START + 2026	// 24	1
WIND_SPEED_MONTH_HIGHS	START + 2050	// 25	1
WIND_SPEED_MONTH_HIGH_DIR	START + 2075	// 25	1
WIND_SPEED_YEAR_HIGHS	START + 2100	// 25	1
WIND_SPEED_YEAR_HIGH_DIR	START + 2125	// 25	1
WIND_DIR_HOUR	START + 2150	// 24	1
WIND_DIR_DAY	START + 2174	// 24	1
WIND_DIR_MONTH	START + 2198	// 24	1
WIND_DIR_DAY_BINS	START + 2222	// 8	2
WIND_DIR_MONTH_BINS	START + 2238	// 8	2
RAIN_RATE_1_MIN	START + 2254	// 24	2
RAIN_RATE_HOUR	START + 2302	// 24	2
RAIN_RATE_DAY_HIGHS	START + 2350	// 24	2
RAIN_RATE_DAY_HIGH_TIMES	START + 2398	// 24	2
RAIN_RATE_MONTH_HIGHS	START + 2446	// 25	2
RAIN_RATE_YEAR_HIGHS	START + 2496	// 25	2
RAIN_15_MIN	START + 2546	// 24	1
RAIN_HOUR	START + 2570	// 24	2
RAIN_STORM	START + 2618	// 25	2
RAIN_STORM_START	START + 2668	// 25	2
RAIN_STORM_END	START + 2718	// 25	2
RAIN_DAY_TOTAL	START + 2768	// 25	2
RAIN_MONTH_TOTAL	START + 2818	// 25	2
RAIN_YEAR_TOTAL	START + 2868	// 25	2
ET_HOUR	START + 2918	// 24	1
ET_DAY_TOTAL	START + 2942	// 25	1
ET_MONTH_TOTAL	START + 2967	// 25	2
ET_YEAR_TOTAL	START + 3017	// 25	2

SOLAR_HOUR_AVG	START + 3067	// 24	2
SOLAR_DAY_HIGHS	START + 3115	// 24	2
SOLAR_DAY_HIGH_TIMES	START + 3163	// 24	2
SOLAR_MONTH_HIGHS	START + 3211	// 25	2
SOLAR_YEAR_HIGHS	START + 3261	// 1	2
UV_HOUR_AVG	START + 3263	// 24	1
UV_MEDS_HOUR	START + 3287	// 24	1
UV_MEDS_DAY	START + 3311	// 24	1
UV_DAY_HIGHS	START + 3335	// 24	1
UV_DAY_HIGH_TIMES	START + 3359	// 24	2
UV_MONTH_HIGHS	START + 3407	// 25	1
UV_YEAR_HIGHS	START + 3432	// 1	1
LEAF_HOUR	START + 3433	// 24	1
LEAF_DAY_LOWS	START + 3457	// 24	1
LEAF_DAY_LOW_TIMES	START + 3481	// 24	2
LEAF_DAY_HIGHS	START + 3529	// 24	1
LEAF_DAY_HIGH_TIMES	START + 3553	// 24	2
WIND_SPEED_HOUR_HIGHS	START + 3601	// 24	1
LEAF_MONTH_LOWS	START + 3625	// 1	1
LEAF_MONTH_HIGHS	START + 3626	// 25	1
LEAF_YEAR_LOWS	START + 3651	// 1	1
LEAF_YEAR_HIGHS	START + 3652	// 1	1
SOIL_HOUR	START + 3653	// 24	1
SOIL_DAY_LOWS	START + 3677	// 24	1
SOIL_DAY_LOW_TIMES	START + 3701	// 24	2
SOIL_DAY_HIGHS	START + 3749	// 24	1
SOIL_DAY_HIGH_TIMES	START + 3773	// 24	2
SOIL_MONTH_LOWS	START + 3821	// 25	1
SOIL_MONTH_HIGHS	START + 3846	// 25	1
SOIL_YEAR_LOWS	START + 3871	// 1	1
SOIL_YEAR_HIGHS	START + 3872	// 1	1
SOIL_YEAR_HIGHS_COMP	START + 3873	// 1	1
RX_PERCENTAGE	START + 3874	// 24	1
SAVE_MIN	RX_PERCENTAGE+25 = 4084		
SAVE_HOUR	SAVE_MIN+1		
SAVE_DAY	SAVE_HOUR+1		
SAVE_MONTH	SAVE_HOUR+2		
SAVE_YEAR	SAVE_HOUR+3		
SAVE_YEAR_COMP	SAVE_HOUR+4		
BAUD_RATE	SAVE_HOUR+5		
DEFAULT_RATE_GRAPH	SAVE_HOUR+6		

## XVI. EEPROM Graph data locations for VP2

Please note that some of the pointer values stored in the EEPROM may not be updated immediately, such as NEXT\_10MIN\_PTR and NEXT\_15MIN\_PTR. This is done to save EEPROM write cycles, since the EEPROM is good for 100,000 times of write. Those data will only be saved into the EEPROM at the beginning of each new month or when the console goes into setup mode.

```
#define GRAPH_START          176

NEXT_10MIN_PTR              GRAPH_START+1
NEXT_15MIN_PTR              GRAPH_START+2
NEXT_HOUR_PTR               GRAPH_START+3
NEXT_DAY_PTR                GRAPH_START+4
NEXT_MONTH_PTR              GRAPH_START+5
NEXT_YEAR_PTR               GRAPH_START+6
NEXT_RAIN_STORM_PTR         GRAPH_START+7
NEXT_RAIN_YEAR_PTR          GRAPH_START+8


#define START                325

//                          NUMBER  NUMBER
//                          OF      OF
//                          ENTRIES BYTES
//                          -----
TEMP_IN_HOUR                START +   0          // 24 || 1
TEMP_IN_DAY_HIGHS           START +  24          // 24 || 1
TEMP_IN_DAY_HIGH_TIMES     START +  48          // 24 || 2
TEMP_IN_DAY_LOWS           START +  96          // 24 || 1
TEMP_IN_DAY_LOW_TIMES      START + 120          // 24 || 2
TEMP_IN_MONTH_HIGHS        START + 168          // 25 || 1
TEMP_IN_MONTH_LOWS         START + 193          // 25 || 1
TEMP_IN_YEAR_HIGHS         START + 218          //  1 || 1
TEMP_IN_YEAR_LOWS          START + 219          //  1 || 1

TEMP_OUT_HOUR               START + 220          // 24 || 1
TEMP_OUT_DAY_HIGHS         START + 244          // 24 || 1
TEMP_OUT_DAY_HIGH_TIMES    START + 268          // 24 || 2
TEMP_OUT_DAY_LOWS          START + 316          // 24 || 1
TEMP_OUT_DAY_LOW_TIMES     START + 340          // 24 || 2
TEMP_OUT_MONTH_HIGHS       START + 388          // 25 || 1
TEMP_OUT_MONTH_LOWS        START + 413          // 25 || 1
TEMP_OUT_YEAR_HIGHS        START + 438          // 25 || 1
TEMP_OUT_YEAR_LOWS         START + 463          // 25 || 1

DEW_HOUR                    START + 488          // 24 || 1
DEW_DAY_HIGHS               START + 512          // 24 || 1
DEW_DAY_HIGH_TIMES         START + 536          // 24 || 2
DEW_DAY_LOWS               START + 584          // 24 || 1
DEW_DAY_LOW_TIMES          START + 608          // 24 || 2
DEW_MONTH_HIGHS            START + 656          // 25 || 1
DEW_MONTH_LOWS             START + 681          // 25 || 1
DEW_YEAR_HIGHS             START + 706          //  1 || 1
DEW_YEAR_LOWS              START + 707          //  1 || 1

CHILL_HOUR                  START + 708          // 24 || 1
CHILL_DAY_LOWS              START + 732          // 24 || 1
CHILL_DAY_LOW_TIMES         START + 756          // 24 || 2
CHILL_MONTH_LOWS           START + 804          // 25 || 1
CHILL_YEAR_LOWS            START + 829          //  1 || 1

THSW_HOUR                   START + 830          // 24 || 1
THSW_DAY_HIGHS              START + 854          // 24 || 1
THSW_DAY_HIGH_TIMES         START + 878          // 24 || 2
THSW_MONTH_HIGHS           START + 926          // 25 || 1
THSW_YEAR_HIGHS            START + 951          //  1 || 1
```

HEAT_HOUR	START + 952	// 24	1
HEAT_DAY_HIGHS	START + 976	// 24	1
HEAT_DAY_HIGH_TIMES	START + 1000	// 24	2
HEAT_MONTH_HIGHS	START + 1048	// 25	1
HEAT_YEAR_HIGHS	START + 1073	// 1	1
HUM_IN_HOUR	START + 1074	// 24	1
HUM_IN_DAY_HIGHS	START + 1098	// 24	1
HUM_IN_DAY_HIGH_TIMES	START + 1122	// 24	2
HUM_IN_DAY_LOWS	START + 1170	// 24	1
HUM_IN_DAY_LOW_TIMES	START + 1194	// 24	2
HUM_IN_MONTH_HIGHS	START + 1242	// 25	1
HUM_IN_MONTH_LOWS	START + 1267	// 25	1
HUM_IN_YEAR_HIGHS	START + 1292	// 1	1
HUM_IN_YEAR_LOWS	START + 1293	// 1	1
HUM_OUT_HOUR	START + 1294	// 24	1
HUM_OUT_DAY_HIGHS	START + 1318	// 24	1
HUM_OUT_DAY_HIGH_TIMES	START + 1342	// 24	2
HUM_OUT_DAY_LOWS	START + 1390	// 24	1
HUM_OUT_DAY_LOW_TIMES	START + 1414	// 24	2
HUM_OUT_MONTH_HIGHS	START + 1462	// 25	1
HUM_OUT_MONTH_LOWS	START + 1487	// 25	1
HUM_OUT_YEAR_HIGHS	START + 1512	// 1	1
HUM_OUT_YEAR_LOWS	START + 1513	// 1	1
BAR_15_MIN	START + 1514	// 24	2
BAR_HOUR	START + 1562	// 24	2
BAR_DAY_HIGHS	START + 1610	// 24	2
BAR_DAY_HIGH_TIMES	START + 1658	// 24	2
BAR_DAY_LOWS	START + 1706	// 24	2
BAR_DAY_LOW_TIMES	START + 1754	// 24	2
BAR_MONTH_HIGHS	START + 1802	// 25	2
BAR_MONTH_LOWS	START + 1852	// 25	2
BAR_YEAR_HIGHS	START + 1902	// 1	2
BAR_YEAR_LOWS	START + 1904	// 1	2
WIND_SPEED_10_MIN_AVG	START + 1906	// 24	1
WIND_SPEED_HOUR_AVG	START + 1930	// 24	1
WIND_SPEED_HOUR_HIGHS	START + 1954	// 24	1
WIND_SPEED_DAY_HIGHS	START + 1978	// 24	1
WIND_SPEED_DAY_HIGH_TIMES	START + 2002	// 24	2
WIND_SPEED_DAY_HIGH_DIR	START + 2050	// 24	1
WIND_SPEED_MONTH_HIGHS	START + 2074	// 25	1
WIND_SPEED_MONTH_HIGH_DIR	START + 2099	// 25	1
WIND_SPEED_YEAR_HIGHS	START + 2124	// 25	1
WIND_SPEED_YEAR_HIGH_DIR	START + 2149	// 25	1
WIND_DIR_HOUR	START + 2174	// 24	1
WIND_DIR_DAY	START + 2198	// 24	1
WIND_DIR_MONTH	START + 2222	// 24	1
WIND_DIR_DAY_BINS	START + 2246	// 8	2
WIND_DIR_MONTH_BINS	START + 2262	// 8	2
RAIN_RATE_1_MIN	START + 2278	// 24	2
RAIN_RATE_HOUR	START + 2326	// 24	2
RAIN_RATE_DAY_HIGHS	START + 2374	// 24	2
RAIN_RATE_DAY_HIGH_TIMES	START + 2422	// 24	2
RAIN_RATE_MONTH_HIGHS	START + 2470	// 25	2
RAIN_RATE_YEAR_HIGHS	START + 2520	// 25	2
RAIN_15_MIN	START + 2570	// 24	1
RAIN_HOUR	START + 2594	// 24	2
RAIN_STORM	START + 2642	// 25	2
RAIN_STORM_START	START + 2692	// 25	2
RAIN_STORM_END	START + 2742	// 25	2
RAIN_DAY_TOTAL	START + 2792	// 25	2
RAIN_MONTH_TOTAL	START + 2842	// 25	2
RAIN_YEAR_TOTAL	START + 2892	// 25	2
ET_HOUR	START + 2942	// 24	1



ET_DAY_TOTAL	START + 2966	// 25	1
ET_MONTH_TOTAL	START + 2991	// 25	2
ET_YEAR_TOTAL	START + 3041	// 25	2
SOLAR_HOUR_AVG	START + 3091	// 24	2
SOLAR_DAY_HIGHS	START + 3139	// 24	2
SOLAR_DAY_HIGH_TIMES	START + 3187	// 24	2
SOLAR_MONTH_HIGHS	START + 3235	// 1	2
SOLAR_YEAR_HIGHS	START + 3237	// 1	2
UV_HOUR_AVG	START + 3239	// 24	1
UV_MEDS_HOUR	START + 3263	// 24	1
UV_MEDS_DAY	START + 3287	// 24	1
UV_DAY_HIGHS	START + 3311	// 24	1
UV_DAY_HIGH_TIMES	START + 3335	// 24	2
UV_MONTH_HIGHS	START + 3383	// 1	1
UV_YEAR_HIGHS	START + 3384	// 1	1
LEAF_HOUR	START + 3385	// 24	1
LEAF_DAY_LOWS	START + 3409	// 24	1
LEAF_DAY_LOW_TIMES	START + 3433	// 24	2
LEAF_DAY_HIGHS	START + 3481	// 24	1
LEAF_DAY_HIGH_TIMES	START + 3505	// 24	2
LEAF_MONTH_LOWS	START + 3553	// 1	1
LEAF_MONTH_HIGHS	START + 3554	// 1	1
LEAF_YEAR_LOWS	START + 3555	// 1	1
LEAF_YEAR_HIGHS	START + 3556	// 1	1
SOIL_HOUR	START + 3557	// 24	1
SOIL_DAY_LOWS	START + 3581	// 24	1
SOIL_DAY_LOW_TIMES	START + 3605	// 24	2
SOIL_DAY_HIGHS	START + 3653	// 24	1
SOIL_DAY_HIGH_TIMES	START + 3677	// 24	2
SOIL_MONTH_LOWS	START + 3725	// 1	1
SOIL_MONTH_HIGHS	START + 3726	// 1	1
SOIL_YEAR_LOWS	START + 3727	// 1	1
SOIL_YEAR_HIGHS	START + 3728	// 1	1
SOIL_YEAR_HIGHS_COMP	START + 3729	// 1	1
RX_PERCENTAGE	START + 3730	// 24	1
SAVE_MIN	RX_PERCENTAGE+25	// 4080	
SAVE_HOUR	SAVE_MIN+1		
SAVE_DAY	SAVE_HOUR+1		
SAVE_MONTH	SAVE_HOUR+2		
SAVE_YEAR	SAVE_HOUR+3		
SAVE_YEAR_COMP	SAVE_HOUR+4		
BAUD_RATE	SAVE_HOUR+5		
DEFAULT_RATE_GRAPH	SAVE_HOUR+6		
LCD_MODEL	SAVE_HOUR+8		
LCD_MODEL_COMP	SAVE_HOUR+9		
LOG_AVERAGE_TEMPS	SAVE_HOUR+11	// MUST BE AT 4092	

#define GRAPH_START		176		
NEXT_10MIN_PTR	GRAPH_START+1			
NEXT_15MIN_PTR	GRAPH_START+2			
NEXT_HOUR_PTR	GRAPH_START+3			
NEXT_DAY_PTR	GRAPH_START+4			
NEXT_MONTH_PTR	GRAPH_START+5			
NEXT_YEAR_PTR	GRAPH_START+6			
NEXT_RAIN_STORM_PTR	GRAPH_START+7			
NEXT_RAIN_YEAR_PTR	GRAPH_START+8			
#define START		325		
//			NUMBER	NUMBER
//			OF	OF
//			ENTRYS	BYTES
//			-----	-----
#define TEMP_OUT_HOUR	START + 0	// 25		2
#define TEMP_OUT_DAY_HIGHS	START + 50	// 25		2
#define TEMP_OUT_DAY_LOWS	START + 100	// 25		2
#define TEMP_OUT_MONTH_HIGHS	START + 150	// 26		2
#define TEMP_OUT_MONTH_LOWS	START + 202	// 26		2
#define TEMP_OUT_YEAR_HIGHS	START + 254	// 1		2
#define TEMP_OUT_YEAR_LOWS	START + 256	// 1		2
#define TEMP_OUT_DAY_HIGH_TIMES	START + 258	// 25		2
#define TEMP_OUT_DAY_LOW_TIMES	START + 308	// 25		2
#define TEMP_IN_HOUR	START + 358	// 25		1
#define TEMP_IN_DAY_HIGHS	START + 383	// 25		1
#define TEMP_IN_DAY_HIGH_TIMES	START + 408	// 25		2
#define TEMP_IN_DAY_LOWS	START + 458	// 25		1
#define TEMP_IN_DAY_LOW_TIMES	START + 483	// 25		2
#define TEMP_IN_MONTH_HIGHS	START + 533	// 26		1
#define TEMP_IN_MONTH_LOWS	START + 559	// 26		1
#define TEMP_IN_YEAR_HIGHS	START + 585	// 1		1
#define TEMP_IN_YEAR_LOWS	START + 586	// 1		1
#define DEW_HOUR	START + 587	// 25		1
#define DEW_DAY_HIGHS	START + 612	// 25		1
#define DEW_DAY_HIGH_TIMES	START + 637	// 25		2
#define DEW_DAY_LOWS	START + 687	// 25		1
#define DEW_DAY_LOW_TIMES	START + 712	// 25		2
#define DEW_MONTH_HIGHS	START + 762	// 26		1
#define DEW_MONTH_LOWS	START + 788	// 26		1
#define DEW_YEAR_HIGHS	START + 814	// 1		1
#define DEW_YEAR_LOWS	START + 815	// 1		1
#define CHILL_HOUR	START + 816	// 25		1
#define CHILL_DAY_LOWS	START + 841	// 25		1
#define CHILL_DAY_LOW_TIMES	START + 866	// 25		2
#define CHILL_MONTH_LOWS	START + 916	// 26		1
#define CHILL_YEAR_LOWS	START + 942	// 1		1
#define CHILL_YEAR_LOWS_COMP	START + 943	// 1		1
#define HEAT_HOUR	START + 944	// 25		1
#define HEAT_DAY_HIGHS	START + 969	// 25		1
#define HEAT_DAY_HIGH_TIMES	START + 994	// 25		2
#define HEAT_MONTH_HIGHS	START + 1044	// 26		1
#define HEAT_YEAR_HIGHS	START + 1070	// 1		1
#define HUM_IN_HOUR	START + 1071	// 25		1
#define HUM_IN_DAY_HIGHS	START + 1096	// 25		1
#define HUM_IN_DAY_HIGH_TIMES	START + 1121	// 25		2
#define HUM_IN_DAY_LOWS	START + 1171	// 25		1
#define HUM_IN_DAY_LOW_TIMES	START + 1196	// 25		2
#define HUM_IN_MONTH_HIGHS	START + 1246	// 26		1
#define HUM_IN_MONTH_LOWS	START + 1272	// 26		1

```

#define HUM_IN_YEAR_HIGHS          START + 1298          // 1 | 1
#define HUM_IN_YEAR_LOWS           START + 1299          // 1 | 1

#define HUM_OUT_HOUR                START + 1300          // 25 | 1
#define HUM_OUT_DAY_HIGHS           START + 1325          // 25 | 1
#define HUM_OUT_DAY_HIGH_TIMES      START + 1350          // 25 | 2
#define HUM_OUT_DAY_LOWS            START + 1400          // 25 | 1
#define HUM_OUT_DAY_LOW_TIMES       START + 1425          // 25 | 2
#define HUM_OUT_MONTH_HIGHS         START + 1475          // 26 | 1
#define HUM_OUT_MONTH_LOWS          START + 1501          // 26 | 1
#define HUM_OUT_YEAR_HIGHS          START + 1527          // 1 | 1
#define HUM_OUT_YEAR_LOWS           START + 1528          // 1 | 1

#define BAR_15_MIN                  START + 1529          // 25 | 2
#define BAR_HOUR                    START + 1579          // 25 | 2
#define BAR_DAY_HIGHS               START + 1629          // 25 | 2
#define BAR_DAY_HIGH_TIMES          START + 1679          // 25 | 2
#define BAR_DAY_LOWS                START + 1729          // 25 | 2
#define BAR_DAY_LOW_TIMES           START + 1779          // 25 | 2
#define BAR_MONTH_HIGHS             START + 1829          // 26 | 2
#define BAR_MONTH_LOWS              START + 1881          // 26 | 2
#define BAR_YEAR_HIGHS              START + 1933          // 1 | 2
#define BAR_YEAR_LOWS               START + 1935          // 1 | 2

#define WIND_SPEED_10_MIN_AVG       START + 1937          // 25 | 1
#define WIND_SPEED_HOUR_AVG         START + 1962          // 25 | 1
#define WIND_SPEED_HOUR_HIGHS       START + 1987          // 25 | 1
#define WIND_SPEED_DAY_HIGHS        START + 2012          // 25 | 1
#define WIND_SPEED_DAY_HIGH_TIMES   START + 2037          // 25 | 2
#define WIND_SPEED_DAY_HIGH_DIR     START + 2087          // 25 | 1
#define WIND_SPEED_MONTH_HIGHS      START + 2112          // 26 | 1
#define WIND_SPEED_MONTH_HIGH_DIR   START + 2138          // 26 | 1
#define WIND_SPEED_YEAR_HIGHS       START + 2164          // 1 | 1
#define WIND_SPEED_YEAR_HIGH_DIR    START + 2165          // 1 | 1

#define WIND_DIR_HOUR               START + 2166          // 25 | 1
#define WIND_DIR_DAY                START + 2191          // 25 | 1
#define WIND_DIR_MONTH              START + 2216          // 25 | 1
#define WIND_DIR_DAY_BINS           START + 2241          // 8 | 2
#define WIND_DIR_MONTH_BINS         START + 2257          // 8 | 2

#define RAIN_RATE_1_MIN              START + 2273          // 25 | 2
#define RAIN_RATE_HOUR              START + 2323          // 25 | 2
#define RAIN_RATE_DAY_HIGHS         START + 2373          // 25 | 2
#define RAIN_RATE_DAY_HIGH_TIMES    START + 2423          // 25 | 2
#define RAIN_RATE_MONTH_HIGHS       START + 2473          // 26 | 2
#define RAIN_RATE_YEAR_HIGHS        START + 2525          // 26 | 2

#define RAIN_15_MIN                  START + 2577          // 25 | 1
#define RAIN_HOUR                    START + 2602          // 25 | 2
#define RAIN_STORM                   START + 2652          // 26 | 2
#define RAIN_STORM_START             START + 2704          // 26 | 2
#define RAIN_STORM_END               START + 2756          // 26 | 2
#define RAIN_DAY_TOTAL               START + 2808          // 26 | 2
#define RAIN_MONTH_TOTAL             START + 2860          // 26 | 2
#define RAIN_YEAR_TOTAL              START + 2912          // 26 | 2

#define ET_HOUR                      START + 2964          // 25 | 1
#define ET_DAY_TOTAL                 START + 2989          // 26 | 1
#define ET_MONTH_TOTAL               START + 3015          // 26 | 2
#define ET_YEAR_TOTAL                START + 3067          // 26 | 2

#define RX_PERCENTAGE                START + 3119          // 25 | 1

#define END_OF_GRAPHPS              RX_PERCENTAGE+25      // 3469

#define COOLING_DD_BASE              END_OF_GRAPHPS
#define HEATING_DD_BASE              END_OF_GRAPHPS+2
#define COOLING_DD                   END_OF_GRAPHPS+4
#define HEATING_DD                   END_OF_GRAPHPS+8      // 4 bytes long

```

```

#define LCD_VOLUME_OFFSET      END_OF_GRAPHS+12
#define LCD_VOLUME_OFFSET_COMP END_OF_GRAPHS+13
#define SAVE_TODAYS_HIGHS_LOWS END_OF_GRAPHS+14
#define END_OF_TODAYS_HIGHS_LOWS SAVE_TODAYS_HIGHS_LOWS+68 // Start 1 after this (3552)
#define WIND_CAL                4000
#define KEY_TEST_PASSED         4002

// stuff at end of EEPROM same position as VP2
#define SAVE_MIN                4080
#define SAVE_HOUR               4081
#define SAVE_DAY                4082
#define SAVE_MONTH              4083
#define SAVE_YEAR               4084
#define SAVE_YEAR_COMP          4085
#define BAUD_RATE               4086
#define DEFAULT_RATE_GRAPH      4087
#define LCD_MODEL               4089
#define LCD_MODEL_COMP          4090
#define LOG_AVERAGE_TEMPS       4092 // MUST BE AT 4092

```