

This document had described the way to inform the wpa\_supplicant to do the WiFi connection by using the wpa\_cli. The wpa\_supplicant had supported all kinds of security connections and WPS defined in the 802.11 specification. So, we suggest use the wpa\_supplicant to do the WiFi connection rather than the iwconfig wireless tool.

## **(A) WPA\_SUPPLICANT + WPA\_CLI User Guide**

1.start wpa\_supplicant in the background

```
wpa_supplicant -Dwext -iwlan0 -c /tmp/net/wpa.conf -B
```

2.Scanning AP and See Results

```
wpa_cli -p/var/run/wpa_supplicant scan
```

```
wpa_cli -p/var/run/wpa_supplicant scan_results
```

3.Connect to AP

a.OPEN

```
wpa_cli -p/var/run/wpa_supplicant remove_network 0
```

```
wpa_cli -p/var/run/wpa_supplicant ap_scan 1
```

```
wpa_cli -p/var/run/wpa_supplicant add_network
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 ssid ""dlink""
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 key_mgmt NONE
```

```
wpa_cli -p/var/run/wpa_supplicant select_network 0
```

b.WEP40 with open system

```
wpa_cli -p/var/run/wpa_supplicant remove_network 0
```

```
wpa_cli -p/var/run/wpa_supplicant ap_scan 1
```

```
wpa_cli -p/var/run/wpa_supplicant add_network
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 ssid ""dlink""
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 key_mgmt NONE
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_key0 1234567890
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_tx_keyidx 0
```

```
wpa_cli -p/var/run/wpa_supplicant select_network 0
```

c.WEP40 with shared key mode

```
wpa_cli -p/var/run/wpa_supplicant remove_network 0
```

```
wpa_cli -p/var/run/wpa_supplicant ap_scan 1
```

```
wpa_cli -p/var/run/wpa_supplicant add_network
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 ssid ""dlink""
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 key_mgmt NONE
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_key0 1234567890
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_tx_keyidx 0
```

```
wpa_cli -p/var/run/wpa_supplicant set_network 0 auth_alg SHARED
```

```
wpa_cli -p/var/run/wpa_supplicant select_network 0
```

#### **d.WEP104 with open system**

```
wpa_cli -p/var/run/wpa_supplicant remove_network 0
wpa_cli -p/var/run/wpa_supplicant ap_scan 1
wpa_cli -p/var/run/wpa_supplicant add_network
wpa_cli -p/var/run/wpa_supplicant set_network 0 ssid "dlink"
wpa_cli -p/var/run/wpa_supplicant set_network 0 key_mgmt NONE
wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_key0
12345678901234567890123456
wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_tx_keyidx 0
wpa_cli -p/var/run/wpa_supplicant select_network 0
```

#### **e.WEP104 with shared key mode**

```
wpa_cli -p/var/run/wpa_supplicant remove_network 0
wpa_cli -p/var/run/wpa_supplicant ap_scan 1
wpa_cli -p/var/run/wpa_supplicant add_network
wpa_cli -p/var/run/wpa_supplicant set_network 0 ssid "dlink"
wpa_cli -p/var/run/wpa_supplicant set_network 0 key_mgmt NONE
wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_key0
12345678901234567890123456
wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_tx_keyidx 0
wpa_cli -p/var/run/wpa_supplicant set_network 0 auth_alg SHARED
wpa_cli -p/var/run/wpa_supplicant select_network 0
```

**#If wep key is ASCII type,use the following cmd:**

```
#WEP40: wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_key0 ""12345""
#WEP104: wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_key0
""1234567890123""
```

**#WEP key index is X from 0 to 3, change X for other key index and select it.**

```
#wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_keyX
12345678901234567890123456
#wpa_cli -p/var/run/wpa_supplicant set_network 0 wep_tx_keyidx X
```

#### **f.TKIP and AES**

```
wpa_cli -p/var/run/wpa_supplicant remove_network 0
wpa_cli -p/var/run/wpa_supplicant ap_scan 1
wpa_cli -p/var/run/wpa_supplicant add_network
wpa_cli -p/var/run/wpa_supplicant set_network 0 ssid "dlink"
wpa_cli -p/var/run/wpa_supplicant set_network 0 psk ""12345678""
wpa_cli -p/var/run/wpa_supplicant select_network 0
```

### **4.Ad-hoc mode**

#### **a.OPEN**

**wpa\_cli -p/var/run/wpa\_supplicant scan**  
**wpa\_cli -p/var/run/wpa\_supplicant scan\_results**  
**wpa\_cli -p/var/run/wpa\_supplicant remove\_network 0**  
**wpa\_cli -p/var/run/wpa\_supplicant ap\_scan 2**  
**wpa\_cli -p/var/run/wpa\_supplicant add\_network**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 ssid "Adhoc\_test"**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 mode 1**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 key\_mgmt NONE**  
**wpa\_cli -p/var/run/wpa\_supplicant select\_network 0**

#### **b.WEP40**

**wpa\_cli -p/var/run/wpa\_supplicant scan**  
**wpa\_cli -p/var/run/wpa\_supplicant scan\_results**  
**wpa\_cli -p/var/run/wpa\_supplicant remove\_network 0**  
**wpa\_cli -p/var/run/wpa\_supplicant ap\_scan 2**  
**wpa\_cli -p/var/run/wpa\_supplicant add\_network**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 ssid "Adhoc\_test"**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 mode 1**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 key\_mgmt NONE**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 wep\_key0 1234567890**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 wep\_tx\_keyidx 0**  
**wpa\_cli -p/var/run/wpa\_supplicant select\_network 0**

#### **c.WEP104**

**wpa\_cli -p/var/run/wpa\_supplicant scan**  
**wpa\_cli -p/var/run/wpa\_supplicant scan\_results**  
**wpa\_cli -p/var/run/wpa\_supplicant remove\_network 0**  
**wpa\_cli -p/var/run/wpa\_supplicant ap\_scan 2**  
**wpa\_cli -p/var/run/wpa\_supplicant add\_network**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 ssid "Adhoc\_test"**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 mode 1**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 key\_mgmt NONE**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 wep\_key0 12345678901234567890123456**  
**wpa\_cli -p/var/run/wpa\_supplicant set\_network 0 wep\_tx\_keyidx 0**  
**wpa\_cli -p/var/run/wpa\_supplicant select\_network 0**

#### **5.Save the Current Connection AP configuration file**

**wpa\_cli -p/var/run/wpa\_supplicant save\_config**

#### **6.WPS Connection**

**Push Button:**

**wpa\_cli -p/var/run/wpa\_supplicant remove\_network 0**

**wpa\_cli -p/var/run/wpa\_supplicant wps\_pbc any**

**Pin Code:**

**wpa\_cli -p/var/run/wpa\_supplicant remove\_network 0**

**wpa\_cli -p/var/run/wpa\_supplicant wps\_pin any 12345670**

**or**

**wpa\_cli -p/var/run/wpa\_supplicant remove\_network 0**

**wpa\_cli -p/var/run/wpa\_supplicant wps\_pin any**

### **7. Get Current Status of wpa\_supplicant**

**wpa\_cli -p/var/run/wpa\_supplicant status**

### **8. Disable current network connection**

**wpa\_cli -p/var/run/wpa\_supplicant disable\_network 0**

## **(B) WPA\_SUPPLICANT + WPA\_CLI - Control interface commands**

Following commands can be used with [wpa\\_cli](#)

### **PING**

This command can be used to test whether wpa\_supplicant is replying to the control interface commands. The expected reply is PONG if the connection is open and wpa\_supplicant is processing commands.

### **STATUS**

Request current status information. The output is a text block with each line in variable=value format. For example:

```
bssid=02:00:01:02:03:04
ssid=test network
pairwise_cipher=CCMP
group_cipher=CCMP
key_mgmt=WPA-PSK
wpa_state=COMPLETED
```

### **LIST\_NETWORKS**

List configured networks.

```
network id / ssid / bssid / flags
0 example network any [CURRENT]
(note: fields are separated with tabs)
```

### **SCAN**

Request a new BSS scan.

### **SCAN\_RESULTS**

Get the latest scan results.

```
bssid / frequency / signal level / flags / ssid
00:09:5b:95:e0:4e 2412 208 [WPA-PSK-CCMP] jkm private
02:55:24:33:77:a3 2462 187 [WPA-PSK-TKIP] testing
00:09:5b:95:e0:4f 2412 209 jkm guest
(note: fields are separated with tabs)
```

## ADD\_NETWORK

Add a new network. This command creates a new network with empty configuration. The new network is disabled and once it has been configured it can be enabled with ENABLE\_NETWORK command. ADD\_NETWORK returns the **network id** of the new network or FAIL on failure

## SELECT\_NETWORK <network id>

Select a network (disable others). Network id can be received from the LIST\_NETWORKS command output.

## ENABLE\_NETWORK <network id>

Enable a network. Network id can be received from the LIST\_NETWORKS command output.

## DISABLE\_NETWORK <network id>

Disable a network. Network id can be received from the LIST\_NETWORKS command output. Special network id **all** can be used to disable all network.

## REMOVE\_NETWORK <network id>

Remove a network. Network id can be received from the LIST\_NETWORKS command output. Special network id **all** can be used to remove all network.

## SET\_NETWORK <network id> <variable> <value>

Set network variables. Network id can be received from the LIST\_NETWORKS command output. This command uses the same variables and data formats as the configuration file.

- ssid (network name, SSID)
- psk (WPA passphrase or pre-shared key)
- key\_mgmt (key management protocol, NONE, WPA-PSK, WPA-EAP)
- proto ( WPA WPA2)
- pairwise ( CCMP TKIP)
- group ( CCMP TKIP WEP40 WEP104)
- wep\_key0 ( set wep key for key index 0)
- wep\_tx\_keyidx ( select wep key index)

## GET\_NETWORK <network id> <variable>

Get network variables. Network id can be received from the LIST\_NETWORKS command output.

## SAVE\_CONFIG

Save the current configuration.

## AP\_SCAN <ap\_scan value>

Change ap\_scan value: 0 = no scanning, 1 = wpa\_supplicant requests scans and uses scan results to select the AP, 2 = wpa\_supplicant does not use scanning and just requests driver to associate and take care of AP selection