

1.3 INSTRUCTION SET 8086

The 8086 instructions are categorized into the following main types.

1. Data Copy / Transfer Instructions
2. Arithmetic and Logical Instructions
3. Shift and Rotate Instructions
4. Loop Instructions
5. Branch Instructions
6. String Instructions
7. Flag Manipulation Instructions
8. Machine Control Instructions

DATA COPY / TRANSFER INSTRUCTIONS:

The data transfer instructions move data between memory and the general-purpose and segment registers, and perform operations such as conditional moves, stack access, and data conversion.

There are four basic 8086 instructions for transferring quantities to and/or from the registers and memory such as,

- General purpose data transfer instructions
- I/O transfer instruction
- Special address transfer instruction
- Flag transfer instruction

General purpose data transfer instructions

- MOV
- PUSH
- POP
- XCHG
- XLAT

MOV:

This instruction copies a word or a byte of data from some source to a destination. The destination can be a register or a memory location. The source can be a register, a memory

S.No.	Type of Transfer	Instruction	Description
1.	Register to register	MOV AX,BX	MOV r1, r2 (Move Data; Move the content of the one register to another). [r1] <-- [r2]
2.	Immediate operand to a register	MOV AX,5000H	MOV r, data. (Move immediate data to register). [r] <-- data.
3.	Immediate operand to a memory location	MOV [8010H],5000H	MOV M, data. (Move immediate data to memory).M <-- data.
4.	Memory location to register	MOV AX,[8010H]	MOV r, m (Move the content of memory register).r <-- [M]
5.	Register to Memory location	MOV [8010H],AX	MOV M, r. (Move the content of register to memory).M <-- [r]
6.	Register to segment register(except CS)	MOV [BX],AX	MOV sr, r. (Move the content of register to segment register). [sr] <-- [r]
7.	segment register to register	MOV AX,[BX]	MOV sr, m. (Move the content of segment register to register).

location, or an immediate number.

Syntax:

MOV destination, source

Depending on the addressing modes it can transfer information from

			[r] <-- [sr]
8.	Segment register to memory	MOV [8010H],[BX]	MOV sr, m. (Move the content of segment register to memory). [M] <-- [sr]

SPECIAL ADDRESS TRANSFER

LEA: Load Effective Address

Load effective address of the operand into specified register

Eg: LEA BX,ADR :effective address of label ADR

LDS: Load DS register and other specified register from memory.

Eg. LDS BX,5000H

LES: Load ES register and other specified register from memory.

Eg. LES BX,5000H

Flag transfer instructions:LAHF:

Load (copy to) AH with the low byte the flag register. [AH] [Flags low byte]

SAHF:

Store (copy) AH registers to low byte of flag register. [Flags low byte] [AH]

PUSHF:

Copy flag register to top of stack.

POPF:

Copy word at top of stack to flag register.

Arithmetic Instructions:

The 8086 provides many arithmetic operations: addition, subtraction, negation, increment, decrement multiplication and comparing two values.

Addition Instruction:

- Add contents of two registers with or without carry

- Add contents of a registers and a memory with or without carry
- Add immediate data to a registers or a memory with or without carry
- Increment the content of a register or a memory location
- To perform ASCII adjustment after addition
- To perform decimal adjustment after addition

ADD:

The add instruction adds the contents of the source operand to the destination operand.

Syntax: ADD oper1, oper2

ADD AX, 0100H	Add immediate value to the content of AX
ADD AX, BX	Add contents of AX and BX and result in AX
ADD AX, [SI]	Add word from memory at offset [SI] in DS to the content of DX
ADD AX, [5000H]	Add content of data whose address is 5000H with AX and result in AX
ADD [5000H], 0100H	Add immediate value to the content of data whose address is 5000H and result in 5000H

ADC: Add with Carry

This instruction performs the same operation as ADD instruction, but adds the carry flag to the result.

ADC AX, 0100H	Add immediate value plus carry status to the content of AX
ADC AX, BX	Add contents of AX and BX plus carry status and result in AX
ADC AX, [SI]	Add word from memory at offset [SI] in DS plus carry status to the content of DX
ADC AX, [5000H]	Add content of data whose address is 5000H plus carry status with AX and result in AX
ADC [5000H], 0100H	Add immediate value to the content of data whose address is 5000H plus carry status and result in 5000H

INC: Increment

This instruction increases the contents of the specified Register or memory location.

Immediate data cannot be operand of this instruction. Eg. INCAX

INC [BX] INC [5000H]

AAA: ASCII Adjust After Addition

- The AAA instruction is executed after an ADD instruction that add two ASCII coded operand to give a byte of result in AL.
- The AAA instruction converts the resulting contents of AL to a unpacked decimal digits.
- After the addition it will check the lower 4 bits of AL is a valid BCD number in the range of 0 to 9
- If it is between 0 to 9 the AF is zero and AAA sets AH=0
- If lower digit of AL is between 0 to 9 AF is set, 06 is added to AL. The upper 4 bits of AL are cleared and AH is incremented by one
- If lower digit of AL greater than 9, then 06 is added to AL. The upper 4 bits of AL are cleared and AH is incremented by one.

DAA: Decimal Adjust After Addition

- The DAA instruction is executed after an ADD instruction that add two ASCII coded operand to give a byte of result in AL.
- The DAA instruction converts the resulting contents of AL to a unpacked decimal digits.
- If lower nibble is greater than 9, after addition it will add 06 to the lower nibble in AL.
- After adding 06 to lower nibble of AL, if upper nibble of AL is greater than 9, then adds 60H to AL.

Subtraction Instruction:

- Subtract contents of two registers with or without carry
- Subtract contents of a registers and a memory with or without carry
- Subtract immediate data to a registers or a memory with or without carry

- Decrement the content of a register or a memory location
- To perform ASCII adjustment after Subtract
- To perform decimal adjustment after Subtract

SUB: Subtract

The subtract instruction subtracts the source operand from the destination operand and the result is left in the destination operand.

SUB AX, 0100H	Subtract immediate value to the content of AX
SUB AX, BX	Subtract contents of AX and BX and result in AX
SUB AX, [SI]	Subtract word from memory at offset [SI] in DS to the content of DX
SUB AX, [5000H]	Subtract content of data whose address is 5000H with AX and result in AX
SUB [5000H], 0100H	Subtract immediate value to the content of data whose address is 5000H and result in 5000H

SBB: Subtract with Borrow

The subtract with borrow instruction subtracts the source operand and the borrow flag (CF) which may reflect the result of the previous calculations, from the destination operand

SBB AX, 0100H	Subtract immediate value plus carry status to the content of AX
SBB AX, BX	Subtract contents of AX and BX plus carry status and result in AX
SBB AX, [SI]	Subtract word from memory at offset [SI] in DS plus carry status to the content of DX
SBB AX, [5000H]	Subtract content of data whose address is 5000H plus carry status with AX and result in AX
SBB [5000H], 0100H	Subtract immediate value to the content of data whose address is 5000H plus carry status and result in 5000H

DEC: Decrement

The decrement instruction subtracts 1 from the contents of the specified register or memory location.

Eg. DEC AX DEC [5000H]

AAS: ASCII Adjust After Subtraction

- The AAA instruction is executed after an SUB instruction that subtracts two ASCII coded operand to give a byte of result in AL.
- The AAA instruction converts the resulting contents of AL to a unpacked decimal digits.
- After the addition it will check the lower 4 bits of AL is a valid BCD number in the range of 0 to 9
- If it is between 0 to 9 the AF is zero and AAA sets AH=0
- If lower digit of AL is between 0 to 9 AF is set, 06 is subtracted to AL. The upper 4 bits of AL are cleared and AH is incremented by one.
- If lower digit of AL greater than 9, then 06 is subtracted to AL. The upper 4 bits of AL are cleared and AH is incremented by one.

DAS: Decimal Adjust After Subtraction

- The DAA instruction is executed after an SUB instruction that subtract two ASCII coded operand to give a byte of result in AL.
- The DAA instruction converts the resulting contents of AL to a unpacked decimal digits.
- If lower nibble is greater than 9, after subtraction it will subtract 06 to the lower nibble in AL.
- After subtracting 06 to lower nibble of AL, if upper nibble of AL is greater than 9, then subtract 60H to AL.

NEG: Negate

The negate instruction forms 2's complement of the specified destination in the instruction. The destination can be a register or a memory location. This instruction can be implemented by inverting each bit and adding 1 to it.

Eg. NEG AL

AL = 0011 0101 35H

Replace number in AL with its 2's complement AL = 1100 1011 = CBH

CMP: Compare

This instruction compares the source operand, which may be a register or an immediate data or a memory location, with a destination operand that may be a register or a memory location

Eg. CMP BX, 0100H CMP AX, 0100H CMP [5000H], 0100H CMP BX, [SI] CMP BX, CX

Multiplication Instruction:

MUL: Unsigned Multiplication Byte or Word

This instruction multiplies an unsigned byte or word by the contents of AL. Eg. MUL BH;
(AX) (AL) x (BH)

MUL CX; (DX)(AX) (AX) x (CX)

MUL WORD PTR [SI]; (DX)(AX) (AX) x ([SI])

IMUL: Signed Multiplication

This instruction multiplies a signed byte in source operand by a signed byte in AL or a signed word in source operand by a signed word in AX.

Eg. IMUL BH IMUL CX IMUL [SI]

AAM: ASCII Adjust after Multiplication

This instruction, after execution, converts the product available in AL into unpacked BCD format.

Eg. MOV AL, 04; AL = 04 MOV BL, 09; BL = 09

MUL BL; AX = AL*BL; AX=24H AAM; AH = 03, AL=06

Division Instruction: DIV: Unsigned division

This instruction is used to divide an unsigned word by a byte or to divide an unsigned double word by a word.

Eg. DIV CL; Word in AX / byte in CL; Quotient in AL, remainder in AH

DIV CX; Double word in DX and AX / word; in CX, and Quotient in AX; remainder in DX

IDIV: Signed division

This instruction is used to divide a signed word by a byte or to divide a signed double word by a word.

Eg. IDIV CL; Word in AX / byte in CL; Quotient in AL, remainder in AH IDIV CX; Double word in DX and AX / word; in CX, and Quotient in AX; remainder in DX

AAD: ASCII Adjust before Division

This instruction converts two unpacked BCD digits in AH and AL to the equivalent binary number in AL. This adjustment must be made before dividing the two unpacked BCD digits in AX by an unpacked BCD byte. In the instruction sequence, this instruction appears before DIV instruction.

Eg. AX 05 08

AAD result in AL 00 3A 58D = 3A H in AL

The result of AAD execution will give the hexadecimal number 3A in AL and 00 in AH where 3A is the hexadecimal Equivalent of 58(decimal).

CBW: Convert Signed Byte to Word

This instruction copies the sign of a byte in AL to all the bits in AH. AH is then said to be sign extension of AL.

Eg. CBW

AX = 0000 0000 1001 1000 Convert signed byte in AL signed word in AX. Result in AX
= 1111 1111 1001 1000

CWD: Convert Signed Word to Double Word

This instruction copies the sign of a byte in AL to all the bits in AH. AH is then said to be sign extension of AL.

Eg. CWD

Convert signed word in AX to signed double word in DX: AX DX= 1111 1111 1111 1111

Result in AX = 1111 0000 1100 0001

Logical instructions AND: Logical AND

This instruction bit by bit ANDs the source operand that may be an immediate register or a memory location to the destination operand that may be a register or a memory location. The result is stored in the destination operand.

Syntax:

AND destination, source

Eg. AND AX, 0008H AND AX, BX

If the Content of AX is 3A0F

AX	0011	1010	0000	1111
AND				
0008	<u>0000</u>	<u>0000</u>	<u>0000</u>	1000
AX	<u>0000</u>	<u>0000</u>	<u>0000</u>	1000

OR: Logical OR

This instruction bit by bit ORs the source operand that may be an immediate, register or a memory location to the destination operand that may be a register or a memory location. The result is stored in the destination operand.

Syntax:

OR destination, source

bit.

Syntax:

NOT destination

XOR: Logical Exclusive OR

This instruction bit by bit XORs the source operand that may be an immediate, register or a memory location to the destination operand that may be a register or a memory location. The result is stored in the destination operand.

Syntax:

XOR destination, source

Eg.

XOR AX, 0098H
XOR AX, BX

TEST: Logical Compare Instruction

The TEST instruction performs a bit by bit logical AND operation on the two operands. The result of this ANDing operation is not available for further use, but flags are affected.

Syntax:

TEST destination, source

Eg.

TEST [0500], 06H

Shift and Rotate Instructions
SAL/SHL:

SAL and SHL are two mnemonics for the same instruction.

- This instruction shifts each bit in the specified destination to the left and 0 is stored at LSB position.
- The MSB is shifted into the carry flag.
- The destination can be a byte or a word.
- It can be in a register or in a memory location.
- The number of shifts is indicated by count.

Syntax:

SAL / SHL destination, count.

SHR: SHR destination, count

This instruction shifts each bit in the specified destination to the right and 0 is stored at MSB position.

- The LSB is shifted into the carry flag.
- The destination can be a byte or a word.
- It can be a register or in a memory location.
- The number of shifts is indicated by count.

Syntax:

SHR destination, count.

SAR: SAR destination, count

This instruction shifts each bit in the specified destination some number of bit positions to the right. As a bit is shifted out of the MSB position, a copy of the old MSB is put in the MSB position. The LSB will be shifted into CF.

Syntax:

SAR destination, count

ROL Instruction: Rotate left without carry

This instruction rotates all bits in a specified byte or word to the left some number of bit positions. MSB is placed as a new LSB and a new CF.

Syntax: ROL destination, count.
--

ROR Instruction: Rotate right without carry

This instruction rotates all bits in a specified byte or word to the right some number of bit

Syntax: ROR destination, count

RCL Instruction: Rotate left with carry

This instruction rotates all bits in a specified byte or word some number of bit positions to the left along with the carry flag. MSB is placed as a new carry and previous carry is placed as new LSB.

Syntax: RCL destination, count.

RCR Instruction: Rotate right with carry

This instruction rotates all bits in a specified byte or word some number of bit positions to the right *along with the carry flag*. LSB is placed as a new carry and previous carry is placed as new MSB.

Syntax: RCR destination, count.

Loop Instructions:

Unconditional LOOP Instructions

LOOP: LOOP Unconditionally

This instruction executes the part of the program from the Label or Address specified in the instruction upto the LOOP instruction CX number of times. At each iteration, CX is decremented automatically and JUMP IF NOT ZERO structure.

Example: MOV CX, 0004H

Conditional LOOP Instructions

LOOPZ / LOOPE Label

Loop through a sequence of instructions from label while ZF=1 and CX=0.

LOOPNZ / LOOPNE Label

Loop through a sequence of instructions from label while ZF=1 and CX=0.

Branch Instructions:

Branch Instructions transfers the flow of execution of the program to a new Address specified in the instruction directly or indirectly. When this type of instruction is executed, the CS and IP registers get loaded with new values of CS and IP corresponding to the location to be transferred. The Branch Instructions are classified into two types

1 Un Conditional Branch Instructions

2 Conditional Branch Instructions.

Unconditional Branch Instructions:

In Unconditional control transfer instructions, the execution control is transferred to the specified location independent of any status or condition. The CS and IP are unconditionally modified to the new CS and IP.

CALL: Unconditional Call

This instruction is used to call a Subroutine (Procedure) from a main program. Address of procedure may be specified directly or indirectly. There are two types of procedure depending upon whether it is available in the same segment or in another segment.

- i. Near CALL i.e., $\pm 32K$ displacement.
- ii. For CALL i.e., anywhere outside the segment.

On execution this instruction stores the incremented IP & CS onto the stack and loads the CS & IP registers with segment and offset Addresses of the procedure to be called.

RET: Return from the Procedure.

At the end of the procedure, the RET instruction must be executed. When it is executed, the previously stored content of IP and CS along with Flags are retrieved into the CS, IP and Flag registers from the stack and execution of the main program continues further.

INT N: Interrupt Type N.

In the interrupt structure of 8086, 256 interrupts are defined corresponding to the types from 00H to FFH. When INT N instruction is executed, the type byte N is multiplied by 4 and the contents of IP and CS of the interrupt service routine will be taken from memory block in 0000 segment.

INTO: Interrupt on Overflow

This instruction is executed, when the overflow flag OF is set. This is equivalent to a Type 4 Interrupt instruction.

JMP: Unconditional Jump

This instruction unconditionally transfers the control of execution to the specified Address using an 8-bit or 16-bit displacement. No Flags are affected by this instruction.

IRET: Return from ISR

When it is executed, the values of IP, CS and Flags are retrieved from the stack to continue the

When this instruction is executed, execution control is transferred to the Address specified relatively in the instruction, provided the condition implicit in the Opcode is satisfied. Otherwise execution continues sequentially.

JZ/JE Label

Transfer execution control to Address 'Label', if ZF=1.

JNZ/JNE Label

Transfer execution control to Address 'Label', if ZF=0

JS Label

Transfer execution control to Address 'Label', if SF=1.

JNS Label

Transfer execution control to Address 'Label', if SF=0.

JO Label

Transfer execution control to Address 'Label', if OF=1.

JNO Label

Transfer execution control to Address 'Label', if OF=0.

JNP Label

Transfer execution control to Address 'Label', if PF=0.

JP Label

Transfer execution control to Address 'Label', if PF=1.

JB Label

Transfer execution control to Address 'Label', if CF=1.

JNB Label

Transfer execution control to Address 'Label', if CF=0.

JCXZ Label

Transfer execution control to Address 'Label', if CX=0

String Manipulation Instructions

A series of data byte or word available in memory at consecutive locations, to be referred as Byte String or Word String. A String of characters may be located in consecutive memory locations, where each character may be represented by its ASCII equivalent. The 8086

- Starting and End Address of the String.
- Length of the String.

The length of the string is usually stored as count in the CX register. The incrementing or decrementing of the pointer, in string instructions, depends upon the Direction Flag (DF) Status. If it is a Byte string operation, the index registers are updated by one. On the other hand, if it is a word string operation, the index registers are updated by two.

REP: Repeat Instruction Prefix

This instruction is used as a prefix to other instructions, the instruction to which the REP prefix is provided, is executed repeatedly until the CX register becomes zero (at each iteration CX is automatically decremented by one).

- REPE / REPZ - repeat operation while equal / zero.
- REPNE / REPNZ - repeat operation while not equal / not zero.

These are used for CMPS, SCAS instructions only, as instruction prefixes.

MOVS / MOVSW: Move String Byte or String Word

Suppose a string of bytes stored in a set of consecutive memory locations is to be moved to another set of destination locations. The starting byte of source string is located in the memory location whose Address may be computed using SI (Source Index) and DS (Data Segment) contents. The starting Address of the destination locations where this string has to be relocated is given by DI (Destination Index) and ES (Extra Segment) contents.

CMPS: Compare String Byte or String Word

The CMPS instruction can be used to compare two strings of byte or words. The length of the string must be stored in the register CX. If both the byte or word strings are equal, zero Flag is set.

The REP instruction Prefix is used to repeat the operation till CX (counter) becomes zero or the condition specified by the REP Prefix is False.

SCAN: Scan String Byte or String Word

This instruction scans a string of bytes or words for an operand byte or word specified in the register AL or AX. The String is pointed to by ES: DI register pair. The length of the string stored in CX. The DF controls the mode for scanning of the string. Whenever a match to the

STOS: Store String Byte or String Word

The STOS instruction Stores the AL / AX register contents to a location in the string pointer by ES: DI register pair. The DI is modified accordingly, No Flags are affected by this instruction.

The direction Flag controls the String instruction execution, the source index SI and Destination Index DI are modified after each iteration automatically. If DF=1, then the execution follows auto decrement mode, SI and DI are decremented automatically after each iteration. If DF=0, then the execution follows auto increment mode. In this mode, SI and DI are incremented automatically after each iteration.

Flag Manipulation and Processor Control Instructions

These instructions control the functioning of the available hardware inside the processor chip.

These instructions are categorized into two types:

- Flag Manipulation instructions.
- Machine Control instructions.

Flag Manipulation instructions

The Flag manipulation instructions directly modify some of the Flags of 8086.

- i. CLC – Clear Carry Flag.
- ii. CMC – Complement Carry Flag.
- iii. STC – Set Carry Flag.
- iv. CLD – Clear Direction Flag.
- v. STD – Set Direction Flag.
- vi. CLI – Clear Interrupt Flag.
- vii. STI – Set Interrupt Flag.

Machine Control instructions

The Machine control instructions control the bus usage and execution

- i. WAIT – Wait for Test input pin to go low.
- ii. HLT – Halt the process.
- iii. NOP – No operation.
- iv. ESC – Escape to external device like NDP
- v. LOCK – Bus lock instruction prefix.