



Hypertext Transfer Protocol (NetX Duo HTTP)

User Guide

Express Logic, Inc.

858.613.6640
Toll Free 888.THREADX
FAX 858.521.4259

www.expresslogic.com

©2002-2013 by Express Logic, Inc.

All rights reserved. This document and the associated NetX software are the sole property of Express Logic, Inc. Each contains proprietary information of Express Logic, Inc. Reproduction or duplication by any means of any portion of this document without the prior written consent of Express Logic, Inc. is expressly forbidden. Express Logic, Inc. reserves the right to make changes to the specifications described herein at any time and without notice in order to improve design or reliability of NetX. The information in this document has been carefully checked for accuracy; however, Express Logic, Inc. makes no warranty pertaining to the correctness of this document.

Trademarks

NetX, Piconet, and UDP Fast Path are trademarks of Express Logic, Inc. ThreadX is a registered trademark of Express Logic, Inc.

All other product and company names are trademarks or registered trademarks of their respective holders.

Warranty Limitations

Express Logic, Inc. makes no warranty of any kind that the NetX products will meet the USER's requirements, or will operate in the manner specified by the USER, or that the operation of the NetX products will operate uninterrupted or error free, or that any defects that may exist in the NetX products will be corrected after the warranty period. Express Logic, Inc. makes no warranties of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, with respect to the NetX products. No oral or written information or advice given by Express Logic, Inc., its dealers, distributors, agents, or employees shall create any other warranty or in any way increase the scope of this warranty, and licensee may not rely on any such information or advice.

Part Number: 000-1054

Revision 5.2

Contents

Chapter 1 Introduction to HTTP	4
HTTP Requirements.....	4
HTTP Constraints.....	4
HTTP URL (Resource Names).....	5
HTTP Client Requests.....	5
HTTP Server Responses	6
HTTP Communication	6
HTTP Authentication	7
HTTP Authentication Callback.....	8
HTTP Request Callback.....	10
HTTP Multi-Thread Support	11
HTTP RFCs.....	11
Chapter 2 Installation and Use of HTTP	12
Product Distribution	12
HTTP Installation.....	12
Using HTTP	12
Small Example System	13
Configuration Options.....	21
Chapter 3 Description of HTTP Services	24
nx_http_client_create	26
nx_http_client_delete	28
nx_http_client_get_start	29
nxd_http_client_get_start	31
nx_http_client_get_packet.....	34
nx_http_client_put_start	36
nxd_http_client_put_start	38
nx_http_client_put_packet.....	40
nx_http_server_callback_data_send	42
nx_http_server_callback_response_send	44
nx_http_server_content_get	46
nx_http_server_content_get_extended	48
nx_http_server_content_length_get	50
nx_http_server_content_length_get_extended	51
nx_http_server_create.....	53
nx_http_server_delete.....	55
nx_http_server_param_get	56
nx_http_server_query_get.....	58
nx_http_server_start.....	60
nx_http_server_stop.....	61

Chapter 1

Introduction to HTTP

The Hypertext Transfer Protocol (HTTP) is a protocol designed for transferring content on the Web. HTTP is a simple protocol that utilizes reliable Transmission Control Protocol (TCP) services to perform its content transfer function. Because of this, HTTP is a highly reliable content transfer protocol. HTTP is one of the most used application protocols. All operations on the Web utilize the HTTP protocol. NetX Duo HTTP accommodates both IPv4 and IPv6 networks. IPv6 does not directly change the HTTP protocol, although some changes in the original NetX HTTP API are necessary to accommodate IPv6 and will be described in this document.

HTTP Requirements

In order to function properly, the NetX Duo HTTP package requires that a NetX Duo (version 5.2 or later) is installed. In addition, an IP instance must already be created and TCP must be enabled on that same IP instance. An IPv6 host application must set its linklocal and global IPv6 address using the IPv6 API and/or DHCPv6. The demo file in section “Small Example System” in **Chapter 2** will demonstrate how this is done.

The HTTP Client portion of the NetX Duo HTTP package has no further requirements.

The HTTP Server portion of the NetX Duo HTTP package has several additional requirements. First, it requires complete access to TCP *well-known port 80* for handling all Client HTTP requests. The HTTP Server is also designed for use with the FileX embedded file system. If FileX is not available, the user may port the portions of FileX used to their own environment. This is discussed in later sections of this guide.

HTTP Constraints

The NetX Duo HTTP protocol implements the HTTP 1.0 standard. However, there are following constraints:

1. Persistent connections are not supported
2. Request pipelining is not supported
3. The HTTP Server supports both basic and MD5 digest authentication, but not MD5-sess. At present, the HTTP Client supports only basic authentication.
4. No content compression is supported.
5. TRACE, OPTIONS, and CONNECT requests are not supported.
6. The packet pool associated with the HTTP Server or Client must be large enough to hold the complete HTTP header.
7. HTTP Client services are for content transfer only—there are no display utilities provided in this package.

HTTP URL (Resource Names)

The HTTP protocol is designed to transfer content on Web. The requested content is specified by the Universal Resource Locator (URL). This is the primary component of every HTTP request. URLs always start with a “/” character and typically correspond to files on the HTTP Server. Common HTTP file extensions are shown below:

Extension	Meaning
.htm (or .html)	Hypertext Markup Language (HTML)
.txt	Plain ASCII text
.gif	Binary GIF image
.xbm	Binary Xbitmap image

HTTP Client Requests

The HTTP has a simple mechanism for requesting Web content. There is basically a set of standard HTTP commands that are issued by the Client after a connection has been successfully established on the TCP *well-known port 80*. The following shows some of the basic HTTP commands:

HTTP Command	Meaning
GET resource HTTP/1.0	<i>Get the specified resource</i>
POST resource HTTP/1.0	<i>Get the specified resource and pass attached input to the HTTP Server</i>

HEAD resource HTTP/1.0 *Treated like a GET but not content is returned by the HTTP Server*

PUT resource HTTP/1.0 *Place resource on HTTP Server*

DELETE resource HTTP/1.0 *Delete resource on the Server*

These ASCII commands are generated internally by Web browsers and the NetX HTTP Client services to perform HTTP operations with an HTTP Server.

HTTP Server Responses

The HTTP Server utilizes the same *well-known TCP port 80* to send Client command responses. Once the HTTP Server processes the Client command, it returns an ASCII response string that includes a 3-digit numeric status code. The numeric response is used by the HTTP Client software to determine whether the operation succeeded or failed. Following is a list of various HTTP Server responses to Client commands:

Numeric Field	Meaning
200	<i>Request was successful</i>
400	<i>Request was not formed properly</i>
401	<i>Unauthorized request, client needs to send authentication</i>
404	<i>Specified resource in request was not found</i>
500	<i>Internal HTTP Server error</i>
501	<i>Request not implemented by HTTP Server</i>
502	<i>Service is not available</i>

For example, a successful Client request to PUT the file “test.htm” is responded with the message “HTTP/1.0 200 OK.”

HTTP Communication

As mentioned previously, the HTTP Server utilizes the *well-known TCP port 80* to field Client requests. HTTP Clients may use any available TCP port. The general sequence of HTTP events is as follows:

HTTP GET Request:

1. Client issues TCP connect to Server port 80.
2. Client sends “**GET resource HTTP/1.0**” request (along with other header information).
3. Server builds an “**HTTP/1.0 200 OK**” message with additional information followed immediately by the resource content (if any).
4. Server performs a disconnection.
5. Client performs a disconnection.

HTTP PUT Request:

1. Client issues TCP connect to Server port 80.
2. Client sends “**PUT resource HTTP/1.0**” request, along with other header information, and followed by the resource content.
3. Server builds an “**HTTP/1.0 200 OK**” message with additional information followed immediately by the resource content.
4. Server performs a disconnection.
5. Client performs a disconnection.

HTTP Authentication

HTTP authentication is optional and isn't required for all Web requests. There are two flavors of authentication, namely *basic* and *digest*. Basic authentication is equivalent to the *name* and *password* authentication found in many protocols. In HTTP basic authentication, the name and passwords are concatenated and encoded in the base64 format. The main disadvantage of basic authentication is the name and password are transmitted openly in the request. This makes it somewhat easy for the name and password to be stolen. Digest authentication addresses this problem by never transmitting the name and password in the request. Instead, an algorithm is used to derive a 128-bit key or digest from the name, password, and other information. The NetX HTTP Server supports the standard MD5 digest algorithm.

When is authentication required? Basically, the HTTP Server decides if a requested resource requires authentication. If authentication is required and the Client request did not include the proper authentication, a “HTTP/1.0 401 Unauthorized” response with the type of authentication

required is sent to the Client. The Client is then expected to form a new request with the proper authentication.

HTTP Authentication Callback

As mentioned before, HTTP authentication is optional and isn't required on all Web transfers. In addition, authentication is typically resource dependent. Access of some resources on the Server require authentication, while others do not. The NetX HTTP Server package allows the application to specify (via the ***nx_http_server_create*** call) an authentication callback routine that is called at the beginning of handling each HTTP Client request.

The callback routine provides the NetX HTTP Server with the username, password, and realm strings associated with the resource and return the type of authentication necessary. If no authentication is necessary for the resource, the authentication callback should return the value of ***NX_HTTP_DONT_AUTHENTICATE***. Otherwise, if basic authentication is required for the specified resource, the routine should return ***NX_HTTP_BASIC_AUTHENTICATE***. And finally, if MD5 digest authentication is required, the callback routine should return ***NX_HTTP_DIGEST_AUTHENTICATE***. If no authentication is required for any resource provided by the HTTP Server, the callback is not needed and a NULL pointer can be provided to the HTTP Server create call.

The format of the application authenticate callback routine is very simple and is defined below:

```
UINT nx_http_server_authentication_check(NX_HTTP_SERVER *server_ptr,
    UINT request_type, CHAR *resource,
    CHAR **name, CHAR **password, CHAR **realm);
```

The input parameters are defined as follows:

Parameter	Meaning
<i>request_type</i>	Specifies the HTTP Client request, valid requests are defined as: <i>NX_HTTP_SERVER_GET_REQUEST</i> <i>NX_HTTP_SERVER_POST_REQUEST</i> <i>NX_HTTP_SERVER_HEAD_REQUEST</i> <i>NX_HTTP_SERVER_PUT_REQUEST</i> <i>NX_HTTP_SERVER_DELETE_REQUEST</i>
<i>resource</i>	Specific resource requested.

<i>name</i>	Destination for the pointer to the required username.
<i>password</i>	Destination for the pointer to the required password.
<i>realm</i>	Destination for the pointer to the realm for this authentication.

The return value of the authentication routine specifies whether or not authentication is required. Of course, the name, password, and realm pointers are not used if **NX_HTTP_DONT_AUTHENTICATE** is returned by the authentication callback routine.

HTTP Request Callback

In addition to the authentication callback, the application can set up a callback routine that is called from the HTTP Server at the beginning of processing each client request (after authentication is complete). This routine is useful in order to extract parameters from the request and to perform some basic operations on the request contents. If this is not required by the application, a NULL pointer should be provided during the HTTP Server create call.

The application request callback routine is very simple and is defined below:

```
UINT nx_http_server_request_notify(NX_HTTP_SERVER *server_ptr,
                                   UINT request_type, CHAR *resource, NX_PACKET *packet_ptr);
```

The input parameters are defined as follows:

Parameter	Meaning
<i>request_type</i>	Specifies the HTTP Client request, valid requests are defined as: NX_HTTP_SERVER_GET_REQUEST NX_HTTP_SERVER_POST_REQUEST NX_HTTP_SERVER_HEAD_REQUEST NX_HTTP_SERVER_PUT_REQUEST NX_HTTP_SERVER_DELETE_REQUEST
<i>resource</i>	Specific resource requested.
<i>packet_ptr</i>	Pointer to the raw request packet.

If everything is okay, the output of this callback function should be **NX_SUCCESS**. Otherwise, if the callback function detects an error, it should return an **NX_HTTP_ERROR** message. This will cause the HTTP Server to send an error response to the client. If the callback function completes the service, it should return an **NX_HTTP_CALLBACK_COMPLETED**.

There are several routines available to extract HTTP parameters, queries, and packet content from the request. These routines are listed below and defined later in this document:

nx_http_server_content_get
nx_http_server_content_length_get
nx_http_server_param_get
nx_http_server_query_get

If the callback function for GET and POST requests needs to supply dynamic data in order to complete the request, it can process the request directly and when finished return with the **NX_HTTP_CALLBACK_COMPLETED** status. In addition to the routines mention above, the following routines are available for GET/POST callback routines:

nx_http_server_callback_data_send
nx_http_server_callback_response_send

HTTP Multi-Thread Support

The NetX HTTP Client services can be called from multiple threads simultaneously. However, read or write requests for a particular HTTP Client instance should be done in sequence from the same thread.

HTTP RFCs

NetX HTTP is compliant with RFC1945 and related RFCs.

Chapter 2

Installation and Use of HTTP

This chapter contains a description of various issues related to installation, setup, and usage of the NetX HTTP component.

Product Distribution

HTTP for NetX is shipped on a single CD-ROM compatible disk. The package includes three source files, two include files, and a PDF file that contains this document, as follows:

<code>nxd_http_client.h</code>	Header file for HTTP Client for NetX Duo
<code>nxd_http_server.h</code>	Header file for HTTP Server for NetX Duo
<code>nxd_http_client.c</code>	C Source file for HTTP Client for NetX Duo
<code>nxd_http_server.c</code>	C Source file for HTTP Server for NetX Duo
<code>md5.c</code>	MD5 digest algorithms
<code>filex_stub.h</code>	Stub file if FileX is not present
<code>nxd_http.pdf</code>	PDF description of HTTP for NetX Duo
<code>demo_netxdue_http.c</code>	NetX Duo HTTP demonstration

HTTP Installation

In order to use HTTP for NetX Duo, the entire distribution mentioned previously should be copied to the same directory where NetX Duo is installed. For example, if NetX Duo is installed in the directory “*threadx\arm7\green*” then the *nxd_http_client.h* and *nxd_http_client.c* for NetX Duo HTTP Client applications, and *nxd_http_server.h* and *ndx_http_server.c* for NetX Duo HTTP Server applications. *md5.c* should be copied into this directory. For the demo ‘ram driver’ application NetX Duo HTTP Client and Server files should be copied into the same directory.

Using HTTP

Using HTTP for NetX Duo is easy. Basically, the application code must include *nxd_http_client.h* and/or *nxd_http_server.h* after it includes *tx_api.h*, *fx_api.h*, and *nx_api.h*, in order to use ThreadX, FileX, and NetX Duo, respectively. Once the HTTP header files are included, the application code is then able to make the HTTP function calls specified later in this guide. The application must also include *nxd_http_client.c*,

nxd_http_server.c, and *md5.c* in the build process. These files must be compiled in the same manner as other application files and its object form must be linked along with the files of the application. This is all that is required to use NetX Duo HTTP.

Note that if `NX_HTTP_DIGEST_ENABLE` is not specified in the build process, the *md5.c* file does not need to be added to the application. Similarly, if no HTTP Client capabilities are required, the *nxd_http_client.c* file may be omitted.

Note also that since HTTP utilizes NetX Duo TCP services, TCP must be enabled with the *nx_tcp_enable* call prior to using HTTP.

Small Example System

An example of how easy it is to use NetX Duo HTTP is described in Figure 1.1 that appears below. This example works with the 'duo' services available in NetX Duo HTTP placement of `#define USE_DUO` on line 23. Otherwise it uses the legacy NetX HTTP equivalent (limited to IPv4 only). Developers are encouraged to migrate existing applications to using the NetX Duo HTTP services.

To specify IPv6 communication, the application defines `IPTYPE` to IPv6 in line 24.

In this example, the HTTP include files *nxd_http_client.h* and *nxd_http_server.h* are brought in at line 8 and 9. Next, the helper HTTP Server thread, packet pool and IP instance are created in lines 89 – 112. The HTTP Server IP instance must be TCP enabled, as seen in line 137. The HTTP Server is then itself created in at line 159.

Next the HTTP Client is created. First the client thread is created in line 172 followed by packet pool and IP instance, similar to the HTTP Server, in lines 186 – 200. Again the HTTP Client IP instance must be TCP enabled (line 217).

The helper HTTP Server thread runs and its first task is validate its IP address with NetX Duo which it does in lines 423 - 450. Now the HTTP Server is ready to take requests.

The HTTP Client thread's first task is create and format the FileX media (lines 236 and 260. After the media is initialized, the HTTP Client is created in line 271. This must be done before the HTTP server can service HTTP requests. It must then validate its IP address with NetX Duo

which it does in lines 282 – 316. The HTTP Client then creates and sends the file `client_test.html` to the HTTP Server, waits briefly, then attempts to read the file back from the HTTP Server. Note where the HTTP Client API uses a different service call if IPv6 is not enabled (*`nx_http_client_put_start`* in line 343 and *`nx_http_client_get_start`* in line 399). This enables NetX Duo to support existing NetX HTTP Client applications.

Note that the HTTP Client API calls are made with relatively short timeouts. It may be necessary to extend those timeouts if an HTTP client is communicating with a busy server or remote server on a slower processor.

```

1  /* This is a small demo of the NetX Duo HTTP Client Server API running on a
2     high-performance NetX Duo TCP/IP stack. This demo is applicable for
3     either IPv4 or IPv6 enabled applications. */
4
5  #include "tx_api.h"
6  #include "fx_api.h"
7  #include "nx_api.h"
8  #include "nxd_http_client.h"
9  #include "nxd_http_server.h"
10
11 #define DEMO_STACK_SIZE 2048
12
13 /* Set up Filex and file memory resources. */
14 CHAR *ram_disk_memory;
15 FX_MEDIA ram_disk;
16 unsigned char media_memory[512];
17
18 /* Define device drivers. */
19 extern void _fx_ram_driver(FX_MEDIA *media_ptr);
20 VOID _nx_ram_network_driver(NX_IP_DRIVER *driver_req_ptr);
21
22
23 #define USE_DUO /* Use the duo service (not legacy netx) */
24 #define IPTYPE 6 /* Send packets over IPv6 */
25
26 /* Set up the HTTP client. */
27 TX_THREAD client_thread;
28 NX_PACKET_POOL client_pool;
29 NX_HTTP_CLIENT my_client;
30 NX_IP client_ip;
31 #define CLIENT_PACKET_SIZE (NX_HTTP_SERVER_MIN_PACKET_SIZE * 2)
32 void thread_client_entry(ULONG thread_input);
33
34 #define HTTP_SERVER_ADDRESS IP_ADDRESS(1,2,3,4)
35 #define HTTP_CLIENT_ADDRESS IP_ADDRESS(1,2,3,5)
36
37 /* Set up the HTTP server */
38
39 NX_HTTP_SERVER my_server;
40 NX_PACKET_POOL server_pool;
41 TX_THREAD server_thread;
42 NX_IP server_ip;
43 #define SERVER_PACKET_SIZE (NX_HTTP_SERVER_MIN_PACKET_SIZE * 2)
44
45 void thread_server_entry(ULONG thread_input);
46 #ifdef FEATURE_NX_IPV6
47 NXD_ADDRESS server_ip_address;
48 #endif
49
50
51 /* Define the application's authentication check. This is called by
52 the HTTP server whenever a new request is received. */
53 UINT authentication_check(NX_HTTP_SERVER *server_ptr, UINT request_type,
54 CHAR *resource, CHAR **name, CHAR **password, CHAR **realm)
55 {
56
57     /* Just use a simple name, password, and realm for all
58 requests and resources. */
59     *name = "name";
60     *password = "password";
61     *realm = "NetX Duo HTTP demo";

```

```

62
63     /* Request basic authentication. */
64     return(NX_HTTP_BASIC_AUTHENTICATE);
65 }
66
67 /* Define main entry point. */
68
69 int main()
70 {
71
72     /* Enter the ThreadX kernel. */
73     tx_kernel_enter();
74 }
75
76
77 /* Define what the initial system looks like. */
78 void tx_application_define(void *first_unused_memory)
79 {
80
81     CHAR    *pointer;
82     UINT    status;
83
84
85     /* Setup the working pointer. */
86     pointer = (CHAR *) first_unused_memory;
87
88     /* Create a helper thread for the server. */
89     tx_thread_create(&server_thread, "HTTP Server thread", thread_server_entry, 0,
90                     pointer, DEMO_STACK_SIZE,
91                     1, 1, TX_NO_TIME_SLICE, TX_AUTO_START);
92
93     pointer = pointer + DEMO_STACK_SIZE;
94
95     /* Initialize the NetX system. */
96     nx_system_initialize();
97
98     /* Create the server packet pool. */
99     status = nx_packet_pool_create(&server_pool, "HTTP Server Packet Pool",
100                                SERVER_PACKET_SIZE, pointer, SERVER_PACKET_SIZE*4);
101
102     pointer = pointer + SERVER_PACKET_SIZE * 4;
103
104     /* Check for pool creation error. */
105     if (status)
106     {
107
108         return;
109     }
110
111     /* Create an IP instance. */
112     status = nx_ip_create(&server_ip, "HTTP Server IP", HTTP_SERVER_ADDRESS,
113                          0xFFFFFFFFUL, &server_pool, _nx_ram_network_driver,
114                          pointer, 4096, 1);
115
116     pointer = pointer + 4096;
117
118     /* Check for IP create errors. */
119     if (status)
120     {
121         printf("nx_ip_create failed. Status 0x%x\n", status);
122         return;
123     }
124
125     /* Enable ARP and supply ARP cache memory for the server IP instance. */
126     status = nx_arp_enable(&server_ip, (void *) pointer, 1024);
127
128     /* Check for ARP enable errors. */
129     if (status)
130     {
131         return;
132     }
133
134     pointer = pointer + 1024;
135
136     /* Enable TCP traffic. */
137     status = nx_tcp_enable(&server_ip);
138
139     if (status)
140     {
141         return;

```

```

142     }
143
144     #if (IP_TYPE==6)
145
146         /* Set up HTTPv6 server, but we have to wait till its address has been
147            validated before we can start the thread_server_entry thread. */
148
149         /* Set up the server's IPv6 address here. */
150         server_ip_address.nxd_ip_address.v6[3] = 0x105;
151         server_ip_address.nxd_ip_address.v6[2] = 0x0;
152         server_ip_address.nxd_ip_address.v6[1] = 0x0000f101;
153         server_ip_address.nxd_ip_address.v6[0] = 0x20010db8;
154         server_ip_address.nxd_ip_version = NX_IP_VERSION_V6;
155
156     #endif
157
158     /* Create the NetX HTTP Server. */
159     status = nx_http_server_create(&my_server, "My HTTP Server", &server_ip,
                                   &ram_disk, pointer, 2048, &server_pool, authentication_check,
                                   NX_NULL);
160
161     if (status)
162     {
163         return;
164     }
165
166     pointer = pointer + 2048;
167
168     /* Save the memory pointer for the RAM disk. */
169     ram_disk_memory = pointer;
170
171     /* Create the HTTP client thread. */
172     status = tx_thread_create(&client_thread, "HTTP Client", thread_client_entry, 0,
173                             pointer, DEMO_STACK_SIZE,
174                             2, 2, TX_NO_TIME_SLICE, TX_AUTO_START);
175
176     pointer = pointer + DEMO_STACK_SIZE;
177
178     /* Check for thread create error. */
179     if (status)
180     {
181
182         return;
183     }
184
185     /* Create the Client packet pool. */
186     status = nx_packet_pool_create(&client_pool, "HTTP Client Packet Pool",
                                   SERVER_PACKET_SIZE, pointer, SERVER_PACKET_SIZE*4);
187
188
189     pointer = pointer + SERVER_PACKET_SIZE * 4;
190
191     /* Check for pool creation error. */
192     if (status)
193     {
194
195         return;
196     }
197
198
199     /* Create an IP instance. */
200     status = nx_ip_create(&client_ip, "HTTP Client IP", HTTP_CLIENT_ADDRESS,
201                          0xFFFFF00UL, &client_pool, _nx_ram_network_driver,
202                          pointer, 2048, 1);
203
204     pointer = pointer + 2048;
205
206     /* Check for IP create errors. */
207     if (status)
208     {
209         return;
210     }
211
212     nx_arp_enable(&client_ip, (void *) pointer, 1024);
213
214     pointer = pointer + 2048;
215
216     /* Enable TCP traffic. */
217     nx_tcp_enable(&client_ip);
218

```



```

219     return;
220 }
221
222
223 VOID thread_client_entry(ULONG thread_input)
224 {
225
226     UINT                status;
227     NX_PACKET           *my_packet;
228     #ifdef FEATURE_NX_IPV6
229     NXD_ADDRESS         client_ip_address;
230     #endif
231
232
233     /* Format the RAM disk - the memory for the RAM disk was setup in
234     tx_application_define above. This must be set up before the client(s) start
235     sending requests. */
236     status = fx_media_format(&ram_disk,
237                             _fx_ram_driver,          // Driver entry
238                             ram_disk_memory,         // RAM disk memory pointer
239                             media_memory,           // Media buffer pointer
240                             sizeof(media_memory),    // Media buffer size
241                             "MY_RAM_DISK",           // Volume Name
242                             1,                       // Number of FATs
243                             32,                     // Directory Entries
244                             0,                       // Hidden sectors
245                             256,                    // Total sectors
246                             128,                    // Sector size
247                             1,                       // Sectors per cluster
248                             1,                       // Heads
249                             1);                     // Sectors per track
250
251     /* Check the media format status. */
252     if (status != FX_SUCCESS)
253     {
254
255         /* Error, bail out. */
256         return ;
257     }
258
259     /* Open the RAM disk. */
260     status = fx_media_open(&ram_disk, "RAM DISK", _fx_ram_driver, ram_disk_memory,
261                             media_memory, sizeof(media_memory));
262
263     /* Check the media open status. */
264     if (status != FX_SUCCESS)
265     {
266
267         /* Error, bail out. */
268         return ;
269     }
270
271     /* Create an HTTP client instance. */
272     status = nx_http_client_create(&my_client, "HTTP client", &client_ip,
273                                     &client_pool, 600);
274
275     /* Check status. */
276     if (status != NX_SUCCESS)
277     {
278         return;
279     }
280
281     /* Attempt to upload a file to the HTTP server. */
282
283     #if (IPTYPE== 6)
284
285     /* Relinquish control so the HTTP server can get set up...*/
286     tx_thread_relinquish();
287
288     /* Set up the client's IPv6 address here. */
289     client_ip_address.nxd_ip_address.v6[3] = 0x101;
290     client_ip_address.nxd_ip_address.v6[2] = 0x0;
291     client_ip_address.nxd_ip_address.v6[1] = 0x0000f101;
292     client_ip_address.nxd_ip_address.v6[0] = 0x20010db1;
293     client_ip_address.nxd_ip_version = NX_IP_VERSION_V6;
294
295     /* Here's where we make the HTTP client IPv6 enabled. */
296     nxd_ipv6_enable(&client_ip);
297

```

```

298     nxd_icmp_enable(&client_ip);
299
300     /* wait till the IP task thread has set the device MAC address. */
301
302     tx_thread_sleep(100);
303
304
305     /* Now update NetX Duo the Client's link local and global IPv6 address. */
306
307     nxd_ipv6_linklocal_address_set(&client_ip, NULL);
308
309     nxd_ipv6_global_address_set(&client_ip, &client_ip_address, 64);
310
311
312     /* Then make sure NetX Duo has had time to validate the addresses. */
313
314
315     tx_thread_sleep(400);
316
317
318
319
320
321     /* Now upload an HTML file to the HTTPv6 server. */
322     status = nxd_http_client_put_start(&my_client, &server_ip_address,
323                                     "/client_test.htm", "name", "password", 103, 500);
324
325
326     /* Check status. */
327     if (status != NX_SUCCESS)
328     {
329
330         return;
331     }
332
333
334     #else
335
336     /* Relinquish control so the HTTP server can get set up...*/
337     tx_thread_relinquish();
338
339     do
340     {
341
342         /* Attempt to upload to the HTTP IPv4 server. */
343         status = nx_http_client_put_start(&my_client, HTTP_SERVER_ADDRESS,
344                                         "/client_test.htm", "name", "password", 103, 500);
345
346
347         /* Check status. */
348         if (status != NX_SUCCESS)
349         {
350             tx_thread_sleep(100);
351         }
352     } while (status != NX_SUCCESS);
353
354
355     #endif /* (IPTYPE== 6) */
356
357
358     /* Allocate a packet. */
359     status = nx_packet_allocate(&client_pool, &my_packet, NX_TCP_PACKET,
360                               NX_WAIT_FOREVER);
361
362     /* Check status. */
363     if (status != NX_SUCCESS)
364     {
365         return;
366     }
367
368     /* Build a simple 103-byte HTML page. */
369     nx_packet_data_append(my_packet, "<HTML>\r\n", 8,
370                          &client_pool, NX_WAIT_FOREVER);
371     nx_packet_data_append(my_packet,
372                          "<HEAD><TITLE>NetX HTTP Test</TITLE></HEAD>\r\n", 44,
373                          &client_pool, NX_WAIT_FOREVER);
374     nx_packet_data_append(my_packet, "<BODY>\r\n", 8,
375                          &client_pool, NX_WAIT_FOREVER);
376     nx_packet_data_append(my_packet, "<H1>Another NetX Test Page!</H1>\r\n", 25,

```

```

376         &client_pool, NX_WAIT_FOREVER);
377 nx_packet_data_append(my_packet, "</BODY>\r\n", 9,
378         &client_pool, NX_WAIT_FOREVER);
379 nx_packet_data_append(my_packet, "</HTML>\r\n", 9,
380         &client_pool, NX_WAIT_FOREVER);
381
382 /* Complete the PUT by writing the total length. */
383 status = nx_http_client_put_packet(&my_client, my_packet, 50);
384
385 /* Check status. */
386 if (status != NX_SUCCESS)
387 {
388     return;
389 }
390
391 /* Now GET the test file */
392
393 #ifdef USE_DUO
394
395     status = nxd_http_client_get_start(&my_client, &server_ip_address,
396     "/client_test.htm", NX_NULL, 0, "name", "password", 50);
397 #else
398     status = nx_http_client_get_start(&my_client, HTTP_SERVER_ADDRESS,
399     "/client_test.htm", NX_NULL, 0, "name", "password", 50);
400 #endif
401
402 /* Check status. */
403 if (status != NX_SUCCESS)
404 {
405     return;
406 }
407
408 status = nx_http_client_delete(&my_client);
409
410 return;
411
412 }
413
414
415 /* Define the helper HTTP server thread. */
416 void thread_server_entry(ULONG thread_input)
417 {
418
419     UINT status;
420
421
422
423     #if (IPTYPE == 6)
424
425         /* Give NetX Duo time for auto configuration e.g. DAD. */
426         tx_thread_sleep(100);
427
428         /* Here's where we make the HTTP server IPv6 enabled. */
429
430         nxd_ipv6_enable(&server_ip);
431         nxd_icmp_enable(&server_ip);
432
433         /* Wait till the IP task thread has had a chance to set the device MAC address.
434         */
435         while (server_ip.nx_ip_arp_physical_address_msw == 0 ||
436             server_ip.nx_ip_arp_physical_address_lsw == 0)
437         {
438             tx_thread_sleep(30);
439         }
440
441         nxd_ipv6_linklocal_address_set(&server_ip, NULL);
442         nxd_ipv6_global_address_set(&server_ip, &server_ip_address, 64);
443
444         /* Wait for NetX Duo to validate server address. */
445         while (server_ip.nx_ipv6_global.nxd_interface_address_state!=
446             NX_IPV6_ADDR_STATE_VALID)
447         {
448             tx_thread_sleep(100);
449         }
450
451     #endif /* (IPTYPE == 6) */
452
453     /* OK to start the HTTPv6 Server. */

```

```
454     status = nx_http_server_start(&my_server);
455
456     if (status != NX_SUCCESS)
457     {
458         return;
459     }
460
461     /* HTTP server ready to take requests! */
462
463     /* Let the IP threads execute.    */
464     tx_thread_relinquish();
465
466     return;
467 }
```

Figure 1.1 Example of HTTP use with NetX Duo

Configuration Options

There are several configuration options for building HTTP for NetX Duo. Following is a list of all options, where each is described in detail. The default values are listed, but can be redefined prior to inclusion of *nxd_http.h*:

Define	Meaning
NX_DISABLE_ERROR_CHECKING	Defined, this option removes the basic HTTP error checking. It is typically used after the application has been debugged.
NX_HTTP_SERVER_PRIORITY	The priority of the HTTP Server thread. By default, this value is defined as 16 to specify priority 16.
NX_HTTP_NO_FILEX	Defined, this option provides a stub for FileX dependencies. The HTTP Client will function without any change if this option is defined. The HTTP Server will need to either be modified or the user will have to create a handful of FileX services in order to function properly.
NX_HTTP_TYPE_OF_SERVICE	Type of service required for the HTTP TCP requests. By default, this value is defined as NX_IP_NORMAL to indicate normal IP packet service.
NX_HTTP_FRAGMENT_OPTION	Fragment enable for HTTP TCP requests. By default, this value is NX_DONT_FRAGMENT to disable HTTP TCP fragmenting.
NX_HTTP_SERVER_WINDOW_SIZE	Server socket window size. By default, this value is 2048 bytes.
NX_HTTP_TIME_TO_LIVE	Specifies the number of routers this packet can pass before it is

discarded. The default value is set to 0x80.

NX_HTTP_SERVER_TIMEOUT

Specifies the number of ThreadX ticks that internal services will suspend for. The default value is set to 1000.

NX_HTTP_SERVER_MAX_PENDING

Specifies the number of connections that can be queued for the HTTP Server. The default value is set to 5.

NX_HTTP_MAX_RESOURCE

Specifies the number of bytes allowed in a client supplied *resource name*. The default value is set to 40.

NX_HTTP_NAME_SIZE

Specifies the number of bytes allowed in a client supplied *username*. The default value is set to 20.

NX_HTTP_PASSWORD_SIZE

Specifies the number of bytes allowed in a client supplied *password*. The default value is set to 20.

NX_HTTP_SERVER_MIN_PACKET_SIZE

Specifies the minimum size of the packets in the pool specified at Server creation. The minimum size is needed to ensure the complete HTTP header can be contained in one packet. The default value is set to 600.

NX_HTTP_CLIENT_MIN_PACKET_SIZE

Specifies the minimum size of the packets in the pool specified at Client creation. The minimum size is needed to ensure the complete HTTP header can be contained in one packet. The default value is set to 300.

Chapter 3

Description of HTTP Services

This chapter contains a description of all NetX Duo HTTP services (listed below) in alphabetical order except for the 'NetX' (IPv4 only) equivalent of the same service are paired together).

In the "Return Values" section in the following API descriptions, values in **BOLD** are not affected by the **NX_DISABLE_ERROR_CHECKING** define that is used to disable API error checking, while non-bold values are completely disabled.

```

nx_http_client_create
    Create an HTTP Client Instance

nx_http_client_delete
    Delete an HTTP Client instance

nx_http_client_get_start
    Start an HTTP GET request (IPv4 only)

nxd_http_client_get_start
    Start an HTTP GET request (IPv4 or IPv6)

nx_http_client_get_packet
    Get next resource data packet

nx_http_client_put_start
    Start an HTTP PUT request (IPv4 only)

nxd_http_client_put_start
    Start an HTTP PUT request (IPv4 or IPv6)

nx_http_client_put_packet
    Send next resource data packet

nx_http_server_callback_data_send
    Send data from callback function

nx_http_server_callback_response_send
    Send response from callback function

```


`nx_http_server_content_get`
Get content from the request

`nx_http_server_content_get_extended`
Get content from the request; supports empty (zero Content Length) requests

`nx_http_server_content_length_get`
Get length of content in the request

`nx_http_server_content_length_get_extended`
Get length of content in the request; supports empty (zero Content Length) requests

`nx_http_server_create`
Create an HTTP Server instance

`nx_http_server_delete`
Delete an HTTP Server instance

`nx_http_server_param_get`
Get parameter from the request

`nx_http_server_query_get`
Get query from the request

`nx_http_server_start`
Start the HTTP Server

`nx_http_server_stop`
Stop the HTTP Server

nx_http_client_create

Create an HTTP Client Instance

Prototype

```
UINT nx_http_client_create(NX_HTTP_CLIENT *client_ptr,
                          CHAR *client_name, NX_IP *ip_ptr, NX_PACKET_POOL *pool_ptr,
                          ULONG window_size);
```

Description

This service creates an HTTP Client instance on the specified IP instance.

Input Parameters

client_ptr	Pointer to HTTP Client control block.
client_name	Name of HTTP Client instance.
ip_ptr	Pointer to IP instance.
pool_ptr	Pointer to default packet pool. Note that the packets in this pool must have a payload large enough to handle the complete response header. This is defined by NX_HTTP_CLIENT_MIN_PACKET_SIZE in nx_http.h.
window_size	Size of the Client's TCP socket receive window.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Client create.
NX_HTTP_ERROR	(0xE0)	HTTP Client create error.
NX_PTR_ERROR	(0x16)	Invalid HTTP, ip_ptr, or packet pool pointer.
NX_HTTP_POOL_ERROR	(0xE9)	Invalid payload size in packet pool.

Allowed From

Initialization, Threads

Example

```
/* Create the HTTP Client instance "my_client" on "ip_0". */
status = nx_http_client_create(&my_client, "my client", &ip_0, &pool_0, 100);

/* If status is NX_SUCCESS an HTTP Client instance was successfully
   created. */
```

See Also

`nx_http_client_delete`, `nx_http_client_get_start`, `nx_http_server_create`,
`nx_http_server_delete`, `nx_http_server_start`, `nx_http_server_stop`

nx_http_client_delete

Delete an HTTP Client Instance

Prototype

```
UINT nx_http_client_delete(NX_HTTP_CLIENT *client_ptr);
```

Description

This service deletes a previously created HTTP Client instance.

Input Parameters

client_ptr Pointer to HTTP Client control block.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Client delete.
NX_HTTP_ERROR	(0xE0)	HTTP Client delete error.
NX_PTR_ERROR	(0x16)	Invalid HTTP pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Delete the HTTP Client instance "my_client." */
status = nx_http_client_delete(&my_client);

/* If status is NX_SUCCESS an HTTP Client instance was successfully
   deleted. */
```

See Also

nx_http_client_create, nx_http_client_get_start, nx_http_server_create,
nx_http_server_delete, nx_http_server_start, nx_http_server_stop

nx_http_client_get_start

Start an HTTP GET request over IPv4

Prototype

```
UINT nx_http_client_get_start(NX_HTTP_CLIENT *client_ptr,
                             ULONG ip_address, CHAR *resource, CHAR *input_ptr,
                             UINT input_size, CHAR *username, CHAR *password,
                             ULONG wait_option);
```

Description

This service attempts to GET the resource specified by “resource” pointer on the previously created HTTP Client instance. If this routine returns NX_SUCCESS, the application can then make multiple calls to *nx_http_client_get_packet* to retrieve packets of data corresponding to the requested resource content.

Input Parameters

client_ptr	Pointer to HTTP Client control block.
ip_address	IP address of the HTTP Server.
resource	Pointer to URL string for requested resource.
input_ptr	Pointer to additional data for the GET request. This is optional. If valid, the specified input is placed in the content area of the message and a POST is used instead of a GET operation.
input_size	Number of bytes in optional additional input pointed to by “input_ptr.”
username	Pointer to optional user name for authentication.
password	Pointer to optional password for authentication.
wait_option	Defines how long the service will wait for the HTTP Client get start. The wait options are defined as follows: <div style="margin-left: 40px;"> timeout value (0x00000001 through 0xFFFFFFFF) TX_WAIT_FOREVER (0xFFFFFFFF) </div>

Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the HTTP Server responds to the request.

Selecting a numeric value (1-0xFFFFFFFF) specifies the maximum number of timer-ticks to stay suspended while waiting for the HTTP Server response.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Client GET start.
NX_HTTP_ERROR	(0xE0)	HTTP Client GET start error.
NX_HTTP_NOT_READY	(0xEA)	HTTP Client not ready for GET.
NX_HTTP_FAILED	(0xE2)	HTTP Client error communicating with the HTTP Server.
NX_HTTP_AUTHENTICATION_ERROR	(0xEB)	Invalid name and/or password.
NX_PTR_ERROR	(0x16)	Invalid HTTP Client or resource pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Start the GET operation on the HTTP Client "my_client." */
status = nx_http_client_get_start(&my_client, IP_ADDRESS(1,2,3,5), "/TEST.HTM",
                                NX_NULL, 0, "myname", "mypassword", 1000);

/* If status is NX_SUCCESS, the GET request for TEST.HTM is started and is so
   far successful. The client must now call nx_http_client_get_packet multiple
   times to retrieve the content associated with TEST.HTM. */
```

See Also

nx_http_client_create, nx_http_client_delete, nx_http_client_put_start,
 nx_http_server_create, nx_http_server_delete, nx_http_server_start,
 nx_http_server_stop

nxd_http_client_get_start

Start an HTTP GET request (IPv4 or IPv6)

Prototype

```
UINT nxd_http_client_get_start(NX_HTTP_CLIENT *client_ptr,
                               NXD_ADDRESS *server_ip, CHAR *resource,
                               CHAR *input_ptr, UINT input_size, CHAR *username,
                               CHAR *password, ULONG wait_option);
```

Description

This service attempts to GET the resource specified by “resource” pointer on the previously created HTTP Client instance. If this routine returns NX_SUCCESS, the application can then make multiple calls to *nxd_http_client_get_packet* to retrieve packets of data corresponding to the requested resource content.

Input Parameters

client_ptr	Pointer to HTTP Client control block.
Server_ip	IP address of the HTTP Server.
resource	Pointer to URL string for requested resource.
input_ptr	Pointer to additional data for the GET request. This is optional. If valid, the specified input is placed in the content area of the message and a POST is used instead of a GET operation.
input_size	Number of bytes in optional additional input pointed to by “input_ptr.”
username	Pointer to optional user name for authentication.
password	Pointer to optional password for authentication.
wait_option	Defines how long the service will wait for the HTTP Client get start. The wait options are defined as follows: <div style="margin-left: 40px;"> timeout value (0x00000001 through 0xFFFFFFFF) TX_WAIT_FOREVER (0xFFFFFFFF) </div>

Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the HTTP Server responds to the request.

Selecting a numeric value (1-0xFFFFFFFF) specifies the maximum number of timer-ticks to stay suspended while waiting for the HTTP Server response.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Client GET start.
NX_HTTP_ERROR	(0xE0)	HTTP Client GET start error.
NX_HTTP_NOT_READY	(0xEA)	HTTP Client not ready for GET.
NX_HTTP_FAILED	(0xE2)	HTTP Client error communicating with the HTTP Server.
NX_HTTP_AUTHENTICATION_ERROR	(0xEB)	Invalid name and/or password.
NX_PTR_ERROR	(0x16)	Invalid HTTP Client or resource pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```

NXD_ADDRESS server_ip_address;

/* for an IPv4 address, define as follows: */
server_ip_address.nxd_ip_version == NX_IP_VERSION_V4;
server_ip_address.nxd_ip_address.v4 = IP_ADDRESS(1,2,3,4);

/* for an IPv6 address, define as follows: */
server_ip_address.nxd_ip_version == NX_IP_VERSION_V6;
server_ip_address.nxd_ip_address.v6[0] = 0x20010db8;
server_ip_address.nxd_ip_address.v6[1] = 0x0;
server_ip_address.nxd_ip_address.v6[2] = 0xf101;
server_ip_address.nxd_ip_address.v6[3] = 0x106;

/* Start the GET operation on the HTTP Client "my_client." */
status = nxd_http_client_get_start(&my_client, server_ip_address, "/TEST.HTM",
                                   NX_NULL, 0, "myname", "mypassword", 1000);

/* If status is NX_SUCCESS, the GET request for TEST.HTM is started and is so
   far successful. The client must now call nx_http_client_get_packet multiple
   times to retrieve the content associated with TEST.HTM. */

```


See also

`nx_http_get_packet`, `nx_http_client_put_packet`

nx_http_client_get_packet

Get next resource data packet

Prototype

```
UINT nx_http_client_get_packet(NX_HTTP_CLIENT *client_ptr,  
                               NX_PACKET **packet_ptr, ULONG wait_option);
```

Description

This service retrieves the next packet of content of the resource requested by the previous *nx_http_client_get_start* call. Successive calls to this routine should be made until the return status of NX_HTTP_GET_DONE is received.

Input Parameters

client_ptr	Pointer to HTTP Client control block.
packet_ptr	Destination for packet pointer containing partial resource content.
wait_option	Defines how long the service will wait for the HTTP Client get packet. The wait options are defined as follows: timeout value (0x00000001 through 0xFFFFFFFF) TX_WAIT_FOREVER (0xFFFFFFFF) Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the HTTP Server responds to the request. Selecting a numeric value (1-0xFFFFFFFF) specifies the maximum number of timer-ticks to stay suspended while waiting for the HTTP Server response.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Client get packet.
NX_HTTP_GET_DONE	(0xEC)	HTTP Client get packet is done.

NX_HTTP_ERROR	(0xE0)	HTTP Client get packet error.
NX_HTTP_NOT_READY	(0xEA)	HTTP Client not in get mode.
NX_HTTP_FAILED	(0xE2)	HTTP Client error communicating with the HTTP Server.
NX_PTR_ERROR	(0x16)	Invalid HTTP Client or packet destination pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Get the next packet of resource content on the HTTP Client "my_client."
   Note that the nx_http_client_get_start routine must have been called
   previously. */
status = nx_http_client_get_packet(&my_client, &next_packet, 1000);

/* If status is NX_SUCCESS, the next packet of content is pointed to
   by "next_packet". */
```

See Also

`nx_http_client_get_start`, `nx_http_client_put_start`,
`nx_http_client_put_packet`

nx_http_client_put_start

Start an HTTP PUT request over IPv4

Prototype

```
UINT nx_http_client_put_start(NX_HTTP_CLIENT *client_ptr,
                             ULONG ip_address, CHAR *resource, CHAR *username,
                             CHAR *password, ULONG total_bytes, ULONG wait_option);
```

Description

This service attempts to PUT (send) the specified resource on the HTTP Server at the supplied IP address. If this routine is successful, the application code should make successive calls to the *nx_http_client_put_packet* routine to actually send the resource contents to the HTTP Server.

Input Parameters

client_ptr	Pointer to HTTP Client control block.
ip_address	IP address of the HTTP Server.
resource	Pointer to URL string for resource to send to Server.
username	Pointer to optional user name for authentication.
password	Pointer to optional password for authentication.
total_bytes	Total bytes of resource being sent. Note that the combined length of all packets sent via subsequent calls to <i>nx_http_client_put_packet</i> must equal this value.
wait_option	Defines how long the service will wait for the HTTP Client PUT start. The wait options are defined as follows: <div style="margin-left: 40px;"> timeout value (0x00000001 through 0xFFFFFFFF) TX_WAIT_FOREVER (0xFFFFFFFF) </div> <p>Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the HTTP Server responds to the request.</p>

Selecting a numeric value (1-0xFFFFFFFF) specifies the maximum number of timer-ticks to stay suspended while waiting for the HTTP Server response.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Client PUT start.
NX_HTTP_ERROR	(0xE0)	HTTP Client PUT error.
NX_HTTP_NOT_READY	(0xEA)	HTTP Client not in PUT mode.
NX_HTTP_FAILED	(0xE2)	HTTP Client error communicating with the HTTP Server.
NX_PTR_ERROR	(0x16)	Invalid HTTP Client or resource pointer.
NX_SIZE_ERROR	(0x09)	Invalid total size of resource.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Start an HTTP PUT to place the 20-byte resource "/TEST.HTM" on the HTTP Server
   at IP address 1.2.3.5. */
status = nx_http_client_put_start(&my_client, IP_ADDRESS(1, 2, 3, 5),
                                  "/TEST.HTM", "myname", "mypassword", 20, NX_WAIT_FOREVER);

/* If status is NX_SUCCESS, the PUT operation for TEST.HTM has successfully been
   started. */
```

See Also

`nx_http_client_get_packet`, `nx_http_client_put_packet`,
`nx_http_server_callback_data_send`, `nxd_http_client_put_start`,
`nx_http_server_callback_response_send`

nxd_http_client_put_start

Start an HTTP PUT request (IPv4 or IPv6)

Prototype

```
UINT nxd_http_client_put_start(NX_HTTP_CLIENT *client_ptr,
                               NXD_ADDRESS *server_ip, CHAR *resource,
                               CHAR *username, CHAR *password,
                               ULONG total_bytes, ULONG wait_option);
```

Description

This service attempts to PUT (send) the specified resource on the HTTP Server at the supplied IP address over IPv6. If this routine is successful, the application code should make successive calls to the *nx_http_client_put_packet* routine to actually send the resource contents to the HTTP Server.

Input Parameters

client_ptr	Pointer to HTTP Client control block.
server_ip	IP address of the HTTP Server.
resource	Pointer to URL string for resource to send to Server.
username	Pointer to optional user name for authentication.
password	Pointer to optional password for authentication.
total_bytes	Total bytes of resource being sent. Note that the combined length of all packets sent via subsequent calls to <i>nx_http_client_put_packet</i> must equal this value.
wait_option	Defines how long the service will wait for the HTTP Client PUT start. The wait options are defined as follows: <div style="margin-left: 40px;"> timeout value (0x00000001 through 0xFFFFFFFFE) TX_WAIT_FOREVER (0xFFFFFFFF) </div> Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the HTTP Server responds to the request.

Selecting a numeric value (1-0xFFFFFFFFE) specifies the maximum number of timer-ticks to stay suspended while waiting for the HTTP Server response.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Client PUT start.
NX_HTTP_ERROR	(0xE0)	HTTP Client PUT error.
NX_HTTP_NOT_READY	(0xEA)	HTTP Client not in PUT mode.
NX_HTTP_FAILED	(0xE2)	HTTP Client error communicating with the HTTP Server.
NX_PTR_ERROR	(0x16)	Invalid HTTP Client or resource pointer.
NX_SIZE_ERROR	(0x09)	Invalid total size of resource.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```

NXD_ADDRESS server_ip_address;

/* for an IPv4 address, define as follows: */
server_ip_address.nxd_ip_version == NX_IP_VERSION_V4;
server_ip_address.nxd_ip_address.v4 = IP_ADDRESS(1,2,3,4);

/* for an IPv6 address, define as follows: */
server_ip_address.nxd_ip_version == NX_IP_VERSION_V6;
server_ip_address.nxd_ip_address.v6[0] = 0x20010db8;
server_ip_address.nxd_ip_address.v6[1] = 0x0;
server_ip_address.nxd_ip_address.v6[2] = 0xf101;
server_ip_address.nxd_ip_address.v6[3] = 0x106;

/* Start an HTTP PUT to place the 20-byte resource Client_test.HTM" on the HTTPv6
Server. */
status = nxd_http_client_put_start(&my_client, &server_ip_address,
                                   "/client_test.htm", "name", "password", 103, 50);

/* If status is NX_SUCCESS, the PUT operation for Client_test.HTM has successfully
been started. */

```

See Also

nx_http_client_get_packet, nx_http_client_put_packet,
nx_http_server_callback_data_send, nx_http_client_put_start,
nx_http_server_callback_response_send

nx_http_client_put_packet

Send next resource data packet

Prototype

```
UINT nx_http_client_put_packet(NX_HTTP_CLIENT *client_ptr,
                               NX_PACKET *packet_ptr, ULONG wait_option);
```

Description

This service attempts to send the next packet of resource content to the HTTP Server. Note that this routine should be called repetitively until the combined length of the packets sent equals the “total_bytes” specified in the previous *nx_http_client_put_start* call.

Input Parameters

client_ptr	Pointer to HTTP Client control block.
packet_ptr	Pointer to next content of the resource to being sent to the HTTP Server.
wait_option	Defines how long the service will wait for the HTTP Client PUT packet. The wait options are defined as follows: <div style="margin-left: 20px;"> <p>timeout value (0x00000001 through 0xFFFFFFFFE)</p> <p>TX_WAIT_FOREVER (0xFFFFFFFFF)</p> <p>Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the HTTP Server responds to the request.</p> <p>Selecting a numeric value (1-0xFFFFFFFFE) specifies the maximum number of timer-ticks to stay suspended while waiting for the HTTP Server response.</p> </div>

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Client PUT packet.
NX_HTTP_ERROR	(0xE0)	HTTP Client PUT packet error.

NX_HTTP_NOT_READY	(0xEA)	HTTP Client not in PUT mode.
NX_HTTP_FAILED	(0xE2)	HTTP Client error communicating with the HTTP Server.
NX_HTTP_AUTHENTICATION_ERROR	(0xEB)	Invalid name and/or password.
NX_PTR_ERROR	(0x16)	Invalid HTTP Client or packet pointer.
NX_INVALID_PACKET	(0x12)	Invalid TCP packet – not enough room for packet header.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Send a 20-byte packet representing the content of the resource
   "/TEST.HTM" to the HTTP Server. */
status = nx_http_client_put_packet(NX_HTTP_CLIENT *client_ptr, NX_PACKET
*packet_ptr, ULONG wait_option);

/* If status is NX_SUCCESS, the 20-byte resource contents of TEST.HTM has
   successfully been sent. */
```

See Also

`nx_http_client_get_packet`, `nx_http_client_put_start`,
`nx_http_server_callback_data_send`,
`nx_http_server_callback_response_send`

nx_http_server_callback_data_send

Send data from callback function

Prototype

```
UINT nx_http_server_callback_data_send(NX_HTTP_SERVER *server_ptr,
                                       VOID *data_ptr, ULONG data_length);
```

Description

This service sends the data in the supplied packet from the application's callback routine. This is typically used to send dynamic data associated with GET/POST requests. Note that if this function is used, the callback routine is responsible for sending the entire response in the proper format. In addition, the callback routine must return the status of NX_HTTP_CALLBACK_COMPLETED.

Input Parameters

server_ptr	Pointer to HTTP Server control block.
data_ptr	Pointer to the data to send.
data_length	Number of bytes to send.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server data send.
NX_HTTP_ERROR	(0xE0)	HTTP Server data send error.

Allowed From

Threads

Example

```

UINT my_request_notify(NX_HTTP_SERVER *server_ptr, UINT request_type,
                      CHAR *resource, NX_PACKET *packet_ptr)
{
    /* Look for the test resource! */
    if ((request_type == NX_HTTP_SERVER_GET_REQUEST) &&
        (strcmp(resource, "/test.htm") == 0))
    {
        /* Found it, override the GET processing by sending the resource
           contents directly. */
        nx_http_server_callback_data_send(server_ptr,
        "HTTP/1.0 200 \r\nContent-Length: 103\r\nContent-Type: text/html\r\n\r\n", 63);
        nx_http_server_callback_data_send(server_ptr, "<HTML>\r\n<HEAD><TITLE>NetX
        HTTP Test</TITLE></HEAD>\r\n<BODY>\r\n<H1>NetX Test
        Page</H1>\r\n</BODY>\r\n</HTML>\r\n", 103);

        /* Return completion status. */
        return(NX_HTTP_CALLBACK_COMPLETED);
    }

    return(NX_SUCCESS);
}

```

See Also

nx_http_client_get_packet, nx_http_client_put_start,
 nx_http_client_put_packet, nx_http_server_callback_response_send,
 nx_http_server_content_get, nx_http_server_content_length_get,
 nx_http_server_param_get, nx_http_server_query_get

nx_http_server_callback_response_send

Send response from callback function

Prototype

```
UINT nx_http_server_callback_response_send(NX_HTTP_SERVER *server_ptr,
    CHAR *header, CHAR *information, CHAR *additional_information);
```

Description

This service sends the supplied response information from the application's callback routine. This is typically used to send custom responses associated with GET/POST requests. Note that if this function is used, the callback routine must return the status of NX_HTTP_CALLBACK_COMPLETED.

Input Parameters

server_ptr	Pointer to HTTP Server control block.
header	Pointer to the ASCII response header string.
information	Pointer to the ASCII information string.
additional_information	Pointer to the ASCII additional information string.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server response send.
NX_HTTP_ERROR	(0xE0)	HTTP Server response send error.

Allowed From

Threads

Example

```

UINT my_request_notify(NX_HTTP_SERVER *server_ptr, UINT request_type,
                      CHAR *resource, NX_PACKET *packet_ptr)
{
    /* Look for the test resource! */
    if ((request_type == NX_HTTP_SERVER_GET_REQUEST) &&
        (strcmp(resource, "/test.htm") == 0))
    {
        /* In this example, we will complete the GET processing with
           a resource not found response. */
        nx_http_server_callback_response_send(server_ptr,
                                              "HTTP/1.0 404 ",
                                              "NetX HTTP Server unable to find file: ",
                                              resource);

        /* Return completion status. */
        return(NX_HTTP_CALLBACK_COMPLETED);
    }

    return(NX_SUCCESS);
}

```

See Also

nx_http_client_get_packet, nx_http_client_put_start,
 nx_http_client_put_packet, nx_http_server_callback_data_send,
 nx_http_server_content_get, nx_http_server_content_length_get,
 nx_http_server_param_get, nx_http_server_query_get,

`nx_http_server_content_get`

Get content from the request

Prototype

```
UINT nx_http_server_content_get(NX_HTTP_SERVER *server_ptr,
                                NX_PACKET *packet_ptr, ULONG byte_offset,
                                CHAR *destination_ptr, UINT destination_size,
                                UINT *actual_size);
```

Description

This service attempts to retrieve the specified amount of content from the POST or PUT HTTP Client request. It should be called from the application's request notify callback specified during HTTP Server creation (*nx_http_server_create*).

Input Parameters

server_ptr	Pointer to HTTP Server control block.
packet_ptr	Pointer to the HTTP Client request packet. Note that this packet must not be released by the request notify callback.
byte_offset	Number of bytes to offset into the content area.
destination_ptr	Pointer to the destination area for the content.
destination_size	Maximum number of bytes available in the destination area.
actual_size	Pointer to the destination variable that will be set to the actual size of the content copied.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server content get.
NX_HTTP_ERROR	(0xE0)	HTTP Server content get error.
NX_HTTP_DATA_END	(0xE7)	End of request content.
NX_HTTP_TIMEOUT	(0xE1)	HTTP Server timeout in getting next packet of content.

NX_PTR_ERROR	(0x16)	Invalid HTTP Server, packet, destination, or actual size pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Assuming we are in the application's request notify callback
   routine, retrieve up to 100 bytes of content starting at offset
   0. */
status = nx_http_server_content_get(&my_server, packet_ptr,
                                     0, my_buffer, 100, &actual_size);

/* If status is NX_SUCCESS, "my_buffer" contains "actual_size" bytes of
   request content. */
```

See Also

`nx_http_server_content_length_get`, `nx_http_server_create`,
`nx_http_server_delete`, `nx_http_server_param_get`,
`nx_http_server_query_get`

`nx_http_server_content_get_extended`

Get content from the request/supports zero length Content Length

Prototype

```
UINT nx_http_server_content_get_extended(NX_HTTP_SERVER *server_ptr,
    NX_PACKET *packet_ptr, ULONG byte_offset,
    CHAR *destination_ptr, UINT destination_size,
    UINT *actual_size);
```

Description

This service is almost identical to *nx_http_server_content_get*; it attempts to retrieve the specified amount of content from the POST or PUT HTTP Client request. However it handles requests with Content Length of zero value ('empty request') as a valid request. It should be called from the application's request notify callback specified during HTTP Server creation (*nx_http_server_create*).

Input Parameters

server_ptr	Pointer to HTTP Server control block.
packet_ptr	Pointer to the HTTP Client request packet. Note that this packet must not be released by the request notify callback.
byte_offset	Number of bytes to offset into the content area.
destination_ptr	Pointer to the destination area for the content.
destination_size	Maximum number of bytes available in the destination area.
actual_size	Pointer to the destination variable that will be set to the actual size of the content copied.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server content get.
NX_HTTP_ERROR	(0xE0)	HTTP Server content get error.
NX_HTTP_DATA_END	(0xE7)	End of request content.
NX_HTTP_TIMEOUT	(0xE1)	HTTP Server timeout in getting next packet.

NX_PTR_ERROR	(0x16)	Invalid HTTP Server, packet, destination, or actual size pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Assuming we are in the application's request notify callback
   routine, retrieve up to 100 bytes of content starting at offset
   0. */
status = nx_http_server_content_get_extended(&my_server, packet_ptr,
                                             0, my_buffer, 100, &actual_size);

/* If status is NX_SUCCESS, "my_buffer" contains "actual_size" bytes of
   request content. */
```

See Also

`nx_http_server_content_get`, `nx_http_server_content_length_get`,
`nx_http_server_create`, `nx_http_server_delete`,
`nx_http_server_param_get`, `nx_http_server_query_get`

nx_http_server_content_length_get

Get length of content in the request

Prototype

```
UINT nx_http_server_content_length_get(NX_PACKET *packet_ptr);
```

Description

This service attempts to retrieve the HTTP content length in the supplied packet. If there is no HTTP content, this routine returns a value of zero. It should be called from the application's request notify callback specified during HTTP Server creation (*nx_http_server_create*).

Input Parameters

packet_ptr	Pointer to the HTTP Client request packet. Note that this packet must not be released by the request notify callback.
-------------------	---

Return Values

content length

Allowed From

Threads

Example

```
/* Assuming we are in the application's request notify callback
   routine, get the content length of the HTTP Client request. */
length = nx_http_server_content_length_get(packet_ptr);

/* The "length" variable now contains the length of the HTTP Client
   request content area. */
```

See Also

`nx_http_server_callback_data_send`,
`nx_http_server_callback_response_send`, `nx_http_server_content_get`,
`nx_http_server_param_get`, `nx_http_server_query_get`

nx_http_server_content_length_get_extended

Get length of content in the request/supports Content Length of zero value

Prototype

```
UINT nx_http_server_content_length_get_extended(NX_PACKET *packet_ptr,
                                                UINT *content_length);
```

Description

This service is similar to *nx_http_server_content_length_get*; attempts to retrieve the HTTP content length in the supplied packet. However, the return value indicates successful completion status, and the actual length value is returned in the input pointer *content_length*. If there is no HTTP content/Content Length = 0, this routine still returns a successful completion status and the *content_length* input pointer points to a valid length (zero). It should be called from the application's request notify callback specified during HTTP Server creation (*nx_http_server_create*).

Input Parameters

packet_ptr	Pointer to the HTTP Client request packet. Note that this packet must not be released by the request notify callback.
content_length	Pointer to value retrieved from Content Length field

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server content get.
NX_HTTP_INCOMPLETE_PUT_ERROR	(0xEF)	Improper HTTP header format
NX_PTR_ERROR	(0x16)	Invalid pointer input

Allowed From

Threads

Example

```
/* Assuming we are in the application's request notify callback
   routine, get the content length of the HTTP Client request. */
ULONG content_length;

status = nx_http_server_content_length_get_extended(packet_ptr, &content_length);
```

```
/* If the "status" variable indicates successful completion, the "length" variable  
contains the length of the HTTP Client request content area. */
```

See Also

`nx_http_server_content_length_get`, `nx_http_server_callback_data_send`,
`nx_http_server_callback_response_send`, `nx_http_server_content_get`,
`nx_http_server_param_get`, `nx_http_server_query_get`

nx_http_server_create

Create an HTTP Server instance

Prototype

```
UINT nx_http_server_create(NX_HTTP_SERVER *http_server_ptr,
    CHAR *http_server_name, NX_IP *ip_ptr, FX_MEDIA *media_ptr,
    VOID *stack_ptr, ULONG stack_size, NX_PACKET_POOL *pool_ptr,
    UINT (*authentication_check)(NX_HTTP_SERVER *server_ptr,
        UINT request_type, CHAR *resource, CHAR **name,
        CHAR **password, CHAR **realm),
    UINT (*request_notify)(NX_HTTP_SERVER *server_ptr,
        UINT request_type, CHAR *resource, NX_PACKET *packet_ptr));
```

Description

This service creates an HTTP Server instance, which runs in the context of its own ThreadX thread. The optional *authentication_check* and *request_notify* application callback routines give the application software control over the basic operations of the HTTP Server.

Input Parameters

- | | |
|-----------------------------|--|
| http_server_ptr | Pointer to HTTP Server control block. |
| http_server_name | Pointer to HTTP Server's name. |
| ip_ptr | Pointer to previously created IP instance. |
| media_ptr | Pointer to previously created FileX media instance. |
| stack_ptr | Pointer to HTTP Server thread stack area. |
| stack_size | Pointer to HTTP Server thread stack size. |
| authentication_check | Function pointer to application's authentication checking routine. If specified, this routine is called for each HTTP Client request. If this parameter is NULL, no authentication will be performed. |
| request_notify | Function pointer to application's request notify routine. If specified, this routine is called prior to the HTTP server processing of the request. This allows the resource name to be redirected or fields within a resource to be updated prior to completing the HTTP Client request. |

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server create.
NX_HTTP_ERROR	(0xE0)	HTTP Server create error.
NX_PTR_ERROR	(0x16)	Invalid HTTP Server, IP, media, stack, or packet pool pointer.
NX_HTTP_POOL_ERROR	(0xE9)	Packet payload of pool is not large enough to contain complete HTTP request.

Allowed From

Initialization, Threads

Example

```
/* Create an HTTP Server instance called "my_server." */
status = nx_http_server_create(&my_server, "my server", &ip_0, &ram_disk,
                               stack_ptr, stack_size, &pool_0,
                               my_authentication_check, my_request_notify);

/* If status equals NX_SUCCESS, the HTTP Server creation was successful. */
```

See Also

nx_http_client_create, nx_http_client_delete, nx_http_client_get_start,
 nx_http_server_callback_data_send,
 nx_http_server_callback_response_send, nx_http_server_start,
 nx_http_server_stop, nx_http_server_delete

nx_http_server_delete

Delete an HTTP Server instance

Prototype

```
UINT nx_http_server_delete(NX_HTTP_SERVER *http_server_ptr);
```

Description

This service deletes a previously created HTTP Server instance.

Input Parameters

http_server_ptr Pointer to HTTP Server control block.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server delete.
NX_PTR_ERROR	(0x16)	Invalid HTTP Server pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Delete the HTTP Server instance called "my_server." */
status = nx_http_server_delete(&my_server);

/* If status equals NX_SUCCESS, the HTTP Server delete was successful. */
```

See Also

nx_http_client_create, nx_http_client_delete, nx_http_client_get_start,
 nx_http_server_callback_data_send,
 nx_http_server_callback_response_send, nx_http_server_start,
 nx_http_server_stop, nx_http_server_create

nx_http_server_param_get

Get parameter from the request

Prototype

```
UINT nx_http_server_param_get(NX_PACKET *packet_ptr,
                             UINT param_number, CHAR *param_ptr, UINT max_param_size);
```

Description

This service attempts to retrieve the specified HTTP URL parameter in the supplied request packet. If the requested HTTP parameter is not present, this routine returns a status of NX_HTTP_NOT_FOUND. This routine should be called from the application's request notify callback specified during HTTP Server creation (*nx_http_server_create*).

Input Parameters

packet_ptr	Pointer to HTTP Client request packet. Note that the application should not release this packet.
param_number	Logical number of the parameter starting at zero, from left to right in the parameter list.
param_ptr	Destination area to copy the parameter.
max_param_size	Maximum size of the parameter destination area.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server parameter get.
NX_HTTP_FAILED	(0xE2)	Parameter size too small.
NX_HTTP_NOT_FOUND	(0xE6)	Specified parameter not found.
NX_PTR_ERROR	(0x16)	Invalid packet or parameter pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Assuming we are in the application's request notify callback
   routine, get the first parameter of the HTTP Client request. */
status = nx_http_server_param_get(request_packet_ptr, 0, param_destination,
                                   30);

/* If status equals NX_SUCCESS, the NULL-terminated first parameter can be found
   in "param_destination." */
```

See Also

`nx_http_server_callback_data_send`,
`nx_http_server_callback_response_send`, `nx_http_server_content_get`,
`nx_http_server_content_length_get`, `nx_http_server_query_get`

nx_http_server_query_get

Get query from the request

Prototype

```
UINT nx_http_server_query_get(NX_PACKET *packet_ptr, UINT query_number,
                             CHAR *query_ptr, UINT max_query_size);
```

Description

This service attempts to retrieve the specified HTTP URL query in the supplied request packet. If the requested HTTP query is not present, this routine returns a status of `NX_HTTP_NOT_FOUND`. This routine should be called from the application's request notify callback specified during HTTP Server creation (*nx_http_server_create*).

Input Parameters

packet_ptr	Pointer to HTTP Client request packet. Note that the application should not release this packet.
query_number	Logical number of the parameter starting at zero, from left to right in the query list.
query_ptr	Destination area to copy the query.
max_query_size	Maximum size of the query destination area.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server query get.
NX_HTTP_FAILED	(0xE2)	Query size too small.
NX_HTTP_NOT_FOUND	(0xE6)	Specified query not found.
NX_PTR_ERROR	(0x16)	Invalid packet or parameter pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Assuming we are in the application's request notify callback
   routine, get the first query of the HTTP Client request. */
status = nx_http_server_query_get(request_packet_ptr, 0, query_destination,
                                   30);

/* If status equals NX_SUCCESS, the NULL-terminated first query can be found
   in "query_destination." */
```

See Also

`nx_http_server_callback_data_send`,
`nx_http_server_callback_response_send`, `nx_http_server_content_get`,
`nx_http_server_content_length_get`, `nx_http_server_param_get`,

nx_http_server_start

Start the HTTP Server

Prototype

```
UINT nx_http_server_start(NX_HTTP_SERVER *http_server_ptr);
```

Description

This service starts the previously create HTTP Server instance.

Input Parameters

http_server_ptr Pointer to HTTP Server instance.

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server start.
NX_HTTP_ERROR	(0xE0)	Error starting HTTP Server.
NX_PTR_ERROR	(0x16)	Invalid HTTP Server pointer.

Allowed From

Initialization, Threads

Example

```
/* Start the HTTP Server instance "my_server." */
status = nx_http_server_start(&my_server);

/* If status equals NX_SUCCESS, the HTTP Server has been started. */
```

See Also

nx_http_server_callback_data_send,
nx_http_server_callback_response_send, nx_http_server_create,
nx_http_server_delete, nx_http_server_stop

nx_http_server_stop

Stop the HTTP Server

Prototype

```
UINT nx_http_server_stop(NX_HTTP_SERVER *http_server_ptr);
```

Description

This service stops the previously create HTTP Server instance. This routine should be called prior to deleting an HTTP Server instance.

Input Parameters

http_server_ptr	Pointer to HTTP Server instance.
------------------------	----------------------------------

Return Values

NX_SUCCESS	(0x00)	Successful HTTP Server stop.
NX_PTR_ERROR	(0x16)	Invalid HTTP Server pointer.
NX_CALLER_ERROR	(0x11)	Invalid caller of this service.

Allowed From

Threads

Example

```
/* Stop the HTTP Server instance "my_server." */
status = nx_http_server_stop(&my_server);

/* If status equals NX_SUCCESS, the HTTP Server has been stopped. */
```

See Also

nx_http_server_callback_data_send,
 nx_http_server_callback_response_send, nx_http_server_create,
 nx_http_server_delete, nx_http_server_start