

TI81XX PCI Express Endpoint Boot Driver User Guide



TI81XX PCI Express Endpoint Boot Driver User Guide

Hemant Pedanekar

This work is licensed under a [Creative Commons Attribution-ShareAlike 3.0 Unported License](#)^[1].

Introduction

This document is applicable to DM816x/AM389x and DM814x/AM387x family of devices referred hereafter as TI816X and TI814X respectively.

Descriptions common across both the device families use the term TI81XX/ti81xx.

TI81XX devices have a PCI Express hardware module which can either be configured to act as a Root Complex or a PCIe Endpoint. When configured as PCIe Endpoint (EP), the device can be set to boot over PCIe. This document caters to the Endpoint boot operation and describes the Driver needed to configure and operate on TI81XX PCI Express Endpoint to perform booting. A sample application (part of release package) is used to carry out boot operation.

NOTE1: Support for TI814X Root Complex is added from 04.01.00.06 release, hence the references/setups described in this document related to TI814X as Root Complex are not applicable for prior TI814X releases.

NOTE2: Various code snippets now use term `ti81xx` when referring to code common for TI81XX devices. For releases prior to 04.00.00.12 (TI816X) please consider the code snippets as having `ti816x` prefix, otherwise, refer the PDF of this user guide from respective release package.

Scope

This document covers the setup involving two TI816X/Dm814x EVMs connected together over PCIe using a PCIe cable having male connectors on both the ends. Here one device is set to boot in any other peripheral or memory boot mode (e.g., NAND) which will be designated as Root Complex (RC) and other TI81XX device configured in PCIe Boot mode (EP).

It is also possible to connect a TI816X EP device to any other PCIe RC. For the scope of this document, we will consider a x86 PC running Linux.

Note: In case of TI814X EVM with device in PCIe boot mode, booting from TI816X or TI814X Root Complex is supported currently (post 04.01.00.06 release for TI814X RC).

Also note that only 32-bit PCIe mode is supported currently on both RC and EP.

Conventions

- This document refers TI816X device set up in PCIe boot mode as EP (Endpoint) and the TI816X device acting as PCIe Root Complex as RC.
- The shell commands executed on Linux host machine as preceded with `LINUXHOST$` and the commands to be executed on TI816X RC are preceded with `ti8168-evm#`.
- It is assumed that the same Linux host machine is used as Root Complex when having PC to TI816X EVM EP connectivity.

NOTE 1: The only major difference between TI816X and TI814X PCIe is TI816X has a x2 link while TI814X has x1 link. Since this doesn't lead to any differences in topology and software execution impact on TI81XX Root Complex, all of the descriptions considering TI816X as Root Complex in rest of the document apply equally to TI814X as RC as well, unless otherwise stated.

NOTE 2: Though we cover EP device as TI816X mainly, most of the description is applicable to TI814X EP device also except for sections covering TI816X EVM modifications and booting from PC. Any other specific differences with TI816X devices are highlighted wherever applicable.

Known Issues/Restrictions (Read this before you proceed)

This section lists various constraints applicable on TI81XX PCIe EP boot operation. Most the the points listed below are covered in respective sections of this document.

- Only 32-bit PCIe boot mode is supported, 64-bit mode not supported currently.
- At the minimum, 3 BARs - BAR0, BAR1 and BAR2 are needed for boot operation and hence only the switch setting mentioned in next section is supported on EP.
- Other possible switch settings which may set up additional BARs may lead to issues in case RC is not able to allocate those BARs.
- Boot driver and application cannot handle multiple TI81XX EPs. Will only boot the first detected EP. If the setup involves combination of TI816X and TI814X devices, TI816X device will be detected and configured for boot.
- In case ramdisk image is used as filesystem on EP, it cannot exceed 8MB. This restriction is imposed by the sample boot application to avoid exceeding the minimum BAR2 size (8MB) on TI816X.
- *Booting EP from a non-TI81XX RC is possible for **TI816X EP** but will require the boot driver and application to be built on respective RC. Note that the boot driver and application are written and tested to work with Linux kernel version 2.6.32 onwards.* So make sure that the RC is running Linux kernel as supported. This document will cover steps for building these components on a PC as RC running Linux. **In addition, you may need to do hardware modifications/configurations as described in Clocking Schemes Guide**
- Current configuration of boot application skips checking boot flag clear indication from EP U-Boot (indicating DDR setup done) and proceeds to load other images to DDR. This may fail in case EP U-Boot is yet to set up the DDR. Try increasing boot flag check delay in this case. Refer Boot Application section below.
- Similarly, EP U-Boot doesn't check for any boot flag indication from the boot application (to notify about completion of kernel download) and may proceed to load kernel (or ramdisk) even before it is completely loaded by boot application. In such cases, you can add 'sleep 3' (or more) in the boot script.
- Though the boot driver supports static build (building into kernel), some filesystem changes are required if you are using Arago/OE based filesystem with udev device cache. Please refer Updating the Filesystem section for details.

Setup

This document considers following distinct setups:

1. **TI816X EVM RC - TI816X EVM EP:** This setup requires two DM8168 boards (EVMs). Ensure that serial port (UART2) on each board is connected to host terminals.
2. **TI816X EVM RC - TI814X EVM EP:** This setup requires one DM8168 EVM set up as RC while DM8148 EVM set up as EP with PCIe-32-bit boot mode. Ensure that serial port on each board (UART2 on DM8168 EVM and UART0 on DM8148 EVM) is connected to host terminals.
3. **TI814X EVM RC - TI814X EVM EP:** This setup requires two DM8148 boards (EVMs). Ensure that serial port (UART0) on each board is connected to host terminals.
4. **TI814X EVM RC - TI816X EVM EP:** This setup requires one DM8148 EVM set up as RC while DM8168 EVM set up as EP with PCIe-32-bit boot mode. Ensure that serial port on each board (UART0 on DM8148 EVM and UART2 on DM8168 EVM) is connected to host terminals.
5. **x86 PC as RC - TI816X EVM EP:** In this setup, the PC is RC and is running Ubuntu 10.04 LTS with Linux kernel 2.6.32. Ensure that serial port (UART2) on TI816X EVM used as EP is connected to host serial port.

Note: In any of the cases covered here, it is advised to power on the EP device first and then RC.

Conflict with NAND/NOR and TI814X/TI816X PCIe Boot Mode setting

Note: This section applies when using U-Boot and/or kernel from PSP releases 04.01.00.06 (TI814X) or 04.00.01.13 (TI816X). For older releases, this issue does not exist and you can skip this section.

The GPMC related boot pin CS0BW used for PCIe boot mode configuration is checked by u-boot and kernel to determine the 8-bit/16-bit NAND/NOR type connected on the board.

This will lead to conflict in few cases such as:

1. PCIe 32-bit boot mode with CS0BW=1 for BAR2 will require the DIP switch associated with CS0BW pin to be set to ON but U-Boot will take it as 8-bit NAND even if actual NAND on board was 16-bit. This will lead to NAND detection failures
2. Similar issue would occur when using 8-bit NOR where CS0BW=1 will be taken by NOR driver on Linux or U-Boot as NOR being 16-bit

Thus, with kernel and/or U-Boot from above mentioned releases, NAND and/or NOR may not be accessible when using PCIe boot mode of TI816X/TI814X EP.

Setting up the TI816X RC

- Flash the TI816X RC on board NAND with U-Boot. Refer PSP Flashing Tools Guide document for details.
- Set the DM8168 EVM switch settings to enable NAND boot mode. Refer U-Boot User Guide for details about building U-Boot for NAND boot mode and switch settings.
- Use Male-Male (x2 or x4) PCIe cable to connect RC and PCIe slot on EP (minimum x4).
- Alternatively, you can set up RC to boot in any other (non-Pcie) boot mode.

Setting up the PC as RC

- Use Male-Male (x2 or x4) PCIe cable to connect to the PCIe slot on PC motherboard and the DM8168 Board (EP).

Note: The cable needs to be modified as described in Clocking Schemes Guide

Setting up TI816X EP

- Set the board designated as PCIe EP in PCIe 32-bit Boot mode as follows:

```
SW3[5:1] ----> BTM[4:0] = 01000 and SW3[8] ----> CS0BW = 1. Rest all switches should be '0' (zero) or 'OFF'
```

- This results into following boot pin configuration for TI816X device

```
SYSBOOT[4:0] = 01000 ==> 32-bit PCIe Boot mode
CS0BW        = 1      ==> for 8MB BAR2, in addition to default 8MB BAR1 and 4KB BAR0
```

- Note: Setting up any other combination of switch settings with PCIe Boot mode is not supported/validated.

Note: When using with non-TI816X device as RC, DM8168 EVM to be set as EP needs to be modified as described in Clocking Schemes Guide.

Taking care of PERSTn

On DM8168 EVMs the SW5 DIP switch has a switch for "PCIe RST". This corresponds to the in/out mode of the PERSTn line of the PCIe slot which in turn is tied to PCIe_PORz. The switch position 'OFF' (or '0') means the pin is set as INPUT while switch position 'ON' means the pin is in OUTPUT mode. Thus, having this switch in ON state (OUTPUT) on EP EVM OFF state (INPUT) on RC EVM will lead to conflicting configuration and the RC may not boot.

- Ensure that the SW5 "PCIe RST" switch on both EP and RC EVMs is set in OFF (INPUT) state.
- For setup involving PC as RC, it is mandatory is set SW5-1 to OFF (INPUT) state otherwise PC may not boot.
- For setup where DM8168 is RC and TI814X device is EP, it is mandatory is set SW5-1 to OFF (INPUT) state otherwise TI814X EP will not get detected from RC.

```
SW5[1] ----> PCIe RST = 0
```

Alternately, you can set the above switch on both the EVMs in ON state (OUTPUT).

Note: Setting SW5 PCIe RST as OFF (INPUT) on EP and ON (OUTPUT) on RC is not supported due to issue SDOCM00077550 (refer Release Notes for the release you are using)

Setting up the TI814X RC

- Flash the TI814X RC on board NAND with U-Boot. Refer PSP Flashing Tools Guide document for details.
- Set the DM8148 EVM switch settings to enable NAND boot mode. Refer U-Boot User Guide for details about building U-Boot for NAND boot mode and switch settings.
- Use Male-Male (x2 or x4) PCIe cable to connect RC and with the PCIe slot (minimum x4) on EP.
- Alternatively, you can set up RC to boot in any other (non-PCIe) boot mode.

Setting up TI814X EP

- Set the board designated as PCIe EP in PCIe 32-bit Boot mode as follows:

```
Boot mode select switch S1[5:1] = 01000 and S1[8] = 1. Rest all switches should be '0' (zero) or 'OFF'
```

- This results into following boot pin configuration for TI814X device

```
SYSBOOT[4:0] = 01000 ==> 32-bit PCIe Boot mode  
CS0BW      = 1      ==> for 16MB BAR2, in addition to default 8MB BAR1 and 4KB BAR0
```

- Note:** Setting up any other combination of switch settings with PCIe Boot mode is not supported/validated.

Keeping the Required Modules Ready

Following section describes various modules involved in EP boot operation and steps for preparing binaries and U-Boot script required to be present on PCIe RC to boot TI81XX EP. In addition, it is assumed that a ramdisk filesystem or NFS based filesystem for EP are available.

Note: Though the kernel (uImage) built with default config for TI81XX RC will boot on TI81XX EP, it will lead to conflicting configuration of the system since the kernel booting on EP will switch the PCIe mode from EP to RC. Due to this, the communication between PCIe RC and EP will no longer happen. For this, the kernel needs to be re-built with PCI support removed for booting on EP.

Also note that the sections below assume you have extracted the TI81XX release package to a directory referred as \$PKGDIR and build environment is setup as described in TI81XX PSP User Guide.

PCIe EP Boot Driver

Note: The default kernel build configuration does not select the driver and needs to be enabled for respective kernels (e.g., TI816X, TI814X, x86 etc) as explained in respective sections below.

This driver runs on TI81XX RC or an x86 PC running Linux kernel 2.6.32 onwards. It configures the first TI816X/TI814X EP device detected in the system and configures it to be able to carry boot operation.

Features Supported

- Support for detecting and configuring TI816X and TI814X devices
- Provides character device interface on Linux Kernel to PCIe boot user-space application
- Provide mmap support to enable the boot application to copy image files (U-Boot, kernel etc) to EP memory
- Can be built as loadable module or into kernel

Features NOT Supported

- Operate more than one TI81XX EP. If more than one TI81XX EPs are connected in the system, this driver operates only on the first detected TI816X or TI814X device detected in order.
- No interrupt support
- Not validated on any other RC than TI81XX and x86 PC. This driver will require porting in case you are using Linux kernel prior to 2.6.32 or any other h/w platform than TI81XX or x86 PC.
- No support for power management (e.g., suspend/resume)

Supported IOCTLs

- **TI81XX_PCI_GET_BAR_INFO:** Returns the size in bytes of the specified BAR.

```
int dev_desc;
dev_desc = open("/dev/ti81xx_pcie_ep", O_RDWR);
...
struct ti81xx_bar_info bar;
bar.num = bar_number;
ioctl(dev_desc, TI81XX_PCI_GET_BAR_INFO, &bar);
...
```

In the above code fragment, the driver returns BAR size in 'size' field of the 'bar' structure object on success.

- **TI81XX_PCI_SET_BAR_WINDOW:** Application can specify the internal address on EP for specified BAR. For example, the boot application sets BAR1 to OCMC1 start on EP (0x40400000) for TI816X EP using this ioctl.

```
...
struct ti81xx_bar_info bar;
bar.num = 1;
bar.addr = 0x40400000;
ioctl(dev_desc, TI81XX_PCI_SET_BAR_WINDOW, &bar);
...
```

- **TI81XX_PCI_SET_DWNLD_DONE:** Set the bootflag on EP. The driver writes '1' to the location 0x4043FFFC on TI816X EP or at address 0x4031B7FC in case of TI814X EP and waits for the flag to be cleared till maximum of the time (in seconds) as specified by the application. Timeout of '0' means no wait for the flag clearing.

```
...
ioctl(dev_desc, TI81XX_PCI_SET_DWNLD_DONE, 3);
...
```

The IOCTL and data structure declarations are in drivers/char/ti81xx_pcie_bootdrv.h file in TI81XX kernel source.

Source Files

The driver files are present at following path relative to extracted kernel source directory for TI81XX.

- drivers/char/ti81xx_pcie_bootdrv.h
- drivers/char/ti81xx_pcie_bootdrv.c

Steps for Building for TI81XX Kernel

- The steps listed below cover building details for TI816X but similar steps are applicable for building TI814X kernel with only differences being you will need to use TI814X kernel release (04.01.00.06 onwards) and the EVM default configuration name is `ti8148_evm_defconfig`
- Navigate to TI81XX kernel source directory and extract the kernel source and create default TI8168 EVM configuration. Note that the release version suffix used in example below can be any later PSP version.

```
LINUXHOST$ cd $PKGDIR/src/kernel
LINUXHOST$ tar -xzf linux-04.00.00.09.tar.gz
LINUXHOST$ cd linux-04.00.00.09
LINUXHOST$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm ti8168_evm_defconfig
```

- Enter the kernel configuration menu

```
LINUXHOST$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm menuconfig
```

- This will open the kernel configuration menu
- Use DOWN Arrow key to till "Device Drivers" is highlighted

```
General setup --->
[*] Enable loadable module support --->
...
Device Drivers --->
```

- Press ENTER to go inside this section. Use DOWN Arrow key to select "Character devices"

```
Generic Driver Options --->
...
Character devices --->
```

- Again press ENTER and scroll down to select "TI81XX PCIe Endpoint Boot Driver". Press 'm' to enable to build as a loadable module.

```
-*- Virtual terminal
...
<M> TI81XX PCIe Endpoint Boot Driver
```

Note that the above option will be shown only if PCI Bus support is enabled in kernel configuration. This is default in ti8168_evm_defconfig.

- Use RIGHT Arrow key to bring focus on 'Exit' and press ENTER. Repeat this to return to previous menu(s) and eventually back to the shell. Make sure to save the changes you have made when prompted at exit.
- Build the driver

```
LINUXHOST$ make modules.
```

- The module will be built as drivers/char/ti81xx_pcie_bootdrv.ko
- The above steps build the driver as loadable kernel module but it can also be built into kernel by pressing 'y' instead of 'm' in kernel menu configuration mentioned above.

Steps for Building for x86 Kernel

Following assumptions are made before proceeding to build the boot driver for PC:

- The PC is running x86 Linux Kernel 2.6.32 or latest (till 2.6.37)
- The source for the kernel running on the PC is available. We will assume this source is extracted in directory /home/builduser/kernel/src on the PC which is being used as RC.
- The native GNU toolchain installed on the PC.
- The user has 'root' or 'sudo' privileges on the PC host.

Building the boot driver as loadable kernel module:

- Transfer the boot driver files (.c and .h) to drivers/char folder inside kernel source directory, e.g.,

```
/home/builduser/kernel/src/drivers/char/ti81xx_pcie_bootdrv.h
/home/builduser/kernel/src/drivers/char/ti81xx_pcie_bootdrv.c
```

- Navigate to the kernel source directory

```
LINUXHOST$ cd /home/builduser/kernel/src
```

- Open the Makefile in drivers/char and add following line at the end:

```
obj-m += ti81xx_pcie_bootdrv.o
```

- You may as well choose to build the driver into kernel in which case, the above line would be changed as:

```
obj-y += ti81xx_pcie_bootdrv.o
```

- Build the module:

```
LINUXHOST$ make modules
```

- You might get some warning related to type casting and/or section mismatch, these can be safely ignored.
- The driver should get built as `ti81xx_pcie_bootdrv.ko` inside `/home/builduser/kernel/src` directory
- Though the above steps consider x86 kernel, same should be applicable for any 32-bit kernel (2.6.32 or later till 2.6.37).

U-Boot

For PCIe boot, the ROM on the EP directly jumps to the start of OCMC RAM when indicated by the boot driver (on RC) that the boot image is copied. **This means that the raw U-Boot binary (without any preceding header) must be used for booting.**

TI816X

For booting TI816X EP, the pre-built U-Boot binary `u-boot.bin` from `$PKGDIR/images/u-boot/ti816x` directory of TI816X release can be used.

TI814X

For booting TI814X EP, you will need U-Boot binaries for 2 stages:

- For 1st stage, you will need to build the U-Boot binary with following steps:
 1. Extract the U-Boot sources and navigate to the base directory of U-Boot source
 2. Make sure that the complete build environment as required for U-Boot build is setup on Linux host. For details, refer U-Boot User Guide from the release package or online [here](#)
 3. Prepare the configuration for build

```
make ti8148_evm_min_sd
```

4. Build U-Boot

```
make
```

5. This will create `u-boot.bin` file, rename this to MLO

- For 2nd stage, you can use the pre-built U-Boot binary `u-boot.bin` from `$PKGDIR/images/u-boot/ti814x` directory

Note: You can even use the pre-built MLO image from the `$PKGDIR/images/u-boot/ti814x` in release package provided the first 8 bytes are removed using binary editor.

TIP: Use following command at Linux shell to strip off 8 bytes -

```
# dd skip=8 if=MLO of=MLO.no_header bs=1
# mv MLO.no_header MLO
```


PCIe EP Boot Application

This application runs on TI81XX/x86 (or any other) RC running Linux and accesses the interfaces provided by the EP Boot Driver to download U-Boot, Kernel, etc images to EP and trigger EP boot.

You need not follow the build steps mentioned below if you want to use pre-built saBootTest ELF present in \$PKGDIR/images/examples/pcie directory. Note that, this ELF is built to be executed on TI81XX RC.

Features Supported

- Download U-Boot, U-Boot bootscript, Kernel and (optionally) filesystem images to EP memory
- Uses 2 stage boot loading in case of TI814X EP -
- Requires only 3 BARs (BAR0, BAR1 and BAR2) to perform complete boot operation. Uses EP boot driver to move internal EP windows to access OCMC and DDR.

Features NOT Supported

- Cannot operate without EP Boot Driver
- Does not support ramdisk filesystem size greater than 8MB
- Kernel image size limit is 8MB and bootscript size if 2MB maximum

Steps for Building for TI81XX RC

- Navigate to TI81XX examples source directory

```
LINUXHOST$ cd $PKGDIR/examples/pcie
```

- Open file Makefile and set the path to kernel source directory as applicable. For more details, refer README file present in the directory.
- Build the application by typing 'make' at the shell. This will create an ELF file named 'saBootTest'.

Steps for Building for PC

- Note all that assumptions listed earlier for building boot driver on x86 PC are applicable.
- Create a directory for boot application source and Makefile. For simplicity, we will create a directory inside kernel source prepared earlier for building boot driver on PC.

```
LINUXHOST$ cd /home/builduser/kernel/src/  
LINUXHOST$ mkdir pci
```

- Copy saBootTest.c and Makefile to this directory
- Edit Makefile to change following files

```
CC=arm-none-linux-gnueabi-gcc  
KERNEL_DIR=../../linux-omap-2.6  
CFLAGS=-I $(KERNEL_DIR)/include -I $(KERNEL_DIR)/arch/arm/include -I $(KERNEL_DIR)/drivers/char
```

- respectively, as follows:

```
CC=gcc  
KERNEL_DIR=../  
CFLAGS=-I $(KERNEL_DIR)/include -I $(KERNEL_DIR)/arch/x86/include -I $(KERNEL_DIR)/drivers/char
```

- Build the application

```
LINUXHOST$ make -C pci
```

- The boot application `saBootTestApp` should get built inside `pci` directory.

Tuning Boot Application

In some cases, the defaults chosen by the boot application may require to be changed. Various such options are covered below with their default settings. Note that in such case, you cannot use the pre-built Boot Application ELF file and will need to build the application as mentioned above.

Following options are defined in `saBootTestApp.c` file: -

- `CONFIG_IGNORE_BOOTFLAG_FAIL`: This flag is enabled by default (set to '1') which directs the boot application to proceed even if the boot flag is not cleared. This is enabled currently since present U-Boot doesn't clear the boot flag and having this flag enables the boot application to proceed to load kernel and boot EP. You can set this flag to '0' if you update the U-Boot to clear the boot flag after setting DDR (refer Boot ROM spec for location of boot flag).
- `CONFIG_BOOTFLAG_FAIL_DELAY`: Time in seconds to wait for boot flag to be cleared. Default is 3 sec. You can lower/increase this value if you face booting issues

Additional configuration options such as load addresses for various images, etc., are present in Boot Driver header file `ti81xx_pcie_bootdrv.h` located in `$PKGDIR/src/kernel/linux-04.00.00.09/driver/char` directory and are used by the boot application.

PCIe EP U-Boot Boot Script

In PCIe boot scenario, the U-Boot environment storage may not be available on EP. In such cases loading a U-Boot script file (referred as 'bootscript') on EP with various environment variables set helps simulating environment storage. This also adds flexibility in a way that the various boot parameters such as kernel boot arguments, filesystem type, paths for EP can be changed through this script without any need to rebuild the U-Boot or need to explicitly set the U-Boot environment variables on EP. Also, setting U-Boot parameters on EP will require to have UART console connected to EP every time.

Creating U-Boot Script

- Refer sample script file named `bootscript.txt` is provided in `$PKGDIR/src/examples/pcie` directory.
- Edit/add parameters as per your requirement. The default script sets up kernel to use RAMDISK image.
- You will need U-Boot's 'mkimage' utility to build the script image from this file. Refer U-Boot User Guide for details about 'mkimage'
- Ensure that the PATH is set to point to 'mkimage'
- Build the boot script as

```
LINUXHOST$ cd $PKGDIR/src/examples/pcie
LINUXHOST$ mkimage -A arm -O linux -T script -C none -n 'PCIe Boot Script' -d bootscript.txt boot.scr
```

- Alternatively, for booting TI816X EP, you can use pre-built `boot.scr` present inside `$PKGDIR/images/examples/pcie` directory. This is built from sample `bootscript.txt`

Note: The sample boot script packaged in release is for TI816X EP only and needs to be changed and re-built for TI814X EP. Especially, `ttyO2` needs to be changed to `ttyO0` for TI814X boot arguments.

Auto Booting with the Bootscript

This section is currently applicable for TI816X only.

Note: The current U-Boot default boot command is set to load the bootscript from MMC. Thus, pre-built u-boot.bin U-Boot binary from the release package, loaded on EP using boot application will not auto boot the kernel image downloaded over PCIe. The same issue applies if the U-Boot is built from source.

This can be resolved by directing the U-Boot running on EP to load the bootscript from DDR location 0x80400000 (as loaded by the boot application). This can be done in one of the following ways:

Updating U-Boot

This approach requires modifying and re-building U-Boot.

- Navigate to \$PKGDIR/src/u-boot directory and extract U-Boot source tarball

```
LINUXHOST$ cd $PKGDIR/src/u-boot
LINUXHOST$ tar -xzf u-boot-04.00.00.09.tar.gz
LINUXHOST$ cd u-boot-04.00.00.09
```

- Edit include/configs/ti8168_evm.h file to change CONFIG_BOOTCOMMAND as below:

```
#define CONFIG_BOOTCOMMAND "source 0x80400000"
```

- Build the U-Boot

```
LINUXHOST$ make CROSS_COMPILE=arm-none-linux-gnueabi- ti8168_evm_config
LINUXHOST$ make CROSS_COMPILE=arm-none-linux-gnueabi-
```

- Note that in the 1st step above, you can chose U-Boot configuration for any boot mode other than NOR boot mode.

Saving Boot Command on EP Storage

This approach requires access to U-Boot console and availability of persistent storage such as NAND on EP.

- Boot U-Boot on EP using PCIe Boot procedure described in next sections
- Halt U-Boot countdown by pressing ENTER at EP console
- Set 'bootcmd' at U-Boot prompt on EP as:

```
set bootcmd 'source 0x80400000'
saveenv
```

- Note that this is a one time operation and U-Boot will jump to correct script location on subsequent resets.

Building Kernel for EP

Note: The change mentioned below is not needed for TI814X when using release 04.01.00.05 or older and the kernel uImage built with ti8148_evm_defconfig can be used. For 04.01.00.06 and onwards release of TI814X kernel, the steps mentioned below should be followed since they have Root Complex support included.

As mentioned earlier in this section, the kernel built with PCIe RC support will result into conflicting configuration when booted on EP. To avoid this, it is recommended to rebuild the kernel with PCIe RC support disabled.

- As explained before, extract kernel source tarball and enter kernel configuration menu.

```
General setup --->
[*] Enable loadable module support --->
-* Enable the block layer --->
```

```
System Type   --->
Bus support   --->
...
```

- Scroll down with the DOWN Arrow key till "Bus Support" gets selected. Press ENTER. This will show following menu:

```
[*] PCI support
[*] Message Signaled Interrupts (MSI and MSI-X)
...
```

- Disable "PCI support" by pressing 'n' key or SPACE key. This will automatically hide other dependent configurations and the above configuration menu will look like as shown below:

```
[ ] PCI support
< > PCCard (PCMCIA/CardBus) support --->
```

- Use RIGHT Arrow key to bring focus on 'Exit' and press ENTER. Repeat this to return to previous menu(s) and eventually back to the shell. Make sure to save the changes you have made when prompted at exit.
- Build the kernel.

Updating the Filesystem

The kernel may not boot or provide shell prompt when the boot driver is built into kernel. This issue is due to the device node numbers (major numbers) used for console device(s) not getting updated as udev in the filesystem still uses stale nodes from the device cache in the filesystem even on detection or removal of EP device across RC reboots.

This issue can be avoided by forcing the rebuild of device cache on detecting change in boot time device detection. This can be achieved by updating the filesystem as follows:

- Add following check in /etc/rcS.d/S03udev inside DEVCACHE block

```
[ -r /proc/devices ] && cat /proc/devices > /tmp/devices || touch /tmp/devices
```

- Similarly, add comparison for saved device list to detect changes in devices

```
cmp -s /tmp/devices /etc/udev/saved.devices && \
```

- Now the devcache block will look as follows

```
if [ "$DEVCACHE" != "" ]; then
    # Invalidate udev cache if the kernel or its bootargs/cmdline have changed
    [ -x /bin/uname ] && /bin/uname -mrspv > /tmp/uname || touch /tmp/uname
    [ -r /proc/cmdline ] && cat /proc/cmdline > /tmp/cmdline || touch /tmp/cmdline
    [ -r /proc/devices ] && cat /proc/devices > /tmp/devices || touch /tmp/devices
    [ -r /proc/atags ] && cat /proc/atags > /tmp/atags || touch /tmp/atags
    if [ -e $DEVCACHE ] && \
        cmp -s /tmp/uname /etc/udev/saved.uname && \
        cmp -s /tmp/cmdline /etc/udev/saved.cmdline && \
        cmp -s /tmp/devices /etc/udev/saved.devices && \
        cmp -s /tmp/atags /etc/udev/saved.atags; then
        (cd /; tar xf $DEVCACHE > /dev/null 2>&1)
        not_first_boot=1
    fi
fi
```

```
fi
fi
```

- Update udev devcache script /etc/rcS.d/S12udev-cache to save device list by adding following line

```
mv /tmp/devices /etc/udev/saved.devices
```

- Update the same file with a line to delete temporary device list

```
rm -f /tmp/devices
```

- Now the dev cache code in this file will look like

```
if [ "$DEVCACHE" != "" ]; then
    echo -n "Populating dev cache"
    (cd /; tar cf $DEVCACHE dev)
    mv /tmp/uname /etc/udev/saved.uname
    mv /tmp/cmdline /etc/udev/saved.cmdline
    mv /tmp/atags /etc/udev/saved.atags
    mv /tmp/devices /etc/udev/saved.devices
    echo
else
    rm -f /tmp/uname
    rm -f /tmp/cmdline
    rm -f /tmp/atags
    rm -f /tmp/devices
fi
fi
```

- The above changes will ensure that udev will rebuild the device cache depending upon detection of PCIe EP presence or removal across RC reboots.

Other simpler (but not recommended) option is to turn of the device cache altogether. This can be done by commenting the DEVCACHE line in /etc/default/udev of the filesystem.

Updating the RC Kernel

Note: You will need RC kernel source to follow this section.

If you are using a non-TI81XX Root Complex device, you will need to patch the kernel to assign a valid class code to the TI816X EP detected. This is required because, TI816X devices configured to boot as PCIe Endpoint have class code = 0. This makes kernel PCI bus code to skip allocating BARs to these devices resulting into following type of error when trying to enable them:

```
"Device 0000:01:00.0 not available because of resource collisions"
```

The device cannot be operated because of the above issue.

Following patch would be required to be applied on RC kernel. Copy and save the text below in a file and apply patch using `patch -p 1 -i <filename>` command (replace <filename> with the name of the file where the patch is saved) in the RC kernel source tree.

```
diff --git a/drivers/pci/quirks.c b/drivers/pci/quirks.c
index 53a786f..2087f3d 100644
--- a/drivers/pci/quirks.c
+++ b/drivers/pci/quirks.c
```

```

@@ -2791,6 +2791,17 @@ DECLARE_PCI_FIXUP_EARLY(PCI_VENDOR_ID_INTEL, 0x342e, vtd_mask_spec_errors);
DECLARE_PCI_FIXUP_EARLY(PCI_VENDOR_ID_INTEL, 0x3c28, vtd_mask_spec_errors);
#endif

+static void __devinit fixup_ti81xx_class(struct pci_dev* dev)
+{
+    /* TI 81xx devices do not have class code set when in PCIe boot mode */
+    if (dev->class == PCI_CLASS_NOT_DEFINED) {
+        dev_info(&dev->dev, "Setting PCI class for 81xx PCIe device\n");
+        dev->class = PCI_CLASS_MULTIMEDIA_VIDEO;
+    }
+}
+DECLARE_PCI_FIXUP_EARLY(PCI_VENDOR_ID_TI, 0xb800, fixup_ti81xx_class);
+DECLARE_PCI_FIXUP_EARLY(PCI_VENDOR_ID_TI, 0xb801, fixup_ti81xx_class);
+
static void pci_do_fixups(struct pci_dev *dev, struct pci_fixup *f,
                        struct pci_fixup *end)
{

```

Note 1: You may need to manually resolve conflicts if RC kernel version is not 2.6.37.

Note 2: The above patch is not required to be applied if the RC is TI81XX and kernel used is from release 04.00.00.09 or onwards since it already comes with above patch applied.

Note: The above mentioned patch is needed only when you are relying on resource assignment from kernel. If the kernel is just using BIOS allocated resources (which is normal case on PCs), you need not apply this patch. Of course your device will be labeled as "unclassified" device when using a kernel without this patch.

For example:

```

LINUXHOST$ sudo lspci -v
...
01:00.0 Non-VGA unclassified device: Texas Instruments Device b800 (rev 01)
  Flags: bus master, fast devsel, latency 0, IRQ 11
  Memory at fe9ff000 (32-bit, non-prefetchable) [size=4K]
  Memory at f0800000 (32-bit, prefetchable) [size=8M]
  Memory at f0000000 (32-bit, prefetchable) [size=8M]
  Memory at <unassigned> (32-bit, prefetchable)
  Capabilities: [40] Power Management version 3
  Capabilities: [50] Message Signalled Interrupts: Mask- 64bit+ Queue=0/0 Enable-
  Capabilities: [70] Express Endpoint, MSI 00
  Capabilities: [100] Advanced Error Reporting <?>
...

```

Ensuring the PCIe System Initialization

Before proceeding to using the TI81XX PCIe EP in the system, we must ensure that the RC is up and has detected and configured the PCIe EP. Steps mentioned below should be carried out before actually accessing the EP and proceeding for boot.

- Make sure that the board setup instructions mentioned in earlier section are followed.
- Power on EP
- Power on RC
- Once shell is available at RC, type 'lspci' command, it should show following two devices (EP in this example is TI816X):

```
ti8168-evm# lspci -v
00:00.0 Class 0604: Device 104c:8888 (rev 01)
    Flags: bus master, fast devsel, latency 0
    Memory at <ignored> (32-bit, non-prefetchable)
    Memory at <ignored> (32-bit, prefetchable)
    Bus: primary=00, secondary=01, subordinate=01, sec-latency=0
    Memory behind bridge: 21000000-210fffff
    Prefetchable memory behind bridge: 20000000-20ffffff
    Capabilities: [40] Power Management version 3
    Capabilities: [50] MSI: Enable- Count=1/1 Maskable- 64bit+
    Capabilities: [70] Express Root Port (Slot-), MSI 00
    Capabilities: [100] Advanced Error Reporting

01:00.0 Class 0004: Device 104c:b800 (rev 01)
    Flags: fast devsel, IRQ 48
    Memory at 21000000 (32-bit, non-prefetchable) [size=4K]
    Memory at 20000000 (32-bit, prefetchable) [size=8M]
    Memory at 20800000 (32-bit, prefetchable) [size=8M]
    Memory at <unassigned> (32-bit, prefetchable)
    Capabilities: [40] Power Management version 3
    Capabilities: [50] MSI: Enable- Count=1/1 Maskable- 64bit+
    Capabilities: [70] Express Endpoint, MSI 00
    Capabilities: [100] Advanced Error Reporting
```

- If 'lspci' is not available in your filesystem, look into `/sys/bus/pci/devices` directory to see if EP is detected. You should see two sub directories in this directory, e.g., see following command and its output:

```
cat /sys/bus/pci/devices/0000\:0*/device
0x8888
0xb800
```

- The first device is RC itself and the second device is EP
- Note that, in case the x86 PC is used as RC, the "lspci" would only show TI816X EP along with other PCI/PCIe devices connected to PC motherboard.
- Notice that the EP is allocated three BARs - BAR0, BAR1 and BAR2 of size 4KB, 8MB and 8MB respectively.
- In case the EP is TI814X device, BAR2 size will be 16MB

Load Addresses

The boot application loads various images at following addresses on EP:

Image	EP Device	Load Address
U-Boot 1st Stage	TI814X	0x40300000
U-Boot	TI816X	0x40400000
	TI814X (2nd Stage)	0x80800000
Kernel	TI816X	0x80900000
	TI814X	
Ramdisk	TI816X	0x81000000
	TI814X	
Bootscrip	TI816X	0x80400000
	TI814X	

Booting EP

- Download PCIe EP Boot driver, U-Boot, U-Boot script, kernel image and ramdisk file (optional) on RC.
- These files can be downloaded over network using TFTP or can be copied to NFS mounted filesystem
- In our example, we will use following commands on RC:

```
ti8168-evm# tftp -m binary 192.168.0.1 -c get ti81xx_pcie_bootdrv.ko
ti8168-evm# tftp -m binary 192.168.0.1 -c get saBootApplication
ti8168-evm# tftp -m binary 192.168.0.1 -c get u-boot.bin
ti8168-evm# tftp -m binary 192.168.0.1 -c get boot.scr
ti8168-evm# tftp -m binary 192.168.0.1 -c get uImage
ti8168-evm# tftp -m binary 192.168.0.1 -c get ramdisk.gz
```

Note: Additionally, transfer the 1st stage U-Boot MLO used for MMC/SD boot in case of TI814X EP.

- Make boot application as executable:

```
ti8168-evm# chmod a+x saBootApplication
```

- Insert boot driver:

```
ti8168-evm# insmod ti81xx_pcie_bootdrv.ko
ti81xx_pcie_ep: Found TI816x PCIe EP @0xc781ec00
pci 0000:01:00.0: This driver supports booting the first TI816x or TI814x target found on the bus
pci 0000:01:00.0: Major number 253 assigned
pci 0000:01:00.0: Added device to the sys file system
pci 0000:01:00.0: BAR Configuration -
      Start      |      Length      |      Flags
pci 0000:01:00.0: 0x21000000 | 4096 | 0x00040200
pci 0000:01:00.0: 0x20000000 | 8388608 | 0x00042208
pci 0000:01:00.0: 0x20800000 | 8388608 | 0x00042208
pci 0000:01:00.0: TI81XX registers mapped to 0xc8886000
pci 0000:01:00.0: TI81XX OCMC1 mapped to 0xca000000
pci 0000:01:00.0: TI81XX DDR mapped to 0xcb000000
```


- Or, if the Linux PC is set up as RC (assuming the source directory mentioned in earlier sections is used):

```
LINUXHOST$ cd /home/builduser/kernel/src/
LINUXHOST$ sudo insmod drivers/char/ti81xx_pcie_bootdrv.ko
```

- The above log shows that three BARs on the EP are set up with 4KB, 8MB and 8MB size respectively.
- You may need to create node "/dev/ti81xx_pcie_ep" with the major number displayed when PCIe Boot Driver module is inserted. This depends on the filesystem and configuration, e.g., 'udev' should do this automatically.
- In case the device node is not created automatically, use following command sequence:

```
ti8168-evm# cat /proc/devices
Character devices:
 1 mem
:
:
253 ti81xx_pcie_ep          <--- Our device major number is 253
:
ti8168-evm# mknod /dev/ti81xx_pcie_ep c 253 0
```

- Run the boot application providing U-Boot, bootscript, kernel and ramdisk names as:

```
ti8168-evm# ./saBootTest u-boot.bin boot.scr uImage ramdisk.gz
```

- For TI814X EP, ensure that MLO binary is present in same directory as boot application
- Or on PC (assuming all required binaries are present in current directory):

```
LINUXHOST$ sudo ./saBootTest u-boot.bin boot.scr uImage ramdisk.gz
```

- Alternatively, you can use NFS root system on EP by updating the bootscript.txt accordingly and using the corresponding bootscript image. In this case, you need not download the ramdisk image.

```
ti8168-evm# ./saBootTest u-boot.bin boot.scr uImage
```

- The boot application will use boot driver to configure the EP and download the images to complete boot operation.

Note: You will see some messages about "Bootflag clear timed out" during the boot process. This is normal since the current U-Boot doesn't support clearing the boot flag in OCMC1 RAM at EP (location 0x40403FFC in case of TI816X EP) as set by the PCIe Boot code running on RC. The application will still proceed to complete boot operation.

References

- [1] <http://creativecommons.org/licenses/by-sa/3.0/>

Article Sources and Contributors

TI81XX PCI Express Endpoint Boot Driver User Guide *Source:* <http://processors.wiki.ti.com/index.php?oldid=95586> *Contributors:* Hemantp

Image Sources, Licenses and Contributors

Image: **TIBanner.png** *Source:* <http://processors.wiki.ti.com/index.php?title=File:TIBanner.png> *License:* unknown *Contributors:* Nsnehaprabha

License

THE WORK (AS DEFINED BELOW) IS PROVIDED UNDER THE TERMS OF THIS CREATIVE COMMONS PUBLIC LICENSE ("CCPL" OR "LICENSE"). THE WORK IS PROTECTED BY COPYRIGHT AND/OR OTHER APPLICABLE LAW. ANY USE OF THE WORK OTHER THAN AS AUTHORIZED UNDER THIS LICENSE OR COPYRIGHT LAW IS PROHIBITED. BY EXERCISING ANY RIGHTS TO THE WORK PROVIDED HERE, YOU ACCEPT AND AGREE TO BE BOUND BY THE TERMS OF THIS LICENSE. TO THE EXTENT THIS LICENSE MAY BE CONSIDERED TO BE A CONTRACT, THE LICENSOR GRANTS YOU THE RIGHTS CONTAINED HERE IN CONSIDERATION OF YOUR ACCEPTANCE OF SUCH TERMS AND CONDITIONS.

License

1. Definitions

- a. **"Adaptation"** means a work based upon the Work, or upon the Work and other pre-existing works, such as a translation, adaptation, derivative work, arrangement of music or other alterations of a literary or artistic work, or phonogram or performance and includes cinematographic adaptations or any other form in which the Work may be recast, transformed, or adapted including in any form recognizably derived from the original, except that a work that constitutes a Collection will not be considered an Adaptation for the purpose of this License. For the avoidance of doubt, where the Work is a musical work, performance or phonogram, the synchronization of the Work in timed-relation with a moving image ("synching") will be considered an Adaptation for the purpose of this License.
- b. **"Collection"** means a collection of literary or artistic works, such as encyclopedias and anthologies, or performances, phonograms or broadcasts, or other works or subject matter other than works listed in Section 1(f) below, which, by reason of the selection and arrangement of their contents, constitute intellectual creations, in which the Work is included in its entirety in unmodified form along with one or more other contributions, each constituting separate and independent works in themselves, which together are assembled into a collective whole. A work that constitutes a Collection will not be considered an Adaptation (as defined below) for the purposes of this License.
- c. **"Creative Commons Compatible License"** means a license that is listed at <http://creativecommons.org/compatlicenses> that has been approved by Creative Commons as being essentially equivalent to this License, including, at a minimum, because that license: (i) contains terms that have the same purpose, meaning and effect as the License Elements of this License; and, (ii) explicitly permits the relicensing of adaptations of works made available under that license under this License or a Creative Commons jurisdiction license with the same License Elements as this License.
- d. **"Distribute"** means to make available to the public the original and copies of the Work or Adaptation, as appropriate, through sale or other transfer of ownership.
- e. **"License Elements"** means the following high-level license attributes as selected by Licensor and indicated in the title of this License: Attribution, ShareAlike.
- f. **"Licensor"** means the individual, individuals, entity or entities that offer(s) the Work under the terms of this License.
- g. **"Original Author"** means, in the case of a literary or artistic work, the individual, individuals, entity or entities who created the Work or if no individual or entity can be identified, the publisher; and in addition (i) in the case of a performance the actors, singers, musicians, dancers, and other persons who act, sing, deliver, declaim, play in, interpret or otherwise perform literary or artistic works or expressions of folklore; (ii) in the case of a phonogram the producer being the person or legal entity who first fixes the sounds of a performance or other sounds; and, (iii) in the case of broadcasts, the organization that transmits the broadcast.
- h. **"Work"** means the literary and/or artistic work offered under the terms of this License including without limitation any production in the literary, scientific and artistic domain, whatever may be the mode or form of its expression including digital form, such as a book, pamphlet and other writing; a lecture, address, sermon or other work of the same nature; a dramatic or dramatico-musical work; a choreographic work or entertainment in dumb show; a musical composition with or without words; a cinematographic work to which are assimilated works expressed by a process analogous to cinematography; a work of drawing, painting, architecture, sculpture, engraving or lithography; a photographic work to which are assimilated works expressed by a process analogous to photography; a work of applied art; an illustration, map, plan, sketch or three-dimensional work relative to geography, topography, architecture or science; a performance; a broadcast; a phonogram; a compilation of data to the extent it is protected as a copyrightable work; or a work performed by a variety or circus performer to the extent it is not otherwise considered a literary or artistic work.
- i. **"You"** means an individual or entity exercising rights under this License who has not previously violated the terms of this License with respect to the Work, or who has received express permission from the Licensor to exercise rights under this License despite a previous violation.
- j. **"Publicly Perform"** means to perform public recitations of the Work and to communicate to the public those public recitations, by any means or process, including by wire or wireless means or public digital performances; to make available to the public Works in such a way that members of the public may access these Works from a place and at a place individually chosen by them; to perform the Work to the public by any means or process and the communication to the public of the performances of the Work, including by public digital performance; to broadcast and rebroadcast the Work by any means including signs, sounds or images.
- k. **"Reproduce"** means to make copies of the Work by any means including without limitation by sound or visual recordings and the right of fixation and reproducing fixations of the Work, including storage of a protected performance or phonogram in digital form or other electronic medium.

2. Fair Dealing Rights

Nothing in this License is intended to reduce, limit, or restrict any uses free from copyright or rights arising from limitations or exceptions that are provided for in connection with the copyright protection under copyright law or other applicable laws.

3. License Grant

Subject to the terms and conditions of this License, Licensor hereby grants You a worldwide, royalty-free, non-exclusive, perpetual (for the duration of the applicable copyright) license to exercise the rights in the Work as stated below:

- a. to Reproduce the Work, to incorporate the Work into one or more Collections, and to Reproduce the Work as incorporated in the Collections;
- b. to create and Reproduce Adaptations provided that any such Adaptation, including any translation in any medium, takes reasonable steps to clearly label, demarcate or otherwise identify that changes were made to the original Work. For example, a translation could be marked "The original work was translated from English to Spanish," or a modification could indicate "The original work has been modified.";
- c. to Distribute and Publicly Perform the Work including as incorporated in Collections; and,
- d. to Distribute and Publicly Perform Adaptations.
- e. For the avoidance of doubt:
- i. **Non-waivable Compulsory License Schemes.** In those jurisdictions in which the right to collect royalties through any statutory or compulsory licensing scheme cannot be waived, the Licensor reserves the exclusive right to collect such royalties for any exercise by You of the rights granted under this License;
- ii. **Waivable Compulsory License Schemes.** In those jurisdictions in which the right to collect royalties through any statutory or compulsory licensing scheme can be waived, the Licensor waives the exclusive right to collect such royalties for any exercise by You of the rights granted under this License; and,
- iii. **Voluntary License Schemes.** The Licensor waives the right to collect royalties, whether individually or, in the event that the Licensor is a member of a collecting society that administers voluntary licensing schemes, via that society, from any exercise by You of the rights granted under this License.

The above rights may be exercised in all media and formats whether now known or hereafter devised. The above rights include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. Subject to Section 8(f), all rights not expressly granted by Licensor are hereby reserved.

4. Restrictions

The license granted in Section 3 above is expressly made subject to and limited by the following restrictions:

- a. You may Distribute or Publicly Perform the Work only under the terms of this License. You must include a copy of, or the Uniform Resource Identifier (URI) for, this License with every copy of the Work You Distribute or Publicly Perform. You may not offer or impose any terms on the Work that restrict the terms of this License or the ability of the recipient of the Work to exercise the rights granted to that recipient under the terms of the License. You may not sublicense the Work. You must keep intact all notices that refer to this License and to the disclaimer of warranties with every copy of the Work You Distribute or Publicly Perform. When You Distribute or Publicly Perform the Work, You may not impose any effective technological measures on the Work that restrict the ability of a recipient of the Work from You to exercise the rights granted to that recipient under the terms of the License. This Section 4(a) applies to the Work as incorporated in a Collection, but this does not require the Collection apart from the Work itself to be made subject to the terms of this License. If You create a Collection, upon notice from any Licensor You must, to the extent practicable, remove from the Collection any credit as required by Section 4(c), as requested. If You create an Adaptation, upon notice from any Licensor You must, to the extent practicable, remove from the Adaptation any credit as required by Section 4(c), as requested.
- b. You may Distribute or Publicly Perform an Adaptation only under the terms of: (i) this License; (ii) a later version of this License with the same License Elements as this License; (iii) a Creative Commons jurisdiction license (either this or a later license version) that contains the same License Elements as this License (e.g., Attribution-ShareAlike 3.0 US); (iv) a Creative Commons Compatible License. If you license the Adaptation under one of the licenses mentioned in (iv), you must comply with the terms of that license. If you license the Adaptation under the terms of any of the licenses mentioned in (i), (ii) or (iii) (the "Applicable License"), you must comply with the terms of the Applicable License generally and the following provisions: (I) You must include a copy of, or the URI for, the Applicable License with every copy of each Adaptation You Distribute or Publicly Perform; (II) You may not offer or impose any terms on the Adaptation that restrict the terms of the Applicable License or the ability of the recipient of the Adaptation to exercise the rights granted to that recipient under the terms of the Applicable License; (III) You must keep intact all notices that refer to the Applicable License and to the disclaimer of warranties with every copy of the Work as included in the Adaptation You Distribute or Publicly Perform; (IV) when You Distribute or Publicly Perform the Adaptation, You may not impose any effective technological measures on the Adaptation that restrict the ability of a recipient of the Adaptation from You to exercise the rights granted to that recipient under the terms of the Applicable License. This Section 4(b) applies to the Adaptation as incorporated in a Collection, but this does not require the Collection apart from the Adaptation itself to be made subject to the terms of the Applicable License.
- c. If You Distribute, or Publicly Perform the Work or any Adaptations or Collections, You must, unless a request has been made pursuant to Section 4(a), keep intact all copyright notices for the Work and provide, reasonable to the medium or means You are utilizing: (i) the name of the Original Author (or pseudonym, if applicable) if supplied, and/or if the Original Author and/or Licensor designate another party or parties (e.g., a sponsor institute, publishing entity, journal) for attribution ("Attribution Parties") in Licensor's copyright notice, terms of service or by other reasonable means, the name of such party or parties; (ii) the title of the Work if supplied; (iii) to the extent reasonably practicable, the URI, if any, that Licensor specifies to be associated with the Work, unless such URI does not refer to the copyright notice or licensing information for the Work; and (iv), consistent with Section 3(b), in the case of an Adaptation, a credit identifying the use of the Work in the Adaptation (e.g., "French translation of the Work by Original Author," or "Screenplay based on original Work by Original Author"). The credit required by this Section 4(c) may be implemented in any reasonable manner; provided, however, that in the case of a Adaptation or Collection, at a minimum such credit will appear, if a credit for all contributing authors of the Adaptation or Collection appears, then as part of these credits and in a manner at least as prominent as the credits for the other contributing authors. For the avoidance of doubt, You may only use the credit required by this Section for the purpose of attribution in the manner set out above and, by exercising Your rights under this License, You may not implicitly or explicitly assert or imply any connection with, sponsorship or endorsement by the Original Author, Licensor and/or Attribution Parties, as appropriate, of You or Your use of the Work, without the separate, express prior written permission of the Original Author, Licensor and/or Attribution Parties.
- d. Except as otherwise agreed in writing by the Licensor or as may be otherwise permitted by applicable law, if You Reproduce, Distribute or Publicly Perform the Work either by itself or as part of any Adaptations or Collections, You must not distort, mutilate, modify or take other derogatory action in relation to the Work which would be prejudicial to the Original Author's honor or reputation. Licensor agrees that in those jurisdictions (e.g. Japan), in which any exercise of the right granted in Section 3(b) of this License (the right to make Adaptations) would be deemed to be a distortion, mutilation, modification or other derogatory action prejudicial to the Original Author's honor and reputation, the Licensor will waive or not assert, as appropriate, this Section, to the fullest extent permitted by the applicable national law, to enable You to reasonably exercise Your right under Section 3(b) of this License (right to make Adaptations) but not otherwise.

5. Representations, Warranties and Disclaimer

UNLESS OTHERWISE MUTUALLY AGREED TO BY THE PARTIES IN WRITING, LICENSOR OFFERS THE WORK AS-IS AND MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND CONCERNING THE WORK, EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF TITLE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT, OR THE ABSENCE OF LATENT OR OTHER DEFECTS, ACCURACY, OR THE PRESENCE OF ABSENCE OF ERRORS, WHETHER OR NOT DISCOVERABLE. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO SUCH EXCLUSION MAY NOT APPLY TO YOU.

6. Limitation on Liability

EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW, IN NO EVENT WILL LICENSOR BE LIABLE TO YOU ON ANY LEGAL THEORY FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES ARISING OUT OF THIS LICENSE OR THE USE OF THE WORK, EVEN IF LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

7. Termination

- a. This License and the rights granted hereunder will terminate automatically upon any breach by You of the terms of this License. Individuals or entities who have received Adaptations or Collections from You under this License, however, will not have their licenses terminated provided such individuals or entities remain in full compliance with those licenses. Sections 1, 2, 5, 6, 7, and 8 will survive any termination of this License.
- b. Subject to the above terms and conditions, the license granted here is perpetual (for the duration of the applicable copyright in the Work). Notwithstanding the above, Licensor reserves the right to release the Work under different license terms or to stop distributing the Work at any time; provided, however that any such election will not serve to withdraw this License (or any other license that has been, or is required to be, granted under the terms of this License), and this License will continue in full force and effect unless terminated as stated above.

8. Miscellaneous

- a. Each time You Distribute or Publicly Perform the Work or a Collection, the Licensor offers to the recipient a license to the Work on the same terms and conditions as the license granted to You under this License.
- b. Each time You Distribute or Publicly Perform an Adaptation, Licensor offers to the recipient a license to the original Work on the same terms and conditions as the license granted to You under this License.
- c. If any provision of this License is invalid or unenforceable under applicable law, it shall not affect the validity or enforceability of the remainder of the terms of this License, and without further action by the parties to this agreement, such provision shall be reformed to the minimum extent necessary to make such provision valid and enforceable.
- d. No term or provision of this License shall be deemed waived and no breach consented to unless such waiver or consent shall be in writing and signed by the party to be charged with such waiver or consent.
- e. This License constitutes the entire agreement between the parties with respect to the Work licensed here. There are no understandings, agreements or representations with respect to the Work not specified here. Licensor shall not be bound by any additional provisions that may appear in any communication from You. This License may not be modified without the mutual written agreement of the Licensor and You.
- f. The rights granted under, and the subject matter referenced, in this License were drafted utilizing the terminology of the Berne Convention for the Protection of Literary and Artistic Works (as amended on September 28, 1979), the Rome Convention of 1961, the WIPO Copyright Treaty of 1996, the WIPO Performances and Phonograms Treaty of 1996 and the Universal Copyright Convention (as revised on July 24, 1971). These rights and subject matter take effect in the relevant jurisdiction in which the License terms are sought to be enforced according to the corresponding provisions of the implementation of those treaty provisions in the applicable national law. If the standard suite of rights granted under applicable copyright law includes additional rights not granted under this License, such additional rights are deemed to be included in the License; this License is not intended to restrict the license of any rights under applicable law.