

# Water Linked DVL serial protocol Draft 1

This document describes the Water Linked DVL protocol.

The document is currently in draft state and might change before release.

## Terminology

- DVL - Doppler Velocity Log - Hydro-acoustic unit which uses acoustic beams to measure distance to bottom surface and the velocity which the unit is moving across the surface.
- ACK - Acknowledgement. The command issued was successful.
- NAK - Negative acknowledgement. The command issued failed.

## Version

This document describes protocol/software version 2,0,x (major,minor,patch)

The protocol versioning follows semantic versioning in that:

- MAJOR version increments represents incompatible API changes,
- MINOR version increments represents added functionality in a backwards-compatible manner
- PATCH version increments represents backwards-compatible bug fixes

## Overview

The serial communication format is 115200 8-N-1 (no hardware flow control).

Packets sent to and received from the DVL start with a **w** and end with end with LF or CR+LF. The packet format is:

Start byte	Direction	Command	Options (0 to many)	Checksum	End byte
<b>w</b>	<b>c</b> or <b>r</b>	<b>x</b>	<b>, [option]</b>	<b>*xx</b>	<b>\n</b> or <b>\r\n</b>

Direction is command (**c**) for commands issued to the DVL and the DVL replies with direction set to response (**r**). The commands can be sent as a string or entered one char at a time from a terminal.

The protocol can support Water Linked DVLs with different features sets. To support any Water Linked DVL the connection procedure is to:

- Get protocol version. Verify that the major version number is 2.
- Get product detail. Verify product type is dvl.

!!!note Checksum is optional when sending commands to the DVL. The DVL always returns a checksum. The checksum algorithm is CRC-8 and it is formatted as a hexadecimal number using 2 lower-case charaters (ex: **\*c3**).

## Commands

Commands in the table are shown **without** the checksum for readability.

Command	Description	Response	Description
<b>wcv</b>	Get protocol version	<b>wrv</b> , [major],[minor],[patch]	Protocol version. eg: <b>wrv</b> , 2, 0, 0
<b>wcw</b>	Get product detail	<b>wrw</b> , [type],[name],[version]	Where type is dvl, name is product name and version is product version: eg: <b>wrw</b> , dvl, dvl-a50, 1.0.0-20191225-xxxxyyyyy
		<b>wrx</b> , [details below]	Velocities measured. See details below
		<b>wr?</b>	Malformed request: Response when packet cannot be understood
		<b>wr!</b>	Malformed request: Packet does not match the given checksum

## Velocity report

Velocity report is outputted after each measurement has been completed. The expected update rate varies depending on the altitude and will be in the range is from 2-10 Hz. The X, Y, Z axis are oriented according to the marking on the DVL.

The velocities measured response is on the following format: **wrx**, [time],[vx],[vy],[vz],[std],[distance]

Variable	Description
time	Milliseconds since last velocity report
vx	Measured velocity in x direction (m/s)
vy	Measured velocity in y direction (m/s)
vz	Measured velocity in z direction (m/s)
std	Standard deviation (m/s), a measure of the accuracy of the measured velocities
distance	Measured distance/altitude to the bottom

If the DVL loses bottom track the distance value will be set to -1, velocities (vx, vy, vz) set to 0 and std set to -100.

Example: **wrx**, 125, 0.05, 0.01, 0.001, 0.5, 0.1