

Manaway Ora – Maintenance and cleaning instructions

Cleaning

Exterior

1. Disconnect hoses and filters
2. Wipe the outside of the cabinet with a damp clean cloth. Light solvents and detergents may be used

Interior

1. Clean the exterior, do not connect hoses until interior cleaning is complete
2. Connect a 22mm hose to the expiration connector on the front of the unit
3. Connect the expiration connector at the rear of the unit to a watertight receptacle
4. If a flow sensor is fitted to the expiration channel (this is an optional extra), then this sensor must be removed prior to the following step. Also prior to the following step, screw the supplied blind fitting in place of the flow sensor.
5. Flush ten (10) litres of water-disinfectant solution through, from the front to the rear, of the expiration channel
6. NEVER FLUSH LIQUIDS THROUGH THE INSPIRATION SIDE OF THE MACHINE.

Maintenance

1. The filters and humidifier are external to the unit and should be maintained/replaced as required by the manufacturer
2. The 12v solenoids should be replaced every 4000 hours.