

# SGS01BTHome Manual



Document-Version: V1.0\_rev\_0

## Operation

Die SGS01BTHome has two operation modes: “Connection Mode” and “Measure Mode”. On startup, if the device is not paired, it enters “Operation Mode” for 60 seconds, before switching to “Measure Mode”. If the device is already paired, it starts up directly with “Measure Mode”.

|                 |  |
|-----------------|--|
| Connection Mode | <p>Connect and pair the device.</p> <p>Unpaired device:</p> <ul style="list-style-type: none"><li>Sends BLE ADVind advertisements with device name and appearance.</li></ul> <p>Paired device:</p> <ul style="list-style-type: none"><li>Sends BLE ADVdirect advertisements (no data).</li></ul> <p>Mode timeout 60 seconds. BLE connection timeout 4 minutes.</p>   |
| Measure Mode    | <p>Config. Device Mode 0 (default, ultra low power):</p> <ul style="list-style-type: none"><li>Sends BLE ADVnoconn advertisements with sensor data in BTHome format. Device is not connectable.</li><li>ADV interval 8 seconds.</li></ul> <p>Config. Device Mode 1:</p> <ul style="list-style-type: none"><li>Sends BLE ADVind advertisements with sensor data in BTHome format and allows BLE connections “low duty”.</li><li>ADV interval 3 seconds.</li></ul> |

## Button

|                     |  |
|---------------------|--|
| Short Press         | Toogle between the operation modes.              |
| Long Press (10 sec) | Factory Reset (reset configuration. and pairing) |

## LED

The LED is connected to the MCU and cannot be controlled direct by the module firmware. The LED should flash in “Connection Mode”.

## Encryption

To encrypt the device after a factory reset:

1. Connect (and pair) the device to get a BLE encrypted device connection.
2. Write a 6 digit pin number to the BLE attribute "Pin Code".  
Format: 4 bytes little endian (eg. 0x40,0xE2,0x01,0x00 for "123456").
3. Disconnect and reconnect/pair the device.  
For authentication enter the 6 digits pin number.  
An authenticated, encrypted and secured connection will be established.  
Rem.: May need delete pairing/bonding info at your BLE master before  
Rem.: Sometimes you need two attempts (Android, unknown reason)
4. The device will itself create and persist store a random CCM encryption key (16 bytes) for BTHome data.  
You can read and modify the key, see BLE attribute "Encryption Key".
5. BTHome data will be send encrypted.

Alternative method "low-level" (No device connection or pairing needed):

1. After flashing the firmware – flash a configuration with a fixed encryption key.
2. Create a bin file with:  
4 bytes magic 68 61 70 70  
4 bytes zero  
16 bytes encryption key  
Example file is at "test/config-keytest.bin".
3. Flash the configuration file to sector 7C000.
4. Restart the sensor with power off/on.

## Sensor configuration

| <b>BLE Attribute</b> | <b>Values</b>  |
|----------------------|--|
| "Pin Code"           | 6 digit number used for authentication.<br>Value type: UINT32 little endian  |
| "Encryption Key"     | 16 bytes value for BTHome data encryption (0=none)   |
| "Power Level"        | +10 to -5 dbm<br>Value type: signed byte   |
| "Device Mode"        | 0x00 = ultra low power (no connect in measure mode)<br>0x01 = medium power (connect in measure mode)<br>see "Operation"                    |
| "Data Format"        | 0x00 = default (BTHome V2)<br>0x01 = BTHome V1 (depreciated, no encryption)<br>0x02 = BTHome V2<br>0x04 = Xiaomi (no encryption supported) |
| "Factory Reset"      | 0x02 = soft restart<br>0x03 = factory reset<br>(Will be executed after disconnect)   |

## Estimated battery lifetime

|                       |  |
|-----------------------|--|
| Current alive         | 3V 20mA (todo ? check/measure average) |
| Current deep sleep    | 3V 19uA                                |
| Critical Bat. Voltage | 2,6V (2x 1,3V low duty)                |
| Bat. Capacity:        | 1000 mAh                               |
| Dev.Mode 0: no conn   | <4 ms / 8 sec (sleep/alive)            |
| Dev.Mode 1: no conn   | 4,5 ms / 3 sec (sleep/alive)           |
| Dev.Mode 2: conn      | 5 ms / 1 sec (sleep/alive)             |

### Lifetime (calculated)

|                     |           |                |
|---------------------|-----------|----------------|
| Dev.Mode 0: no conn | 34800 hrs | <b>4 years</b> |
| Dev.Mode 1: no conn | 20400 hrs | 2,3 years      |
| Dev.Mode 1: conn    | 8500 hrs  | 1 year         |

Remark: Values have to be checked.

## BLE GATT attribute list

|                   |                                      |                    |
|-------------------|--------------------------------------|--------------------|
| Service           | 1800                                 | GAP                |
| Device Name       | 2a00                                 |                    |
| Appearance        | 2a01                                 |                    |
| Peri.Conn.Param.  | 2a04                                 |                    |
| Service           | 1801                                 | GATT               |
| Service Changed   | 2a05                                 |                    |
| Service           | 180A                                 | Device Information |
| Serial Number     | 2a25                                 |                    |
| Firmware Revision | 2a26                                 |                    |
| Hardware Revision | 2a27                                 |                    |
| Software Revision | 2a28                                 |                    |
| Manufacturer      | 2a29                                 |                    |
| Service           | 180F                                 | Battery Service    |
| Battery Level     | 2a19                                 |                    |
| Service           | DE8A5AAC-A99B-C315-0C80-60D4CBB51225 |                    |
| Pin Code          | 0ffb7104-860c-49ae-8989-1f946d5f6c03 |                    |
| Encryption Key    | eb0fb41b-af4b-4724-a6f9-974f55aba81a |                    |
| Power Level       | 2a07                                 |                    |
| Device Mode       | 9546a800-d32e-4573-81e1-d597c5e1da74 |                    |
| Data Format       | 9546a801-d32e-4573-81e1-d597c5e1da74 |                    |
| BTHome Data       | d52246df-98ac-4d21-be1b-70d5f66a5ddb |                    |
| Factory Reset     | b0a7e40f-2b87-49db-801c-eb3686a24bdb |                    |
| Service           | 00010203-0405-0607-0809-0a0b0c0d1912 | TELink OTA         |
| OTA Data          | 00010203-0405-0607-0809-0a0b0c0d2b12 |                    |

## Copyright / Licence

Copyright (c) 2025, haraldapp, <https://github.com/haraldapp>

Licensed under the Apache License, Version 2.0 (the "License"), you may not use this file except in compliance with the License.

You may obtain a copy of the License at <http://www.apache.org/licenses/LICENSE-2.0>.

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied.

See the License for the specific language governing permissions and limitations under the License.