

PCF8574-I2C

Generated on Sat Jan 17 2026 09:02:39 for PCF8574-I2C by Doxygen 1.9.8

Sat Jan 17 2026 09:02:39

1 PCF8574-I2C Library	1
1.1 Contents	1
1.2 Library Documentation	1
1.3 Library Usage	1
1.3.1 Controllers	1
1.3.2 Usage the PCF8574-I2C Library in the Code	2
1.3.3 Status Codes of PCF8574	2
1.4 License	2
1.5 Helpful Links	2
2 Class Index	3
2.1 Class List	3
3 File Index	5
3.1 File List	5
4 Class Documentation	7
4.1 PCF8574_I2C::PCF8574 Class Reference	7
4.1.1 Constructor & Destructor Documentation	7
4.1.1.1 PCF8574()	7
4.1.2 Member Function Documentation	8
4.1.2.1 begin()	8
4.1.2.2 readPin()	8
4.1.2.3 resetPort()	8
4.1.2.4 rotateLeft()	9
4.1.2.5 rotateRight()	9
4.1.2.6 setPin()	9
4.1.2.7 setPort()	10
4.1.2.8 toggle()	10
5 File Documentation	13
5.1 src/PCF8574-I2C.cpp File Reference	13
5.1.1 Detailed Description	13
5.2 src/PCF8574-I2C.hpp File Reference	13
5.2.1 Detailed Description	14
5.3 PCF8574-I2C.hpp	14
Index	17

Chapter 1

PCF8574-I2C Library

Arduino Library for PCF8574, a 8-port GPIO exander via i2c

1.1 Contents

- Library Documentation
- Library Usage
- License
- Helpful Links

1.2 Library Documentation

The library documentation is mainly placed in the following pdf document [refman.pdf](#) or located under the following github pages [github.io](#).
Additionally in combination with the technical datasheet of microchip [PCF8574-Datasheet](#).

1.3 Library Usage

1.3.1 Controllers

The library is intended to be used on each microcontroller for Example:

- Arnuino Nano
- Arduino Nano 33 IOT
- ESP8266
- ESP32
- etc ...

1.3.2 Usage the PCF8574-I2C Library in the Code

Include the library in you project via:

```
#include <PCF8574-I2C.h>
```

Instance an new PCF8574 object by:

```
PCF8574_I2C::PCF8574 pcf{0x20, &Wire};  
or simply use implicit defined Wire object like:  
PCF8574_I2C::PCF8574 pcf{0x20};
```

Now you can use the object and his members as normal like:

```
PCF8574_I2C::PCF8574 pcf{0x20, &Wire};  
void setup() {  
    Serial.begin(115200);  
    Serial.print("\n\nPCF8574 Test file with ESP8266-01\n");  
  
    Wire.begin(2, 0);  
  
    if (pcf.begin() == PCF8574_I2C::PCF8574_STATE_OK) {  
        Serial.print("\tPCF8574 Connection OK!\n");  
    }  
    else {  
        Serial.print("\tNO PCF8574 device found!\n");  
    }  
    pcf.resetPort();  
}
```

Please refer to the examples and the above mentioned documentation files.

1.3.3 Status Codes of PCF8574

The following status codes exists:

- PCF8574_STATE_OK {0};
- PCF8574_ERROR_PIN {-1};
- PCF8574_ERROR_I2C {-2};
- PCF8574_ERROR_VALUE {-3};

1.4 License

This library is licensed under MIT Licence.

[PCF8574-I2C License](#)

1.5 Helpful Links

- [ESP8266-01-Adapter](#)

Chapter 2

Class Index

2.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

PCF8574_I2C::PCF8574	7
--	-------------------

Chapter 3

File Index

3.1 File List

Here is a list of all documented files with brief descriptions:

src/ PCF8574-I2C.cpp	
Library for a PCF8574 GPIO expander	13
src/ PCF8574-I2C.hpp	
Library for a PCF8574 GPIO expander	13

Chapter 4

Class Documentation

4.1 PCF8574_I2C::PCF8574 Class Reference

Public Member Functions

- [PCF8574](#) (const uint8_t address=0x20, TwoWire *wire=&Wire)
Construct a new [PCF8574](#) object.
- int8_t [begin](#) () const
begin method which initializes and verifies connection. Calls isDevicePresent()
- int8_t [resetPort](#) ()
reset the [PCF8574](#) device, set all port pins to input
- int16_t [readPin](#) (int8_t pin=-1)
read pin(s) from port
- int8_t [setPin](#) (uint8_t pin, uint8_t value)
Set the a specific pin on the PCF8474 to 0 or 1.
- int8_t [setPort](#) (uint8_t value)
Set the Port at once to an value.
- int8_t [toggle](#) (uint8_t mask)
toggle pins by give a mask which pin to toggle
- int8_t [rotateLeft](#) ()
rotate Port to the left
- int8_t [rotateRight](#) ()
rotate port to the right

4.1.1 Constructor & Destructor Documentation

4.1.1.1 PCF8574()

```
PCF8574::PCF8574 (
    const uint8_t address = 0x20,
    TwoWire * wire = &Wire )
```

Construct a new [PCF8574](#) object.

Parameters

<i>address</i>	of PCF8574 device
<i>wire</i>	pointer of TwoWire object

4.1.2 Member Function Documentation

4.1.2.1 begin()

```
int8_t PCF8574::begin ( ) const
```

begin method which initializes and verifies connection. Calls isDevicePresent()

Return values

0	if device is connected
-2	if connection failed due to missing connection or line error.

4.1.2.2 readPin()

```
int16_t PCF8574::readPin (
    int8_t pin = -1 )
```

read pin(s) from port

Parameters

<i>pin</i>	give pin number 0...7; or ommit for all read all port pins
------------	--

Returns

int8_t return error code or value

Return values

>0	read was ok => return pin/Port value
<0	error during readPin => return error code

4.1.2.3 resetPort()

```
int8_t PCF8574::resetPort ( )
```

reset the [PCF8574](#) device, set all port pins to input

Returns

int8_t status of the write command

Return values

0	successfull
-2	error on i2c connection

4.1.2.4 rotateLeft()

```
int8_t PCF8574::rotateLeft ( )
```

rotate Port to the left

Returns

int8_t status of the write command

Return values

0	successfull
-2	error on i2c connection

4.1.2.5 rotateRight()

```
int8_t PCF8574::rotateRight ( )
```

rotate port to the right

Returns

int8_t status of the write command

Return values

0	successfull
-2	error on i2c connection

4.1.2.6 setPin()

```
int8_t PCF8574::setPin (
    uint8_t pin,
    uint8_t value )
```

Set the a specific pin on the PCF8474 to 0 or 1.

Parameters

<i>pin</i>	number of port pin P0...P7
<i>value</i>	value of pin 0 or 1

Returns

int8_t status of the write command

Return values

0	successfull
-1	pin error; wrong pin number
-2	error on i2c connection
-3	wrong value for pin

4.1.2.7 setPort()

```
int8_t PCF8574::setPort (
    uint8_t value )
```

Set the Port at once to an value.

Parameters

<i>value</i>	for port to set
--------------	-----------------

Returns

int8_t status of the write command

Return values

0	successfull
-2	error on i2c connection

4.1.2.8 toggle()

```
int8_t PCF8574::toggle (
    uint8_t mask )
```

toggle pins by give a mask which pin to toggle

Parameters

<i>mask</i>	define which pin to toggle like: 0b10010101
-------------	---

Returns

int8_t status of the write command

Return values

0	successfull
-2	error on i2c connection

The documentation for this class was generated from the following files:

- [src/PCF8574-I2C.hpp](#)
- [src/PCF8574-I2C.cpp](#)

Chapter 5

File Documentation

5.1 src/PCF8574-I2C.cpp File Reference

Library for a PCF8574 GPIO expander.

```
#include "PCF8574-I2C.hpp"
```

5.1.1 Detailed Description

Library for a PCF8574 GPIO expander.

Author

Frank Häfele (mail@frankhaefele.de)

Version

1.0.0

Date

2026-01-12

Copyright

Copyright (c) 2026

5.2 src/PCF8574-I2C.hpp File Reference

Library for a PCF8574 GPIO expander.

```
#include "Wire.h"
```

Classes

- class [PCF8574_I2C::PCF8574](#)

Variables

- constexpr const char * **PCF8574_I2C::PCF8574_LIB_VERSION** {"1.0.0"}
- constexpr int8_t **PCF8574_I2C::PCF8574_STATE_OK** {0x00}
constant which states all ok, no error
- constexpr int8_t **PCF8574_I2C::PCF8574_ERROR_PIN** {-1}
constant which states a wrong pin number was used
- constexpr int8_t **PCF8574_I2C::PCF8574_ERROR_I2C** {-2}
constant which states an error during I2C communication
- constexpr int8_t **PCF8574_I2C::PCF8574_ERROR_VALUE** {-3}
constant which states that there was an error regarding a parameter value

5.2.1 Detailed Description

Library for a PCF8574 GPIO expander.

Author

Frank Häfele (mail@frankhaefele.de)

Version

1.0.0

Date

2026-01-12

Copyright

Copyright (c) 2026

5.3 PCF8574-I2C.hpp

[Go to the documentation of this file.](#)

```
00001
00012 #pragma once
00013
00014 #define __PCF8574_I2C_HPP__
00015
00016 #include "Wire.h"
00017
00018 namespace PCF8574_I2C {
00019
00020     constexpr const char *PCF8574_LIB_VERSION    {"1.0.0"};
00021
00026     constexpr int8_t PCF8574_STATE_OK            {0x00};
00027
00032     constexpr int8_t PCF8574_ERROR_PIN          {-1};
00033
```

```
00038     constexpr int8_t PCF8574_ERROR_I2C           {-2};
00039
00044     constexpr int8_t PCF8574_ERROR_VALUE         {-3};
00045
00046
00047     class PCF8574 {
00048     public:
00055         PCF8574(const uint8_t address = 0x20, TwoWire* wire = &Wire);
00056
00064         int8_t begin() const;
00065
00074         int8_t resetPort();
00075
00085         int16_t readPin(int8_t pin = -1);
00086
00099         int8_t setPin(uint8_t pin, uint8_t value);
00100
00110         int8_t setPort(uint8_t value);
00111
00121         int8_t toggle(uint8_t mask);
00122
00131         int8_t rotateLeft();
00132
00141         int8_t rotateRight();
00142
00143
00144     private:
00145         // internal address of PCF8574 device
00146         uint8_t _address;
00147
00148         // internal pointer to wire object
00149         TwoWire* _wire;
00150
00151         // holds the last error
00152         int8_t _error;
00153
00154         // holds the las readings from device
00155         uint8_t _input{0};
00156
00157         // holds the last sending to device
00158         uint8_t _output{0xFF};
00159
00160
00169         bool isDevicePresent() const;
00170
00179         int8_t readPort();
00180
00190         int8_t writePort(uint8_t value);
00191
00199         bool isPinValid(int8_t pin);
00200
00201
00202     };
00203
00204 }
```


Index

- begin
 - PCF8574_I2C::PCF8574, [8](#)
- PCF8574
 - PCF8574_I2C::PCF8574, [7](#)
- PCF8574-I2C Library, [1](#)
- PCF8574_I2C::PCF8574, [7](#)
 - begin, [8](#)
 - PCF8574, [7](#)
 - readPin, [8](#)
 - resetPort, [8](#)
 - rotateLeft, [9](#)
 - rotateRight, [9](#)
 - setPin, [9](#)
 - setPort, [10](#)
 - toggle, [10](#)
- readPin
 - PCF8574_I2C::PCF8574, [8](#)
- resetPort
 - PCF8574_I2C::PCF8574, [8](#)
- rotateLeft
 - PCF8574_I2C::PCF8574, [9](#)
- rotateRight
 - PCF8574_I2C::PCF8574, [9](#)
- setPin
 - PCF8574_I2C::PCF8574, [9](#)
- setPort
 - PCF8574_I2C::PCF8574, [10](#)
- src/PCF8574-I2C.cpp, [13](#)
- src/PCF8574-I2C.hpp, [13](#), [14](#)
- toggle
 - PCF8574_I2C::PCF8574, [10](#)