



OS Abstraction Layer Application Programming Interface

Document Number: SWRA194

Texas Instruments, Inc.
San Diego, California USA

Version	Description	Date
1.0	Initial ZigBee v1.0 release.	04/08/2005
1.1	Added note on NV initialization to NV Memory API introduction.	07/22/2005
1.2	Modified discussion of .the Task Management API.	08/25/2005
1.3	Changed logo on title page, changed copyright on page footer.	02/27/2006
1.4	Modified power management API.	11/27/2006
1.5	Deprecated osal_self() and osalTaskAdd()	12/18/2007
1.6	Added OSAL_Clock functions.	02/21/2008
1.7	Updated byte to uint8 and added Misc section	04/01/2009
1.8	Updated NV item ID table and changed ZSUCCESS to SUCCESS	04/09/2009

TABLE OF CONTENTS

1. INTRODUCTION	1
1.1 PURPOSE.....	1
1.2 SCOPE.....	1
1.3 ACRONYMS.....	1
2. API OVERVIEW.....	2
2.1 OVERVIEW.....	2
3. MESSAGE MANAGEMENT API.....	3
3.1 INTRODUCTION	3
3.2 OSAL_MSG_ALLOCATE ().....	3
3.3 OSAL_MSG_DEALLOCATE().....	3
3.4 OSAL_MSG_SEND()	4
3.5 OSAL_MSG_RECEIVE()	5
4. TASK SYNCHRONIZATION API	6
4.1 INTRODUCTION	6
4.2 OSAL_SET_EVENT()	6
5. TIMER MANAGEMENT API.....	7
5.1 INTRODUCTION	7
5.2 OSAL_START_TIMEREx().....	7
5.3 OSAL_STOP_TIMEREx()	7
5.4 OSAL_GetSYSTEMCLOCK()	8
6. INTERRUPT MANAGEMENT API.....	9
6.1 INTRODUCTION	9
6.2 OSAL_INT_ENABLE().....	9
6.3 OSAL_INT_DISABLE()	9
7. TASK MANAGEMENT API	11
7.1 INTRODUCTION	11
7.2 OSAL_INIT_SYSTEM()	11
7.3 OSAL_START_SYSTEM().....	12
8. MEMORY MANAGEMENT API.....	13
8.1 INTRODUCTION	13
8.2 OSAL_MEM_ALLOC().....	13
8.3 OSAL_MEM_FREE().....	13
9. POWER MANAGEMENT API.....	14
9.1 INTRODUCTION	14
9.2 OSAL_PWRMGR_INIT().....	14
9.3 OSAL_PWRMGR_POWERCONSERVE()	14
9.4 OSAL_PWRMGR_DEVICE()	15
9.5 OSAL_PWRMGR_TASK_STATE()	15
10. NON-VOLATILE MEMORY API.....	17
10.1 INTRODUCTION	17
10.2 OSAL_NV_ITEM_INIT().....	17
10.3 OSAL_NV_READ().....	18

10.4	OSAL_NV_WRITE()	19
10.5	OSAL_OFFSETOF()	19
11.	OSAL CLOCK SYSTEM	21
11.1	INTRODUCTION	21
11.2	OSAL_CLOCK_CHECK()	21
11.3	OSAL_SETCLOCK()	21
11.4	OSAL_GETCLOCK()	22
11.5	OSAL_CONVERTUTCTIME()	22
12.	OSAL MISC	23
12.1	INTRODUCTION	23
12.2	OSAL_RAND()	23
12.3	OSAL_MEMCMP()	23
12.4	OSAL_MEMSET()	23
12.5	OSAL_MEMCPY()	24

1. Introduction

1.1 Purpose

The purpose of this document is to define the OS Abstraction Layer (OSAL) API. This API allows the software components in a TI stack software, such as Z-stack and RemoTI (Zigbee RF4CE stack), to be written independently of the specifics of the operating system, kernel or tasking environment (including control loops or connect-to-interrupt systems). The OSAL is implemented on the target.

1.2 Scope

This document enumerates all the function calls provided by the OSAL. The function calls are specified in sufficient detail so as to allow a programmer to implement them.

1.3 Acronyms

API	Application Programming Interface
OSAL	Operating System (OS) Abstraction Layer
PC	Personal Computer
SPI	Serial Port Interface

2. API Overview

2.1 Overview

The OS abstraction layer is used to shield the TI stack software components from the specifics of the processing environment. It provides the following functionality in a manner that is independent of the processing environment.

1. Task registration, initialization, starting
2. Message exchange between tasks
3. Task synchronization
4. Interrupt handling
5. Timers
6. Memory allocation

3. Message Management API

3.1 Introduction

The message management API provides a mechanism for exchanging messages between tasks or processing elements with distinct processing environments (for example, interrupt service routines or functions called within a control loop). The functions in this API enable a task to allocate and de-allocate message buffers, send command messages to another task and receive reply messages.

3.2 `osal_msg_allocate ()`

3.2.1 Description

This function is called by a task to allocate a message buffer, the task/function will then fill in the message and call `osal_msg_send ()` to send the message to another task. If the buffer can not be allocated, `msg_ptr` will be set to `NULL`.

NOTE: Do not confuse this function with `osal_mem_alloc ()`, this function is used to allocate a buffer to send messages between tasks [using `osal_msg_send ()`]. Use `osal_mem_alloc ()` to allocate blocks of memory.

3.2.2 Prototype

```
uint8 *osal_msg_allocate( uint16 len )
```

3.2.3 Parameter Details

`len` is the length of the message.

3.2.4 Return

The return value is a pointer to the buffer allocated for the message. A `NULL` return indicates the message allocation operation failed.

3.3 `osal_msg_deallocate()`

3.3.1 Description

This function is used to de-allocate a message buffer. This function is called by a task (or processing element) after it has finished processing a received message.

3.3.2 Prototype

```
uint8 osal_msg_deallocate( uint8 *msg_ptr )
```

3.3.3 Parameter Details

`msg_ptr` is a pointer to the message buffer that needs to be de-allocated.

3.3.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	De-allocation Successful
INVALID_MSG_POINTER	Invalid message pointer
MSG_BUFFER_NOT_AVAILABLE	Buffer is queued

3.4 osal_msg_send()

3.4.1 Description

The `osal_msg_send` function is called by a task to send a command or data message to another task or processing element. The `destination_task` identifier field must refer to a valid system task. The `osal_msg_send()` function will also set the `SYS_EVENT_MSG` event in the destination tasks event list.

3.4.2 Prototype

```
uint8 osal_msg_send(uint8 destination_task, uint8 *msg_ptr )
```

3.4.3 Parameter Details

`destination_task` is the ID of the task to receive the message.

`msg_ptr` is a pointer to the buffer containing the message. `Msg_ptr` must be a pointer to a valid message buffer allocated via `osal_msg_allocate()`.

3.4.4 Return

Return value is a 1 byte field indicating the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Message sent successfully
INVALID_MSG_POINTER	Invalid Message Pointer
INVALID_TASK	Destination_task is not valid

3.5 osal_msg_receive()

3.5.1 Description

This function is called by a task to retrieve a received command message. The calling task must de-allocate the message buffer after processing the message using the `osal_msg_deallocate()` call.

3.5.2 Prototype

```
uint8 *osal_msg_receive(uint8 task_id )
```

3.5.3 Parameter Details

`task_id` is the identifier of the calling task (to which the message was destined).

3.5.4 Return

Return value is a pointer to a buffer containing the message or NULL if there is no received message.

4. Task Synchronization API

4.1 Introduction

This API enables a task to wait for events to happen and return control while waiting. The functions in this API can be used to set events for a task and notify the task once any event is set.

4.2 `osal_set_event()`

4.2.1 Description

This function is called to set the event flags for a task.

4.2.2 Prototype

```
uint8 osal_set_event(uint8 task_id, uint16 event_flag )
```

4.2.3 Parameter Details

`task_id` is the identifier of the task for which the event is to be set.

`event_flag` is a 2 byte bitmap with each bit specifying an event. There is only 1 system event (SYS_EVENT_MSG), the rest of the events/bits are defined by the receiving task.

4.2.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Success
INVALID_TASK	Invalid Task

5. Timer Management API

5.1 Introduction

This API enables the use of timers by internal (TI stack) tasks as well as external (Application level) tasks. The API provides functions to start and stop a timer. The timers can be set in increments of 1millisecond.

5.2 osal_start_timerEx()

5.2.1 Description

This function is called to start a timer. When the timer expires, the given event bit will be set. The event will be set in the specified with taskID.

5.2.2 Prototype

```
uint8 osal_start_timerEx( uint8 taskID, uint16 event_id, uint16
timeout_value);
```

5.2.3 Parameter Details

taskID is the task ID of the task that is to get the event when the timer expires.

event_id is a user defined event bit. When the timer expires, the calling task will be notified (event).

timeout_value is the amount of time (in milliseconds) before the timer event is set.

5.2.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Timer Start Successful
NO_TIMER_AVAILABLE	Unable to start the timer

5.3 osal_stop_timerEx()

5.3.1 Description

This function is called to stop a timer that has already been started. If successful, the function will cancel the timer and prevent the event associated with the timer.

5.3.2 Prototype

```
uint8 osal_stop_timerEx( uint8 task_id, uint16 event_id );
```

5.3.3 Parameter Details

`task_id` is the task to stop the timer for.

`event_id` is the identifier of the timer that is to be stopped.

5.3.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Timer Stopped Successfully
INVALID_EVENT_ID	Invalid Event

5.4 osal_GetSystemClock()

5.4.1 Description

This function is called to read the system clock

5.4.2 Prototype

```
uint32 osal_GetSystemClock( void );
```

5.4.3 Parameter Details

None.

5.4.4 Return

The system clock in milliseconds.

6. Interrupt Management API

6.1 Introduction

This API enables a task to interface with external interrupts. The functions in the API allow a task to associate a specific service routine with each interrupt. The interrupts can be enabled or disabled. Inside the service routine, events may be set for other tasks.

6.2 `osal_int_enable()`

6.2.1 Description

This function is called to enable an interrupt. Once enabled, occurrence of the interrupt causes the service routine associated with that interrupt to be called.

6.2.2 Prototype

```
uint8 osal_int_enable( uint8 interrupt_id )
```

6.2.3 Parameter Details

`interrupt_id` identifies the interrupt to be enabled.

6.2.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Interrupt Enabled Successfully
INVALID_INTERRUPT_ID	Invalid Interrupt

6.3 `osal_int_disable()`

6.3.1 Description

This function is called to disable an interrupt. When a disabled interrupt occurs, the service routine associated with that interrupt is not called.

6.3.2 Prototype

```
uint8 osal_int_disable( uint8 interrupt_id )
```

6.3.3 Parameter Details

`interrupt_id` identifies the interrupt to be disabled.

6.3.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Interrupt Disabled Successfully
INVALID_INTERRUPT_ID	Invalid Interrupt

7. Task Management API

7.1 Introduction

This API is used to add and manage tasks in the OSAL system. Each task is made up of an initialization function and an event processing function. OSAL calls `osalInitTasks()` [application supplied] to initialize the tasks and OSAL uses a task table (`const pTaskEventHandlerFn tasksArr[]`) to call the event processor for each task (also application supplied).

Example of a task table implementation:

```
const pTaskEventHandlerFn tasksArr[] =
{
    macEventLoop,
    nwk_event_loop,
    Hal_ProcessEvent,
    MT_ProcessEvent,
    APS_event_loop,
    ZDApp_event_loop,
};

const uint8 tasksCnt = sizeof( tasksArr ) / sizeof( tasksArr[0] );
```

Example of an `osalInitTasks()` implementation:

```
void osalInitTasks( void )
{
    uint8 taskID = 0;

    tasksEvents = (uint16 *)osal_mem_alloc( sizeof( uint16 ) * tasksCnt );
    osal_memset( tasksEvents, 0, (sizeof( uint16 ) * tasksCnt) );

    macTaskInit( taskID++ );
    nwk_init( taskID++ );
    Hal_Init( taskID++ );
    MT_TaskInit( taskID++ );
    APS_Init( taskID++ );
    ZDApp_Init( taskID++ );
}
```

7.2 `osal_init_system()`

7.2.1 Description

This function initializes the OSAL system. The function must be called at startup prior to using any other OSAL function.

7.2.2 Prototype

```
uint8 osal_init_system( void )
```

7.2.3 Parameter Details

None.

7.2.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Success

7.3 osal_start_system()

7.3.1 Description

This function is the main loop function of the task system. It will look through all task events and call the task event processor function for the task with the event. Events are handled one at a time at the event process routine of the corresponding task. After an event is serviced, the remaining events will be returned back to the main loop for next time around. If there are no events (for all tasks), this function puts the processor into a Sleep mode.

7.3.2 Prototype

```
void osal_start_system( void )
```

7.3.3 Parameter Details

None

7.3.4 Return

None

8. Memory Management API

8.1 Introduction

This API represents a simple memory allocation system. These functions allow dynamic memory allocation.

8.2 `osal_mem_alloc()`

8.2.1 Description

This function is a simple memory allocation function that returns a pointer to a buffer (if successful).

8.2.2 Prototype

```
void *osal_mem_alloc( uint16 size );
```

8.2.3 Parameter Details

`size` – the number of bytes wanted in the buffer.

8.2.4 Return

A void pointer (which should be cast to the intended buffer type) to the newly allocated buffer. A NULL pointer is returned if there isn't enough memory to allocate.

8.3 `osal_mem_free()`

8.3.1 Description

This function frees the allocated memory to be used again. This only works if the memory had already been allocated with `osal_mem_alloc()`.

8.3.2 Prototype

```
void osal_mem_free( void *ptr );
```

8.3.3 Parameter Details

`ptr` – pointer to the buffer to be “freed”. This buffer must have been previously allocated with `osal_mem_alloc()`.

8.3.4 Return

None.

9. Power Management API

9.1 Introduction

This section describes the OSAL's power management system. The system provides a way for the applications/tasks to notify OSAL when it's safe to turn off the receiver and external hardware, and put the processor in to sleep.

There are 2 functions to control the power management. The first, `osal_pwrmgr_device()`, is called to set the device level mode (power save or no power savings). Then, there is the task power state, each task can hold off the power manager from conserving power by calling `osal_pwrmgr_task_state(PWRMGR_HOLD)`. If a task "Holds" the power manager, it will need to call `osal_pwrmgr_task_state(PWRMGR_CONSERVE)` to allow the power manager to continue in power conserve mode.

By default, when the task is initialized, each task's power state is set to `PWRMGR_CONSERVE`, so if a task doesn't want to hold off power conservation (no change) it doesn't need to call `osal_pwrmgr_task_state()`.

Also, by default, a battery operated device will be in `PWRMGR_ALWAYS_ON` state until it joins the network, then it will change its state to `PWRMGR_BATTERY`. This means that if the device can't find a device to join it will not enter a power save state. If you want to change this behavior, add `osal_pwrmgr_device(_PWRMGR_BATTERY)` in your application's task initialisation function or when your application stops/pauses the joining process.

The power manager will look at the device mode and the collective power state of all the tasks before going in to power conserve state.

9.2 `osal_pwrmgr_init()`

9.2.1 Description

This function will initialize variables used by the power management system. **IMPORTANT:** Don't call this function, it is already called by `osal_init_system()`.

9.2.2 Prototype

```
void osal_pwrmgr_init( void );
```

9.2.3 Parameter Details

none.

9.2.4 Return

None.

9.3 `osal_pwrmgr_powerconserve()`

9.3.1 Description

This function is want is called to go into power down **IMPORTANT:** Don't call this function, it is already called in the OSAL main loop [`osal_start_system()`].

9.3.2 Prototype

```
void osal_pwrmgr_powerconserve( void );
```

9.3.3 Parameter Details

none.

9.3.4 Return

None.

9.4 osal_pwrmgr_device()

9.4.1 Description

This function is called on power- up or whenever the power requirements change (ex. Battery backed coordinator). This function sets the overall ON/OFF State of the device's power manager. This function should be called from a central controlling entity (like ZDO).

9.4.2 Prototype

```
void osal_pwrmgr_device( uint8 pwrmgr_device );
```

9.4.3 Parameter Details

Pwrmgr_device – changes or sets the power savings mode.

Type	Description
PWRMGR_ALWAYS_ON	With this selection there is no power savings and the device is most likely on mains power.
PWRMGR_BATTERY	Turns power savings on.

9.4.4 Return

None.

9.5 osal_pwrmgr_task_state()

9.5.1 Description

This function is called by each task to state whether or not this task wants to conserve power. The task will call this function to vote whether it wants the OSAL to conserve power or it wants to hold off on the power savings. By default, when a task is created, its own power state is set to conserve. If the task always wants to converse power, it doesn't need to call this function at all.

9.5.2 Prototype

```
uint8 osal_pwrmgr_task_state(uint8 task_id, uint8 state );
```

9.5.3 Parameter Details

state – changes a task's power state.

Type	Description
PWRMGR_CONSERVE	Turns power savings on, all tasks have to agree. This is the default state when a task is initialized.
PWRMGR_HOLD	Turns power savings off.

9.5.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Success
INVALID_TASK	Invalid Task

10. Non-Volatile Memory API

10.1 Introduction

This section describes the OSAL Non-Volatile (NV) memory system. The system provides a way for applications to store information into the device's memory persistently. It is also used by the stack for persistent storage of certain items required by the ZigBee specification. The NV functions are designed to read and write user-defined items consisting of arbitrary data types such as structures or arrays. The user can read or write an entire item or an element of the item by setting the appropriate offset and length. The API is independent of the NV storage medium and can be implemented for flash or EEPROM.

Each NV item has a unique ID. There is a specific ID value range for applications while some ID values are reserved or used by the stack or platform. If your application creates its own NV items it must select an ID from the Application value range. See the table below.

VALUE	USER
0x0000	Reserved
0x0001 – 0x0020	OSAL
0x0021 – 0x0040	NWK
0x0041 – 0x0060	APS
0x0061 – 0x0080	Security
0x0081 – 0x00A0	ZDO
0x00A1 – 0x0200	Reserved
0x0201 – 0x0300	Reserved for Zigbee RF4CE network layer Available for Z-stack application
0x0301 – 0x0400	Reserved for Zigbee RF4CE application framework (RTI) Available for Z-stack application
0x0401 – 0x0FFF	Application
0x1000 -0xFFFF	Reserved

There are some important considerations when using this API:

1. These are blocking function calls and an operation may take several milliseconds to complete. This is especially true for NV write operations. In addition, interrupts may be disabled for several milliseconds. It is best to execute these functions at times when they do not conflict with other timing-critical operations. For example, a good time to write NV items would be when the receiver is turned off.
2. Try to perform NV writes infrequently. It takes time and power; also most flash devices have a limited number of erase cycles.
3. If the structure of one or more NV items changes, especially when upgrading from one version of a TI stack software to another, it is necessary to erase and re-initialize the NV memory. Otherwise, read and write operations on NV items that changed will fail or produce erroneous results.

10.2 osal_nv_item_init()

10.2.1 Description

Initialize an item in NV. This function checks for the presence of an item in NV. If it does not exist, it is created and initialized with the data passed to the function, if any.

This function must be called for each item before calling `osal_nv_read()` or `osal_nv_write()`.

10.2.2 Prototype

```
uint8 osal_nv_item_init( uint16 id, uint16 len, void *buf );
```

10.2.3 Parameter Details

`id` – User-defined item ID.

`len` – Item length in bytes.

`*buf` – Pointer to item initialization data. If no initialization data, set to NULL.

10.2.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Success
NV_ITEM_UNINIT	Success but item did not exist
NV_OPER_FAILED	Operation failed

10.3 `osal_nv_read()`

10.3.1 Description

Read data from NV. This function can be used to read an entire item from NV or an element of an item by indexing into the item with an offset. Read data is copied into `*buf`.

10.3.2 Prototype

```
uint8 osal_nv_read( uint16 id, uint16 offset, uint16 len, void *buf );
```

10.3.3 Parameter Details

`id` – User-defined item ID.

`offset` – Memory offset into item in bytes.

`len` – Item length in bytes.

`*buf` – Data is read into this buffer.

10.3.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
--------------	-------------

SUCCESS	Success
NV_ITEM_UNINIT	Item is not initialized
NV_OPER_FAILED	Operation failed

10.4 osal_nv_write()

10.4.1 Description

Write data to NV. This function can be used to write an entire item to NV or an element of an item by indexing into the item with an offset.

10.4.2 Prototype

```
uint8 osal_nv_write( uint16 id, uint16 offset, uint16 len, void *buf );
```

10.4.3 Parameter Details

`id` – User-defined item ID.

`offset` – Memory offset into item in bytes.

`len` – Item length in bytes.

`*buf` – Data to write.

10.4.4 Return

Return value indicates the result of the operation.

RETURN VALUE	DESCRIPTION
SUCCESS	Success
NV_ITEM_UNINIT	Item is not initialized
NV_OPER_FAILED	Operatoin failed

10.5 osal_offsetof()

10.5.1 Description

This macro calculates the memory offset in bytes of an element within a structure. It is useful for calculating the offset parameter used by NV API functions.

10.5.2 Prototype

```
osal_offsetof(type, member)
```

10.5.3 Parameter Details

`type` – Structure type.

member – Structure member.

11. OSAL Clock System

11.1 Introduction

This section describes the OSAL Clock system. The system provides a way to keep date and time for a device. This system will keep the number of seconds since 0 hrs, 0 minutes, 0 seconds on the 1st of January 2000 UTC. The following 2 data types/structures are used in this system (defined in OSAL_Clock.h):

```
// number of seconds since 0 hrs, 0 minutes, 0 seconds, on the
// 1st of January 2000 UTC
typedef uint32 UTCTime;

// To be used with
typedef struct
{
    uint8 seconds;    // 0-59
    uint8 minutes;    // 0-59
    uint8 hour;       // 0-23
    uint8 day;        // 0-30
    uint8 month;      // 0-11
    uint16 year;      // 2000+
} UTCTimeStruct;
```

You must enable the OSAL_CLOCK compiler flag to use this feature. **Also**, this feature **doesn't** maintain time for sleeping devices.

11.2 osal_clock_check()

11.2.1 Description

Called from osal_start_system() to keep the time. This function reads the number of MAC 320usec ticks to maintain the OSAL Clock time. Don't call this anywhere else.

11.2.2 Prototype

```
extern void osal_clock_check( void );
```

11.2.3 Parameter Details

none.

11.2.4 Return

none.

11.3 osal_setClock()

11.3.1 Description

Call this function to initialize the device's time.

11.3.2 Prototype

```
extern void osal_setClock( UTCTime newTime );
```

11.3.3 Parameter Details

`newTime` – new time in seconds since 0 hrs, 0 minutes, 0 seconds, on the 1st of January 2000 UTC.

11.3.4 Return

none.

11.4 osal_getClock()

11.4.1 Description

Call this function to retrieve the device's time.

11.4.2 Prototype

```
extern UTCTime osal_getClock( void );
```

11.4.3 Parameter Details

none.

11.4.4 Return

time in seconds since 0 hrs, 0 minutes, 0 seconds, on the 1st of January 2000 UTC.

11.5 osal_ConvertUTCTime()

11.5.1 Description

Call this function to convert UTCTime to UTCTimeStruct.

11.5.2 Prototype

```
extern void osal_ConvertUTCTime( UTCTimeStruct * tm, UTCTime secTime );
```

11.5.3 Parameter Details

`secTime` - time in seconds since 0 hrs, 0 minutes, 0 seconds, on the 1st of January 2000 UTC.

`tm` – pointer to time structure.

11.5.4 Return

none.

12. OSAL Misc

12.1 Introduction

This section describes the OSAL functions that don't fit into existing OSAL categories.

12.2 osal_rand()

12.2.1 Description

This function returns a 16 bit random number.

12.2.2 Prototype

```
uint16 osal_rand( void );
```

12.2.3 Parameter Details

none.

12.2.4 Return

Return a random number.

12.3 osal_memcmp()

12.3.1 Description

Compare to memory sections.

12.3.2 Prototype

```
uint8 osal_memcmp( const void GENERIC *src1, const void GENERIC *src2,  
unsigned int len );
```

12.3.3 Parameter Details

src1 - memory compare location 1.

src2 - memory compare location 2.

len - length of compare.

12.3.4 Return

TRUE - same, FALSE - different.

12.4 osal_memset()

12.4.1 Description

Sets a buffer to a specific value.

12.4.2 Prototype

```
void *osal_memset( void *dest, uint8 value, int len );
```

12.4.3 Parameter Details

dest – memory buffer to set “value” to.

value – what to set each byte of “dest”.

len – length to set “value” in “dest”.

12.4.4 Return

pointer to where in the buffer this function stopped.

12.5 osal_memcpy()

12.5.1 Description

Copies one buffer to another buffer.

12.5.2 Prototype

```
void *osal_memcpy( void *dst, const void GENERIC *src, unsigned int len );
```

12.5.3 Parameter Details

dst – destination buffer.

src – source buffer.

len – length of copy.

12.5.4 Return

pointer to end of destination buffer.