

Tips:

You can set our module into power transmission mode by executing the following AT commands successively. And you should reboot module by AT+NRB when a single testing finished.

- 1、 AT+NRDTEST=8,0000400213020000
- 2、 AT+NRDTEST=8,0100400213020000
- 3、 The corresponding AT command is different for each BAND. Just as following.

B1

TX_Frequency=1920MHz:

[illegible]

TX_Frequency=1950MHz:

AT+NRDTEST=240,03004A0021302e8000cf8d7f**80A3**3A742c01000000000000000000000000200000
00580200005802000058020000000000a00000800200000000000c8000000000000000000000
00000000000000000000000000000000b000200000100001700010000000000000000000000000
00
00
00
0000011900100e000001010000

TX_Frequency=1979.9MHz:

[illegible]

B3

TX Frequency=1710MHz:

AT+NRDTEST=240,030040021302e800a051d26d**8087ec6**52c0100000000000000000000200000
000580200005802000058020000000000a0000008002000000000000c800000000000000000
00000000000000000000000000000000b00020000010000170001000000000000000000000000000000

[illegible]

[illegible][illegible]

B28

[illegible][illegible][illegible]

0000011900100e000001010000

BC95-D

1915MHz-23dbm

[illegible]

1918MHz-23dbm

[illegible]

1920MHz-23dbm

[illegible]