

## Let's get started!

Create™ 2 Programmable Robot will help you discover the exciting world of robotics, programming and 3-D printing. Make a drawing robot. Build a storage tray for your microcomputer. Or show students the power of coding. The options are as limitless as your imagination.

**Stumped?** Need some ideas on how to begin? Make sure to visit [iRobot.com/create](http://iRobot.com/create) to find unique ways to use Create 2. Then let us know what you come up with.

Share your designs with us and your fellow Creators on social media:



iRobot



iRobot



#irobotcreate

CAN  
YOU  
HACK  
IT?!

**iRobot®**

# IMPORTANT!


Remove the faceplate prior to drilling

The drill marks on the faceplate are approximate; if more precision is required, please use the online template at [www.irobot.com/Create](http://www.irobot.com/Create).

## Getting started


Before first use:

- 1 Activate the Create™ Programmable Robot by removing the battery pull tab.



Remove battery pull tab

- 2 Charge Create™ overnight.



Using the Home Base®

# Safety and Compliance Information

To reduce the risk of injury or damage, keep these safety precautions in mind when setting up, using, and maintaining your robot:

## GENERAL SAFETY INSTRUCTIONS

- Retain the safety and operating instructions for future reference.
- Read all safety and operating instructions before operating your robot.
- Heed all warnings on your robot, battery, battery charger, and in the Safety and Compliance Information.
- Follow all operating and use instructions.

## CREATE™ USE RESTRICTIONS

- Your robot is for indoor use on hard surface floors only.
- Your robot is not a toy. Do not sit or stand on this device. Small children and pets should be supervised when your robot is operating.
- Create has electrical parts. Do not submerge it in water. Clean with a cloth dampened with water only.
- Do not use this device to pick up anything that is burning or smoking.
- Do not use this device to pick up large debris, bleach, paint, or other chemicals.
- Before using Create, remove fragile objects from the cleaning area, including objects on furniture that can fall if the furniture is pushed or bumped.
- Move any power cords as well as cords for blinds and curtains out of the way to reduce the risk of objects being pulled down.
- If the room contains a balcony, a physical barrier should be used to prevent access to the balcony and ensure safe operation.
- Operate and store your robot in room temperature environments only.
- Children should be supervised to ensure they do not play with the robot. Cleaning and maintenance should not be performed by children without supervision.
- Do not place anything on top of your robot.
- Do not operate the robot in areas with exposed electrical outlets in the floor.

**THIS APPLIANCE CAN BE USED BY CHILDREN AGED FROM 8 YEARS AND ABOVE AND PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES OR LACK OF EXPERIENCE AND KNOWLEDGE IF THEY HAVE BEEN GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE APPLIANCE IN A SAFE WAY AND UNDERSTAND THE HAZARDS INVOLVED. CHILDREN SHALL NOT PLAY WITH THE APPLIANCE. CLEANING AND USER MAINTENANCE SHALL NOT BE MADE BY CHILDREN WITHOUT SUPERVISION.**

Retain these safety instructions



Always exercise caution when operating your robot. To reduce the risk of injury or damage, keep the above safety precautions in mind when setting up, using and maintaining your robot.

## CREATE™ BATTERY AND CHARGING

- Before every use, check the battery pack for any sign of damage or leakage. Do not charge damaged or leaking battery packs.
- Charge indoors only.
- Only use the included battery charger to charge the iRobot battery.
- Charge using a standard outlet only. Product may not be used with any type of power converter. Use of other power converters will immediately void the warranty.
- Please ensure voltage rating for enclosed battery charger matches standard outlet voltage.
- Never handle the battery charger with wet hands.
- Only use rechargeable battery packs with the correct specifications supplied with your robot by iRobot.
- For replacement battery pack, visit [www.irobot.com](http://www.irobot.com).
- Always charge and remove the battery from your robot before long-term storage or transportation.
- Always remove battery pack before cleaning your robot.
- Keep battery pack clean and dry. Wipe the cell or battery terminals with a clean dry cloth if they become dirty.
- Do not crush, dismantle or shred battery packs.
- Do not subject cells or batteries to mechanical shock.
- Do not heat the battery pack or place the battery pack near any heat source.
- Do not store in direct sunlight.
- Do not incinerate the battery pack.
- Do not short-circuit the battery pack.
- Do not submerge the battery pack in any liquid.
- The battery pack must be removed from the robot before disposal.
- When disposing of the battery pack, contact your local or regional waste authority for more information on collection, reuse and recycling programs.
- In the event of cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.



### The symbol on the product indicates:

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local authority for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new ones, the retailer is legally obliged to take back your old appliance for disposal at least free of charge.

For EU Declaration of Conformity information, visit [www.irobot.com/compliance](http://www.irobot.com/compliance).

## FCC and IC Compliance Information:

This device complies with part 15 of the FCC Rules as well as ICES-003 Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules as well as ICES-003 Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.