



LTE Probe

Version: 2024-12-23

Table of Contents

1	Introduction	1
2	Features	2
3	Requirements	3
3.1	Hardware requirements	3
3.2	Software requirements	3
4	Installation	4
4.1	Radio front end setup	4
4.2	LTEPROBE installation	4
4.3	Initial testing	4
4.4	Useful tips	4
5	Configuration reference	5
5.1	Configuration file syntax	5
5.1.1	JSON merge rules	6
5.2	Global properties	7
6	Remote API	13
6.1	Messages	13
6.2	Startup	14
6.3	Errors	15
6.4	Sample nodejs program	15
6.5	Common messages	15
7	Log file format	19
7.1	PHY layer	19
7.2	MAC and RRC layers	19
7.3	RLC, PDCP and NAS layers	20
7.4	IP layer	20
8	Limitations	21
9	Change history	22
9.1	Version 2024-09-13	22
9.2	Version 2024-06-14	22
9.3	Version 2023-06-10	22
9.4	Version 2023-03-17	22
9.5	Version 2022-12-16	22
9.6	Version 2022-06-17	22
10	License	23

1 Introduction

lteprobe is a real time LTE downlink and uplink passive protocol logger. It can also be used to get the temporary identifiers (C-RNTI, TMSI) of UEs. It takes I/Q samples as input from SDR devices. All the signal processing is done on the PC CPU.

2 Features

- Supports FDD bandwidths from 1.4 to 20 MHz for downlink and uplink.
- Automatically acquires the cell parameters from the System Information Blocks.
- Decodes both downlink and uplink signals.
- Supports MIMO 2x2 and transmission modes 1 to 3.
- Tracks several UEs and bearer contexts at the same time.
- Supported PHY messages: PDCCH, PCFICH, PHICH, PDSCH, PRACH, PUSCH.
- Log PHY, MAC, RLC, PDCP, RRC, NAS and IP messages in textual logs compatible with the other Amarisoft tools.
- Plots for QAM constellations and channel response.
- Log received IP packets to Wireshark compatible PCAP files.
- Keep a journal of connected UEs with eNodeB and local timing advances (for approximate UE location), PRACH SNR, RNTI and TMSI.
- Log all paging messages.

3 Requirements

3.1 Hardware requirements

- A PC:
 - Quad core Intel CPU (Core i5 or Core i7) supporting AVX2 (i.e. a CPU using at least the Haswell microarchitecture).
 - At least 2 GB of RAM.
 - At least 1 GB of hard disk space.
 - The video adapter does not matter.
- Radio front end:
 - 2 PCIe SDR boards (FDD) or 1 PCIe SDR board (TDD)
- Appropriate antennas for the intended LTE frequencies or cables and attenuators to connect to UE(s) and eNodeB(s).

3.2 Software requirements

- A 64 bit Linux distribution. Fedora 39 is the officially supported distribution. The following distributions are known as compatible:
 - Fedora 22 to 39
 - Cent OS 7
 - Ubuntu 14 to 22

Your system requires at least GLIBC 2.17.

Other distributions can be used provided the radio frontend drivers are available for them.

4 Installation

4.1 Radio front end setup

Two PCIe SDR boards must be installed in the PC for FDD operation. They must be time and frequency synchronized (connect them with the clock cable). GPS synchronization is not needed.

Read the PCIe SDR documentation ([trx_sdr.pdf](#)) to have more information about the hardware and software setup.

4.2 LTEPROBE installation

Decompress the LTEPROBE archive to a convenient place. The executable `lteprobe` can be launched from this directory.

4.3 Initial testing

Update the configuration file `config/probe.cfg` to select the EARFCN of a known LTE carrier (modify the line with `dl_earfcn`). Then start `lteprobe`:

```
./lteprobe config/probe.cfg
```

If an LTE carrier is found, the following messages are displayed:

```
got SIB1
got SIB2
```

If you don't see them, check the EARFCN and cabling.

Then for each received PRACH the following message is displayed:

```
PRACH: sequence_index=x ta=y snr=z dB
```

All the receiving uplink and downlink messages are written to the text log `/tmp/probe.log`. The log of detected UEs is in `/tmp/profue_ue.log`. The decoded IP packets can be analyzed with Wireshark using the PCAP file `/tmp/probe.pcap`.

4.4 Useful tips

- If you want to log all the RRC and IP messages, be sure that neither RRC nor DRB data are encrypted. If the RRC is encrypted, `auto_rb_add` can be set to log some RLC/PDCP information, but it cannot work reliably because the RRC reconfiguration messages are lost.
- Use the `epr` information in the PUSCH/PDSCH logs (PHY layer) to modify the receive gain (`rx_gain` parameter) in order not to saturate the receiver. The maximum value should be smaller than -15 dBFS.
- You must use at least 2 downlink antennas to receive the MIMO 2x2 transmitted data.
- Assuming the signal is strong enough, `ul_timing_offset` can be modified to select the distance of the received UEs (the current PUSCH receiver only tolerates an uplink timing offset between -4 and 4). The timing advance measured for each PUSCH (`ta=` in the PUSCH PHY logs) can be used to adjust `ul_timing_offset`.

5 Configuration reference

5.1 Configuration file syntax

The main configuration file uses a syntax very similar to the Javascript Object Notation (JSON) with few extensions.

1. Supported types:
 - Numbers (64 bit floating point). Notation: 13.4
 - Complex numbers. Notation: 1.2+3*I
 - Strings. Notation: "string"
 - Booleans. Notation: true or false.
 - Objects. Notation: { field1: value1, field2: value2, }
 - Arrays. Notation: [value1, value2,]
2. The basic operations +, -, * and / are supported with numbers and complex numbers. + also concatenates strings. The operators !, ||, &&, ==, !=, <, <=, >=, > are supported too.
3. The numbers 0 and 1 are accepted as synonyms for the boolean values false and true.
4. {} at top level are optional.
5. " for property names are optional, unless the name starts with a number.
6. Properties can be duplicated.

If properties are duplicated, they will be merged following [JSON merge rules], page 6, with overriding occuring in reading direction (last overrides previous).

Ex:

```
{
  value: "foo",
  value: "bar",
  sub: {
    value: "foo"
  },
  sub: {
    value: "bar"
  }
}
```

Will be equivalent to:

```
{
  value: "bar",
  sub: {
    value: "bar"
  }
}
```

7. Files can be included using *include* keyword (must not be quoted) followed by a string (without :) representing the file to include (path is relative to current file) and terminating by a comma.

Arrays can't be included.

Merge will be done as for duplicate properties.

If *file1.cfg* is:

```
value: "foo",
include "file2.cfg",
foo: "foo"
```

And *file2.cfg* is:

```
value: "bar",
foo: "bar"
```

Final config will be:

```
{
  value: "bar",
  foo: "foo"
}
```

8. A C like preprocessor is supported. The following preprocessor commands are available:

#define var *expr*

Define a new variable with value *expr*. *expr* must be a valid JSON expression. Note that unlike the standard C preprocessor, *expr* is evaluated by the preprocessor.

#undef var

Undefine the variable *var*.

#include *expr*

Include the file whose filename is the evaluation of the string expression *expr*.

#if *expr* Consider the following text if *expr* is true.

#else Alternative of **#if** block.

#elif Composition of **#else** and **#if**.

#endif End of **#if** block.

#ifdef var

Shortcut for **#if defined(var)**

#ifndef var

Shortcut for **#if !defined(var)**

In the JSON source, every occurrence of a defined preprocessor variable is replaced by its value.

9. Backquote strings: JSON expression can be inserted in backquote delimited strings with the ``${expr}` syntax. Example: `'abc${1+2}d'` is evaluated as the string `"abc3d"`. Preprocessor variables can be used inside the expression. Backquote strings may span several lines.

5.1.1 JSON merge rules

Merge overriding direction depends on context, i.e source may override destination or the opposite.

JSON merge is recursive for Objects and Arrays.

Example, merging

```
{
  foo: { value: "bar" },
  same: "one",
  one: 1
}
```

with

```
{
  foo: { value: "none", second: true },
```



```

    same: "two",
    two: 1
}

```

Will become:

```

{
  foo: { value: "bar", second: true },
  same: "one",
  one: 1
  two: 1
}

```

assuming first object overrides second one.

In case of Array merging, the final array length will be the maximum length of all merged arrays.

For each element of the final array, merge will be done considering defined elements only.

Ex:

```

{
  array: [0, 1, 2, { foo: "bar" } ],
  array: [3, 4],
  array: [5, 6, 7, { bar: "foo" }, 8 ]
}

```

Will be merged to:

```

{
  array: [5, 6, 7, { foo: "bar", bar: "foo" }, 8 ],
}

```

5.2 Global properties

log_filename

String. Set the log filename. If no leading /, it is relative to the configuration file path. See [Log file format], page 18.

log_options

String. Set the logging options as a comma separated list of assignments.

- *layer.level=verbosity*. For each layer, the log verbosity can be set to **none**, **error**, **info** or **debug**. In debug level, the content of the transmitted data is logged.
- *layer.max_size=n*. When dumping data content, at most **n** bytes are shown in hexa. For ASN.1, NAS or Diameter content, show the full content of the message if **n > 0**.
- *layer.payload=[0|1]*. Dump ASN.1, NAS, SGsAP or Diameter payload in hexadecimal.
- *layer.key=[0|1]*. Dump security keys (NAS and RRC layers).
- *layer.crypto=[0|1]*. Dump plain and ciphered data (NAS and PCDP layers).
- *phy.signal=[0|1]*. Dump binary received signal data of the physical layer to another file (*log_filename.bin*). The currently available data are QAM constellations and channel estimation for PDSCH, PUSCH and SRS. The GUI can be used to display them. Note: the size of the binary signal data is larger than the textual logs, so they should be enabled only when needed.

- `bccch=[0|1]`. Enable or disable BCCH log. The BCCH is always transmitted, so it gives large logs when enabled.
- `time=[sec|short|full]`. Display the time as seconds, time only or full date and time (default = time only).
- `time.us=[0|1]`. Dump time with microseconds precision.
- `file=cut`. Close current file log and open a new one.
- `file.rotate=now`. Rename current log with timestamp and open new one.
- `file.rotate=size`. Rename current log every time it reaches *size* bytes open new one. Size is an integer and can be followed by K, M or G.
- `file.path=path`. When log rotation is enabled, move current log to this path instead of initial log path.
- `append=[0|1]`. (default=0). If 0, truncate the log file when opening it. Otherwise, append to it.

Available layers are: `phy`, `mac`, `rlc`, `pdcp`, `rrc`, `nas`, `ip`

log_sync Optional boolean (default = false). If true, logs will be synchronously dumped to file.

Warning, this may lead to performances decrease.

pcap_filename

String. Set the filename of the Wireshark compatible IP logs. For each IP packet, specific MAC addresses are used to identify the eNodeB, UE and DRB identity. The MAC address 02:00:00:00:00:00 corresponds to the eNodeB. The MAC address 06:00:00:UEID1:UEID0:DRBID corresponds to the UE whose 16 bit ID is UEID1:UEID0 and DRB identity DRBID.

ue_filename

String. Set the filename of the log of detected UEs. In the log, # indicates a comment (used in the first lines to give the information about the cell). The following columns are defined:

TIME	Local time (ms resolution) of the connection.
RAR RNTI	Temporary RNTI in the Random Access Response message.
RAR TA	Timing alignment information in the Random Access Response message. Can be used to estimate the distance to the eNodeB with a 150 meter resolution provided a calibration is done to know the origin.
PRACH TA	Timing alignment information computed by lteprobe. Can be used to estimate the distance to the UE with a 150 meter resolution provided a calibration is done to know the origin. Note: if the UE is too far the PRACH may not be received.
PRACH SNR	PRACH SNR measurement in dB.
MMEC/M-TMSI	MMEC/M-TMSI information of the connected UE. It is available only if the PRACH and first PUSCH message (msg3) were successfully received.

rf_driver

Object. Parameters of the radio driver. See `trx_sdr.pdf` to have more information.

rx_gain

Float or array of floats. Receive gain in dB. The range is device dependent. With an array of floats a different gain is specified for each channel.

rx_epre_in_dbfs

Optional boolean (default = false). In the logs, the EPRE (Energy Per Resource Element) is displayed in dBm if the RF interface provides its reference receive power and if `rx_epre_in_dbfs` = false. Otherwise it is displayed in dBFS (Decibels relative to Full Scale).

rx_epre_offset

Optional float (default = 0). Offset in dB applied to all the receive EPRE measurements.

bandwidth

Optional float. Defines the maximum received bandwidth. It can be 20, 15, 10, 5, 3 or 1.4. The RF sample rate is set accordingly.
If omitted, `sample_rate` has to be set.

sample_rate

Optional float. Sample rate in MHz. It is normally automatically set depending on the radio head capabilities and selected bandwidth.
It is mandatory if `bandwidth` is not set.

sample_rate_num

Optional integer. Main sample rate used for the LTE signal processing in 1.92 MHz units (hence 3 means 5.76 MHz). It is normally automatically set depending on the radio head capabilities and selected bandwidth. If the resulting rate is different from `sample_rate`, a fractional sample rate interpolator is used to convert the sample rate.

auto_rb_add

Boolean. If true, the MAC Logical Channel Identity (LCID) is used to automatically determine the DRB/SRB type. It cannot be 100% reliable, so it is useful only when the RRC reconfiguration messages configuring the SRB/DRB cannot be received (e.g. if the RRC is encrypted).

dump_pcch

Boolean. If true, the paging data is logged.

pdsch_max_turbo_its

Optional integer (default = 6). Maximum number of iterations for the downlink (PDSCH) turbo decoder.

pusch_max_turbo_its

Optional integer (default = 6). Maximum number of iterations for the uplink (PUSCH) turbo decoder.

inactivity_timer

Optional integer (default = 10000). If no data is received for a given UE during `inactivity_timer` ms, then the corresponding UE context is automatically destroyed. It is necessary in order to reduce the number of concurrent UE contexts.

cells

Array of objects. Define the cell parameters. Currently only a single cell is supported. The following properties are available in each cell:

dl_earfcn

Integer. Downlink EARFCN of the cell.

ul_earfcn

Optional integer. Uplink EARFCN. If omitted it is automatically determined from the downlink EARFCN assuming a standard TX-RX gap.

n_antenna_dl
Optional. 1, 2, 4 or 8 (default = 1). Number of downlink receive antennas.

n_antenna_ul
Optional 1, 2, 4 or 8 (default = 1). Number of uplink receive antennas.

n_id_cell
Optional. Range -1 to 503 (default = -1). Select the Physical cell ID. -1 indicates that the best received cell should be used. The exact Physical cell ID is displayed in the logs.

ul_timing_offset
Optional integer. Adjust the time offset between the uplink and the downlink, in 1/1.92 microsecond units. It is useful to modify it in case the received UEs are very far (the current PUSCH receiver only tolerates an uplink timing offset between -4 and 4).

custom_freq_band
Optional object or array of objects. Define a non standard LTE or NR frequency band. Standard bands can also be overridden by this option. If the uplink information is not provided, it is assumed to be the same as the downlink (TDD band). Use an array of objects if you want to define more than one custom band.

For LTE bands, the following parameters are available:

band Range: 1 to 256.

dl_earfcn_min
Range: 0 to 262143.

dl_earfcn_max
Range: 0 to 262143.

dl_freq_min
Float. Low DL frequency in MHz.

ul_earfcn_min
Optional integer. Range: 0 to 262143.

ul_earfcn_max
Optional integer. Range: 0 to 262143.

ul_freq_min
Optional Float. Low UL frequency in MHz.

ntn Optional boolean. True if this is a NTN band.

For NR bands, the following parameters are available:

band_nr Range: 1 to 1024. NR band number.

dl_freq_min
Float. Range: 0 to 65535. Minimum DL frequency in MHz. Use 0 if no DL.

dl_freq_max
Float. Range: 0 to 65535. Maximum DL frequency in MHz. Use 0 if no DL.

ul_freq_min
Float. Range: 0 to 65535. Minimum UL frequency in MHz. Use 0 if no UL. If not provided, use the same value as DL (TDD).

<code>ul_freq_max</code>	Float. Range: 0 to 65535. Maximum UL frequency in MHz. Use 0 if no UL.
<code>ssb_scs</code>	Array of integers. List of allowed SSB subcarrier spacing for this band. Allowed values: 15, 30, 120 or 240.
<code>f_raster</code>	Enumeration: 100, 15, 15_30, 15_30_100, 60_120, 100_enhanced. Frequency raster in kHz.
<code>ssb_case_c</code>	Boolean. True if SSB case C is enabled on this band.
<code>min_40mhz_bw</code>	Boolean. True if the minimum allowed bandwidth on this band is at least 40 MHz. This information is used to select the CoReSet #0 table in standalone mode.
<code>delta_gscn</code>	Optional enumeration: 1, 3, 7, 16 (default = 1). GSCN step size.
<code>ntn</code>	Optional boolean. True if this is a NTN band.
<code>com_addr</code>	Optional string. Address of the WebSocket server remote API. See [Remote API], page 12. If set, the WebSocket server for remote API will be enabled and bound to this address. Default port is 9005. Setting IP address to <code>::</code> will make remote API reachable through all network interfaces.
<code>com_name</code>	Optional string. Sets server name. UE by default
<code>com_ssl_certificate</code>	Optional string. If set, forces SSL for WebSockets. Defines CA certificate filename.
<code>com_ssl_key</code>	Optional string. Mandatory if <code>com_ssl_certificate</code> is set. Defines CA private key filename.
<code>com_ssl_peer_verify</code>	Optional boolean (default is false). If <code>true</code> , server will check client certificate.
<code>com_ssl_ca</code>	Optional string. Set CA certificate. In case of peer verification with self signed certificate, you should use the client certificate.
<code>com_log_lock</code>	Optional boolean (default is false). If <code>true</code> , logs configuration can't be changed via <code>config_set</code> remote API.
<code>com_log_us</code>	Optional boolean (default is false). If <code>true</code> , logs sent by <code>log_get</code> remote API response will have a <code>timestamp_us</code> parameters instead of <code>timestamp</code>
<code>com_auth</code>	Optional object. If set, remote API access will require authentication. Authentication mechanism is describe in [Remote API Startup], page 14, section.
<code>passfile</code>	Optional string. Defines filename where password is stored (plaintext). If not set, <code>password</code> must be set

password Optional string. Defines password.
If not set, **passfile** must be set.

unsecure Optional boolean (default false). If set, allow password to be sent plain-text.
NB: you should set it to true if you access it from a Web Browser (Ex: Amarisoft GUI) without SSL (https) as your Web Browser may prevent secure access to work.

com_log_count

Optional number (Default = 8192). Defines number of logs to keep in memory before dropping them.
Must be between 4096 and 2097152).

6 Remote API

You can access LTEPROBE via a remote API.

Protocol used is WebSocket as defined in RFC 6455 (<https://tools.ietf.org/html/rfc6455>).

Note that Origin header is mandatory for the server to accept connections.
This behavior is determined by the use of `nopoll` library.
Any value will be accepted.

6.1 Messages

Messages exchanged between client and LTEPROBE server are in strict JSON format.

Each message is represented by an object. Multiple message can be sent to server using an array of message objects.

Time and delay values are floating number in seconds.

There are 3 types of messages:

- Request

Message sent by client.

Common definition:

message String. Represent type of message. This parameter is mandatory and depending on its value, other parameters will apply.

message_id

Optional any type. If set, response sent by the server to this message will have same `message_id`. This is used to identify response as WebSocket does not provide such a concept.

start_time

Optional float. Represent the delay before executing the message.
If not set, the message is executed when received.

absolute_time

Optional boolean (default = false). If set, `start_time` is interpreted as absolute.
You can get current clock of system using `time` member of any response.

standalone

Optional boolean (default = false). If set, message will survive WebSocket disconnection, else, if socket is disconnected before end of processing, the message will be cancelled.

loop_count

Optional integer (default = 0, max = 1000000). If set, message will be repeated `loop_count` time(s) after `loop_delay` (From message beginning of event).
Response will have a `loop_index` to indicate iteration number.

loop_delay

Optional number (min = 0.1, max = 86400). Delay in seconds to repeat message from its `start_time`. Mandatory when `loop_count` is set > 0.

- Response

Message sent by server after any request message as been processed.

Common definition:

message String. Same as request.

message_id
 Optional any type. Same as in request.

time Number representing time in seconds since start of the process.
 Usefull to send command with absolute time.

utc Number representing UTC seconds.

- Events

Message sent by server on its own initiative.

Common definition:

message String. Event name.

time Number representing time in seconds.
 Usefull to send command with absolute time.

6.2 Startup

When WebSocket connections is setup, LTEPROBE will send a first message with name set to `com_name` and type set to `UE`.

If authentication is not set, message will be `ready`:

```
{
  "message": "ready",
  "type": "UE",
  "name": <com_name>,
  "version": <software version>,
  "product": <Amarisoft product name (optional)>
}
```

If authentication is set, message will be `authenticate` :

```
{
  "message": "authenticate",
  "type": "UE",
  "name": <com_name>,
  "challenge": <random challenge>
}
```

To authenticate, the client must answer with a `authenticate` message and a `res` parameter where:

```
res = HMAC-SHA256( "<type>:<password>:<name>", "<challenge>" )
```

`res` is a string and HMAC-SHA256 refers to the standard algorithm (<https://en.wikipedia.org/wiki/HMAC>)

If the authentication succeeds, the response will have a `ready` field set to `true`.

```
{
  "message": "authenticate",
  "message_id": <message id>,
  "ready": true
}
```


If authentication fails, the response will have an **error** field and will provide a new challenge.

```
{
  "message": "authenticate",
  "message_id": <message id>,
  "error": <error message>,
  "type": "UE",
  "name": <name>,
  "challenge": <new random challenge>
}
```

If any other message is sent before authentication succeeds, the error "Authentication not done" will be sent as a response.

6.3 Errors

If a message produces an error, response will have an error string field representing the error.

6.4 Sample nodejs program

You will find in this documentation a sample program: **ws.js**.

It is located in doc subdirectory.

This is a nodejs program that allow to send message to LTEPROBE.

It requires nodejs to be installed:

```
dnf install nodejs npm
npm install nodejs-websocket
```

Use relevant package manager instead of NPM depending on your Linux distribution.

Then simply start it with server name and message you want to send:

```
./ws.js 127.0.0.1:9005 '{"message": "config_get"}'
```

6.5 Common messages

config_get

Retrieve current config.

Response definition:

type	Always "UE"
name	String representing server name.
logs	Object representing log configuration. With following elements:
layers	Object. Each member of the object represent a log layer configuration:
layer name	Object. The member name represent log layer name and parameters are:
level	See [log_options], page 7,
max_size	See [log_options], page 7,
key	See [log_options], page 7,

	crypto	See [log-options], page 7,	
	payload	See [log-options], page 7,	
	signal	Optional boolean. See [log-options], page 7,	
	count	Number. Number of bufferizer logs.	
	rotate	Optional number. Max log file size before rotation.	
	path	Optional string. Log rotation path.	
	bcch	Boolean. True if BCCH dump is enabled (eNB only).	
	mib	Boolean. True if MIB dump is enabled (eNB only).	
	locked	Optional boolean. If true , logs configuration can't be changed with config_set API.	
config_set			
Change current config.			
Each member is optional.			
Message definition:			
	logs	Optional object. Represent logs configuration. Same structure as config_get (See [config_get logs member], page 15). All elements are optional. Layer name can be set to all to set same configuration for all layers. If set and logs are locked, response will have logs property set to locked .	
log_get			
Get logs.			
This API has a per connection behavior. This means that the response will depend on previous calls to this API within the same WebSocket connection.			
In practice, logs that have been provided in a response won't be part of subsequent request unless connection is reestablished. To keep on receiving logs, client should send a new log_get request as soon as the previous response has been received.			
If a request is sent before previous request has been replied, previous request will be replied right now without considering specific min/max/timeout conditions.			
Message definition:			
	min	Optional number (default = 1). Minimum amount of logs to retrieve. Response won't be sent until this limit is reached (Unless timeout occurs).	
	max	Optional number (default = 4096). Maximum logs sent in a response.	
	timeout	Optional number (default = 1). If at least 1 log is available and no more logs have been generated for this time, response will be sent.	
	allow_empty	Optional boolean (default = false). If set, response will be sent after timeout, event if no logs are available.	
	rnti	Optional number. If set, send only logs matching rnti.	
	ue_id	Optional number. If set, send only logs with matching ue_id.	
	layers	Optional Object. Each member name represents a log layer and values must be string representing maximum level. See [log-options], page 7. If layers is not set, all layers level will be set to <i>debug</i> , else it will be set	

to *none*.

Note also the logs is also limited by general log level. See [log_options], page 7.

short	Optional boolean (default = false). If set, only first line of logs will be dumped.
headers	Optional boolean. If set, send log file headers.
start_timestamp	Optional number. Is set, filter logs older than this value in milliseconds.
end_timestamp	Optional number. Is set, filter logs more recent than this value in milliseconds.
max_size	Optional number (default = 1048576, i.e. 1MB). Maximum size in bytes of the generated JSON message. If the response exceeds this size, the sending of logs will be forced independently from other parameters.

Response definition:

logs	Array. List of logs. Each item is a an object with following members:
data	Array. Each item is a string representing a line of log.
timestamp	Number. Milliseconds since January 1st 1970. Not present if com_log_us is set in configuration.
timestamp_us	Number. Microseconds since January 1st 1970. Only present if com_log_us is set in configuration.
layer	String. Log layer.
level	String. Log level: <i>error</i> , <i>warn</i> , <i>info</i> or <i>debug</i> .
dir	Optional string. Log direction: <i>UL</i> , <i>DL</i> , <i>FROM</i> or <i>TO</i> .
ue_id	Optional number. UE.ID.
cell	Optional number (only for PHY layer logs). Cell ID.
rnti	Optional number (only for PHY layer logs). RNTI.
frame	Optional number (only for PHY layer logs). Frame number (Subframe is decimal part).
channel	Optional string (only for PHY layer logs). Channel name.
src	String. Server name.
idx	Integer. Log index.
headers	Optional array. Array of strings.
discontinuity	Optional number. If set, this means some logs have been discarded due to log buffer overflow.

	microseconds	Optional boolean. Present and set to true if <code>com_log_us</code> is set in configuration file.
log_set	Add log. Message definition:	
	log	Optional string. Log message to add. If set, <i>layer</i> and <i>level</i> are mandatory.
	layer	String. Layer name. Only mandatory if <i>log</i> is set.
	level	String. Log level: <i>error</i> , <i>warn</i> , <i>info</i> or <i>debug</i> . Only mandatory if <i>log</i> is set.
	dir	Optional string. Log direction: <i>UL</i> , <i>DL</i> , <i>FROM</i> or <i>TO</i> .
	ue_id	Optional number. UE-ID.
	flush	Optional boolean (default = false). If set, flushes fog file.
	rotate	Optional boolean (default = false). If set, forces log file rotation.
	cut	Optional boolean (default = false). If set, forces log file reset.
log_reset	Resets logs buffer.	
license	Retrieves license file information.	
quit	Terminates lteprobe.	
help	Provides list of available messages in <i>messages</i> array of strings and events to register in <i>events</i> array of strings.	
stats	Report statistics for LTEPROBE. Every time this message is received by server, statistics are reset. Warning, calling this message from multiple connections simultaneously will modify the statistics sampling time. Response definition:	
	cpu	Object. Each member name defines a type and its value cpu load in % of one core.
	instance_id	Number. Constant over process lifetime. Changes on process restart.

7 Log file format

7.1 PHY layer

When a PHY message is dumped (debug level), the format is:

```
time layer dir ue_id cell rnti frame.subframe channel:short_content
long_content
```

time Time using the selected format.

layer Layer ([PHY] here).

dir UL (uplink) or DL (downlink).

ue_id eNodeB UE identifier (hexadecimal, unique among all cells).

cell Cell index (hexadecimal).

rnti Associated RNTI (hexadecimal) or - if none.

frame.subframe

Frame number (0-1023) and either subframe number (0-9) for LTE and NB-IoT cells or slot number for NR cells.

channel PHY channel name (e.g. PUSCH, PUCCH, PRACH, SRS, PSS, PBCH, PCFICH, PDSCH, PHICH, PDCCH, EPDCCH, ...).

short_content

Single line content.

long_content

Hexadecimal dump of the message if `phy.max_size > 0`.

In the uplink messages, **epre** is the relative Energy per Resource Element in dB. The origin 0 dB corresponds to **tx_gain_offset** dBFS.

If UE power control is enabled, **p** is the absolute transmit power in dBm.

If the UE channel simulator is enabled, **p** is the absolute power before the channel simulation is applied. Moreover, if the UE channel simulator is enabled, **epre** is clamped to 0 dB to avoid a potential saturation in the RF interface.

7.2 MAC and RRC layers

When a message is dumped, the format is:

```
time layer - ue_id message
```

When a PDU is dumped (debug level), the format is:

```
time layer dir ue_id short_content
long_content
```

time Time using the selected format

layer Layer ([MAC] or [RRC] here).

dir UL (uplink) or DL (downlink).

ue_id eNodeB UE identifier (hexadecimal, unique among all cells).

cell_id Primary cell index.

short_content

Single line content.

`long_content`

- MAC: hexadecimal dump of the message if `layer.max_size > 0`.
- RRC: full ASN.1 content of the RRC message if `layer.max_size > 0`.

`long_content`

- MAC, RLC, PDCP: hexadecimal dump of the message if `layer.max_size > 0`.
- RRC: full ASN.1 content of the RRC message if `layer.max_size > 0`.

7.3 RLC, PDCP and NAS layers

When a message is dumped, the format is:

```
time layer - ue_id message
```

When a PDU is dumped (debug level), the format is:

```
time layer dir ue_id short_content
      long_content
```

`time` Time using the selected format

`layer` Layer ([RLC], [PDCP], or [NAS] here).

`dir` UL (uplink) or DL (downlink).

`ue_id` eNodeB UE identifier (hexadecimal, unique among all cells).

`short_content`

Single line content.

- RLC, PDCP: preceded by the SRB or DRB identifier.

`long_content`

- NAS: full content of the NAS message if `layer.max_size > 0`.

7.4 IP layer

When a IP data PDU is dumped (debug level), the format is:

```
time layer dir short_content
      long_content
```

`time` Time using the selected format

`layer` Indicate the layer ([IP] here).

`dir` UL (uplink) or DL (downlink).

`short_content`

Single line content (at least the IP protocol and the source and destination address).

`long_content`

Optional hexadecimal dump of the PDU if `ip.max_size > 0`.

8 Limitations

Currently unsupported features:

- TDD
- PUCCH decoding
- CSI (CQI, RI) decoding
- SRS decoding
- More precise UE location with multi-antenna system
- PUSCH decoding with large UL/DL timing offset
- Carrier aggregation

Known limitations:

- the maximum received bitrate is currently limited.

9 Change history

9.1 Version 2024-09-13

- `license` remote API is added
- `com_logs_lock` parameter is renamed to `com_log_lock`. `com_logs_lock` is still supported for backward compatibility
- `com_log_us` parameter is added

9.2 Version 2024-06-14

- OpenSSL library is upgraded to 1.1.1w

9.3 Version 2023-06-10

- `com_logs_lock` parameter added to disable logs configuration change via remote API

9.4 Version 2023-03-17

- `com_addr` parameter now uses `::]` address instead of `0.0.0.0` in the delivered configuration file to allow IPv6 connection

9.5 Version 2022-12-16

- `utc` parameter is added to remote API response messages

9.6 Version 2022-06-17

- OpenSSL library is upgraded to 1.1.1n
- `start_timestamp` and `end_timestamp` are added to `log_get` API

10 License

`lteprobe` is copyright (C) 2012-2024 Amarisoft. Its redistribution without authorization is prohibited.

`lteprobe` is available without any express or implied warranty. In no event will Amarisoft be held liable for any damages arising from the use of this software.

For more information on licensing, please refer to `license.pdf` file.