


CHECK CAN MAIN BUS LINE FOR DISCONNECTION (RHD, w/o LEXUS Navigation System)

CIRCUIT DESCRIPTION

There may be an open circuit in the CAN main bus line and/or the DLC3 sub bus line when the resistance between terminals 6 (CANH) and 14 (CANL) of the DLC3 is 69 Ω or more.


Symptom	Trouble Area
Resistance between terminals 6 (CANH) and 14 (CANL) of the DLC3 is 69 Ω or more.	<ul style="list-style-type: none">• CAN main bus line or connector• Junction connector (P-CAN J/C)• Junction connector (D-CAN J/C)• DLC3 sub bus line or connector

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK DLC3



- (a) Turn the ignition switch to the LOCK position.
- (b) Measure the resistance according to the value(s) in the table below.

Result:

Tester connection	Condition	Specified value	Result
D1-6 (CANH) - D1-14 (CANL)	Ignition Switch OFF	108 to 132 Ω	A
D1-6 (CANH) - D1-14 (CANL)	Ignition Switch OFF	132 Ω or more	B

NOTICE:

When the measured value is 132 Ω or more and a CAN communication system diagnostic trouble code is output, there may be a fault besides disconnection of the DLC3 sub bus line. For that reason, troubleshooting should be performed again from "HOW TO PROCEED WITH TROUBLESHOOTING" (see page 05-3306) after repairing the trouble area.


B

REPAIR OR REPLACE DLC3 SUB BUS LINE OR CONNECTOR (CAN-H, CAN-L)

A

2 CHECK CAN MAIN BUS LINE OR CONNECTOR(P-CAN J/C)

P-CAN J/C A Side (w/ Earth Terminal)
Wire Harness View:



- (a) Disconnect the CAN main bus line connector (J43) from the P-CAN J/C A side (w/ earth terminal).

NOTICE:

- Before disconnecting the connector, make a note of where it is connected.
 - Reconnect the connector to its original position.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified value
J43-1 (CANH) - J43-2 (CANL)	Ignition Switch OFF	108 to 132 Ω

OK

REPLACE JUNCTION CONNECTOR (P-CAN J/C)

NG

3


CONNECT CONNECTOR

- (a) Reconnect the CAN main bus line connector (J43) to the P-CAN J/C.



4

CHECK CAN MAIN BUS LINE OR CONNECTOR(D-CAN J/C)



- (a) Disconnect the CAN main bus line connector (J34) from the D-CAN J/C A side (w/ earth terminal).

NOTICE:

- **Before disconnecting the connector, make a note of where it is connected.**
 - **Reconnect the connector to its original position.**
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified value
J34-1 (CANH) - J34-2 (CANL)	Ignition Switch OFF	108 to 132 Ω

NG

REPAIR OR REPLACE CAN MAIN BUS LINE OR CONNECTOR (CAN-H, CAN-L)



REPLACE JUNCTION CONNECTOR (D-CAN J/C)