

DYNAMIC LASER CRUISE CONTROL SYSTEM

OSHOM-01

PRECAUTION

NOTICE:

When the negative (–) battery terminal is disconnected, initialize the following systems after the terminal is reconnected.

System Name	See page
Power Window Control System	01-20
Front Power Seat Control System	01-20
Back Guide Monitor System	01-20

Keep in mind the following points when inspecting the dynamic laser cruise control system.

- As there is a limitation to the vehicle-to-vehicle distance controlling capability, do not overly rely on the dynamic laser cruise control system.
- Do not neglect to pay constant attention to the vehicle-to-vehicle distance and the traffic conditions when using the dynamic laser cruise control system. Decelerate with the brake pedal, or accelerate with the accelerator pedal, according to the situation, to keep an appropriate distance with the vehicle in front.
- When the vehicle in front decelerates rapidly or another vehicle pulls out in front of the vehicle, decelerating in time to avoid a collision may not be possible without additional braking.
- The dynamic laser cruise control system is designed to assist in maintaining an appropriate distance with the vehicle in front. However, the system alone is not sufficient. It is imperative that the driver pays attention at all times.
- The laser sensor has functions to automatically detect dirt on the sensor face and inform the driver, but it is not perfect. Keep the sensor face clean.
- The dynamic laser cruise control system does not work, or give vehicle-approaching warning, for vehicles which are stopped or driving at significantly slower speeds. Always pay attention to those other vehicles.
- The laser sensor detection area is narrow at close range, so detection of a vehicle pulling out just in front may be delayed, or a motorcycle running on the side of the same lane may not be detected. The distance to the vehicle in front may not be maintained properly due to these reasons.
- Even if ACCEL is operated to increase the set vehicle speed, the vehicle does not accelerate because the speed is controlled in accordance with the speed of the vehicle in front while driving with the vehicle-to-vehicle distance control mode on (follow-up cruising). However, as the set vehicle speed has been increased by ACCEL operation, the vehicle keeps accelerating when there is no vehicle in front. Check the set speed with the set vehicle speed indication on the display.
- The controlled vehicle distance may be shorter than the set vehicle distance when cruising on a long downhill road.
- Push the cruise control main switch ON-OFF button off and reset the cruise control if the master warning light comes on, the CRUISE main indicator light blinks, and the fail indication is shown on the display with a "pong" sound during dynamic laser cruise control operation.
- The vehicle-approaching warning buzzer does not sound in the constant speed control mode because the existence of the vehicle in front and the distance to it are not judged as in the vehicle-to-vehicle distance control mode. Pay attention to the distance to the vehicle in front.
- The dynamic laser cruise control system has two cruise control modes: the constant speed control mode and vehicle-to-vehicle distance control mode. Confirm which mode is selected when using the dynamic laser cruise control system.