

## BASIC INSPECTION

When the malfunction is not confirmed in the DTC check, troubleshooting should be carried out in all the circuits considered as possible causes of the problem. In many cases, by carrying out the basic engine check shown in the following flowchart, the problem can be found quickly and efficiently. Therefore, using this check is essential in the engine troubleshooting.

### 1 CHECK BATTERY VOLTAGE

#### NOTICE:

Carry out this check with the engine stopped and ignition switch OFF.

	OK	NG
Voltage	11V or more	Less than 11V

NG → CHARGE OR REPLACE BATTERY

OK

### 2 CHECK IF ENGINE CRANKS

NG → PROCEED TO PROBLEM SYMPTOMS TABLE ON [PAGE 05-14](#)

OK

### 3 CHECK IF ENGINE STARTS

NG → Go to step 6

OK

### 4 CHECK AIR FILTER

Visually check that the air filter is not excessively dirty or oily.

NG → REPLACE AIR FILTER

OK

### 5 CHECK IDLE SPEED ([See page 14-1](#))

NG → PROCEED TO PROBLEM SYMPTOMS TABLE ON [PAGE 05-14](#)

OK

PROCEED TO PROBLEM SYMPTOMS TABLE ON [PAGE 05-14](#)

6 CHECK FUEL PRESSURE (See page 11-9)

NG PROCEED TO PAGE 11-9  
AND CONTINUE TO TROUBLESHOOT

OK

7 CHECK FOR SPARK (See page 18-4)

NG PROCEED TO PAGE 18-4  
AND CONTINUE TO TROUBLESHOOT

OK

PROCEED TO PROBLEM SYMPTOMS TABLE ON PAGE 05-14