

## PROBLEM SYMPTOMS TABLE

If a normal system code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

Symptom	Suspected Area	See page
Damping force control does not operate at all	1. Absorber control actuator circuit 2. TS terminal 3. Pneumatic cylinder/shock absorber 4. Suspension control ECU	<a href="#">05-276</a> <a href="#">05-512</a> <a href="#">26-12</a> <a href="#">27-10</a> <a href="#">25-20</a>
Lighting up position of height control indicator light does not change according to operation of height control switch	1. Height control switch circuit 2. Suspension control ECU	<a href="#">05-328</a> <a href="#">25-20</a>
Vehicle height control function does not operate	1. Height control sensor circuit 2. Height control solenoid valve circuit 3. Height control switch circuit 4. Height control exhaust valve circuit 5. AIR SUS relay circuit 6. Suspension control ECU	<a href="#">05-257</a> <a href="#">05-286</a> <a href="#">05-328</a> <a href="#">05-283</a> <a href="#">05-294</a> <a href="#">25-20</a>
Hunting of vehicle height occurs	1. Air leakage 2. Height control sensor circuit 3. Suspension control ECU	<a href="#">25-4</a> <a href="#">05-257</a> <a href="#">25-20</a>
Vehicle height control operates, but vehicle height is uneven	1. Height control sensor circuit 2. Height control sensor link 3. Suspension control ECU	<a href="#">05-257</a> <a href="#">25-4</a> <a href="#">25-20</a>
Vehicle height control operates, but vehicle height is high or low. (Vehicle height in NORMAL mode varies from the standard value)	1. Height control sensor link 2. Height control sensor circuit 3. Suspension control ECU	<a href="#">25-4</a> <a href="#">05-257</a> <a href="#">25-20</a>
When vehicle height control is adjusted, it stops at extremely high or extremely low position	Height control sensor circuit	<a href="#">05-257</a>
Height control indicator abnormal	1. Height control indicator circuit 2. Combination meter assy 3. Suspension control ECU	<a href="#">05-334</a> <a href="#">05-2135</a> <a href="#">25-20</a>
Absorber control indicator light abnormal	1. Absorber control indicator circuit 2. Combination meter assy 3. Suspension control ECU	<a href="#">05-337</a> <a href="#">05-2135</a> <a href="#">25-20</a>
DTC check cannot be done	Only when 1, 2 and 3 are all normal and the problem is still occurring, replace the suspension control ECU. 1. Absorber control indicator circuit 2. CAN communication system 3. TC terminal circuit	<a href="#">05-337</a> <a href="#">05-3294</a> <a href="#">05-508</a>
Input signal check (Test mode) cannot be done	1. CAN communication system 2. TS terminal circuit 3. Suspension control ECU	<a href="#">05-3294</a> <a href="#">05-512</a> <a href="#">25-20</a>

Vehicle height is extremely low when vehicle is parked	<ol style="list-style-type: none"><li>1. Air leakage</li><li>2. Pneumatic cylinder/shock absorber</li><li>3. Height control sensor link</li><li>4. Height control exhaust valve circuit</li></ol>	<a href="#">25-4</a> <a href="#">26-1</a> <a href="#">27-1</a> <a href="#">25-4</a> <a href="#">05-283</a>
Compressor motor continues to operate	<ol style="list-style-type: none"><li>1. Air leakage</li><li>2. AIR SUS relay circuit</li><li>3. Height control compressor circuit</li><li>4. Height control sensor link</li><li>5. Pneumatic cylinder/shock absorber</li><li>6. Suspension control ECU</li></ol>	<a href="#">25-4</a> <a href="#">05-294</a> <a href="#">05-299</a> <a href="#">25-4</a> <a href="#">26-1</a> <a href="#">27-1</a> <a href="#">25-20</a>