

FREEZE FRAME DATA OF ABS

1. FREEZE FRAME DATA

HINT:

- Whenever a DTC is detected or the ABS operates, the skid control ECU stores the current vehicle (sensor) state as freeze frame data.
 - The skid control ECU stores the number of times (maximum: 31) the ignition switch has been turned from off to the ON position since the last time ABS was activated. However, if the vehicle was stopped or at low speed (7 km/h (4.3 mph) or less), or if a DTC is detected, the skid control ECU will not count the number after that.
 - Freeze frame data at the time the ABS operates:
The skid control ECU stores and updates data whenever the ABS system operates.
When the ECU stores data at the time a DTC is detected, the data stored when the ABS operated is erased.
 - Freeze frame data at the time a DTC is detected:
When the skid control ECU stores data at the time a DTC is detected, no updates will be performed until the data is cleared.
- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch to the ON position.
- (c) From the display on the tester, select the "FREEZE FRAME DATA".

Intelligent tester II display	Measurement Item	Reference Value*
Vehicle Speed	Wheel speed sensor reading	Speed indicated on speedometer
Stop Light SW	Stop light switch signal	Stop light switch ON: ON, OFF: OFF
Number of IG ON	Number of operations of ignition switch ON after memorizing freeze frame data	0 to 31
Master Cylinder Sensor 1	Master cylinder pressure sensor reading	Brake pedal release : 0.3 to 0.9 V Brake pedal depress: 0.8 to 4.5 V
Master Cylinder Grade	Master cylinder pressure sensor change	-30 to 200 MPa/s
Operated System	System status	ABS activated: ABS VSC/TRC activated: VSC/TRC BA activated: BA Fail safe mode activated: FAIL SF No system activated: NO SYS
Yaw Rate Sensor	Yaw rate angle sensor reading	-100 to 100
Steering Angle Sensor	Steering sensor reading	Left turn: Increase Right turn: Drop (Deceleration)
Throttle Sensor	Throttle position sensor reading	Release accelerator pedal: Approx. 0 deg. Depress accelerator pedal: Approx. 90 deg.
Right And Left G	Right and left G (Yaw Rate)	-1.869 to 1.869
Back And Forth G	Back and forth G (Deceleration)	-1.869 to 1.869
VSC/TRC OFF SW	VSC (TRC) OFF switch signal	TRC OFF SW ON: ON OFF: OFF
Shift Lever Position	Shift lever position	FAIL P,N R D 4 3 2 L
Freeze DTC	Freeze DTC	0 to 255
Number of DTC	Number of trouble codes	0 to 255