

ISO Geodetic Registry

<i>Item class</i>	Conversion	
<i>Name</i>	UTM zone 48S	
<i>Item status</i>	VALID	
<i>Identifier</i>	838	
<i>Alias</i>	UTM zone -48	
<i>Information source</i>	<i>Title</i>	Geomatics Guidance Note No 7, part 2: Coordinate Conversions and Transformations including Formulas
	<i>Author</i>	International Association of Oil and Gas Producers (IOGP)
	<i>Publisher</i>	International Association of Oil and Gas Producers (IOGP)
	<i>Revision date</i>	2021-11
	<i>Edition</i>	61
	<i>Series/Journal name</i>	IOGP Publication
	<i>Issue identification</i>	373-7-2
	<i>Other citation details</i>	https://epsg.org/guidance-notes.html (accessed 2022-01-19)
	<i>Title</i>	The Universal Grids and the Transverse Mercator and Polar Stereographic Map Projections
	<i>Author</i>	National Geospatial-Intelligence Agency (NGA)
<i>Information source</i>	<i>Publisher</i>	National Geospatial-Intelligence Agency (NGA)
	<i>Revision date</i>	2014-03-25
	<i>Series/Journal name</i>	National Geospatial-Intelligence Agency Standardization Document
	<i>Issue identification</i>	NGA.SIG.0012_2.0.0_UTMUPS Version 2.0.0
	<i>Other citation details</i>	https://nsgreg.nga.mil/doc/view?i=4056&month=3&day=28&year=2022 (accessed 2022-04-20)
<i>Data source</i>	ISO Geodetic Registry	
<i>Scope</i>	Spatial referencing	
<i>Operation method</i>	Transverse Mercator Projection	

Extent

<i>Description</i>	World - onshore and offshore - between 102°E and 108°E, southern hemisphere between equator and 80°S.	
<i>Geographic Bounding Box</i>	<i>West-bound longitude</i>	102.0
	<i>North-bound latitude</i>	-80.0
	<i>East-bound longitude</i>	108.0
	<i>South-bound latitude</i>	0.0

Operation parameter values

<i>Latitude of natural origin</i>	0.0 degree
<i>Longitude of natural origin</i>	105.0 degree
<i>Scale factor at natural origin</i>	0.9996 unity
<i>False easting</i>	500000.0 metre
<i>False northing</i>	1.0E7 metre

ISO Geodetic Registry

<i>Item class</i>	OperationMethod
<i>Name</i>	Transverse Mercator Projection
<i>Item status</i>	VALID
<i>Identifier</i>	834
<i>Alias</i>	Gauss-Boaga
<i>Alias</i>	TM
<i>Alias</i>	Gauss-Kruger
<i>Data source</i>	ISO Geodetic Registry

Operation parameters

<i>Latitude of natural origin</i>
<i>Longitude of natural origin</i>
<i>Scale factor at natural origin</i>
<i>False easting</i>
<i>False northing</i>