



# Easy Gateway Manual

V1.0

## About this Document

This document supports “RT58x\_SDK\_v1.2.0” and later version.

## Table of Contents

<b>About this Document.....</b>	<b>1</b>
1. Introduction.....	6
2. Hardware Interface Setup .....	6
3. Command Data Format.....	6
3.1. Command Structure.....	6
3.1.1. Header field .....	6
3.1.2. Length field .....	6
3.1.3. Command id field .....	6
3.1.4. Address field .....	7
3.1.5. Address mode field .....	7
3.1.6. Endpoint field .....	7
3.1.7. Parameter field .....	7
3.1.8. Checksum field .....	7
3.2. Command Example .....	8
4. Device and Network Management Service.....	9
4.1. Device and Service Discovery .....	9
4.1.1. Network address request (0x0000-0000).....	9
4.1.2. Network address response (0x0000-8000) .....	10
4.1.3. IEEE address request (0x0000-0001).....	13
4.1.4. IEEE address response (0x0000-8001) .....	14
4.1.5. Node descriptor request (0x0000-0002) .....	17
4.1.6. Node descriptor response (0x0000-8002).....	18
4.1.7. Power descriptor request (0x0000-0003).....	19

4.1.8.	Power descriptor response (0x0000-8003) .....	20
4.1.9.	Simple descriptor request (0x0000-0004) .....	21
4.1.10.	Simple descriptor response (0x0000-8004) .....	21
4.1.11.	Active endpoint request (0x0000-0005) .....	23
4.1.12.	Active endpoint response (0x0000-8005) .....	23
4.1.13.	Match descriptor request (0x0000-0006) .....	24
4.1.14.	Match descriptor response (0x0000-8006) .....	26
4.1.15.	Device announce indication (0x0000-0013).....	27
4.1.16.	Parent announce indication (0x0000-001F).....	28
4.2.	Device Bind Management .....	29
4.2.1.	Bind request (0x0000-0021) .....	29
4.2.2.	Bind response (0x0000-8021) .....	30
4.2.3.	Unbind request (0x0000-0022).....	31
4.2.4.	Unbind response (0x0000-8022).....	33
4.3.	Network Management.....	33
4.3.1.	Device binding information request (0x0000-0033) .....	33
4.3.2.	Device binding information response (0x0000-8033) .....	34
4.3.3.	Device leave request (0x0000-0034) .....	35
4.3.4.	Device leave response (0x0000-8034).....	36
4.3.5.	Direct join request (0x0000-0035) .....	36
4.3.6.	Direct join response (0x0000-8035) .....	37
4.3.7.	Permit join request (0x0000-0036) .....	38
4.3.8.	Permit join response (0x0000-8036) .....	39
4.3.9.	Network update request (0x0000-0038).....	39
4.3.10.	Network update notify (0x0000-8038).....	41
4.3.11.	Gateway Start (0x0000-0039) .....	43
4.3.12.	Gateway Start response (0x0000-8039) .....	44
4.3.13.	Gateway reset (0x0000-0040).....	44
4.3.14.	Gateway reset response (0x0000-8040).....	44
4.4.	Device and Network Management Service Status Enumeration Description	45
5.	Application Service Management .....	47
5.1.	Device Information .....	47
5.1.1.	Get device version info (0x0001-0000) .....	47
5.1.2.	Get device version info response (0x0001-8000) .....	47
5.1.3.	Get device manufacture name (0x0001-0001).....	47
5.1.4.	Get device manufacture name response (0x0001-8001).....	48

5.1.5.	Get device model id (0x0001-0002) .....	48
5.1.6.	Get device model id response (0x0001-8002) .....	48
5.1.7.	Get device date code (0x0001-0003) .....	48
5.1.8.	Get device date code response (0x0001-8003) .....	49
5.1.9.	Get software build id (0x0001-0004) .....	49
5.1.10.	Get software build id response (0x0001-8004) .....	49
5.1.11.	Default Response (0x0001-8800) .....	49
5.1.12.	Read device attributes (0x0002-0000) .....	50
5.1.13.	Read device attributes response (0x0002-8000) .....	50
5.2.	Device Identify .....	51
5.2.1.	Identify (0x0004-0000) .....	51
5.2.2.	Identify query (0x0004-0001) .....	51
5.2.3.	Identify query response (0x0004-8001) .....	51
5.3.	Group Management .....	51
5.3.1.	Add group (0x0005-0000) .....	51
5.3.2.	Add group response (0x0005-8000) .....	52
5.3.3.	View group (0x0005-0001) .....	52
5.3.4.	View group response (0x0005-8001) .....	52
5.3.5.	Get group membership (0x0005-0002) .....	52
5.3.6.	Get group membership response (0x0005-8002) .....	53
5.3.7.	Remove group (0x0005-0003) .....	53
5.3.8.	Remove group response (0x0005-8003) .....	53
5.3.9.	Remove all groups (0x0005-0004) .....	54
5.3.10.	Add group if identifying (0x0005-0005) .....	54
5.4.	Scene Management .....	54
5.4.1.	Add scene (0x0006-0000) .....	54
5.4.2.	Add scene response (0x0006-8000) .....	56
5.4.3.	View scene (0x0006-0001) .....	56
5.4.4.	View scene response (0x0006-8001) .....	57
5.4.5.	Remove scene (0x0006-0002) .....	59
5.4.6.	Remove scene response (0x0006-8002) .....	59
5.4.7.	Remove all scene (0x0006-0003) .....	59
5.4.8.	Remove all scene response (0x0006-8003) .....	59
5.4.9.	Store scene (0x0006-0004) .....	60
5.4.10.	Store scene response (0x0006-8004) .....	60
5.4.11.	Recall scene (0x0006-0005) .....	60
5.4.12.	Get scene membership (0x0006-0006) .....	60

5.4.13.	Get scene membership response (0x0006-8006) .....	61
5.5.	On/Off Control.....	61
5.5.1.	Off (0x0007-0000).....	61
5.5.2.	On (0x0007-0001).....	61
5.5.3.	Toggle (0x0007-0002).....	62
5.5.4.	On with recall global scene (0x0007-0003).....	62
5.5.5.	On with timed off (0x0007-0004) .....	63
5.6.	Level Control.....	63
5.6.1.	Move to level (0x0009-0000).....	63
5.6.2.	Move (0x0009-0001) .....	63
5.6.3.	Step (0x0009-0002).....	64
5.6.4.	Stop (0x0009-0003).....	64
5.6.5.	Move to level (with On/Off) (0x0009-0004) .....	64
5.6.6.	Move (with On/Off) (0x0009-0005).....	65
5.6.7.	Step (with On/Off) (0x0009-0006) .....	65
5.7.	Lighting Color Control .....	65
5.7.1.	Move to hue (0x0021-0000) .....	65
5.7.2.	Move hue (0x0021-0001) .....	66
5.7.3.	Step hue (0x0021-0002).....	66
5.7.4.	Move to saturation (0x0021-0003) .....	66
5.7.5.	Move saturation (0x0021-0004) .....	66
5.7.6.	Step saturation (0x0021-0005).....	67
5.7.7.	Move to hue and saturation (0x0021-0006) .....	67
5.7.8.	Move to color (0x0021-0007).....	67
5.7.9.	Move color (0x0021-0008).....	68
5.7.10.	Step color (0x0021-0009).....	68
5.7.11.	Move to color temperature (0x0021-000A) .....	68
5.7.12.	Move color temperature (0x0021-004B) .....	68
5.7.13.	Step color temperature (0x0021-004C) .....	69
5.8.	Application Service Management Status Enumeration Description.....	69
6.	Easy Gateway Service .....	71
6.1.	Device Table Control.....	71
6.1.1.	Device table get (0x1000-0100) .....	71
6.1.2.	Device table get response (0x1000-8100) .....	71
6.1.3.	Device name set (0x1000-0101) .....	72
6.1.4.	Device name set response (0x1000-8101) .....	72
6.1.5.	End point name set (0x1000-0102) .....	72

6.1.6. End point name set response (0x1000-8102) .....	73
6.1.7. Device table remove all (0x1000-0103).....	73
6.1.8. Device table remove all response (0x1000-8103) .....	73
6.1.9. Device table remove specific device (0x1000-0104) .....	73
6.1.10. Device table remove specific device response (0x1000-8104) .	74
6.2. Group Table Control.....	74
6.2.1. Group table get (0x1000-0200) .....	74
6.2.2. Group table get response (0x1000-8200) .....	74
6.2.3. Group name set (0x1000-0201) .....	75
6.2.4. Group name set response (0x1000-8201) .....	75
6.2.5. Group table remove all (0x1000-0202).....	75
6.2.6. Group table remove all response (0x1000-8202).....	76
6.2.7. Group table create (0x1000-0203) .....	76
6.2.8. Group table create response (0x1000-8203) .....	76
6.3. Scene Table Control .....	76
6.3.1. Scene table get (0x1000-0300) .....	76
6.3.2. Scene table get response (0x1000-8300) .....	77
6.3.3. Scene name set (0x1000-0301) .....	77
6.3.4. Scene name set response (0x1000-8301) .....	77
6.3.5. Scene table remove all (0x1000-0302) .....	78
6.3.6. Scene table remove all response (0x1000-8302) .....	78
6.3.7. Scene table create (0x1000-0303) .....	78
6.3.8. Scene table create response (0x1000-8303) .....	78
6.4. Bind Table Control .....	79
6.4.1. Bind table get (0x1000-0400) .....	79
6.4.2. Bind table get response (0x1000-8400) .....	79
6.4.3. Bind table remove all (0x1000-0401) .....	80
6.4.4. Bind table remove all response (0x1000-8401) .....	80
6.5. ZC Information Control .....	80
6.5.1. ZC information get (0x1000-0A00) .....	80
6.5.2. ZC information get response (0x1000-8A00) .....	80
6.5.3. ZC information change notification (0x1000-8A01).....	81
6.6. Easy Gateway Service Status Enumeration Description .....	81
<b>Revision History</b> .....	<b>82</b>

# 1. Introduction

This document is the command sets for implementing the Zigbee gateway function with coordinator module. It includes the Zigbee network management and application service commands.

## 2. Hardware Interface Setup

The coordinator module is connected to host control unit by UART port. The default baud rate is 115200 with 8-bit data length, no parity bit, and 1 stop bit format.

## 3. Command Data Format

### 3.1. Command Structure

The Zigbee gateway command is constructed as the following format. It uses the little endian format

Header	Length	Command Id	Address	Address mode	Endpoint	Parameter	Checksum
4 octets	1 octet	4 octets	2 octets	1 octets	0/1 octet	n octets	1 octet

#### 3.1.1. Header field

The command header is 4 bytes long and should be formatted as 0xFF 0xFC 0xFC 0xFF.

#### 3.1.2. Length field

The command data length value is the length sum of address, address mode, command id, and parameter.

#### 3.1.3. Command id field

The command id is 4 bytes long and will be defined in the following command description.

### 3.1.4. Address field

Address data is 2 bytes long, and could be unicast or group address identified by address mode field.

Some special addresses are defined as broadcast address and the address mode data will be ignored if these addresses are used.

0xFFFF: Broadcast to all devices in PAN.

0xFFFE: Reserved.

0xFFFD: Broadcast to devices which Rx are on when in idle state (macRxOnWhenIdle = TRUE).

0xFFFC: Broadcast to all routers and coordinator.

0xFFFB: Broadcast to all low power routers only.

0xFFF8 – 0xFFFA: Reserved

### 3.1.5. Address mode field

Address is 1-byte long. Mode value is defined as follow.

Mode value 0: the address is a unicast address.

Mode value 1: the address is a group address.

### 3.1.6. Endpoint field

For “Device and Network Management Service” and “RT58x Gateway Service”, the “Endpoint” field will not present.

For “Application Management Service”, the “Endpoint” field should present for specific endpoint and its application.

### 3.1.7. Parameter field

The parameter is variable bytes and used for command to configure the devices. The following command description has more detail information.

### 3.1.8. Checksum field

The checksum is 1-byte long and to confirm the received data correctly. Its value is bitwise not(~) of the sum of all command data fields but header field excluded.

Checksum value = ~(length[0]+command id[0]+ command id[1]+ command id[2]+



command id[3]+address[0]+address[1]+address mode[0]+endpoint[0]+parameter[0]+parameter[1]+.....+parameter[n-1]).

## 3.2. Command Example

Assume host sends a “Device and Network Management Service” command to group devices with group address is 0x5566, command id is 0x12005678, parameter is 2-octet short integer 0x3567.

The command data should be formatted as flowing byte stream in little endian style. The endpoint field is not presented.

Header: 0xFF 0xFC 0xFC 0xFF

Length: 0x09

Command id: 0x78 0x56 0x00 0x12

Address: 0x66 0x55

Address Mode: 0x01

Parameters: 0x67 0x35

Checksum:  $\sim(0x09+0x78+0x56+0x00+0x12+0x66+0x55+0x01+0x67+0x35) = 0xBE$

Then the command should be

{0xFF 0xFC 0xFC 0xFF 0x09 0x78 0x56 0x00 0x12 0x66 0x55 0x01 0x67 0x35 0xBE}

Assume host sends an “Application Management Service” command to single device with address is 0x5566, command id is 0x12005678, endpoint is 0x0c, parameter is 2-octet short integer 0x3567.

The command data should be formatted as flowing byte stream in little endian style. The endpoint field must be presented.

Header: 0xFF 0xFC 0xFC 0xFF

Length: 0x0A

Command id: 0x78 0x56 0x00 0x12

Address: 0x66 0x55

Address Mode: 0x00

Endpoint: 0x0C

Parameters: 0x67 0x35

Checksum:

$\sim(0x0A+0x78+0x56+0x00+0x12+0x66+0x55+0x00+0x0C+0x67+0x35) = 0xB2$

Then the command should be



{0xFF 0xFC 0xFC 0xFF 0x0A 0x78 0x56 0x00 0x12 0x66 0x55 0x00 0x0C 0x67  
0x35 0xB2}

## 4. Device and Network Management Service

### 4.1. Device and Service Discovery

#### 4.1.1. Network address request (0x0000-0000)

The network address request is generated for wishing to inquire as to the 16-bit address of the Remote Device based on its known IEEE address. The destination addressing on this command shall be unicast or broadcast to all devices for which macRxOnWhenIdle = TRUE.

- Command Id  
0x0000-0000
- Parameter

8 octets	1 octet	1 octet
IEEEAddr	RequestType	StartIndex

Name	Type	Valid Range	Description
IEEEAddr	IEEE Address	A valid 64-bit IEEE address	The IEEE address to be matched by the Remote Device
RequestType	Integer	0x00-0xff	Request type for this command: 0x00 – Single device response 0x01 – Extended response 0x02-0xFF –

			reserved
StartIndex	Integer	0x00-0xff	If the Request type for this command is Extended response, the StartIndex provides the starting index for the requested elements of the associated devices list

Request type: Single device response

A NWK\_addr\_resp command shall be generated and sent back to the local device with the Status field set to SUCCESS, the IEEEAddrRemoteDev field set to the IEEE address of the request; the NWKAddrRemoteDev field set to the NWK address of the discovered device; and the NumAssocDev, StartIndex, and NWKAddrAssocDevList fields shall not be included.

Request type: Extended response

The Remote Device is either the ZigBee coordinator or router, a NWK\_addr\_resp command shall be generated and sent back to the local device with the Status field set to SUCCESS, the IEEEAddrRemoteDev field set to the IEEE address of the device itself, and the NWKAddrRemoteDev field set to the NWK address of the device itself. The Remote Device shall also supply a list of all 16-bit NWK addresses in the NWKAddrAssocDevList field, starting with the entry StartIndex and continuing with whole entries until the packet maximum length reached.

#### 4.1.2. Network address response (0x0000-8000)

The network address response is a Remote Device in response to a network address request command inquiring as to the NWK address of the Remote Device or the NWK address of an address held in the neighbor table

- Command id

0x0000-8000

● Parameter

1 octet	8 octets	2 octets	0/1 octet	0/1 octet	variable
Status	IEEEAddr RemoteDev	NWKAddr RemoteDev	Num AssocDev	StartIndex	NWKAddr AssocDevList

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, INV_REQUESTTYPE, or DEVICE_NOT_FOUND	The status of the NWK_addr_req command.
IEEEAddrRemoteDev	Device Address	An extended 64-bit, IEEE address	64-bit address for the Remote Device
NWKAddrRemoteDev	Device Address	A 16-bit, NWK address	16-bit address for the Remote Device
NumAssocDev	Integer	0x00-0xff	Count of the number of 16-bit short addresses to follow. If the RequestType in the request is Extended Response and there are no associated devices on the Remote Device, this field shall be set to 0. If an error occurs or the Request Type in the request is for a

			Single Device Response, this field shall not be included in the frame.
StartIndex	Integer	0x00-0xff	Starting index into the list of associated devices for this report. If the RequestType in the request is Extended Response and there are no associated devices on the Remote Device, this field shall not be included in the frame. If an error occurs or the Request Type in the request is for a Single Device Response, this field shall not be included in the frame.
NWKAddrAssocDevList	Device Address Lis	List of NumAssocDev 16-bit short addresses, each with range 0x0000 - 0xffff	A list of 16-bit addresses, one corresponding to each associated device to Remote Device;

			<p>The number of 16-bit network addresses contained in this field is specified in the NumAssocDev field. If the RequestType in the request is Extended Response and there are no associated devices on the Remote Device, this field shall not be included in the frame. If an error occurs or the Request Type in the request is for a Single Device Response, this field shall not be included in the frame.</p>
--	--	--	--

#### 4.1.3. IEEE address request (0x0000-0001)

The IEEE address request is generated for wishing to inquire as to the 64-bit IEEE address of the Remote Device based on their known 16-bit address. The destination addressing on this command shall be unicast or broadcast to all devices for which macRxOnWhenIdle = TRUE.

- Command id

0x0000-0001

- Parameter

2 octets	1 octet	1 octet
NWKAddrOfInterest	RequestType	StartIndex

Name	Type	Valid Range	Description
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address that is used for IEEE address mapping
RequestType	Integer	0x00-0xff	Request type for this command: 0x00 – Single device response 0x01 – Extended response 0x02-0xFF – reserved
StartIndex	Integer	0x00-0xff	If the Request type for this command is Extended response, the StartIndex provides the starting index for the requested elements of the associated devices list

#### 4.1.4. IEEE address response (0x0000-8001)

The IEEE address response is in response to an IEEE address request command inquiring as to the 64-bit IEEE address of the Remote Device or the 64-bit IEEE address of an address held in the neighbor table.

*Rafael Microelectronics      Rafael Easy Gateway Manual*

The information contained herein is the exclusive property of Rafael Microelectronics, Inc. and shall not be distributed, reproduced or disclosed in whole or in part without prior written permission of Rafael Microelectronics, Inc.

- Command Id  
0x0000-8001

- Parameter

1 octet	8 octets	2 octets	0/1 octet	0/1 octet	variable
Status	IEEEAddr RemoteDev	NWKAddr RemoteDev	Num AssocDev	StartIndex	NWKAddr AssocDevList

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, INV_REQUESTTYPE, or DEVICE_NOT_FOUND	The status of the NWK_addr_req command.
IEEEAddrRemoteDev	Device Address	An extended 64-bit, IEEE address	64-bit address for the Remote Device
NWKAddrRemoteDev	Device Address	A 16-bit, NWK address	16-bit address for the Remote Device
NumAssocDev	Integer	0x00-0xff	Count of the number of 16-bit short addresses to follow. If the RequestType in the request is Extended Response and there are no associated devices on the Remote Device, this field shall be set to 0. If an error occurs or the Request



			Type in the request is for a Single Device Response, this field shall not be included in the frame.
StartIndex	Integer	0x00-0xff	Starting index into the list of associated devices for this report. If the RequestType in the request is Extended Response and there are no associated devices on the Remote Device, this field shall not be included in the frame. If an error occurs or the Request Type in the request is for a Single Device Response, this field shall not be included in the frame.
NWKAddrAssocDevList	Device Address Lis	List of NumAssocDev 16-bit short addresses, each with range 0x0000 - 0xffff	A list of 16-bit addresses, one corresponding to each associated

			<p>device to Remote Device; The number of 16-bit network addresses contained in this field is specified in the NumAssocDev field. If the RequestType in the request is Extended Response and there are no associated devices on the Remote Device, this field shall not be included in the frame. If an error occurs or the Request Type in the request is for a Single Device Response, this field shall not be included in the frame.</p>
--	--	--	---

#### 4.1.5. Node descriptor request (0x0000-0002)

The Node descriptor request command is generated for wishing to inquire as to the node descriptor of a remote device. This command shall be unicast either to the remote device itself or to an alternative device that contains the discovery information of the remote device.

- Command id  
0x0000-0002

- Parameter

2 octets
NWKAddrOfInterest

Name	Type	Valid Range	Description
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request

#### 4.1.6. Node descriptor response (0x0000-8002)

The node descriptor response is in response to a node descriptor request directed to the remote device. This command shall be unicast to the originator of the node descriptor request command.

- Command id  
0x0000-80002

- Parameter

1 octet	2 octets	Variable
Status	NWKAddrOfInterest	Node Descriptor

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, DEVICE_NOT_FOUND, INV_REQUESTTYPE, or NO_DESCRIPTOR	The status of the command
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request
NodeDescriptor	Node Descriptor		This field shall only be included

			in the frame if the status field is equal to SUCCESS
--	--	--	--

### Node Descriptor

The node descriptor contains information about the capabilities of the ZigBee node and is mandatory for each node. There shall be only one node descriptor in a node.

Field Name	Length(bits)
Logical type	3
Complex descriptor available	1
User descriptor available	1
Reserved	3
APS flags	3
Frequency band	5
MAC capability flags	8
Manufacturer code	16
Maximum buffer size	8
Maximum incoming transfer size	16
Server mask	16
Maximum outgoing transfer size	16
Descriptor capability field	8

#### 4.1.7. Power descriptor request (0x0000-0003)

The Power descriptor request command is generated for wishing to inquire as to the power descriptor of a remote device. This command shall be unicast either to the remote device itself or to an alternative device that contains the discovery information of the remote device.

- Command id  
0x0000-0003
- Parameter

2 octets
NWKAddrOfInterest

Name	Type	Valid Range	Description
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request

#### 4.1.8. Power descriptor response (0x0000-8003)

The power descriptor response is in response to a power descriptor request directed to the remote device. This command shall be unicast to the originator of the power descriptor request command.

- Command id  
0x0000-8003
- Parameter

1 octet	2 octets	Variable
Status	NWKAddrOfInterest	Power Descriptor

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, DEVICE_NOT_FOUND, INV_REQUESTTYPE, or NO_DESCRIPTOR	The status of the command
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request
PowerDescriptor	Power Descriptor		This field shall only be included in the frame if the status field is equal to SUCCESS

#### Power Descriptor

The node power descriptor gives a dynamic indication of the power status of the

*Rafael Microelectronics      Rafael Easy Gateway Manual*

The information contained herein is the exclusive property of Rafael Microelectronics, Inc. and shall not be distributed, reproduced or disclosed in whole or in part without prior written permission of Rafael Microelectronics, Inc.

node and is mandatory for each node. There shall be only one node power descriptor in a node.

Field Name	Length(bits)
Current power mode	4
Available power sources	4
Current power source	4
Current power source level	4

#### 4.1.9. Simple descriptor request (0x0000-0004)

The Simple descriptor request command is generated for wishing to inquire as to the simple descriptor of a remote device on a specified endpoint. This command shall be unicast either to the remote device itself or to an alternative device that contains the discovery information of the remote device.

- Command id  
0x0000-0004

- Parameter

2 octets	1 octet
NWKAddrOfInterest	EndPoint

Name	Type	Valid Range	Description
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request
Endpoint	8 bits	1-254	The endpoint on the destination

#### 4.1.10. Simple descriptor response (0x0000-8004)

The simple descriptor response is in response to a simple descriptor request directed to the remote device. This command shall be unicast to the originator of the simple descriptor request command.

- Command id  
0x0000-8004

- Parameter

1 octet	2 octets	1 octet	Variable
Status	NWKAddrOfInterest	Length	Simple Descriptor

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, DEVICE_NOT_FOUND, INV_REQUESTTYPE, or NO_DESCRIPTOR	The status of the command
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request
Length	Integer	0x00-0xff	Length in bytes of the Simple Descriptor to follow.
SimpleDescriptor	Simple Descriptor		This field shall only be included in the frame if the status field is equal to SUCCESS

### Simple Descriptor

The simple descriptor contains information specific to each endpoint contained in this node. The simple descriptor is mandatory for each endpoint present in the node.

Field Name	Length(bits)
Endpoint	8
Application profile identifier	16
Application device identifier	16
Application device version	4
Reserved	4
Application input cluster count	8
Application input cluster list	16*i (where i is



	the value of the application input cluster count)
Application output cluster count	8
Application output cluster list	16*o (where o is the value of the application output cluster count)

#### 4.1.11. Active endpoint request (0x0000-0005)

The Active endpoint request command is generated for wishing to acquire the list of endpoints on a remote device with simple descriptors. This command shall be unicast either to the remote device itself or to an alternative device that contains the discovery information of the remote device.

- Command id  
0x0000-0005
- Parameter

2 octets
NWKAddrOfInterest

Name	Type	Valid Range	Description
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request

#### 4.1.12. Active endpoint response (0x0000-8005)

The active endpoint response is in response to an active endpoint request directed to the remote device. This command shall be unicast to the originator of the active endpoint request command.

- Command id  
0x0000-8005

## ● Parameter

1 octet	2 octets	1 octet	Variable
Status	NWKAddrOfInterest	ActiveEPCCount	ActiveEPList

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, DEVICE_NOT_FOUND, INV_REQUESTTYPE, or NO_DESCRIPTOR	The status of the command
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request
ActiveEPCCount	Integer	0x00-0xff	The count of active endpoints on the Remote Device.
ActiveEPList			List of bytes each of which represents an 8-bit endpoint

## 4.1.13. Match descriptor request (0x0000-0006)

The Match descriptor request command is generated from a local device wishing to find remote devices supporting a specific simple descriptor match criterion. This command shall either be broadcast to all devices for which `macRxOnWhenIdle = TRUE`, or unicast. If the command is unicast, it shall be directed either to the remote device itself or to an alternative device that contains the discovery information of the remote device.

The `NWKAddrOfInterest` field shall contain the network address indicating a broadcast to all devices with address `0xFFFFD` if the command is to be broadcast, or the network address of the remote device for which the match is required.

The remaining fields shall contain the required criterion for which the simple descriptor match is requested. The `ProfileID` field shall contain the identifier of the profile for which the match is being sought or the wildcard profile ID of `0xFFFF`.

The `NumInClusters` field shall contain the number of elements in the `InClusterList` field. If the value of this field is 0, the `InClusterList` field shall not be included. If the

value of the NumInClusters field is not equal to 0, the InClusterList field shall contain the list of input cluster identifiers for which the match is being sought. The NumOutClusters field shall contain the number of elements in the OutClusterList field. If the value of this field is 0, the OutClusterList field shall not be included. If the value of the NumOutClusters field is not equal to 0, the OutClusterList field shall contain the list of output cluster identifiers for which the match is being sought.

- Command id  
0x0000-0006
- Parameter

2 octets	2 octets	1 octets	Variable	1 octets	Variable
NWKAddrOfInterest	ProfileID	NumInClusters	InClusterList	NumOutClusters	OutClusterList

Name	Type	Valid Range	Description
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request
ProfileID	Integer	0x0000-0xffff	Profile ID to be matched at the destination
NumInClusters	Integer	0x00-0xff	The number of Input Clusters provided for matching within the InClusterList.
InClusterList	2 bytes * NumInClusters		List of Input ClusterIDs to be used for matching; the InClusterList is the desired list to be matched by the Remote Device (the elements of

			the InClusterList are the supported output clusters of the Local Device)
NumOutClusters	Integer	0x00-0xff	The number of Output Clusters provided for matching within OutClusterList.
OutClusterList	2 bytes * NumOutClusters		List of Output ClusterIDs to be used for matching; the OutClusterList is the desired list to be matched by the Remote Device (the elements of the OutClusterList are the supported input clusters of the Local Device).

#### 4.1.14. Match descriptor response (0x0000-8006)

The match descriptor response is in response to a match descriptor request either broadcast or unicast to the remote device. This command shall be unicast to the originator of the match descriptor request command.

- Command id  
0x0000-8006
- Parameter

1 octet	2 octets	1 octet	Variable
Status	NWKAddrOfInterest	Match Length	Match List

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, DEVICE_NOT_FOUND, INV_REQUESTTYPE, or NO_DESCRIPTOR	The status of the command
NWKAddrOfInterest	Device Address	16-bit NWK address	NWK address for the request
MatchLength	Integer	0x00-0xff	The count of endpoints on the Remote Device that match the request criteria.
MatchList			List of bytes each of which represents an 8-bit endpoint

#### 4.1.15. Device announce indication (0x0000-0013)

The Device announce indication is provided to notify upper layer that the device has joined or re-joined the network, identifying the device's 64-bit IEEE address and new 16-bit NWK address, and informing the Remote Devices of the capability of the ZigBee device

- Command id  
0x0000-0013
- Parameter

2 octets	8 octets	1 octet
NWKAddr	IEEEAddr	Capability

Name	Type	Valid Range	Description
NWKAddr	Device Address	16-bit NWK address	NWK address for the Local Device
IEEEAddr	Device Address	64-bit IEEE	IEEE address for

		address	the Local Device
Capability	Bitmap		Capability of the local device

#### MAC Capability Flags Field

Bit 0	Bit 1	Bit 2	Bit 3	Bit 4-5	Bit 6	Bit 7
Alternate PAN coordinator	Device type	Power source	Receiver on when idle	Reserved	Security capability	Allocate address

Bit 0: 1, node is capable of becoming a PAN coordinator. Otherwise, 0.

Bit 1: 1, node is full function device(FFD). 0, node is reduced function device.

Bit 2: 1, the power source is mains power. Otherwise, 0.

Bit 3: 1, the device does not disable its receiver to conserve power during idle periods. Otherwise, 0.

Bit 6: 1, the device is capable of sending and receiving frames secured using the security suite specified in IEEE 802.15.4-2015. Otherwise, 0.

Bit 7: 1, the device is wishing to allocate a network address. Otherwise, 0.

#### 4.1.16. Parent announce indication (0x0000-001F)

The Parent announce indication is provided upper layer when ZigBee routers on the network about all the end devices known to the local device.

- Command id  
0x0000-001F

- Parameter

1 octet	Variable	....	Variable
NumberOfChildren	ChildInfo[0]	....	ChildInfo[n]

Name	Type	Valid Range	Description
NumberOfChildren	Integer	1-255	Number of children bound

#### ChildInfo Structure

Rafael Microelectronics *Rafael Easy Gateway Manual*

The information contained herein is the exclusive property of Rafael Microelectronics, Inc. and shall not be distributed, reproduced or disclosed in whole or in part without prior written permission of Rafael Microelectronics, Inc.

Name, 8 octets	Type	Valid Range	Description
Extended Address	64-bit IEEE address	64-bit IEEE address	The IEEE address of the child bound to the parent

## 4.2. Device Bind Management

### 4.2.1. Bind request (0x0000-0021)

The bind request is for wishing to create a Binding Table entry for the source and destination addresses contained as parameters. The destination addressing on this command shall be unicast only.

- Command id  
0x0000-0021
- Parameter

8 octets	1 octet	2 octets	1 octet	2/8 octets	0/1 octet
SrcAddress	SrcEndp	ClusterID	DstAddrMode	DstAddress	DstEndp

Name	Type	Valid Range	Description
SrcAddress	IEEE Address	A valid 64-bit IEEE address	The IEEE address for the source.
SrcEndp	Integer	0x01-0xfe	The source endpoint for the binding entry.
ClusterID	Integer	0x0000-0xffff	The identifier of the cluster on the source device that is bound to the destination
DstAddrMode	Integer	0x00-0xff	The addressing mode for the destination address used in this command.



			<p>This field can take one of the non-reserved values from the following list:</p> <p>0x00 = reserved</p> <p>0x01 = 16-bit group address for DstAddress and DstEndp not present</p> <p>0x02 = reserved</p> <p>0x03 = 64-bit extended address for DstAddress and DstEndp present</p> <p>0x04 – 0xff = reserved</p>
DstAddress	Address	As specified by the DstAddrMode field	The destination address for the binding entry.
DstEndp	Integer	0x01-0xfe	This field shall be present only if the DstAddrMode field has a value of 0x03 and, if present, shall be the destination endpoint for the binding entry

#### 4.2.2. Bind response (0x0000-8021)

The bind response is in response to a bind request. If the bind request is processed and the Binding Table entry committed on the Remote Device, a Status of SUCCESS is returned.

- Command id  
0x0000-8021

- Parameter

1 octet
Status

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, NOT_SUPPORTED, INVALID_EP, TABLE_FULL or NOT_AUTHORIZED	The status of the command

#### 4.2.3. Unbind request (0x0000-0022)

The unbind request is for wishing to remove a Binding Table entry for the source and destination addresses contained as parameters. The destination addressing on this command shall be unicast only.

- Command id  
0x0000-0022

- Parameter

8 octets	1 octet	2 octets	1 octet	2/8 octets	0/1 octet
SrcAddress	SrcEndp	ClusterID	DstAddrMode	DstAddress	DstEndp

Name	Type	Valid Range	Description
SrcAddress	IEEE Address	A valid 64-bit IEEE address	The IEEE address for the source.
SrcEndp	Integer	0x01-0xfe	The source endpoint for the binding entry.

ClusterID	Integer	0x0000-0xffff	The identifier of the cluster on the source device that is bound to the destination
DstAddrMode	Integer	0x00-0xff	The addressing mode for the destination address used in this command. This field can take one of the non-reserved values from the following list: 0x00 = reserved 0x01 = 16-bit group address for DstAddress and DstEndp not present 0x02 = reserved 0x03 = 64-bit extended address for DstAddress and DstEndp present 0x04 – 0xff = reserved
DstAddress	Address	As specified by the DstAddrMode field	The destination address for the binding entry.
DstEndp	Integer	0x01-0xfe	This field shall be present only if the DstAddrMode field has a value of 0x03 and, if

			present, shall be the destination endpoint for the binding entry
--	--	--	--

#### 4.2.4. Unbind response (0x0000-8022)

The unbind response is in response to an unbind request. If the unbind request is processed and the corresponding Binding Table entry is removed from the Remote Device, a Status of SUCCESS is returned.

- Command id  
0x0000-8022
- Parameter

1 octet
Status

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, NOT_SUPPORTED, INVALID_EP, TABLE_FULL or NOT_AUTHORIZED	The status of the command

### 4.3. Network Management

#### 4.3.1. Device binding information request (0x0000-0033)

The device binding information request is for wishing to retrieve the contents of the Binding Table from the Remote Device. The destination addressing on this command shall be unicast only.

- Command id  
0x0000-0033

- Parameter

1 octet
StartIndex

Name	Type	Valid Range	Description
StartIndex	Integer	0x00-0xff	Starting Index for the requested elements of the Binding Table.

#### 4.3.2. Device binding information response (0x0000-8033)

The device binding information response is in response to a device binding information request. If this management command is not supported, a status of NOT\_SUPPORTED shall be returned and all parameter fields after the Status field shall be omitted.

- Command id  
0x0000-8033

- Parameter

1 octet	1 octet	1 octet	1 octet	variable
Status	BindingTable Entries	Start Index	BindingTable ListCount	BindingTable List

Name	Type	Valid Range	Description
Status	Integer	NOT_SUPPORTED or any status code	The status of the command
BindingTableEntries	Integer	0x00-0xff	Total number of Binding Table entries within the Remote Device.
StartIndex	Integer	0x00-0xff	Starting index within the Binding Table to

			begin reporting for the BindingTableList.
BindingTableListCount	Integer	0x00-0xff	Number of Binding Table entries included within BindingTableList
BindingTableList	List of Binding Descriptors	The list shall contain the number elements given by the BindingTableListCount	A list of descriptors, beginning with the StartIndex element and continuing for BindingTableListCount, of the elements in the Remote Device's Binding Table

#### 4.3.3. Device leave request (0x0000-0034)

The device leave request is for requesting that a Remote Device leave the network.

- Command id  
0x0000-0034
- Parameter

8 octets	1 octet	1 octet
Device Address	Remove Children	Rejoin

Name	Type	Valid Range	Description
DeviceAddress	Device Address	An extended 64-bit, IEEE address	Device IEEE address
Remove Children	Bool	0/1	This field has a value of 1 if the device being asked to leave the network is also

			being asked to remove its child devices, if any. Otherwise, it has a value of 0.
Rejoin	Bool	0/1	This field has a value of 1 if the device being asked to leave from the current parent is requested to rejoin the network. Otherwise, it has a value of 0.

#### 4.3.4. Device leave response (0x0000-8034)

The device leave response is in response to a device leave request. If this management command is not supported, a status of NOT\_SUPPORTED shall be returned.

- Command id  
0x0000-8034
- Parameter

1 octet
Status

Name	Type	Valid Range	Description
Status	Integer	NOT_SUPPORTED, NOT_AUTHORIZED or any status code	The status of the command

#### 4.3.5. Direct join request (0x0000-0035)



The direct join request is requesting that a Remote Device permit a device designated by DeviceAddress to join the network directly.

- Command id  
0x0000-0035
- Parameter

8 octets	1 octet
Device Address	Capability Information

Name	Type	Valid Range	Description
DeviceAddress	Device Address	An extended 64-bit, IEEE address	Device IEEE address
CapabilityInformation	Bitmap	See Device announce indication	Device capability information could get from Device announce indication

#### 4.3.6. Direct join response (0x0000-8035)

The direct join response is in response to a direct join request. If this management command is not supported, a status of NOT\_SUPPORTED shall be returned.

- Command id  
0x0000-8035
- Parameter

1 octet
Status

Name	Type	Valid Range	Description
Status	Integer	NOT_SUPPORTED, NOT_AUTHORIZED or	The status of the command

		any status code	
--	--	-----------------	--

#### 4.3.7. Permit join request (0x0000-0036)

The permit join request is requesting that a remote device or devices allow or disallow association. If the remote device is the Trust Center and TC\_Significance is set to 1, the Trust Center authentication policy will be affected. The addressing may be unicast or 'broadcast to all routers.

- Command id  
0x0000-0036
- Parameter

1 octet	1 octet
PermitDuration	TC_Significance

Name	Type	Valid Range	Description
PermitDuration	Integer	0x00-0xfe	The length of time in seconds during which the ZigBee coordinator or router will allow associations. The value 0x00 and 0xff indicate that permission is disabled or enabled, respectively, without a specified time limit.
TC_Significance	Bool	0/1	This field shall always have a value of 1, indicating a request to change

			the Trust Center policy. If a frame is received with a value of 0, it shall be treated as having a value of 1.
--	--	--	--

#### 4.3.8. Permit join response (0x0000-8036)

The permit join response is in response to a unicast permit join request. In the description which follows, note that no response shall be sent if the permit join request was received as a broadcast to all routers.

- Command id  
0x0000-8036

- Parameter

1 octet
Status

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, INVALID_REQUEST, NOT_AUTHORIZED or any status code	The status of the command

#### 4.3.9. Network update request (0x0000-0038)

This command is provided to allow updating of network configuration parameters or to request information from devices on network conditions in the local operating environment. The destination addressing on this primitive shall be unicast or broadcast to all devices for which macRxOnWhenIdle = TRUE.

- Command id  
0x0000-0038

● Parameter

4 octets	1 octet	0/1 octet	0/1 octet	0/2 octet
ScanChannels	ScanDuration	ScanCount	nwkUpdateId	nwkManagerAddr

Name	Type	Valid Range	Description
ScanChannels	Bitmap	32-bit field	The five most significant bits (b27,..., b31) represent the binary encoded Channel Page. The 27 least significant bits (b0, b1,... b26) indicate which channels are to be scanned (1 = scan, 0 = do not scan) for each of the 27 valid channels
ScanDuration	Integer	0x00-0x05 or 0xfe or 0xff	0x00-0x05: A value used to calculate the length of time to spend scanning each channel. If ScanDuration has a value of 0xfe this is a request for channel change. If ScanDuration has a value of 0xff this is a request to change the apsChannelMaskList and nwkManagerAddr attributes.

ScanCount	Integer	0x00-0x01	This field represents the number of energy scans to be conducted and reported. This field shall be present only if the ScanDuration is within the range of 0x00 to 0x05.
nwkUpdateId	Integer	0x00 - 0xFF	The value of the nwkUpdateId contained in this request. This value is set by the Network Channel Manager prior to sending the message. This field shall only be present if the ScanDuration is 0xfe or 0xff. If the ScanDuration is 0xff, then the value in the nwkUpdateID shall be ignored.
nwkManagerAddr	Device Address	16-bit NWK address	This field shall be present only if the ScanDuration is set to 0xff, and, where present, indicates the NWK address for the device with the Network Manager bit set in its Node Descriptor.

#### 4.3.10. Network update notify (0x0000-8038)

The network update notify is provided to enable ZigBee devices to report the condition on local channels to a network manager.

When sent in response to a network update request command the status field shall represent the status of the request.

- Command id  
0x0000-8038

- Parameter

1 octet	4 octets	2 octets	2 octets	1 octet	variable
Status	Scanned Channels	TotalTransmissions	TransmissionFailures	ScannedChannelsListCount	EnergyValues

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, INVALID_REQUEST, NOT_SUPPORTED or any status values	The status of this command
ScanChannels	Bitmap	32-bit field	The five most significant bits (b27,..., b31) represent the binary encoded Channel Page. The 27 least significant bits (b0, b1,... b26) indicate which channels are to be scanned (1 = scan, 0 = do not scan) for each of the 27 valid

			channels
TotalTransmissions	Integer	0x0000 -0xffff	Count of the total transmissions reported by the device
TransmissionFailures	Integer	0x0000 -0xffff	Sum of the total transmission failures reported by the device
ScannedChannelsListCount	Integer	0x00 - 0xff	The list shall contain the number of records contained in the EnergyValues parameter.
EnergyValues	Integer	List of ED values each of which can be in the range of 0x00 - 0xff	The result of an energy measurement made on this channel

#### 4.3.11. Gateway Start (0x0000-0039)

Start the Gateway to form a network.

- Command id  
0x0000-0039
- Parameter

1 octet	2 octets	1 octet
Channel (11-26)	PanID	ResetFlag (0/1)

Rafael Microelectronics *Rafael Easy Gateway Manual*

The information contained herein is the exclusive property of Rafael Microelectronics, Inc. and shall not be distributed, reproduced or disclosed in whole or in part without prior written permission of Rafael Microelectronics, Inc.

#### 4.3.12. Gateway Start response (0x0000-8039)

The gateway start response is in response to a gateway start. If this command is sent before, a status of FAILURE shall be returned.

- Command id  
0x0000-8039

- Parameter

1 octet
status

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, FAILURE	The status of the command

#### 4.3.13. Gateway reset (0x0000-0040)

Software reset Gateway.

- Command id  
0x0000-0040

- Parameter

1 octet
MagicNumber = 0x88

#### 4.3.14. Gateway reset response (0x0000-8040)

The gateway reset response is in response to a gateway reset. If the parameter “MagicNumber” of gateway reset is not 0x88, a status of FAILURE shall be returned

- Command id



0x0000-8040

## ● Parameter

1 octet
status

Name	Type	Valid Range	Description
Status	Integer	SUCCESS, FAILURE	The status of the command

## 4.4. Device and Network Management Service Status

### Enumeration Description

Enumeration	Value	Description
SUCCESS	0x00	The requested operation or transmission was completed successfully.
FAILURE	0x01	Operation was not successful.
DEVICE_NOT_FOUND	0x81	The requested device did not exist on a device following a child descriptor request to a parent.
INVALID_EP	0x82	The supplied endpoint was equal to 0x00 or 0xff.
NOT_ACTIVE	0x83	The requested endpoint is not described by a simple descriptor.
NOT_SUPPORTED	0x84	The requested optional feature is not supported on the target device.
TIMEOUT	0x85	A timeout has occurred with the requested operation.
NO_MATCH	0x86	The end device bind request was unsuccessful due to a

		failure to match any suitable clusters.
NO_ENTRY	0x88	The unbind request was unsuccessful due to the coordinator or source device not having an entry in its binding table to unbind.
NO_DESCRIPTOR	0x89	A child descriptor was not available following a discovery request to a parent.
INSUFFICIENT_SPACE	0x8a	The device does not have storage space to support the requested operation.
NOT_PERMITTED	0x8b	he device is not in the proper state to support the requested operation.
TABLE_FULL	0x8c	The device does not have table space to support the operation.
NOT_AUTHORIZED	0x8d	The device has rejected the command due to security restrictions.
DEVICE_BINDING_TABLE_FULL	0x8e	The device does not have binding table space to support the operation.
INVALID_INDEX	0x8f	The index in the received command is out of bounds.

## 5. Application Service Management

### 5.1. Device Information

#### 5.1.1. Get device version info (0x0001-0000)

- Command id  
0x0001-0000
- Parameter  
None

#### 5.1.2. Get device version info response (0x0001-8000)

- Command id  
0x0001-8000
- Parameter

1 octet	1 octet	1 octet	1 octet
ZCLVersion	ApplicationVersion	StackVersion	HWVersion

Name	Type	Valid Range	Description
ZCLVersion	UInt8	0x00-0xff	ZCL version number
ApplicationVersion	UInt8	0x00-0xff	Application version number
StackVersion	UInt8	0x00-0xff	Stack version number
HWVersion	UInt8	0x00-0xff	Hardware version number

#### 5.1.3. Get device manufacture name (0x0001-0001)

- Command id  
0x0001-0001

- Parameter  
None

#### 5.1.4. Get device manufacture name response (0x0001-8001)

- Command id  
0x0001-8001

- Parameter

1 octet	variable
String Length	String value

#### 5.1.5. Get device model id (0x0001-0002)

- Command id  
0x0001-0002

- Parameter  
None

#### 5.1.6. Get device model id response (0x0001-8002)

- Command id  
0x0001-8002

- Parameter

1 octet	variable
String Length	String value

#### 5.1.7. Get device date code (0x0001-0003)

- Command id  
0x0001-0003

- Parameter

None

#### 5.1.8. Get device date code response (0x0001-8003)

- Command id  
0x0001-8003
- Parameter

1 octet	variable
String Length	String value

#### 5.1.9. Get software build id (0x0001-0004)

- Command id  
0x0001-0004
- Parameter  
None

#### 5.1.10. Get software build id response (0x0001-8004)

- Command id  
0x0001-8004
- Parameter

1 octet	variable
String Length	String value

#### 5.1.11. Default Response (0x0001-8800)

- Command id  
0x0001-8800
- Parameter

1 octet	1 octet
Command identifier	Status

### 5.1.12. Read device attributes (0x0002-0000)

- Command id  
0x0002-0000

- Parameter

2 octets	2 octets
ClusterID	AttributeID

### 5.1.13. Read device attributes response (0x0002-8000)

- Command id  
0x0002-8000

- Parameter

2 octets	2 octets	1 octet	0/1 octet	0/Variable
ClusterID	AttributeID	Status	AttributeDataType	AttributeData

AttributeDataType & AttributeData field only be included when Status field is the value of Success. AttributeDataType field use to indicate the data type of AttributeData field. The definition of AttributeDataType field were list in following table:

Data Type	Type	Attribute Data Type	Valid Value
Boolean	bool	0x10	0xff
Unsigned 8-bit integer	uint8	0x20	0xff
Unsigned 16-bit integer	uint16	0x21	0xffff
Unsigned 32-bit integer	uint32	0x23	0xffffffff

## 5.2. Device Identify

### 5.2.1. Identify (0x0004-0000)

- Command id  
0x0004-0000
- Parameter

1 octet	2 octets
DefRspFlg	Identify Time

### 5.2.2. Identify query (0x0004-0001)

- Command id  
0x0004-0001
- Parameter  
None

### 5.2.3. Identify query response (0x0004-8001)

- Command id  
0x0004-8001
- Parameter

2 octet
Timeout

## 5.3. Group Management

### 5.3.1. Add group (0x0005-0000)

- Command id  
0x0005-0000

- Parameter

2 octet
Group ID

### 5.3.2. Add group response (0x0005-8000)

- Command id  
0x0005-8000

- Parameter

1 octet	2 octets
Status	Group ID

### 5.3.3. View group (0x0005-0001)

- Command id  
0x0005-0001

- Parameter

2 octet
Group ID

### 5.3.4. View group response (0x0005-8001)

- Command id  
0x0005-8001

- Parameter

1 octet	2 octets
Status	Group ID

### 5.3.5. Get group membership (0x0005-0002)



- Command id  
0x0005-0002

- Parameter

1 octet	variable
Group count	Group list

### 5.3.6. Get group membership response (0x0005-8002)

- Command id  
0x0005-8002

- Parameter

1 octet	1 octet	variable
Capacity	Group count	Group list

### 5.3.7. Remove group (0x0005-0003)

- Command id  
0x0005-0003

- Parameter

2 octet
Group ID

### 5.3.8. Remove group response (0x0005-8003)

- Command id  
0x0005-8003

- Parameter

1 octet	2 octets
Status	Group ID

### 5.3.9. Remove all groups (0x0005-0004)

- Command id  
0x0005-0004
- Parameter

1 octet
DefRspFlg

### 5.3.10. Add group if identifying (0x0005-0005)

- Command id  
0x0005-0005
- Parameter

1 octet	2 octets
DefRspFlg	Group ID

## 5.4. Scene Management

### 5.4.1. Add scene (0x0006-0000)

- Command id  
0x0006-0001
- Parameter

The scene name is omitted and set the string length is “0”. For different device, the scene parameter is different. Currently this gateway will support the scene functions of the following devices.

Device ID: 0x0100 On/Off light

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition	0x00	0x0006	0x01

Rafael Microelectronics      Rafael Easy Gateway Manual

The information contained herein is the exclusive property of Rafael Microelectronics, Inc. and shall not be distributed, reproduced or disclosed in whole or in part without prior written permission of Rafael Microelectronics, Inc.

		Time	(Name)	(On/Off)	(length)
--	--	------	--------	----------	----------

1 octets
On/Off State

Device ID: 0x0101 Dimmable light

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition Time	0x00 (Name)	0x0006 (On/Off)	0x01 (length)

1 octets	2 octets	1 octets	1 octets
On/Off State	0x0008 (Level)	0x01 (length)	Current Level

Device ID: 0x0102 Color dimmable light

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition Time	0x00 (Name)	0x0006 (On/Off)	0x01 (length)

1 octets	2 octets	1 octets	1 octets	2 octets	1 octets
On/Off State	0x0008 (Level)	0x01 (length)	Current Level	0x0300 (Color)	0x0D (length)

2 octets	2 octets	2 octet	1 octets	1 octets	1 octets	2 octets
CurrentX	CurrentY	Enhanced CurrentHue	Current Saturation	ColorLoop Active	ColorLoop Direction	ColorLoop Time

2 octets
ColorTemperature Mireds

Device ID: 0x010A On/Off plug-in unit

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition Time	0x00 (Name)	0x0006 (On/Off)	0x01 (length)

1 octets
On/Off State

Device ID: 0x010B Dimmable plug-in unit

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition Time	0x00 (Name)	0x0006 (On/Off)	0x01 (length)

1 octets	2 octets	1 octets	1 octets
On/Off State	0x0008 (Level)	0x01 (length)	Current Level

#### 5.4.2. Add scene response (0x0006-8000)

- Command id  
0x0006-8001
- Parameter

1 octet	2 octets	1 octet
Status	Group ID	Scene ID

#### 5.4.3. View scene (0x0006-0001)

- Command id  
0x0006-0002
- Parameter

2 octets	1 octet
----------	---------

Group ID	Scene ID
----------	----------

#### 5.4.4. View scene response (0x0006-8001)

- Command id  
0x0006-8002
- Parameter  
All devices will receive first status byte and following the different response parameters by different device.

First byte:

1 octets	.....
Status	.....

Device ID: 0x0100 On/Off light

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition Time	0x00 (Name)	0x0006 (On/Off)	0x01 (length)

1 octets
On/Off State

Device ID: 0x0101 Dimmable light

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition Time	0x00 (Name)	0x0006 (On/Off)	0x01 (length)

1 octets	2 octets	1 octets	1 octets
On/Off State	0x0008 (Level)	0x01 (length)	Current Level

## Device ID: 0x0102 Color dimmable light

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition Time	0x00 (Name)	0x0006 (On/Off)	0x01 (length)

1 octets	2 octets	1 octets	1 octets	2 octets	1 octets
On/Off State	0x0008 (Level)	0x01 (length)	Current Level	0x0300 (Color)	0x0D (length)

2 octets	2 octets	2 octet	1 octets	1 octets	1 octets	2 octets
CurrentX	CurrentY	Enhanced CurrentHue	Current Saturation	ColorLoop Active	ColorLoop Direction	ColorLoop Time

2 octets
ColorTemperature Mireds

## Device ID: 0x010A On/Off plug-in unit

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition Time	0x00 (Name)	0x0006 (On/Off)	0x01 (length)

1 octets
On/Off State

## Device ID: 0x010B Dimmable plug-in unit

2 octets	1 octets	2 octets	1 octets	2 octets	1 octets
Group ID	Scene ID	Transition Time	0x00 (Name)	0x0006 (On/Off)	0x01 (length)

1 octets	2 octets	1 octets	1 octets
On/Off	0x0008	0x01	Current

State	(Level)	(length)	Level
-------	---------	----------	-------

#### 5.4.5. Remove scene (0x0006-0002)

- Command id  
0x0006-0003
- Parameter

2 octets	1 octet
Group ID	Scene ID

#### 5.4.6. Remove scene response (0x0006-8002)

- Command id  
0x0006-8003
- Parameter

1 octet	2 octets	1 octet
Status	Group ID	Scene ID

#### 5.4.7. Remove all scene (0x0006-0003)

- Command id  
0x0006-0004
- Parameter

2 octets
Group ID

#### 5.4.8. Remove all scene response (0x0006-8003)

- Command id  
0x0006-8004

- Parameter

1 octet	2 octets
Status	Group ID

#### 5.4.9. Store scene (0x0006-0004)

- Command id  
0x0006-0005

- Parameter

2 octets	1 octet
Group ID	Scene ID

#### 5.4.10. Store scene response (0x0006-8004)

- Command id  
0x0006-8005

- Parameter

1 octet	2 octets	1 octet
Status	Group ID	Scene ID

#### 5.4.11. Recall scene (0x0006-0005)

- Command id  
0x0006-0006

- Parameter

1 octet	2 octets	1 octet	0/2 octets
DefRspFlg	Group ID	Scene ID	Transition Time

#### 5.4.12. Get scene membership (0x0006-0006)



- Command id  
0x0006-0007

- Parameter

2 octets
Group ID

#### 5.4.13. Get scene membership response (0x0006-8006)

- Command id  
0x0006-8007

- Parameter

1 octet	1 octet	2 octet	0/1 octet	variable
Status	Capacity	Group ID	Scene count	Scene list

### 5.5. On/Off Control

#### 5.5.1. Off (0x0007-0000)

- Command id  
0x0007-0000

- Parameter

1 octet
DefRspFlg

Name	Type	Valid Range	Description
DefRspFlg	Bool	0/1	Enable/Disable the default response

#### 5.5.2. On (0x0007-0001)

- Command id  
0x0007-0001

- Parameter

1 octet
DefRspFlg

Name	Type	Valid Range	Description
DefRspFlg	Bool	0/1	Enable/Disable the default response

### 5.5.3. Toggle (0x0007-0002)

- Command id  
0x0007-0002

- Parameter

1 octet
DefRspFlg

Name	Type	Valid Range	Description
DefRspFlg	Bool	0/1	Enable/Disable the default response

### 5.5.4. On with recall global scene (0x0007-0003)

- Command id  
0x0007-0003

- Parameter

1 octet
---------

DefRspFlg

Name	Type	Valid Range	Description
DefRspFlg	Bool	0/1	Enable/Disable the default response

#### 5.5.5. On with timed off (0x0007-0004)

- Command id  
0x0007-0004

- Parameter

1 octet	1 octet	2 octets	2 octets
DefRspFlg	On/Off Control	On time	Off Wait time

### 5.6. Level Control

#### 5.6.1. Move to level (0x0009-0000)

- Command id  
0x0009-0000

- Parameter

1 octet	1 octet	2 octets
DefRspFlg	Level	Transition time

#### 5.6.2. Move (0x0009-0001)

- Command id  
0x0009-0001

- Parameter

1 octet	1 octet	1 octet
DefRspFlg	Move mode	Rate

### 5.6.3. Step (0x0009-0002)

- Command id  
0x0009-0002
- Parameter

1 octet	1 octet	1 octet	2 octets
DefRspFlg	Step mode	Step size	Transition time

### 5.6.4. Stop (0x0009-0003)

- Command id  
0x0009-0003
- Parameter

1 octet
DefRspFlg

Name	Type	Valid Range	Description
DefRspFlg	Bool	0/1	Enable/Disable the default response

### 5.6.5. Move to level (with On/Off) (0x0009-0004)

- Command id  
0x0009-0004
- Parameter

1 octet	1 octet	2 octets
DefRspFlg	Level	Transition time

#### 5.6.6. Move (with On/Off) (0x0009-0005)

- Command id  
0x0009-0005

- Parameter

1 octet	1 octet	1 octet
DefRspFlg	Move mode	Rate

#### 5.6.7. Step (with On/Off) (0x0009-0006)

- Command id  
0x0009-0006

- Parameter

1 octet	1 octet	1 octet	2 octets
DefRspFlg	Step mode	Step size	Transition time

### 5.7. Lighting Color Control

#### 5.7.1. Move to hue (0x0021-0000)

- Command id  
0x0021-0000

- Parameter

1 octet	1 octet	1 octet	2 octets
DefRspFlg	Hue	Direction	Transition time

### 5.7.2. Move hue (0x0021-0001)

- Command id  
0x0021-0001
- Parameter

1 octet	1 octet	1 octet
DefRspFlg	Move mode	Rate

### 5.7.3. Step hue (0x0021-0002)

- Command id  
0x0021-0002
- Parameter

1 octet	1 octet	1 octet	1 octet
DefRspFlg	Step mode	Step size	Transition Time

### 5.7.4. Move to saturation (0x0021-0003)

- Command id  
0x0021-0003
- Parameter

1 octet	1 octet	2 octet
DefRspFlg	Saturation	Transition Time

### 5.7.5. Move saturation (0x0021-0004)

- Command id  
0x0021-0004
- Parameter

1 octet	1 octet	1 octet
DefRspFlg	Move mode	Rate

#### 5.7.6. Step saturation (0x0021-0005)

- Command id  
0x0021-0005

- Parameter

1 octet	1 octet	1 octet	1 octet
DefRspFlg	Step mode	Step size	Transition Time

#### 5.7.7. Move to hue and saturation (0x0021-0006)

- Command id  
0x0021-0006

- Parameter

1 octet	1 octet	1 octet	2 octet
DefRspFlg	Hue	Saturation	Transition Time

#### 5.7.8. Move to color (0x0021-0007)

- Command id  
0x0021-0007

- Parameter

1 octet	2 octet	2 octet	2 octet
DefRspFlg	ColorX	ColorY	Transition Time

### 5.7.9. Move color (0x0021-0008)

- Command id  
0x0021-0008
- Parameter

1 octet	2 octet	2 octet
DefRspFlg	RateX	RateY

### 5.7.10. Step color (0x0021-0009)

- Command id  
0x0021-0009
- Parameter

1 octet	2 octet	2 octet	2 octet
DefRspFlg	StepX	StepY	Transition Time

### 5.7.11. Move to color temperature (0x0021-000A)

- Command id  
0x0021-000A
- Parameter

1 octet	2 octet	2 octet
DefRspFlg	Color Temperature Mireds	Transition Time

### 5.7.12. Move color temperature (0x0021-004B)

- Command id  
0x0021-004B



- Parameter

1 octet	1 octets	2 octets	2 octets	2 octets
DefRspFlg	Move Mode	Rate	Color Temperature Minimum Mireds	Color Temperature Maximum Mireds

### 5.7.13. Step color temperature (0x0021-004C)

- Command id  
0x0021-004C

- Parameter

1 octet	1 octet	2 octets	2 octets	2 octets	2 octets
DefRspFlg	Step Mode	Step Size	Transition Time	Color Temperature Minimum Mireds	Color Temperature Maximum Mireds

## 5.8. Application Service Management Status Enumeration

### Description

Enumeration	Value	Description
SUCCESS	0x00	Operation was successful.
FAILURE	0x01	Operation was not successful.
NOT_AUTHORIZED	0x7E	The sender of the command does not have authorization to carry out this comma
MALFORMED_COMMAND	0x80	The command appears to contain the

		wrong fields, as detected either by the presence of one or more invalid field entries or by there being missing fields. Command not carried out. Implementer has discretion as to whether to return this error or INVALID_FIELD.
UNSUP_COMMAND	0x81	The specified command is not supported on the device. Command not carried out.
INVALID_FIELD	0x85	At least one field of the command contains an incorrect value, according to the specification the device is implemented to.
UNSUPPORTED_ATTRIBUTE	0x86	The specified attribute does not exist on the device.
INVALID_VALUE	0x87	Out of range error or set to a reserved value. Attribute keeps its old value. Note that an attribute value may be out of range if an attribute is related to another, e.g., with minimum and maximum attributes. See the individual attribute descriptions for specific details
READ_ONLY	0x88	Attempt to write a read-only attribute.
INSUFFICIENT_SPACE	0x89	An operation failed due to an insufficient amount of free space available.
NOT_FOUND	0x8B	The requested information (e.g., table entry) could not be found.
UNREPORTABLE_ATTRIBUTE	0x8C	Periodic reports cannot be issued for this attribute.
INVALID_DATA_TYPE	0x8D	The data type given for an attribute is incorrect. Command not carried out.
INVALID_SELECTOR	0x8E	The selector for an attribute is incorrect.
TIMEOUT	0x94	The exchange was aborted due to

		excessive response time.
ABORT	0x95	Failed case when a client or a server decides to abort the upgrade process.
INVALID_IMAGE	0x96	Invalid OTA upgrade image (ex. failed signature validation or signer information check or CRC check)
WAIT_FOR_DATA	0x97	Server does not have data block available yet
NO_IMAGE_AVAILABLE	0x98	No OTA upgrade image available for the client
REQUIRE_MORE_IMAGE	0x99	The client still requires more OTA upgrade image files to successfully upgrade
NOTIFICATION_PENDING	0x9A	The command has been received and is being processed
UNSUPPORTED_CLUSTER	0xC3	The cluster is not supported

## 6. Easy Gateway Service

### 6.1. Device Table Control

#### 6.1.1. Device table get (0x1000-0100)

- Command id  
0x1000-0100

- Parameter  
None

#### 6.1.2. Device table get response (0x1000-8100)

- Command id  
0x1000-8100
- Parameter

1 octet	0/8 octets	0/2 octets	0/2 octets	0/1 octet
---------	------------	------------	------------	-----------

Status	Device IEEEAddr	NWKAddr	Device ID	Endpoint
--------	-----------------	---------	-----------	----------

0/1 octet	Variable	0/1 octet	Variable
Device Name length	Device Name	Endpoint Name length	Endpoint Name

The fields Device IEEEAddr, NWKAddr, Device ID, Endpoint, Device Name length, Device Name, Endpoint Name length and Endpoint Name exist when status filed is success. The maximum size of Device Name length filed is 16. And the length of Device Name field is according to the field Device Name length. Similarly, Endpoint Name length filed maximum size is 16 that also use to define the length of Endpoint Name field.

### 6.1.3. Device name set (0x1000-0101)

- Command id  
0x1000-0101
- Parameter

2 octets	1 octet	Variable
NWKAddr	Device Name length	Device Name

### 6.1.4. Device name set response (0x1000-8101)

- Command id  
0x1000-8101
- Parameter

1 octet	0/2 octets
Status	NWKAddr

The fields NWKAddr exist when status filed is not success.

### 6.1.5. End point name set (0x1000-0102)

- Command id  
0x1000-0102

- Parameter

2 octets	1 octet	1 octet	Variable
NWKAddr	Endpoint	End point Name length	End point Name

#### 6.1.6. End point name set response (0x1000-8102)

- Command id  
0x1000-8102

- Parameter

1 octet	0/2 octets	0/1 octet
Status	NWKAddr	Endpoint

The fields NWKAddr and Endpoint exist when status filed is not success.

#### 6.1.7. Device table remove all (0x1000-0103)

- Command id  
0x1000-0103

- Parameter  
None

#### 6.1.8. Device table remove all response (0x1000-8103)

- Command id  
0x1000-8103

- Parameter

1 octet
Status

#### 6.1.9. Device table remove specific device (0x1000-0104)

- Command id

0x1000-0104

- Parameter

8 octets
Device Address

#### 6.1.10. Device table remove specific device response (0x1000-8104)

- Command id  
0x1000-8104

- Parameter

1 octet
Status

### 6.2. Group Table Control

#### 6.2.1. Group table get (0x1000-0200)

- Command id  
0x1000-0200

- Parameter  
None

#### 6.2.2. Group table get response (0x1000-8200)

- Command id  
0x1000-8200

- Parameter

1 octet	0/2 octets	0/1 octets	0/Variable
Status	Group ID	Group Name length	Group Name

0/2 octet	0/1 octet	...	0/2 octet	0/1 octet
-----------	-----------	-----	-----------	-----------

NwkAddr 0	Endpoint 0	...	NwkAddr N	Endpoint N
-----------	------------	-----	-----------	------------

The fields Group ID, Group Name length, Group Name, Endpoint, NwkAddr, and Endpoint exist when status filed is success. The maximum size of Group Name length filed is 20. And the length of field Group Name is according to the field Group Name length.

### 6.2.3. Group name set (0x1000-0201)

- Command id  
0x1000-0201

- Parameter

2 octets	1 octet	Variable
Group ID	Group Name length	Group Name

### 6.2.4. Group name set response (0x1000-8201)

- Command id  
0x1000-8201

- Parameter

1 octet	2 octets	1 octet	Variable
Status	Group ID	Group Name length	Group Name

The fields Group ID, Group Name length and Group Name exist when status filed is not success.

### 6.2.5. Group table remove all (0x1000-0202)

- Command id  
0x1000-0202

- Parameter  
None

### 6.2.6. Group table remove all response (0x1000-8202)

- Command id  
0x1000-8202
- Parameter

1 octet
Status

### 6.2.7. Group table create (0x1000-0203)

- Command id  
0x1000-0203
- Parameter

2 octets
Group ID

### 6.2.8. Group table create response (0x1000-8203)

- Command id  
0x1000-8203
- Parameter

1 octet	2 octets
Status	Group ID

If the group table is already full, the status field will be "INSUFFICIENT\_SPACE"

## 6.3. Scene Table Control

### 6.3.1. Scene table get (0x1000-0300)

- Command id  
0x1000-0300



- Parameter  
None

### 6.3.2. Scene table get response (0x1000-8300)

- Command id  
0x1000-8300
- Parameter

1 octet	0/2 octets	0/1 octet	0/1 octets	0/Variable
Status	Group ID	Scene ID	Scene Name length	Scene Name

0/2 octet	0/1 octet	...	0/2 octet	0/1 octet
NwkAddr 0	Endpoint 0	...	NwkAddr N	Endpoint N

The fields Group ID, Scene ID, Scene Name length, Scene Name, Endpoint, NwkAddr, and Endpoint exist when status filed is success. The maximum size of Scene Name length filed is 20. And the length of field Scene Name is according to the field Scene Name length.

### 6.3.3. Scene name set (0x1000-0301)

- Command id  
0x1000-0301
- Parameter

2 octets	1 octets	1 octet	Variable
Group ID	Scene ID	Scene Name length	Scene Name

### 6.3.4. Scene name set response (0x1000-8301)

- Command id  
0x1000-8301
- Parameter

1 octet	2 octets	1 octets	1 octet	Variable
Status	Group ID	Scene ID	Scene Name length	Scene Name

The fields Group ID, Scene ID, Scene Name length and Scene Name exist when Status field is not success.

### 6.3.5. Scene table remove all (0x1000-0302)

- Command id  
0x1000-0302

- Parameter  
None

### 6.3.6. Scene table remove all response (0x1000-8302)

- Command id  
0x1000-8302

- Parameter

1 octet
Status

### 6.3.7. Scene table create (0x1000-0303)

- Command id  
0x1000-0303

- Parameter

2 octets	1 octets
Group ID	Scene ID

### 6.3.8. Scene table create response (0x1000-8303)

- Command id  
0x1000-8303

- Parameter

1 octet	2 octets	1 octets
Status	Group ID	Scene ID

If the Scene table is already full, the status field will be "INSUFFICIENT\_SPACE".

## 6.4. Bind Table Control

### 6.4.1. Bind table get (0x1000-0400)

- Command id  
0x1000-0400

- Parameter  
None

### 6.4.2. Bind table get response (0x1000-8400)

- Command id  
0x1000-8400

- Parameter

1 octet	0/8 octets	0/1 octet	0/2 octets	0/1 octets
Status	Source IEEEAddr	Source Endpoint	Cluster ID	Destination Address Mode

0/2/8 octet	0/1 octet
Destination address	Destination Endpoint

The fields Source IEEEAddr, Source Endpoint, Cluster ID, Destination address mode, Destination address, and Destination Endpoint exist when status filed is success.

If Destination address mode filed has a value of 0x01, Destination address is 16-bit group address,

If Destination address mode filed is 0x03, Destination address filed is 64-bit extended address and Destination Endpoint field shall be present.  
Destination address mode filed 0x00, 0x02 and 0x04-0xff were reserved values and these values should not exist for bind table.

#### 6.4.3. Bind table remove all (0x1000-0401)

- Command id  
0x1000-0401

- Parameter  
None

#### 6.4.4. Bind table remove all response (0x1000-8401)

- Command id  
0x1000-8401

- Parameter

1 octet
Status

### 6.5. ZC Information Control

#### 6.5.1. ZC information get (0x1000-0A00)

- Command id  
0x1000-0A00

- Parameter  
None

#### 6.5.2. ZC information get response (0x1000-8A00)

- Command id  
0x1000-8A00

- Parameter

1 octet	0/2 octets	0/1 octet
Status	PAN ID	Channel

### 6.5.3. ZC information change notification (0x1000-8A01)

- Command id  
0x1000-8A01

- Parameter

1 octet	0/2 octets	0/1 octet
Status	PAN ID	Channel

## 6.6. Easy Gateway Service Status Enumeration Description

Enumeration	Value	Description
SUCCESS	0x00	Operation was successful.
FAILURE	0x01	Operation was not successful.
UNSUP_COMMAND	0x81	The specified command is not supported on the device. Command not carried out.
INVALID_FIELD	0x85	At least one field of the command contains an incorrect value, according to the specification the device is implemented to.
INSUFFICIENT_SPACE	0x89	An operation failed due to an insufficient amount of free space available.
NOT_FOUND	0x8B	The requested information (e.g., table entry) could not be found.

## Revision History

Revision	Description	Owner	Date
0.1	Initial version	Nat	2022/07/18

© 2021 by Rafael Microelectronics, Inc.

All Rights Reserved.

Information in this document is provided in connection with **Rafael Microelectronics, Inc.** ("**Rafael Micro**") products. These materials are provided by **Rafael Micro** as a service to its customers and may be used for informational purposes only. **Rafael Micro** assumes no responsibility for errors or omissions in these materials. **Rafael Micro** may make changes to this document at any time, without notice. **Rafael Micro** advises all customers to ensure that they have the latest version of this document and to verify, before placing orders, that information being relied on is current and complete. **Rafael Micro** makes no commitment to update the information and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to its specifications and product descriptions.

THESE MATERIALS ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, RELATING TO SALE AND/OR USE OF **RAFAEL MICRO** PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, CONSEQUENTIAL OR INCIDENTAL DAMAGES, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT. **RAFAEL MICRO** FURTHER DOES NOT WARRANT THE ACCURACY OR COMPLETENESS OF THE INFORMATION, TEXT, GRAPHICS OR OTHER ITEMS CONTAINED WITHIN THESE MATERIALS. **RAFAEL MICRO** SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION, LOST REVENUES OR LOST PROFITS, WHICH MAY RESULT FROM THE USE OF THESE MATERIALS.

**Rafael Micro** products are not intended for use in medical, lifesaving or life sustaining applications. **Rafael Micro** customers using or selling **Rafael Micro** products for use in such applications do so at their own risk and agree to fully indemnify **Rafael Micro** for any damages resulting from such improper use or sale. **Rafael Micro**, logos and **RT568** are **Trademarks** of **Rafael Microelectronics, Inc.** Product names or services listed in this publication are for identification purposes only, and may be trademarks of third parties. Third-party brands and names are the property of their respective owners.